


Loop order and type defined as in the linear case

(Unity feedback - Phase Comparator and/or VCO may not be linear)

1st order (type 1) slave loop




Acquisition

Burst-mode transmission
(often a phase-aligner)

OK

OK

2nd order and type 1 slave loop




Tracking

Continuous mode transmission

Regenerators

-

2nd order and type 2 slave loop



-

All slaves