13 MARCH 1992

LO 9-2805-257-12 TO 38G2-103-2LC-1

(Supersedes LO 9-2805-257-12, 21 November 1986)

ENGINE, GASOLINE, 3 HP, MILITARY STANDARD MODELS

(MODEL 2A016-1, NSN 2805-00-601-5127) (MODEL 2A016-2, NSN 2805-00-714-8553) (MODEL 2A016-3, NSN 2805-00-072-4871) (MODEL 2A016-4, NSN 2805-01-169-1100)

References: TM 9-2805-257-14, C9100-IL and FM 9-207

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), directly to: US Army Troop Support Command, ATTN: AMSTR-MMTS, 4300 Goodfellow Blvd., St. Louis, MO 53120-1798. A reply will be furnished directly to you.

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited

NOTES

This LO is for crew/operator (C) or organizational (O) maintenance. Lube intervals (on-condition or hard time) and task hour times are based on normal hours of operation. Change the intervals if your lubricants are contaminated or if you are operating the equipment under adverse operating conditions. Lube more during constant use and less during periods of low activity. Adequate preservation precautions must be taken during inactive periods. Use correct grade of lubricant for seasonal temperature expected.

WARNING - Dry cleaning solvent PD-680 used to clean parts is potentially dangerous to personnel and property. Avoid repeated and prolonged skin contact. Do not use near open flame or excessive heat. Flash point of solvent is 100°F-138°F(38°C-60°C).

Clean parts with dry cleaning solvent PD-680 and dry before lubricating.

Before you start your lube service.

ALWAYS NEVER

a. Clean parts before lubricating.

- a. Use wrong type/grade lubricant
- b. Use the lubrication order as your guide.
- b. Use too much lubricant.

The 3 HP military standard gasoline engine is not enrolled in the Army Oil Analysis Program (AOAP) HARD TIME INTERVALS APPLY.

*TOTAL TASK-HR		*TOTAL TASK-HR		
INTERVAL 8 50	TASK-HR 0.5 1.5	INTERVAL 500	TASK-HR 0.3	

*The time specified is the time required to perform all services at the particular interval (on-condition or hard time)

LUBRICANT • INTERVAL


INTERVAL • LUBRICANT

Crankcase Fill and Level
(Check level)
(See table 1) (C)

CAUTION: When OEA
oil is used the level will be

Ignition CamWick (O) (Sparingly) (See note 3)

checked more often



MODELS 2A016-1 AND 2A016-2

OE/ Air Cleaner HDO (Refill oil reservoir) to level mark; every

to level mark; every 50 hours disassemble entire unit, clean, reoil and reassemble) (See table 1) (O)


OE/ Crankcase Drain HDO (Drain and refill) (See note 4) (O)

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Crankcase Fill and DE/ Level HDO (Check level) (See table 1) (C)

<u>CAUTION</u>: When OEA oil is used the level will be checked more often.



Model 2A016-3 only

OE/ Ignition Cam Wick HDO (Sparingly) (O) (See note 3)

OE/ Crankcase Drain HDO (Drain and refill) (See note 4) (O)

MODELS 2A016-3 AND 2A016-4

Table 1. Lubricant Table for 3 HP Military Standard Gasoline Engine

E/HDO 15/40 (0-1236) IL-L-2104 E/HDO 30 -238) IL-L-2104	*4/5 qt or (0.77L) **1.8 qt or (0.1182L)	50 hrs 8 hrs 50 hrs	0.5
-238)	1		0.5
E/HDO 15/40	*4/5 qt or (0.77L)	50 hrs	1.5
,	**1/8qt or (0.1 <u>18</u> 2L)	8 hrs 50 hrs	0.5
-183)	*4/5 qt or (0.77L)	50 hrs	1.5
L-L-46167	**1/8 qt or (0.1182L)	8 hrs	0.5
		**1/8qt or (0.1182L) EA/APG-PD-1	**1/8qt or 8 hrs (0.1182L) EA/APG-PD-1 -183) (1L-L-46167 **1/8qt or 50 hrs (0.77L) **1/8 qt or 8 hrs (0.1182L)

NOTES:

- 1. FOR OPERATION OF EQUIPMENT IN PROTRACTED COLD TEMPERATURE. -10°F (-23°C). Remove lubricant prescribed in table 1 for temperatures above -10°F (-23°C). Clean parts with dry cleaning solvent PD-680. Relubricate with lubricants specified in table 1 for temperatures below -l0°F (-23°C). For arctic operation refer to FM 9-207.
- 2. OIL CAN POINTS. Every 25 hours lubricate all exposed adjusting threads with OE/HDO.
- 3. Insure camwick is lubricated with OE/HDO (sparingly) whenever ignition contact points are replaced or adjusted.
- 4. CRANKCASE. Drain crankcase when hot. Every 50 hours drain and refill crankcase, operate engine for five minutes, check for leaks, check crankcase oil level and bring to full mark.

Copy of this lubrication order will remain with the equipment at all times; instructions herein are mandatory.

LO 9-2805-257-12 TO 38G2-103-2LC-1

By Order of the Secretaries of the Army and Air Force:

Official: Milto A. Damilton

MILTON H. HAMILTON Administrative Assistant to the Secretary of the Army GORDON F. SULLIVAN General, United States Army Chief of Staff

> MERRILL A. McPEAK, General USAF Chief of Staff

Official:

CHARLES C. McDONALD

General, USAF Commander, Air Force Logistics Command

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25E, (qty rqr block no. 4457)

☆ U.S. GOVERNMENT PRINTING OFFICE : 1994 0 - 300-721 (00334)

This fine document...

Was brought to you by me:



<u>Liberated Manuals -- free army and government manuals</u>

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

Free Military and Government Manuals

SincerelyIgor Chudovhttp://igor.chudov.com/