

14317 **AIRPORT DIAGRAM** BALTIMORE/WASHINGTON INTL THURGOOD MARSHALL (BWI) BALTIMORE, MARYLAND

AL-804 (FAA)

BALTIMORE, MARYLAND

ATIS
115.1 127.8
BALTIMORE TOWER
119.4 257.8
GND CON
121.9
CLNC DEL
118.05

324 Δ

39°12'N


- RWY 04-22
PCN 62 F/A/W/T
S-80, D-220, 2D-600, 2D/2D2-790
- RWY 10-28
PCN 105 F/A/W/T
S-80, D-220, 2D-1020, 2D/2D2-1340
- RWY 15L-33R
PCN 15 F/A/W/T
S-30, D-45
- RWY 15R-33L
PCN 70 F/A/W/T
S-80, D-220, 2D-675, 2D/2D2-890



ANNUAL RATE OF CHANGE
0.0° W

NE-3, 13 NOV 2014 to 08 JAN 2015

NE-3, 13 NOV 2014 to 08 JAN 2015



ASDE-X Surveillance System in use.
Operate transponders with Mode C
on all twys and rwys.

**CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.**

76°41'W

76°40'W

39°10'N

AIRPORT DIAGRAM BALTIMORE, MARYLAND BALTIMORE/WASHINGTON INTL THURGOOD MARSHALL (BWI)

14317