LUBRICATION L05 3805 243 12-2 ORDER 10 APRIL 1968 LOADER, SCOOP TYPE, D.E.D., 4 WHEEL DRIVE, PNEUMATIC TIRES, HINGED FRAME STEER, W/FORKLIFT FRONT MOUNTED, HYDRAULIC OPERATED, 10,00 LB CAPACITY (EATON YALE & TOWN, TROJAN MODEL 3000M) W/ENGINE **CUMMINS MODEL C-180-CI** Reference: LO 5-3805-243-12-1 and C9100-IL Clean parts with SOLVENT, dry-cleaning, or with OIL, Fuel, Diesel. Dry Intervals are based on normal hours of operation. Adjust to compensate for abnormal operations and severe conditions. During inactive periods, before lubricating. sufficient lubrication must be performed for adequate preservation. Lubricate points indicated by dotted arrow shafts on both sides of Clean fittings before lubricating. equipment. Relubricate after washing or fording. Drain gearcases when hot. Fill and check level. FOLD FOLD LUBRICANT 

INTERVAL INTERVAL 


LUBRICANT 50 Front Differential Fill GO and Level 0 (Check level.) 10 GAA Steering Bellcrank End (See key.) 100 Hydraulic Reservoir 1000 **Front Differential** Breather (Remove, clean, and Drain (Drain and refill.) install.) 10 OE Hydraulic Reservoir 50 Front Universal Joints GAA Fill and Level and Spline

Transmission Torque Converter Drain 500

(6 Fittings) (Sparingly)

Hydraulic Reservoir

1000




Drain (Drain and refill.)

(See key.) (Check

level.) (See note 3.)

Steering Hydraulic System Filter (See note 3.)



## NOTES:

1.FOR OPERATION OF EQUIPMENT in PROTRACTED COLD TEMPERATURES BELOW-10°F. Remove lubricants prescribed in the key for temperatures above-10°F. Relubricate with lubricants specified in the key for temperatures below-10°F

4. LUBRICANTS: The following is a list of lubricants with the Military Symbols and the applicable specification numbers.

OE-MIL-L-2104 OES GO-MIL-L-2105 GOS GAA-MIL-G-10924

OES-MIL-L-10295 GOS-MIL-L-10324

2.OIL CAN POINTS. Every 50 hours lubricate handbrake, control lever linkage, and all exposed adjusting threads with OE.

3. HYDRAULIC SYSTEM. Every 100 hours remove breather, wash in solvent, blow dry and reinstall. Every 250 hours remove steering system return filter element, clean housing, and install new element. Every 1000 hours of operation drain and clean hydraulic reservoir, install new element, fill system, operate equip for 5 minutes, check for leaks, check oil level and bring to full mark.

Copy of this Lubrication Order will remain with the equipment at all times; instructions contained herein are mandatory.

BY ORDER OF THE SECRETARY OF THE ARMY:

HAROLD K. JOHNSON, General, United States Army, Chief of Staff.

OFFICIAL:

KENNETH G. WICKHAM, Major General, United States Army, The Adjutant General.

LO 5-3805-243-12-2 DISTRIBUTION: To de distributed in accordance with DA Form 12-25, Section II, Organizational Maintenance Requirements for Earth Moving Equipment Leaders.

☆ U.S. GOVERNMENT PRINTING OFFICE : 1994 O - 300-721 (329)

PIN: 029934-000

This fine document...

Was brought to you by me:



## Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap "watermarks" and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<u>http://www.liberatedmanuals.com/</u>>Free Military and Government Manuals</A>

Sincerely
 Igor Chudov
 http://igor.chudov.com/