


LIBRARY
ANNEX



J. Frank Lyman,

Cornell University Library

THE GIFT OF

Mrs. A. F. Lyman

A. 257076

27/17/11



Cornell University Library

The original of this book is in
the Cornell University Library.

There are no known copyright restrictions in
the United States on the use of the text.

THE
AMERICAN HOUSE-CARPENTER.

A TREATISE

ON

THE ART OF BUILDING,

AND

THE STRENGTH OF MATERIALS.

BY

R. G. HATFIELD, ARCHITECT,
MEM. AM. INST. OF ARCHITECTS.

SEVENTH EDITION, REVISED AND ENLARGED
WITH ADDITIONAL ILLUSTRATIONS.

NEW YORK:
JOHN WILEY & SON,
15 ASTOR PLACE.
1872.
v.

7991
D9

A.257076

Entered according to Act of Congress, in the year 1857, by

R. G. HATFIELD,

In the Clerk's Office of the District Court of the United States, for the Southern District
of New York.

PREFACE.

THIS book is intended for carpenters—for masters, journeymen and apprentices. It has long been the complaint of this class that architectural books, intended for their instruction, are of a price so high as to be placed beyond their reach. This is owing, in a great measure, to the costliness of the plates with which they are illustrated: an unnecessary expense, as illustrations upon wood, printed on good paper, answer every useful purpose. Wood engravings, too, can be distributed among the letter-press; an advantage which plates but partially possess, and one of great importance to the reader.


Considerations of this kind induced the author to undertake the preparation of this volume. The subject matter has been gleaned from works of the first authority, and subjected to the most careful examination. The explanations have all been written out from the figures themselves, and not taken from any other work; and the figures have all been drawn expressly for this book. In doing this, the utmost care has been taken to make everything as plain as the nature of the case would admit.

The attention of the reader is particularly directed to the following new inventions, viz; an easy method of describing the curves of mouldings through three given

points ; a rule to determine the projection of eave cornices ; a new method of proportioning a cornice to a larger given one ; a way to determine the lengths and bevils of rafters for hip-roofs ; a way to proportion the rise to the tread in stairs ; to determine the true position of butt-joints in hand-rails ; to find the bevils for splayed-work ; a general rule for scrolls, &c. Many problems in geometry, also, have been simplified, and new ones introduced. Much labour has been bestowed upon the section on stairs, in which the subject of hand-railing is presented, in many respects, in a new, and it is hoped, more practical form than in previous treatises on that subject.

The author has endeavoured to present a fund of useful information to the *American house-carpenter* that would enable him to excel in his vocation ; how far he has been successful in that object, the book itself must determine.

New York, Oct. 15, 1844.



FIFTH EDITION.

SINCE the first edition of this work was published, I have received numerous testimonials of its excellent practical value, from the very best sources, viz. from the workmen themselves who have used it, and who have profited by it. As a convenient manual for reference in respect to every question relating either to the simpler operations of Carpentry or the more intricate and

abstruse problems of Geometry, those who have tried it assure me that they have been greatly assisted in using it. And, indeed, to the true workman, there is, in the study of the subjects of which this volume treats, a continual source of profitable and pleasurable interest. Gentlemen, in numerous instances, have placed it in the hands of their sons, who have manifested a taste for practical studies; and have also procured it for the use of the workmen upon their estates, as a guide in their mechanical operations. I was not, then, mistaken in my impressions, that a work of this kind was wanted; and this evidence of its usefulness rewards me in a measure for the pains taken in its preparation.

New York, Oct. 1, 1852.

SEVENTH EDITION.

It is now thirteen years since the first edition of the *American House Carpenter* was published. The attempt to furnish the recipients of this book with a fund of useful information in a compact and accessible form, has been so far successful that the sixth edition was exhausted nearly a year ago. At that time it was determined, before issuing another edition, to make a thorough revision of the work. The time occupied in this labour has been unexpectedly prolonged by at least six months, and this has resulted from various causes, but more especially from the absorbing nature of my professional duties. A large portion of the work has been rewritten,

about 130 pages of new matter introduced and many new cuts inserted.

The most important additions to the work will be found in the section on Framing or Construction. Here will be found, now first published, the results of experiments on such building materials as are in common use in this country, and an extended series of rules for the application of this experimental knowledge to the practical purposes of building. Some of the rules are new, while others heretofore in use have been simplified. This section has been much improved, and it is hoped that it will be of service, not only to the house carpenter but also to the architect and civil engineer.

In preparing the original work, a desire to state the subjects treated of in terms suited to the comprehension of all classes of workmen, precluded the use of algebraical symbols and formulæ. In this edition, however, it has been deemed best to introduce them wherever they would contribute to the clearer elucidation of the subject; but care has been taken to state them in a simple form at first, and so to explain the symbols as they are introduced that those heretofore uninstructed in regard to them, may comprehend what little is here exhibited, and at the same time be induced to pursue the study more fully in works more strictly mathematical. But for those who may not succeed in comprehending the algebraical formulæ, it may be stated that all the practical deductions derived from them are written out in words at length, so as to be fully understood without their assistance.

R. G. H.

TABLE OF CONTENTS.

INTRODUCTION. —Directions for Drawing	PAGES 1-14
--	----------------------

SECTION I.—PRACTICAL GEOMETRY

Definitions	15-70
Problems on Lines and Angles	71-80
Problems on the Circle	81-92
Problems on Polygons	93-106
Problems on Proportions	107-110
Problems on the Conic Sections	111-128
Demonstrations.—Definitions, Axioms, &c.	130-139
Demonstrations.—Propositions and Corollaries	140-167

SECTION II.—ARCHITECTURE.

History	168-181
Styles.—Origin, Definitions, Proportions	182-196
Grecian Orders.—Doric, Ionic and Corinthian	197-211
Roman Orders.—Doric, Ionic, Corinthian and Composite	212-215
Egyptian Style	216, 217
Buildings generally	218-222
Plans and Elevation for a City Dwelling	223, 224
Principles of Architecture.—Requisites in a Building	225-229
Principles of Construction.—The Foundations, Column	230-232
Principles of Construction.—The Wall, Lintel, Arch	233-235
Principles of Construction.—The Vault, Dome, Roof	236-239

SECTION III.—MOULDINGS, CORNICES, &c.

	ARTS
Mouldings.—Elements, Examples	239-250
Cornices.—Designs	251
Cornices.—Problems	252-256

SECTION IV.—FRAMING, OR CONSTRUCTION.

First Principles.—Laws of Pressure	257-282
Resistance of Materials.—Strength, Stiffness	283-286
Resistance to Compression.—Various kinds	287-290
Results of Experiments on American Materials, Tables I, II	291-293
Practical Rules and Examples	294-305
Resistance to Tension	306
Results of Experiments on American Materials, Table III.	307, 308
Practical Rules and Examples	309-316
Resistance to Cross Strains.—Strength, Stiffness	317-319
Resistance to Deflection.—Stiffness, Formulæ	320-322
Practical Rules and Examples	323-326
Table IV.—Weight on Beams, Formulæ	326
Practical Rules and Examples	327-329
Table V.—Dimensions of Beams, Formulæ	329
Resistance to Rupture.—Strength	331
Results of Experiments on American Materials, Table VI.	331
Table VII.—Safe Weight on Beams, Formulæ	333
Practical Rules and Examples	333
Table VIII.—Dimensions of Beams, Formulæ	334
Practical Rules and Examples	334
Systems of Framing, Simplicity of Designs	335
Floors.—Various, Cross-furring, Reduction of Formulæ	336, 337
Practical Rules and Examples	338-344
Bridging-strips, Girders, Precautions	345-349
Partitions.—Examples, Load on Partitions, &c.	350-353
Roofs.—Stability, Inclination	354, 355
Load.—Roofing, Truss, Ceiling, Wind, Snow	356-358
Strains.—Vertical, Oblique, Horizontal	359-368
Resistance of the Material in Rafter and Tie-beam	368
Dimensions.—Rafter, Braces, Tie-beam, Iron Rods	370-374
Practical Rules and Examples	375-387
Table IX.—Weight of Roofs, per Foot	376

TABLE OF CONTENTS.

ix

	ARTS
Examples of Roofs	384-588
Problems for Hip-rafter	387-388
<i>Domes.</i> —Examples, Area of Ribs	389-391
Problems in Domes	392-398
<i>Bridges.</i> —Examples	399-401
Rules for Dimensions	401-405
Abutments and Piers	406, 407
Stone Bridges, Centreing	408-417
Joints in Timberwork	418-427
Iron Work.—Pins, Nails, Bolts, Straps	428
Iron-Girders.—Cast Girder, Bow-string, Brick Arch	429-435
Practical Rules and Examples	431-435

SECTION V.—DOORS, WINDOWS, &c.

Doors.—Dimensions, Proportions, Examples	436-441
Windows.—Form, Size, Arrangement, Problems	442-448

SECTION VI.—STAIRS.

Principles, Pitch Board	449-456
Platform Stairs, Cylinders, Rail, Face Mould	457-463
Winding Stairs, Falling Mould, Face Mould, Joints	469-476
Elucidation of Butt Joint	477
Quarter-circle Stairs.—Falling Mould, Face Mould	478-480
Face Mould.—Elucidation	481
Face Moulds.—Applied to Plank, Bevils, &c.	482-484
Face Moulds.—Another method	485-488
Scrolls, Rule, Falling and Face Moulds, Newel Cap	489-498

SECTION VII.—SHADOWS.

Shadows on Mouldings, Curves, Inclinations, &c.	499-522
Shadows.—Reflected Light	521

APPENDIX.

	PAGE
Algebraical Signs	3
Trigonometrical Terms	5

	PAGE
Glossary of Architectural Terms	7
Tables of Squares, Cubes and Roots	18
Rules for Reduction of Decimals	27
Table of Areas and Circumferences of Circles	29
Table of Capacity of Wells, Cisterns, &c.	33
Table of Areas of Polygons, &c.	34
Table of Weights of Materials	55

INTRODUCTION.

ART. 1.—A knowledge of the properties and principles of *lines* can best be acquired by practice. Although the various problems throughout this work may be understood by inspection, yet they will be impressed upon the mind with much greater force, if they are actually performed with pencil and paper by the student. Science is acquired by study—art by practice : he, therefore, who would have any thing more than a theoretical, (which must of necessity be a superficial,) knowledge of Carpentry, will attend to the following directions, provide himself with the articles here specified, and perform all the operations described in the following pages. Many of the problems may appear, at the first reading, somewhat confused and intricate ; but by making one line at a time, according to the explanations, the student will not only succeed in copying the figures correctly, but by ordinary attention will learn the principles upon which they are based, and thus be able to make them available in any unexpected case to which they may apply.

2.—The following articles are necessary for drawing, viz : a drawing-board, paper, drawing-pins or mouth-glue, a sponge, a T-square, a set-square, two straight-edges, or flat rulers, a lead pencil, a piece of india-rubber, a cake of india-ink, a set of drawing-instruments, and a scale of equal parts.

3.—The size of the *drawing-board* must be regulated according to the size of the drawings which are to be made upon it. Yet for ordinary practice, in learning to draw, a board about 15

by 20 inches, and one inch thick, will be found large enough, and more convenient than a larger one. This board should be well-seasoned, perfectly square at the corners, and without clamps on the ends. A board is better without clamps, because the little service they are supposed to render by preventing the board from warping, is overbalanced by the consideration that the shrinking of the panel leaves the ends of the clamps projecting beyond the edge of the board, and thus interfering with the proper working of the stock of the T-square. When the stuff is well-seasoned, the warping of the board will be but trifling; and by exposing the rounding side to the fire, or to the sun, it may be brought back to its proper shape.

4.—For mere line drawings, it is unnecessary to use the *best* drawing-paper; and since, where much is used the expense will be considerable, it is desirable for economy to procure paper of as low a price as will be suitable for the purpose. The best paper is made in England and marked "Whatman." This is a hand-made paper. There is also a machine-made paper at about half-price, and the Manilla paper, of various tints of russet color, is still less in price. These papers are of the various sizes needed, and are quite sufficient for ordinary drawings.

5.—A *drawing-pin* is a small brass button, having a steel pin projecting from the under side. By having one of these at each corner, the paper can be fixed to the board; but this can be done in a much better manner with *mouth-glue*. The pins will prevent the paper from changing its position on the board; but, more than this, the glue keeps the paper perfectly tight and smooth, thus making it so much the more pleasant to work on.

To attach the paper with mouth-glue, lay it with the bottom side up, on the board; and with a straight-edge and penknife, cut off the rough and uneven edge. With a sponge moderately wet, rub all the surface of the paper, except a strip around the edge about half an inch wide. As soon as the glistening of the water disappears, turn the sheet over, and place it upon the

board just where you wish it glued. Commence upon one of the longest sides, and proceed thus: lay a flat ruler upon the paper, parallel to the edge, and within a quarter of an inch of it. With a knife, or any thing similar, turn up the edge of the paper against the edge of the ruler, and put one end of the cake of mouth-glue between your lips to dampen it. Then holding it upright, rub it against and along the entire edge of the paper that is turned up against the ruler, bearing moderately against the edge of the ruler, which must be held firmly with the left hand. Moisten the glue as often as it becomes dry, until a sufficiency of it is rubbed on the edge of the paper. Take away the ruler, restore the turned-up edge to the level of the board, and lay upon it a strip of pretty stiff paper. By rubbing upon this, not very hard but pretty rapidly, with the thumb nail of the right hand, so as to cause a gentle friction, and heat to be imparted to the glue that is on the edge of the paper, you will make it adhere to the board. The other edges in succession must be treated in the same manner.

Some short distances along one or more of the edges, may afterwards be found loose: if so, the glue must again be applied, and the paper rubbed until it adheres. The board must then be laid away in a warm or dry place; and in a short time, the surface of the paper will be drawn out, perfectly tight and smooth, and ready for use. The paper dries best when the board is laid level. When the drawing is finished, lay a straight-edge upon the paper, and cut it from the board, leaving the glued strip still attached. This may afterwards be taken off by wetting it freely with the sponge; which will soak the glue, and loosen the paper. Do this as soon as the drawing is taken off, in order that the board may be dry when it is wanted for use again. Care must be taken that, in applying the glue, the edge of the paper does not become damper than the rest: if it should, the paper must be laid aside to dry, (to use at another time,) and another sheet be used in its place.

Sometimes, especially when the drawing board is new, the paper will not stick very readily; but by persevering, this difficulty may be overcome. In the place of the mouth-glue, a strong solution of gum-arabic may be used, and on some accounts is to be preferred; for the edges of the paper need not be kept dry, and it adheres more readily. Dissolve the gum in a sufficiency of warm water to make it of the consistency of linseed oil. It must be applied to the paper with a brush, when the edge is turned up against the ruler, as was described for the mouth-glue. If two drawing-boards are used, one may be in use while the other is laid away to dry; and as they may be cheaply made, it is advisable to have two. The drawing-board having a frame around it, commonly called a panel-board, may afford rather more facility in attaching the paper when this is of the size to suit; yet it has objections which overbalance that consideration.

6 —A *T-square* of mahogany, at once simple in its construction, and affording all necessary service, may be thus made. Let the stock or handle be seven inches long, two and a quarter inches wide, and three-eighths of an inch thick: the blade, twenty inches long, (exclusive of the stock,) two inches wide, and one-eighth of an inch thick. In joining the blade to the stock, a very firm and simple joint may be made by dovetailing it—as shown at *Fig. 1*.




Fig. 1.

7.—The *set-square* is in the form of a right-angled triangle ; and is commonly made of mahogany, one-eighth of an inch in thickness. The size that is most convenient for general use, is six inches and three inches respectively for the sides which contain the right angle ; although a particular length for the sides is by no means necessary. Care should be taken to have the square corner exactly true. This, as also the T-square and rulers, should have a hole bored through them, by which to hang them upon a nail when not in use.

8.—One of the *rulers* may be about twenty inches long, and the other six inches. The *pencil* ought to be hard enough to retain a fine point, and yet not so hard as to leave ineffaceable marks. It should be used lightly, so that the extra marks that are not needed when the drawing is inked, may be easily rubbed off with the rubber. The best kind of *india-ink* is that which will easily rub off upon the plate ; and, when the cake is rubbed against the teeth, will be free from grit.

9.—The *drawing-instruments* may be purchased of mathematical instrument makers at various prices : from one to one hundred dollars a set. In choosing a set, remember that the lowest price articles are not always the cheapest. A set, comprising a sufficient number of instruments for ordinary use, well made and fitted in a mahogany box, may be purchased of the mathematical instrument-makers in New York for four or five dollars. But for permanent use those which come at ten or twelve dollars will be found to be the best.

10.—The best *scale of equal parts* for carpenters' use, is one that has one-eighth, three-sixteenths, one-fourth, three-eighths, one-half, five-eighths, three-fourths, and seven-eighths of an inch, and one inch, severally divided into *twelfths*, instead of being divided, as they usually are, into tenths. By this, if it be required to proportion a drawing so that every foot of the object represented will upon the paper measure one-fourth of an inch, use that part of the scale which is divided into one-fourths of an

inch taking for every foot one of those divisions, and for every inch one of the subdivisions into twelfths; and proceed in like manner in proportioning a drawing to any of the other divisions of the scale. An instrument in the form of a semi-circle, called a *protractor*, and used for laying down and measuring angles, is of much service to surveyors, but not much to carpenters.

11.—In drawing parallel lines, when they are to be parallel to either side of the board, use the T-square; but when it is required to draw lines parallel to a line which is drawn in a direction oblique to either side of the board, the set-square must be used. Let $a b$, (*Fig. 2*,) be a line, parallel to which it is




Fig 2

desired to draw one or more lines. Place any edge, as $c d$, of the set-square even with said line; then place the ruler, $g h$, against one of the other sides, as $c e$, and hold it firmly; slide the set-square along the edge of the ruler as far as it is desired, as at f ; and a line drawn by the edge, $i f$, will be parallel to $a b$.

12.—To draw a line, as $k l$, (*Fig. 3*,) perpendicular to another, as $a b$, set the shortest edge of the set-square at the line, $a b$; place the ruler against the longest side, (the hypotenuse of the right-angled triangle;) hold the ruler firmly, and slide the set-square along until the side, $e d$ touches the point, k ; then the line, $l k$, drawn by it, will be perpendicular to $a b$. In like

manner, the drawing of other problems may be facilitated, as will be discovered in using the instruments.




Fig. 3.

13.—In drawing a problem, proceed, with the pencil sharpened to a point, to lay down the several lines until the whole figure is completed; observing to let the lines cross each other at the several angles, instead of merely meeting. By this, the length of every line will be clearly defined. With a drop or two of water, rub one end of the cake of ink upon a plate or saucer, until a sufficiency adheres to it. Be careful to dry the cake of ink; because if it is left wet, it will crack and crumble in pieces. With an inferior camel's-hair pencil, add a little water to the ink that was rubbed on the plate, and mix it well. It should be diluted sufficiently to flow freely from the pen, and yet be thick enough to make a *black* line. With the hair pencil, place a little of the ink between the nibs of the drawing-pen, and screw the nibs together until the pen makes a fine line. Beginning with the curved lines, proceed to ink *all* the lines of the figure; being careful now to make every line of its requisite length. If they are a trifle too short or too long, the drawing will have a ragged appearance; and this is opposed to that neatness and accuracy which is indispensable to a good drawing. When the ink is dry, efface the pencil-marks with the india-rubber. If

the pencil is used lightly, they will all rub off, leaving those lines only that were inked.

14.—In problems, all auxiliary lines are drawn light; while the lines given and those sought, in order to be distinguished at a glance, are made much heavier. The heavy lines are made so, by passing over them a second time, having the nibs of the pen separated far enough to make the lines as heavy as desired. If the heavy lines are made before the drawing is cleaned with the rubber, they will not appear so black and neat; because the india-rubber takes away part of the ink. If the drawing is a ground-plan or elevation of a house, the shade-lines, as they are termed, should not be put in until the drawing is shaded; as there is danger of the heavy lines spreading, when the brush, in shading or coloring, passes over them. If the lines are inked with common writing-ink, they will, however fine they may be made, be subject to the same evil; for which reason, india-ink is the only kind to be used.

THE
AMERICAN HOUSE-CARPENTER.

SECTION I.—PRACTICAL GEOMETRY.

DEFINITIONS.

15. — *Geometry* treats of the properties of magnitudes.
- 16.—A *point* has neither length, breadth, nor thickness.
17. —A *line* has length only.
- 18.—*Superficies* has length and breadth only.
- 19.—A *plane* is a surface, perfectly straight and even in every direction ; as the face of a panel when not warped nor winding.
- 20.—A *solid* has length, breadth and thickness.
- 21.—A *right*, or *straight*, line is the shortest that can be drawn between two points.
- 22.—*Parallel lines* are equi-distant throughout their length.
- 23.—An *angle* is the inclination of two lines towards one another. (*Fig. 4.*)




Fig. 4.



Fig. 5.

Fig. 6.

24.—A *right angle* has one line perpendicular to the other. (Fig. 5.)

25.—An *oblique angle* is either greater or less than a right angle. (Fig. 4 and 6.)

26.—An *acute angle* is less than a right angle. (Fig. 4.)

27.—An *obtuse angle* is greater than a right angle. (Fig. 6.)

When an angle is denoted by three letters, the middle one, in the order they stand, denotes the angular point, and the other two the sides containing the angle; thus, let $a b c$, (Fig. 4,) be the angle, then b will be the angular point, and $a b$ and $b c$ will be the two sides containing that angle.

28.—A *triangle* is a superficies having three sides and angles. (Fig. 7, 8, 9 and 10.)



Fig. 7.



Fig. 8.

29.—An *equi-lateral triangle* has its three sides equal. (Fig. 7.)

30.—An *isosceles triangle* has only two sides equal. (Fig. 8.)

31.—A *scalene triangle* has all its sides unequal. (Fig. 9)




Fig. 9.




Fig. 10.

32.—A *right-angled triangle* has one right angle. (Fig. 10.)

33.—An *acute-angled triangle* has all its angles acute. (Fig. 7 and 8.)

34.—An *obtuse-angled triangle* has one obtuse angle. (Fig. 9.)

35.—A *quadrangle* has four sides and four angles. (Fig. 11 to 16.)



Fig. 11.



Fig. 12.

36.—A *parallelogram* is a quadrangle having its opposite sides parallel. (Fig. 11 to 14.)

37.—A *rectangle* is a parallelogram, its angles being right angles. (Fig. 11 and 12.)

38.—A *square* is a rectangle having equal sides. (Fig. 11.)

39.—A *rhombus* is an equi-lateral parallelogram having oblique angles. (Fig. 13.)



Fig. 13.



Fig. 14.

40.—A *rhomboid* is a parallelogram having oblique angles. (Fig. 14.)

41.—A *trapezoid* is a quadrangle having only two of its sides parallel. (Fig. 15.)



Fig. 15.




Fig. 16.

42.—A *trapezium* is a quadrangle which has no two of its sides parallel. (Fig. 16.)

43.—A *polygon* is a figure bounded by right lines.

44.—A *regular polygon* has its sides and angles equal.

45.—An *irregular polygon* has its sides and angles unequal.

46.—A *trigon* is a polygon of three sides, (Fig. 7 to 10,) a *tetragon* has four sides, (Fig. 11 to 16;) a *pentagon* has

five, (*Fig. 17*;) a *hexagon* six, (*Fig. 18*;) a *heptagon* seven, (*Fig. 19*;) an *octagon* eight, (*Fig. 20*;) a *nonagon* nine; a *decagon* ten; an *undecagon* eleven; and a *dodecagon* twelve sides.




Fig. 17.




Fig. 18.



Fig. 19.




Fig. 20.

47.—A *circle* is a figure bounded by a curved line, called the *circumference*; which is every where equi-distant from a certain point within, called its *centre*.

The circumference is also called the *periphery*, and sometimes the *circle*.

48.—The *radius* of a circle is a right line drawn from the centre to any point in the circumference. (*a b*, *Fig. 21*.)

All the *radii* of a circle are equal.




Fig. 21.

49.—The *diameter* is a right line passing through the centre, and terminating at two opposite points in the circumference. Hence it is twice the length of the radius. (*c d*, *Fig. 21*.)

50.—An *arc* of a circle is a part of the circumference. (*c b* or *b e d*, *Fig. 21*.)

51.—A *chord* is a right line joining the extremities of an *arc*. (*b d*, *Fig. 21*.)

52.—A *segment* is any part of a circle bounded by an arc and its chord. (*A*, *Fig. 21.*)

53.—A *sector* is any part of a circle bounded by an arc and two radii, drawn to its extremities. (*B*, *Fig. 21.*)

54.—A *quadrant*, or quarter of a circle, is a sector having a quarter of the circumference for its arc. (*C*, *Fig. 21.*)

55.—A *tangent* is a right line, which in passing a curve, touches, without cutting it. (*f g*, *Fig. 21.*)

56.—A *cone* is a solid figure standing upon a circular base diminishing in straight lines to a point at the top, called its vertex. (*Fig. 22.*)



Fig. 22.




Fig. 23.

57.—The *axis* of a cone is a right line passing through it, from the vertex to the centre of the circle at the base.

58.—An *ellipsis* is described if a cone be cut by a plane, not parallel to its base, passing quite through the curved surface. (*a b*, *Fig. 23.*)

59.—A *parabola* is described if a cone be cut by a plane, parallel to a plane touching the curved surface. (*c d*, *Fig. 23*—*c d* being parallel to *f g*.)

60.—An *hyperbola* is described if a cone be cut by a plane, parallel to any plane within the cone that passes through its vertex. (*e h*, *Fig. 23.*)

61.—*Foci* are the points at which the pins are placed in describing an ellipse. (See *Art. 115*, and *f, f*, *Fig. 24.*)




Fig. 24.

62.—The *transverse axis* is the longest diameter of the ellipse. (*a b*, Fig. 24.)

63.—The *conjugate axis* is the shortest diameter of the ellipse; and is, therefore, at right angles to the transverse axis. (*c d*, Fig. 24.)

64.—The *parameter* is a right line passing through the focus of an ellipse, at right angles to the transverse axis, and terminated by the curve. (*g h* and *g t*, Fig. 24.)

65.—A *diameter of an ellipse* is any right line passing through the centre, and terminated by the curve. (*k l*, or *m n*, Fig. 24.)

66.—A diameter is *conjugate* to another when it is parallel to a tangent drawn at the extremity of that other—thus, the diameter, *m n*, (Fig. 24,) being parallel to the tangent; *o p*, is therefore conjugate to the diameter, *k l*.

67.—A *double ordinate* is any right line, crossing a diameter of an ellipse, and drawn parallel to a tangent at the extremity of that diameter. (*i t*, Fig. 24.)

68.—A *cylinder* is a solid generated by the revolution of a right-angled parallelogram, or rectangle, about one of its sides; and consequently the ends of the cylinder are equal circles. (Fig. 25.)




Fig. 25.




Fig. 26.

69.—The *axis* of a cylinder is a right line passing through it, from the centres of the two circles which form the ends.

70.—A *segment* of a cylinder is comprehended under three planes, and the curved surface of the cylinder. Two of these are segments of circles : the other plane is a parallelogram, called by way of distinction, the *plane of the segment*. The circular segments are called, the ends of the cylinder. (*Fig. 26.*)

N. B.—For Algebraical Signs, Trigonometrical Terms, &c., see Appendix.

PROBLEMS.

RIGHT LINES AND ANGLES.

71.—*To bisect a line.* Upon the ends of the line, $a b$, (*Fig.* 27,) as centres, with any distance for radius greater than half




Fig. 27.

$a b$, describe arcs cutting each other in c and d ; draw the line, $c d$, and the point, e , where it cuts $a b$, will be the middle of the line, $a b$.

In practice, a line is generally divided with the compasses, or dividers; but this problem is useful where it is desired to draw, at the middle of another line, one at right angles to it. (See *Art.* 85.)




Fig. 28.

72.—*To erect a perpendicular.* From the point, a , (*Fig.* 28,))

set off any distance, as $a b$, and the same distance from a to c , upon c , as a centre, with any distance for radius greater than $c a$, describe an arc at d ; upon b , with the same radius, describe another at d ; join d and a , and the line, $d a$, will be the perpendicular required.

This, and the three following problems, are more easily performed by the use of the set-square—(see *Art. 12.*) Yet they are useful when the operation is so large that a set-square cannot be used.




Fig. 29.

73.—*To let fall a perpendicular.* Let a , (*Fig. 29,*) be the point, above the line, $b c$, from which the perpendicular is required to fall. Upon a , with any radius greater than $a d$, describe an arc, cutting $b c$ at e and f ; upon the points, e and f with any radius greater than $e d$, describe arcs, cutting each other at g ; join a and g , and the line, $a d$, will be the perpendicular required.




Fig. 30.

74.—*To erect a perpendicular at the end of a line.* Let a , (*Fig. 30,*) at the end of the line, $c a$, be the point at which the perpendicular is to be erected. Take any point, as b , above the line, $c a$, and with the radius, $b a$, describe the arc, $d a e$. through d and b , draw the line, $d e$; join e and a , then $e a$ will be the perpendicular required.

The principle here made use of, is a very important one; and is applied in many other cases—(see *Art.* 81, *b.* and *Art.* 84. For proof of its correctness, see *Art.* 156.)




Fig. 31.

74, *a.*—*A second method.* Let *b*, (*Fig.* 31,) at the end of the line, *a b*, be the point at which it is required to erect a perpendicular. Upon *b*, with any radius less than *b a*, describe the arc, *c e d*; upon *c*, with the same radius, describe the small arc at *e*, and upon *e*, another at *d*; upon *e* and *d*, with the same or any other radius greater than half *e d*, describe arcs intersecting at *f*; join *f* and *b*, and the line, *f b*, will be the perpendicular required. This method of erecting a perpendicular and that of the following article, depend for accuracy upon the fact that the side of a hexagon is equal to the radius of the circumscribing circle.




Fig. 32.

74, *b.*—*A third method.* Let *b*, (*Fig.* 32,) be the given point at which it is required to erect a perpendicular. Upon *b*, with any radius less than *b a*, describe the quadrant, *d e f*; upon *d*, with the same radius, describe an arc at *e*, and upon *e*, another at *c*,

through d and e , draw $d c$, cutting the arc in c ; join c and b , then $c b$ will be the perpendicular required.

This problem can be solved by the *six, eight and ten* rule, as it is called; which is founded upon the same principle as the problems at *Art.* 103, 104; and is applied as follows. Let $a d$, (*Fig.* 30,) equal eight, and $a e$, six; then, if $d e$ equals ten, the angle, $e a d$, is a right angle. Because the square of six and that of eight, added together, equal the square of ten, thus: $6 \times 6 = 36$, and $8 \times 8 = 64$; $36 + 64 = 100$, and $10 \times 10 = 100$. Any sizes, taken in the same proportion, as six, eight and ten, will produce the same effect: as 3, 4 and 5, or 12, 16 and 20. (See *Art.* 103.)

By the process shown at *Fig.* 30, the end of a board may be squared without a carpenters'-square. All that is necessary is a pair of compasses and a ruler. Let $c a$ be the edge of the board, and a the point at which it is required to be squared. Take the point, b , as near as possible at an angle of forty-five degrees, or on a *mitre*-line, from a , and at about the middle of the board. This is not necessary to the working of the problem, nor does it affect its accuracy, but the result is more easily obtained. Stretch the compasses from b to a , and then bring the leg at a around to d ; draw a line from d , through b , out indefinitely; take the distance, $d b$, and place it from b to e ; join e and a ; then $e a$ will be at right angles to $c a$. In squaring the foundation of a building, or laying-out a garden, a rod and chalk-line may be used instead of compasses and ruler.

75.—*To let fall a perpendicular near the end of a line.* Let e , (*Fig.* 30,) be the point above the line, $c a$, from which the perpendicular is required to fall. From e , draw any line, as $e d$, obliquely to the line, $c a$; bisect $e d$ at b ; upon b , with the radius, $b e$, describe the arc, $e a d$; join e and a ; then $e a$ will be the perpendicular required.




Fig. 33.

76.—*To make an angle, (as $e d f$, *Fig.* 33,) equal to a given angle, (as $b a c$.)* From the angular point, a , with any radius describe the arc, $b c$; and with the same radius, on the line, $d e$,

and from the point, d , describe the arc, fg ; take the distance, bc , and upon g , describe the small arc at f ; join f and d ; and the angle, edf , will be equal to the angle, bac .

If the given line upon which the angle is to be made, is situated parallel to the similar line of the given angle, this may be performed more readily with the set-square. (See *Art.* 11.)




Fig. 34.

77.—*To bisect an angle.* Let abc , (*Fig.* 34,) be the angle to be bisected. Upon b , with any radius, describe the arc, ac ; upon a and c , with a radius greater than half ac , describe arcs cutting each other at d ; join b and d ; and bd will bisect the angle, abc , as was required.

This problem is frequently made use of in solving other problems; it should therefore be well impressed upon the memory.




Fig. 35.

78.—*To trisect a right angle.* Upon a , (*Fig.* 35,) with any radius, describe the arc, bc ; upon b and c , with the same radius, describe arcs cutting the arc, bc , at d and e ; from d and e , draw lines to a , and they will trisect the angle as was required.

The truth of this is made evident by the following operation. Divide a circle into quadrants: also, take the radius in the dividers, and space off the circumference. This will divide the circumference into just six parts. A semi-circumference, there-

fore, is equal to three, and a quadrant to one and a half of those parts. The radius, therefore, is equal to $\frac{2}{3}$ of a quadrant; and this is equal to a right angle.




Fig. 36.

79.—*Through a given point, to draw a line parallel to a given line.* Let a , (Fig. 36,) be the given point, and bc the given line. Upon any point, as d , in the line, bc , with the radius, da , describe the arc, ac ; upon a , with the same radius, describe the arc, de ; make de equal to ac ; through e and a draw the line, ea ; which will be the line required.

This is upon the same principle as *Art.* 76.




Fig. 37

80.—*To divide a given line into any number of equal parts.* Let ab , (Fig. 37,) be the given line, and 5 the number of parts. Draw ac , at any angle to ab ; on ac , from a , set off 5 equal parts of any length, as at 1, 2, 3, 4 and c ; join c and b ; through the points, 1, 2, 3 and 4, draw 1 e , 2 f , 3 g and 4 h , parallel to cb ; which will divide the line, ab , as was required.

The lines, ab and ac , are divided in the same proportion. (See *Art.* 109.)

THE CIRCLE.

81.—*To find the centre of a circle.* Draw any chord, as ab




Fig. 38.

(Fig. 38,) and bisect it with the perpendicular, $c d$; bisect $c a$ with the line, $e f$, as at g ; then g is the centre as was required.




Fig. 39.

81, *a*.—A second method. Upon any two points in the circumference nearly opposite, as a and b . (Fig. 39,) describe arcs cutting each other at c and d : take any other two points, as e and f , and describe arcs intersecting as at g and h ; join g and h , and c and d ; the intersection, o , is the centre.

This is upon the same principle as *Art. 85*.




Fig. 40.

81, *b*.—A third method. Draw any chord, as $a b$, (Fig. 40,)

and from the point, a , draw $a c$, at right angles to $a b$; join c and b ; bisect $c b$ at d —which will be the centre of the circle.

If a circle be not too large for the purpose, its centre may very readily be ascertained by the help of a carpenters'-square, thus: app'y the corner of the square to any point in the circumference, as at a ; by the edges of the square, (which the lines, $a b$ and $a c$, represent,) draw lines cutting the circle, as at b and c ; join b and c ; then if $b c$ is bisected, as at d , the point, d , will be the centre. (See *Art.* 156.)




Fig. 41.

82.—At a given point in a circle, to draw a tangent thereto. Let a , (*Fig.* 41,) be the given point, and b the centre of the circle. Join a and b ; through the point, a , and at right angles to $a b$, draw $c d$; then $c d$ is the tangent required.




Fig. 42

83.—The same, without making use of the centre of the circle. Let a , (*Fig.* 42,) be the given point. From a , set off any distance to b , and the same from b to c ; join a and c , upon a , with $a b$ for radius, describe the arc, $d b e$; make $d b$ equal to $b e$; through a and d , draw a line; this will be the tangent required.

The correctness of this method depends upon the fact that the angle formed by a chord and tangent is equal to any

inscribed angle in the opposite segment of the circle, (*Art.* 163;) $a b$ being the chord, and $b c a$ the angle in the opposite segment of the circle. Now, the angles $d a b$ and $b c a$ are equal, because the angles $d a b$ and $b a c$ are, by construction, equal; and the angles $b a c$ and $b c a$ are equal, because the triangle $a b c$ is an isosceles triangle, having its two sides, $a b$ and $b c$, by construction equal; therefore the angles $d a b$ and $b c a$ are equal.




Fig. 43.

84.—*A circle and a tangent given, to find the point of contact.* From any point, as a , (*Fig.* 43,) in the tangent, $b c$, draw a line to the centre d ; bisect $a d$ at e ; upon e , with the radius, $e a$, describe the arc, $a f d$; f is the point of contact required.

If f and d were joined, the line would form right angles with the tangent, $b c$. (See *Art.* 156.)




Fig. 44.

85.—*Through any three points not in a straight line, to draw a circle.* Let a , b and c , (*Fig.* 44,) be the three given points. Upon a and b , with any radius greater than half $a b$, describe

arcs intersecting at d and e ; upon b and c , with any radius greater than half $b c$, describe arcs intersecting at f and g ; through d and e , draw a right line, also another through f and g ; upon the intersection, h , with the radius, $h a$, describe the circle, $a b c$, and it will be the one required.




Fig. 45.

86.—*Three points not in a straight line being given, to find a fourth that shall, with the three, lie in the circumference of a circle.* Let $a b c$, (Fig. 45,) be the given points. Connect them with right lines, forming the triangle, $a c b$; bisect the angle, $c b a$, (Art. 77,) with the line $b d$; also bisect $c a$ in e , and erect $e d$, perpendicular to $a c$, cutting $b d$ in d ; then d is the *fourth* point required.

A fifth point may be found, as at f , by assuming a, d and b , as the three given points, and proceeding as before. So, also, any number of points may be found; simply by using any three already found. This problem will be serviceable in obtaining short pieces of very flat sweeps. (See Art. 397.)

The proof of the correctness of this method is found in the fact that equal chords subtend equal angles, (Art. 162.) Join d and c ; then since $a e$ and $e c$ are, by construction, equal, therefore the chords $a d$ and $d c$ are equal; hence the angles they subtend, $d b a$ and $d b c$, are equal. So likewise chords drawn from a to f , and from f to d , are equal, and subtend the equal angles, $d b f$ and $f b a$. Additional points, beyond a or b , may be obtained on the same principle. To obtain a point beyond a , on b , as a centre, describe with any radius the arc $i o n$, make $o n$ equal to $o i$; through b and n draw $b g$; on a as

centre and with af for radius, describe the arc, cutting gb at g , then g is the point sought.




Fig. 46.

87.—*To describe a segment of a circle by a set-triangle.* Let ab , (Fig. 46,) be the chord, and cd the height of the segment. Secure two straight-edges, or rulers, in the position, ce and cf , by nailing them together at c , and affixing a brace from e to f ; put in pins at a and b ; move the angular point, c , in the direction, acb ; keeping the edges of the triangle hard against the pins, a and b ; a pencil held at c will describe the arc, acb .

A curve described by this process is accurately *circular*, and is not a mere approximation to a circular arc, as some may suppose. This method produces a circular curve, because all inscribed angles on one side of a chord line are equal. (Art. 161.) To obtain the radius from a chord and its versed sine, see Art. 165.

If the angle formed by the rulers at c be a right angle, the segment described will be a semi-circle. This problem is useful in describing centres for brick arches, when they are required to be rather flat. Also, for the head hanging-stile of a window-frame, where a brick arch, instead of a stone lintel, is to be placed over it.

87 a.—*To find the radius of an arc of a circle when the chord and versed sine are given.* The radius is equal to the sum of the squares of half the chord and of the versed sine, divided by twice the versed sine. This is expressed, algebraically, thus— $r = \frac{(\frac{c}{2})^2 + v^2}{2v}$, where r is the radius, c the chord, and v the versed sine. (Art. 165.)

Example.—In a given arc of a circle, a chord of 12 feet has

the rise at the middle, or the versed sine, equal to 2 feet, what is the radius?

Half the chord equals 6, the square of 6 is, $6 \times 6 = 36$
 The square of the versed sine is, $2 \times 2 =$ 4

Their sum equals, 40

Twice the versed sine equals 4, and 40 divided by 4 equals 10
 Therefore the radius, in this case, is 10 feet. This result is shown in less space and more neatly by using the above algebraical formula. For the letters, substituting their value, the

formula $r = \frac{(\frac{c}{2})^2 + v^2}{2v}$ becomes $r = \frac{(\frac{12}{2})^2 + 2^2}{2 \times 2}$, and performing the arithmetical operations here indicated equals

$$\frac{6^2 + 2^2}{4} = \frac{36 + 4}{4} = \frac{40}{4} = 10$$

87 b.—To find the versed sine of an arc of a circle when the radius and chord are given. The versed sine is equal to the radius, less the square root of the difference of the squares of the radius and half chord: expressed algebraically thus— $v = r - \sqrt{r^2 - (\frac{c}{2})^2}$, where r is the radius, v the versed sine, and c the chord. (Art. 158.)

Example.—In an arc of a circle whose radius is 75 feet, what is the versed sine to a chord of 120 feet? By the table in the Appendix it will be seen that—

The square of the radius, 75, equals, 5625
 The square of half the chord, 60, equals, 3600

The difference is, 2025

The square root of this is, 45
 This deducted from the radius, 75

The remainder is the versed sine, = 30

This is expressed by the formula thus—

$$v = 75 - \sqrt{75^2 - (\frac{120}{2})^2} = 75 - \sqrt{5625 - 3600} = 75 - 45 = 30$$




Fig. 47.

88.—To describe the segment of a circle by intersection of lines. Let $a b$, (Fig. 47,) be the chord, and $c d$ the height of the segment. Through c , draw $e f$, parallel to $a b$; draw $b f$ at right angles to $c b$; make $c e$ equal to $c f$; draw $a g$ and $b h$, at right angles to $a b$; divide $c e$, $c f$, $d a$, $d b$, $a g$, and $b h$, each into a like number of equal parts, as four; draw the lines, 1 1, 2 2, &c., and from the points, o , o and o , draw lines to c ; at the intersection of these lines, trace the curve, $a c b$, which will be the segment required.

In very large work, or in laying out ornamented gardens, &c., this will be found useful; and where the centre of the proposed arc of a circle is inaccessible it will be invaluable. (To trace the curve, see note at Art. 117.)

The lines $e a$, $c d$ and $f b$, would, were they extended, meet in a point, and that point would be in the opposite side of the circumference of the circle of which $a c b$ is a segment. The lines 1 1, 2 2, 3 3, would likewise, if extended, meet in the same point. The line, $c d$, if extended to the opposite side of the circle, would become a diameter. The line, $f b$, forms, by construction, a right angle with $b c$, and hence the extension of $f b$ would also form a right angle with $b c$, on the opposite side of $b c$; and this right angle would be the inscribed angle in the semicircle; and since this is required to be a *right* angle, (Art. 156,) therefore the construction thus far is correct, and it will be found likewise that at each point in the curve formed by the intersection of the radiating lines, these intersecting lines are at right angles.




Fig. 47 a.

88 a.—Points in the circumference of a circle may be obtained arithmetically, and positively accurate, by the calculation of *ordinates*, or the parallel lines, 0 1, 0 2, 0 3, 0 4. (Fig.

47 a.) These ordinates are drawn at right angles to the chord line, $a b$, and they may be drawn at any distance apart, either equally distant or unequally, and there may be as many of them as is desirable; the more there are the more points in the curve will be obtained. If they are located in pairs, equally distant from the versed sine, $c d$, calculation need be made only for those on one side of $c d$, as those on the opposite side will be of equal lengths, respectively; for example, 0 1, on the left-hand side of $c d$, is equal to 0 1 on the right-hand side, 0 2 on the right equals 0 2 on the left, and in like manner for the others.

The length of any ordinate is equal to the square root of the difference of the squares of the radius and abscissa, less the difference between the radius and versed sine. (*Art.* 166.) The abscissa being the distance from the foot of the versed sine to the foot of the ordinate. Algebraically, $y = \sqrt{r^2 - x^2} - (r - v)$, where y is put to represent the ordinate; x , the abscissa; v , the versed sine; and r , the radius.

Example.—An arc of a circle has its chord, $a b$, (*Fig.* 47 a,) 100 feet long, and its versed sine, $c d$, 5 feet. It is required to ascertain the length of ordinates for a sufficient number of points through which to describe the curve. To this end it is requisite, first, to ascertain the radius. This is readily done in accordance with *Art.* 87 a. For, $\frac{(c)^2 + v^2}{2v}$, becomes $\frac{50^2 + 5^2}{2 \times 5} = 252.5 =$ radius. Having the radius, the curve might at once be described without the ordinate points, but for the impracticability that usually occurs, in large, flat segments of the circle, of getting a location for the centre; the centre usually being inaccessible. The ordinates are, therefore, to be calculated. In *Fig.* 47 a the ordinates are located equidistant, and are 10 feet apart. It will only be requisite, therefore, to calculate those on one side of the versed sine, $c d$. For the first ordinate, 0 1, the formula, $y = \sqrt{r^2 - x^2} - (r - v)$ becomes

$$\begin{aligned} y &= \sqrt{252.5^2 - 10^2} - (252.5 - 5). \\ &= \sqrt{63756.25 - 100} - 247.5. \\ &= 252.3019 - 247.5. \\ &= 4.8019 = \text{the first ordinate, } 0\ 1. \end{aligned}$$

For the second—

$$\begin{aligned} y &= \sqrt{252 \cdot 5^2 - 20^2} - (252 \cdot 5 - 5). \\ &= 251 \cdot 7066 - 247 \cdot 5. \\ &= 4 \cdot 2066 = \text{the second ordinate, } 02. \end{aligned}$$

For the third—

$$\begin{aligned} y &= \sqrt{252 \cdot 5^2 - 30^2} - 247 \cdot 5. \\ &= 250 \cdot 7115 - 247 \cdot 5. \\ &= 3 \cdot 2115 = \text{the third ordinate, } 03. \end{aligned}$$

For the fourth—

$$\begin{aligned} y &= \sqrt{252 \cdot 5^2 - 40^2} - 247 \cdot 5. \\ &= 249 \cdot 3115 - 247 \cdot 5. \\ &= 1 \cdot 8115 = \text{the fourth ordinate, } 04. \end{aligned}$$

The results here obtained are in feet and decimals of a foot. To reduce these to feet, inches, and eighths of an inch, proceed as at Reduction of Decimals in the Appendix. If the two-foot rule, used by carpenters and others, were decimally divided, there would be no necessity of this reduction, and it is to be hoped that the rule will yet be thus divided, as such a reform would much lessen the labor of computations, and insure more accurate measurements.

Versed sine, $c d$,	= ft. 5.0	= ft. 5.0 inches.
Ordinates,	0 1, = 4.8019	= 4.9 $\frac{5}{8}$ inches nearly.
“	0 2, = 4.2066	= 4.2 $\frac{1}{2}$ inches nearly.
“	0 3, = 3.2115	= 3.2 $\frac{1}{4}$ inches nearly.
“	0 4, = 1.8115	= 1.9 $\frac{3}{4}$ inches nearly.




Fig. 48.

89.—*In a given angle, to describe a tanged curve.* Let $a b c$, (Fig. 48,) be the given angle, and 1 in the line, $a b$, and 5 in the line, $b c$, the termination of the curve. Divide $1 b$ and $b 5$ into a like number of equal parts, as at 1, 2, 3, 4 and 5; join 1 and 1, 2 and 2, 3 and 3, &c.; and a regular curve will be formed that will be tangential to the line, $a b$, at the point, 1, and to $b c$ at 5.

This is of much use in stair-building, in easing the angles formed between the wall-string and the base of the hall, also

between the front string and level fascia, and in many other instances. The curve is not circular, but of the form of the parabola, (*Fig. 93*;) yet in large angles the difference is not perceptible. This problem can be applied to describing the




Fig. 49.

curve for door heads, window-heads, &c., to rather better advantage than *Art. 87*. For instance, let $a b$, (*Fig. 49*;) be the width of the opening, and $c d$ the height of the arc. Extend $c d$, and make $d e$ equal to $c d$; join a and e , also e and b ; and proceed as directed above.




Fig. 50

90.—*To describe a circle within any given triangle, so that the sides of the triangle shall be tangential.* Let $a b c$, (*Fig. 50*;) be the given triangle. Bisect the angles a and b , according to *Art. 77*; upon d , the point of intersection of the bisecting lines, with the radius, $d e$, describe the required circle.





Fig. 51.

91.—About a given circle, to describe an equi-lateral triangle. Let $a d b c$, (Fig. 51,) be the given circle. Draw the diameter, $c d$; upon d , with the radius of the given circle, describe the arc, $a e b$; join a and b ; draw $f g$, at right angles to $d c$; make $f c$ and $c g$, each equal to $a b$; from f , through a , draw $f h$, also from g , through b , draw $g h$; then $f g h$ will be the triangle required.



92.—To find a right line nearly equal to the circumference of a circle. Let $a b c d$, (Fig. 52,) be the given circle. Draw the diameter, $a c$; on this erect an equi-lateral triangle, $a e c$, according to Art. 93; draw $g f$, parallel to $a c$; extend $e c$ to f , also $e a$ to g ; then $g f$ will be nearly the length of the semi-circle, $a d c$; and twice $g f$ will nearly equal the circumference of the circle, $a b c d$, as was required.

Lines drawn from e , through any points in the circle, as o , o and o , to p , p and p , will divide $g f$ in the same way as the semi-circle, $a d c$, is divided. So, any portion of a circle may be transferred to a straight line. This is a very useful problem, and should be well studied; as it is frequently used to solve problems on stairs, domes, &c.

92, a.—Another method. Let $a b f c$, (Fig. 53,) be the given circle. Draw the diameter, $a c$; from d , the centre, and at right angles to $a c$, draw $d b$; join b and c ; bisect $b c$ at e ; from d , through e , draw $d f$; then $e f$ added to three times the diameter, will equal the circumference of the circle sufficiently near for




Fig. 53.

many uses. The result is a trifle too large, If the circumference found by this rule, be divided by 648·22, the quotient will be the excess. Deduct this excess, and the remainder will be the true circumference. This problem is rather more curious than useful, as it is less labor to perform the operation arithmetically: simply multiplying the given diameter by 3·1416, or where a great degree of accuracy is needed by 3·1415926.

POLYGONS, &C.




Fig. 54.

93.—*Upon a given line to construct an equi-lateral triangle.* Let $a b$, (Fig. 54,) be the given line. Upon a and b , with $a b$ for radius, describe arcs, intersecting at c ; join a and c , also c and b ; then $a c b$ will be the triangle required.

94.—*To describe an equi-lateral rectangle, or square.* Let $a b$, (Fig. 55,) be the length of a side of the proposed square. Upon a and b , with $a b$ for radius, describe the arcs $a d$ and $b c$; bisect the arc, $a e$, in f ; upon e , with $e f$ for radius, de-




Fig. 55.

scribe the arc, cfd ; join a and c , c and d , d and b ; then aob will be the square required.




Fig. 56.

95.—*Within a given circle, to inscribe an equi-lateral triangle, hexagon or dodecagon.* Let $abc d$, (Fig. 56,) be the given circle. Draw the diameter, bd ; upon b , with the radius of the given circle, describe the arc, $ae c$; join a and c , also a and d , and c and d —and the triangle is completed. For the hexagon: from a , also from c , through e , draw the lines, af and cg ; join a and b , b and c , c and f , &c., and the hexagon is completed. The dodecagon may be formed by bisecting the sides of the hexagon.

Each side of a regular hexagon is exactly equal to the radius of the circle that circumscribes the figure. For the radius is equal to a chord of an arc of 60 degrees; and, as every circle is supposed to be divided into 360 degrees, there is just 6 times 60, or 6 arcs of 60 degrees, in the whole circumference. A line drawn from each angle of the hexagon to the centre, (as in the figure,) divides it into six equal, equi-lateral triangles.

96.—*Within a square to inscribe an octagon.* Let $abc d$,




Fig. 57.

(Fig. 57,) be the given square. Draw the diagonals, $a d$ and $b c$; upon a, b, c and d , with $a e$ for radius, describe arcs cutting the sides of the square at 1, 2, 3, 4, 5, 6, 7 and 8; join 1 and 2, 3 and 4, 5 and 6, &c., and the figure is completed.

In order to eight-square a hand-rail, or any piece that is to be afterwards rounded, draw the diagonals, $a d$ and $b c$, upon the end of it, after it has been squared-up. Set a gauge to the distance, $a e$, and run it upon the whole length of the stuff, from each corner both ways. This will show how much is to be chamfered off, in order to make the piece octagonal. . (Art. 159.)




Fig. 58.




Fig. 59.




Fig. 60.

97.—Within a given circle to inscribe any regular polygon. Let $a b c 2$, (Fig. 58, 59 and 60,) be given circles. Draw the diameter, $a c$; upon this, erect an equi-lateral triangle, $a e c$, according to Art. 93; divide $a c$ into as many equal parts as the polygon is to have sides, as at 1, 2, 3, 4, &c.; from e ,

lines $a e$ and $b \delta$, (*Fig. 63*,) have to be extended before they will intersect. This method of describing polygons is founded on correct principles, and is therefore accurate. In the circle equal arcs subtend equal angles, (*Arts. 86 and 162*.) Although this method is accurate, yet polygons may be described as accurately and more simply in the following manner. It will be observed that much of the process in this method is for the purpose of ascertaining the centre of a circle that will circumscribe the proposed polygon. By reference to the Table of Polygons in the Appendix it will be seen how this centre may be obtained arithmetically. This is the *Rule*.—Multiply the given side by the tabular radius for polygons of a like number of sides with the proposed figure, and the product will be the radius of the required circumscribing circle. Divide this circle into as many equal parts as the polygon is to have sides, connect the points of division by straight lines, and the figure is complete. For example: It is desired to describe a polygon of 7 sides, and 20 inches a side. The tabular radius is 1.1523824. This multiplied by 20, the product, 23.047648 is the required radius in inches. The Rules for the Reduction of Decimals, also in the Appendix, show how to change decimals to the fractions of a foot or an inch. From this, 23.047648 is equal to $23\frac{1}{4}$ inches nearly. It is not needed to take all the decimals in the table, three or four of them will give a result sufficiently near for all ordinary practice.




Fig. 64.

99.—To construct a triangle whose sides shall be severally equal to three given lines. Let a, b and c , (*Fig. 64*,) be the given lines. Draw the line, $d e$, and make it equal to c ; upon e , with b for radius, describe an arc at f ; upon d , with a for radius, describe an arc intersecting the other at f ; join d and f , also f and e ; then $d f e$ will be the triangle required.




Fig. 65.




Fig. 66.

100.—*To construct a figure equal to a given, right-lined figure.* Let $abcd$, (*Fig. 65*,) be the given figure. Make ef , (*Fig. 66*,) equal to cd ; upon f , with da for radius, describe an arc at g ; upon e , with ca for radius, describe an arc intersecting the other at g ; join g and e ; upon f and g , with db and ab for radius, describe arcs intersecting at h ; join g and h , also h and f ; then *Fig. 66* will every way equal *Fig. 65*.

So, right-lined figures of any number of sides may be copied, by first dividing them into triangles, and then proceeding as above. The shape of the floor of any room, or of any piece of land, &c., may be accurately laid out by this problem, at a scale upon paper; and the contents in square feet be ascertained by the next.




Fig. 67.

101.—*To make a parallelogram equal to a given triangle.* Let abc , (*Fig. 67*,) be the given triangle. From a , draw ad , at right angles to bc ; bisect ad in e ; through e , draw fg , parallel to bc ; from b and c , draw bf and cg , parallel to de ; then $bfgc$ will be a parallelogram containing a surface exactly equal to that of the triangle, abc .

Unless the parallelogram is required to be a rectangle, the lines, bf and cg , need not be drawn parallel to de . If a rhomboid is desired, they may be drawn at an oblique angle, provided they be parallel to one another. To ascertain the area of a triangle, multiply the base, bc , by half the perpendicular height, da . In doing this, it matters not which side is taken for base.




Fig. 68.

102.—*A parallelogram being given, to construct another equal to it, and having a side equal to a given line.* Let *A*, (Fig. 68,) be the given parallelogram, and *B* the given line. Produce the sides of the parallelogram, as at *a*, *b*, *c* and *d*; make *e d* equal to *B*; through *d*, draw *c f*, parallel to *g b*; through *e*, draw the diagonal, *c a*; from *a*, draw *a f*, parallel to *e d* then *C* will be equal to *A*. (See Art. 144.)




Fig. 69.

103.—*To make a square equal to two or more given squares.* Let *A* and *B*, (Fig. 69,) be two given squares. Place them so as to form a right angle, as at *a*; join *b* and *c*; then the square, *C*, formed upon the line, *b c*, will be equal in extent to the squares, *A* and *B*, added together. Again: if *a b*, (Fig. 70,) be equal to




Fig. 70.

the side of a given square, *c a*, placed at right angles to *a b*, be the side of another given square, and *c d*, placed at right angles to

c , b , be the side of a third given square; then the square, A , formed upon the line, d , b , will be equal to the three given squares. (See *Art.* 157.)

The usefulness and importance of this problem are proverbial. To ascertain the length of braces and of rafters in framing, the length of stair-strings, &c., are some of the purposes to which it may be applied in carpentry. (See note to *Art.* 74, *b.*) If the length of any two sides of a right-angled triangle is known, that of the third can be ascertained. Because the square of the hypotenuse is equal to the united squares of the two sides that contain the right angle.

(1.)—The two sides containing the right angle being known, to find the hypotenuse. *Rule.*—Square each given side, add the squares together, and from the product extract the square-root: this will be the answer. For instance, suppose it were required to find the length of a rafter for a house, 34 feet wide,—the ridge of the roof to be 9 feet high, above the level of the wall-plates. Then 17 feet, half of the span, is one, and 9 feet, the height, is the other of the sides that contain the right angle. Proceed as directed by the rule:

17	9
17	9
—	—
119	81 = square of 9.
17	289 = square of 17.
—	—
289 = square of 17.	370 Product.

1) 370 (19·235 + = square-root of 370; equal 19 feet, 2 $\frac{3}{8}$ in.
 1 1 nearly: which would be the required
 ——— length of the rafter.

29) 270
 9 261

382) 0·900
 2 764

3843) 13600
 3 11529

38465) 207100 (By reference to the table of square-roots
 192325 in the Appendix, the root of almost any
 ——— number may be found ready calculated;

also, to change the decimals of a foot to inches and parts, see Rules for the Reduction of Decimals in the Appendix.)

Again : suppose it be required, in a frame building, to find the length of a brace, having a run of three feet each way from the point of the right angle. The length of the sides containing the right angle will be each 3 feet : then, as before—

$$\begin{array}{r} 3 \\ 3 \\ \hline \end{array}$$

9 = square of one side.

3 times 3 = 9 = square of the other side.

18 Product : the square-root of which is 4.2426 + ft., or 4 feet, 2 inches and $\frac{2}{3}$ ths. full.

(2.)—The hypotenuse and one side being known, to find the other side. *Rule.*—Subtract the square of the given side from the square of the hypotenuse, and the square-root of the product will be the answer. Suppose it were required to ascertain the greatest perpendicular height a roof of a given span may have, when pieces of timber of a given length are to be used as rafters. Let the span be 20 feet, and the rafters of 3×4 hemlock joist. These come about 13 feet long. The known hypotenuse, then, is 13 feet, and the known side, 10 feet—that being half the span of the building.

$$\begin{array}{r} 13 \\ 13 \\ \hline 39 \\ 13 \\ \hline \end{array}$$

169 = square of hypotenuse.

10 times 10 = 100 = square of the given side.

69 Product : the square-root of which is 8.3066 + feet, or 8 feet, 3 inches and $\frac{2}{5}$ ths. full. This will be the greatest perpendicular height, as required. Again : suppose that in a story of 8 feet, from floor to floor, a step-ladder is required, the strings of which are to be of plank, 12 feet long ; and it is desirable to know the greatest run such a length of string will afford. In this case, the two given sides are—hypotenuse 12, perpendicular 8 feet.

12 times 12 = 144 = square of hypotenuse.

8 times 8 = 64 = square of perpendicular.

80 Product : the square-root of which is 8.9442 + feet, or 8 feet, 11 inches and $\frac{2}{3}$ ths.—the answer, as required.

Many other cases might be adduced to show the utility of this problem. A practical and ready method of ascertaining the length of braces, rafters, &c., when not of a great length, is to apply a rule across the carpenters'-square. Suppose, for the length of a rafter, the base be 12 feet and the height 7. Apply the rule diagonally on the square, so that it touches 12 inches from the corner on one side, and 7 inches from the corner on the other. The number of inches on the rule, which are intercepted by the sides of the square, $13\frac{7}{8}$ nearly, will be the length of the rafter in feet; viz, 13 feet and $\frac{7}{8}$ ths of a foot. If the dimensions are large, as 30 feet and 20, take the half of each on the sides of the square, viz, 15 and 10 inches; then the length in inches across, will be one-half the number of feet the rafter is long. This method is just as accurate as the preceding; but when the length of a very long rafter is sought, it requires great care and precision to ascertain the fractions. For the least variation on the square, or in the length taken on the rule, would make perhaps several inches difference in the length of the rafter. For shorter dimensions, however, the result will be true enough.




Fig. 71.

104.—*To make a circle equal to two given circles.* Let *A* and *B*, (Fig. 71,) be the given circles. In the right-angled triangle, *a b c*, make *a b* equal to the diameter of the circle, *B*, and *c b* equal to the diameter of the circle, *A*; then the hypotenuse,




Fig. 72.

$a c$, will be the diameter of a circle, C , which will be equal in area to the two circles, A and B , added together.

Any polygonal figure, as A , (*Fig. 72*), formed on the hypotenuse of a right-angled triangle, will be equal to two similar figures,* as B and C , formed on the two legs of the triangle.




Fig. 73.

105.—*To construct a square equal to a given rectangle.* Let A , (*Fig. 73*), be the given rectangle. Extend the side, $a b$, and make $b c$ equal to $b e$; bisect $a c$ in f , and upon f , with the radius, $f a$, describe the semi-circle, $a g c$; extend $e b$, till it cuts the curve in g ; then a square, $b g h d$, formed on the line, $b g$, will be equal in area to the rectangle, A .




Fig. 74.

105, *a*.—*Another method.* Let A , (*Fig. 74*), be the given rectangle. Extend the side, $a b$, and make $a d$ equal to $a c$,

* Similar figures are such as have their several angles respectively equal, and their sides respectively proportionate.

bisect $a d$ in e ; upon e , with the radius, $e a$, describe the semi-circle, $a f d$; extend $g b$ till it cuts the curve in f ; join a and f ; then the square, B , formed on the line, $a f$, will be equal in area to the rectangle, A . (See *Art.* 156 and 157.)

106.—*To form a square equal to a given triangle.* Let $a b$, (*Fig.* 73,) equal the base of the given triangle, and $b e$ equal half its perpendicular height, (see *Fig.* 67;) then proceed as directed at *Art.* 105.




Fig. 75.

107.—*Two right lines being given, to find a third proportional thereto.* Let A and B , (*Fig.* 75,) be the given lines. Make $a b$ equal to A ; from a , draw $a c$, at any angle with $a b$; make $a c$ and $a d$ each equal to B ; join c and b ; from d , draw $d e$, parallel to $c b$; then $a e$ will be the third proportional required. That is, $a e$ bears the same proportion to B , as B does to A .




Fig. 76.

108.—*Three right lines being given, to find a fourth proportional thereto.* Let A , B and C , (*Fig.* 76,) be the given lines. Make $a b$ equal to A ; from a , draw $a c$, at any angle with $a b$; make $a c$ equal to B , and $a e$ equal to C ; join c and b ; from e , draw $e f$, parallel to $c b$; then $a f$ will be the fourth proportional required. That is, $a f$ bears the same proportion to C , as B does to A .

To apply this problem, suppose the two axes of a given ellipsis and the longer axis of a proposed ellipsis are given. Then, by this problem, the length of the shorter axis to the proposed ellipsis, can be found; so that it will bear the same proportion to the longer axis, as the shorter of the given ellipsis does to its longer. (See also, *Art.* 126.)




Fig. 77.

109.—*A line with certain divisions being given, to divide another, longer or shorter, given line in the same proportion.* Let *A*, (*Fig.* 77,) be the line to be divided, and *B* the line with its divisions. Make *a b* equal to *B*, with all its divisions, as at 1, 2, 3, &c.; from *a*, draw *a c*, at any angle with *a b*; make *a c* equal to *A*; join *c* and *b*; from the points, 1, 2, 3, &c., draw lines, parallel to *c b*; then these will divide the line, *a c*, in the same proportion as *B* is divided—as was required.

This problem will be found useful in proportioning the members of a proposed cornice, in the same proportion as those of a given cornice of another size. (See *Art.* 253 and 254.) So of a pilaster, architrave, &c.




Fig. 78.

110.—*Between two given right lines, to find a mean proportional.* Let *A* and *B*, (*Fig.* 78,) be the given lines. On the line, *a c*, make *a b* equal to *A*, and *b c* equal to *B*; bisect *a c* in *e*; upon *e*, with *e a* for radius, describe the semi-circle, *a d*

c ; at b , erect $b d$, at right angles to $a c$; then $b d$ will be the mean proportional between A and B . That is, $a b$ is to $b d$ as $b d$ is to $b c$. This is usually stated thus— $a b : b b :: b d : b c$, and since the product of the means equals the product of the extremes, therefore, $a b \times b c = \overline{b d}^2$. This is shown geometrically at *Art.* 105.

CONIC SECTIONS.

111.—If a cone, standing upon a base that is at right angles with its axis, be cut by a plane, perpendicular to its base and passing through its axis, the section will be an isosceles triangle ;





Fig. 79.

(as abc , *Fig.* 79;) and the base will be a semi-circle. If a cone be cut by a plane in the direction, ef , the section will be an *ellipsis*; if in the direction, ml , the section will be a *parabola*; and if in the direction, ro , an *hyperbola*. (See *Art.* 56 to 60.) If the cutting planes be at right angles with the plane, abc , then—

112.—*To find the axes of the ellipsis, bisect ef , (*Fig.* 79,) in g ; through g , draw hi , parallel to ab ; bisect hi in j ; upon j , with jh for radius, describe the semi-circle, hki ; from g , draw gk , at right angles to hi ; then twice gk will be the conjugate axis, and ef the transverse.*

113.—*To find the axis and base of the parabola.* Let $m l$, (Fig. 79,) parallel to $a c$, be the direction of the cutting plane. From m , draw $m d$, at right angles to $a b$; then $l m$ will be the axis and height, and $m d$ an ordinate and half the base; as at Fig. 92, 93.

114.—*To find the height, base and transverse axis of an hyperbola.* Let $o r$, (Fig. 79,) be the direction of the cutting plane. Extend $o r$ and $a c$ till they meet at n ; from o , draw $o p$, at right angles to $a b$; then $r o$ will be the height, $n r$ the transverse axis, and $o p$ half the base; as at Fig. 94.



115.—*The axes being given, to find the foci, and to describe an ellipsis with a string.* Let $a b$, (Fig. 80,) and $c d$, be the given axes. Upon c , with $a e$ or $b e$ for radius, describe the arc, $f f$; then f and f , the points at which the arc cuts the transverse axis, will be the *foci*. At f and f place two pins, and another at c ; tie a string about the three pins, so as to form the triangle, $f f c$; remove the pin from c , and place a pencil in its stead; keeping the string taut, move the pencil in the direction, $c g a$; it will then describe the required ellipsis. The lines, $f g$ and $g f$, show the position of the string when the pencil arrives at g .

This method, when performed correctly, is perfectly accurate; but the string is liable to stretch, and is, therefore, not so good to use as the trammel. In making an ellipse by a string or twine, that kind should be used which has the least tendency to elasticity. For this reason, a cotton cord, such as chalk-lines are commonly made of, is not proper for the purpose: a linen, or flaxen cord is much better.




Fig. 81

116.—*The axes being given, to describe an ellipse with a trammel.* Let ab and cd , (*Fig. 81*,) be the given axes. Place the trammel so that a line passing through the centre of the grooves, would coincide with the axes; make the distance from the pencil, e , to the nut, f , equal to half cd ; also, from the pencil, e , to the nut, g , equal to half ab ; letting the pins under the nuts slide in the grooves, move the trammel, eg , in the direction, $cb d$; then the pencil at e will describe the required ellipse.

A trammel may be constructed thus: take two straight strips of board, and make a groove on their face, in the centre of their width; join them together, in the middle of their length, at right angles to one another; as is seen at *Fig. 81*. A rod is then to be prepared, having two moveable nuts made of wood, with a mortise through them of the size of the rod, and pins under them large enough to fill the grooves. Make a hole at one end of the rod, in which to place a pencil. In the absence of a regular trammel, a temporary one may be made, which, for any short job, will answer every purpose. Fasten two straight-edges at right angles to one another. Lay them so as to coincide with the axes of the proposed ellipse, having the angular point at the centre. Then, in a rod having a hole for the pencil at one end, place two brad-awls at the distances described at *Art. 116*. While the pencil is moved in the direction of the curve, keep the brad-awls hard against the straight-edges, as directed for using the trammel-rod, and one-quarter of the ellipse will be drawn. Then, by shifting the straight-edges, the other three quarters in succession may be drawn. If the required ellipse be not too large, a carpenters'-square may be made use of, in place of the straight-edges.

An improved method of constructing the trammel, is as follows: make the sides of the grooves bevelling from the face of the stuff, or dove-tailing instead of square. Prepare two slips of wood, each about two inches long, which shall be of a shape to just fill the groove when slipped in at the end. These, instead of

pins, are to be attached one to each of the moveable nuts with a screw, loose enough for the nut to move freely about the screw as an axis. The advantage of this contrivance is, in preventing the nuts from slipping out of their places, during the operation of describing the curve.




Fig. 82.

117.—*To describe an ellipsis by ordinates.* Let $a b$ and $c a$, (Fig. 82,) be given axes. With $c e$ or $e d$ for radius, describe the quadrant, $f g h$; divide $f h$, $a e$ and $e b$, each into a like number of equal parts, as at 1, 2 and 3; through these points, draw ordinates, parallel to $c d$ and $f g$; take the distance, 1 i , and place it at 1 l , transfer 2 j to 2 m , and 3 k to 3 n ; through the points, a, n, m, l and c , trace a curve, and the ellipsis will be completed.

The greater the number of divisions on $a e$, &c., in this and the following problem, the more points in the curve can be found, and the more accurate the curve can be traced. If pins are placed in the points, n, m, l , &c., and a thin slip of wood bent around by them, the curve can be made quite correct. This method is mostly used in tracing face-moulds for stair hand-railing.




Fig. 83.

118.—*To describe an ellipsis by intersection of lines.* Let

$a b$ and $c d$, (*Fig. 83*.) be given axes. Through c , draw $f g$, parallel to $a b$; from a and b , draw $a f$ and $b g$, at right angles to $a b$; divide $f a$, $g b$, $a e$ and $e b$, each into a like number of equal parts, as at 1, 2, 3 and o, o, o ; from 1, 2 and 3, draw lines to c ; through o, o and o , draw lines from d , intersecting those drawn to c ; then a curve, traced through the points, i, i, i , will be that of an ellipsis.




Fig. 84.

Where neither trammel nor string is at hand, this, perhaps, is the most ready method of drawing an ellipsis. The divisions should be small, where accuracy is desirable. By this method, an ellipsis may be traced without the axes, provided that a diameter and its conjugate be given. Thus, $a b$ and $c d$, (*Fig. 84*.) are conjugate diameters: $f g$ is drawn parallel to $a b$, instead of being at right angles to $c d$; also, $f a$ and $g b$ are drawn parallel to $c d$, instead of being at right angles to $a b$.




Fig. 85.

119.—*To describe an ellipsis by intersecting arcs.* Let $a b$

arcs, $i l$ and $m n$; upon r and k , with $r a$ for radius, describe the arcs, $m i$ and $l n$; this will complete the figure.

When the axes are proportioned to one another as 2 to 3, the extremities, c and d , of the shortest axis, will be the centres for describing the arcs, $i l$ and $m n$; and the intersection of $e d$ with the transverse axis, will be the centre for describing the arc, $m i$, &c. As the elliptic curve is continually changing its course from that of a circle, a true ellipsis cannot be described with a pair of compasses. The above, therefore, is only an approximation.




Fig. 87.

121.—*To draw an oval in the proportion, seven by nine.* Let $c d$, (Fig. 87,) be the given conjugate axis. Bisect $c d$ in o , and through o , draw $a b$, at right angles to $c d$; bisect $c o$ in e , upon o , with $o e$ for radius, describe the circle, $e f g h$; from e , through h and f , draw $e j$ and $e i$; also, from g , through h and f , draw $g k$ and $g l$; upon g , with $g c$ for radius, describe the arc, $k l$; upon e , with $e d$ for radius, describe the arc, $j i$; upon h and f , with $h k$ for radius, describe the arcs, $j k$ and $l i$; this will complete the figure.

This is an approximation to an ellipsis; and perhaps no method can be found, by which a well-shaped oval can be drawn with greater facility. By a little variation in the process, ovals of different proportions may be obtained. If quarter of the transverse axis is taken for the radius of the circle, $e f g h$, one will be drawn in the proportion, five by seven.




Fig. 88.

122.—*To draw a tangent to an ellipsis.* Let $a b c d$, (Fig. 88,) be the given ellipsis, and d the point of contact. Find the foci, (Art. 115,) f and f , and from them, through d , draw $f e$ and $f d$; bisect the angle, (Art. 77,) $e d o$, with the line, $s r$; then $s r$ will be the tangent required.




Fig 89

123.—*An ellipsis with a tangent given, to detect the point of contact.* Let $a g b f$, (Fig. 89,) be the given ellipsis and tangent. Through the centre, e , draw $a b$, parallel to the tangent; any where between e and f , draw $c d$, parallel to $a b$; bisect $c d$ in o ; through o and e , draw $f g$; then g will be the point of contact required.

124.—*A diameter of an ellipsis given, to find its conjugate.* Let $a b$, (Fig. 89,) be the given diameter. Find the line, $f g$, by the last problem; then $f g$ will be the diameter required.

PRACTICAL GEOMETRY.




Fig. 90.

125.—*Any diameter and its conjugate being given, to ascertain the two axes, and thence to describe the ellipse.* Let $a b$ and $c d$, (Fig. 90,) be the given diameters, conjugate to one another. Through c , draw $e f$, parallel to $a b$; from c , draw $c g$, at right angles to $e f$; make $c g$ equal to $a h$ or $h b$; join g and h ; upon g , with $g c$ for radius, describe the arc, $i k c j$; upon h , with the same radius, describe the arc, $l n$; through the intersections, l and n , draw $n o$, cutting the tangent, $e f$, in o ; upon o , with $o g$ for radius, describe the semi-circle, $e i g f$; join e and g , also g and f , cutting the arc, $i c j$, in k and t ; from e , through h , draw $e m$, also from f , through h , draw $f p$; from k and t , draw $k r$ and $t s$, parallel to $g h$, cutting $e m$ in r , and $f p$ in s ; make $h m$ equal to $h r$, and $h p$ equal to $h s$; then $r m$ and $s p$ will be the axes required, by which the ellipse may be drawn in the usual way.

126.—*To describe an ellipse, whose axes shall be proportionate to the axes of a larger or smaller given one.* Let $a c b d$, (Fig. 91,) be the given ellipse and axes, and $i j$ the transverse axis of a proposed smaller one. Join a and c ; from i , draw $i e$, parallel to $a c$; make $o f$ equal to $o e$; then $e f$ will be




Fig. 91.

the conjugate axis required, and will bear the same proportion to j , as $c d$ does to $a b$. (See *Art.* 108.)






Fig. 92.

127.—*To describe a parabola by intersection of lines.* Let $m l$, (*Fig.* 92,) be the axis and height, (see *Fig.* 79,) and $d d$, a double ordinate and base of the proposed parabola. Through l , draw $a a$, parallel to $d d$; through d and d , draw $d a$ and $d a$, parallel to $m l$; divide $a d$ and $d m$, each into a like number of equal parts; from each point of division in $d m$, draw the lines, 1 1, 2 2, &c., parallel to $m l$; from each point of division in $d a$, draw lines to l ; then a curve traced through the points of intersection, o, o and o, o , will be that of a parabola.

127, *a.*—*Another method.* Let $m l$, (*Fig.* 93,) be the axis and height, and $d d$ the base. Extend $m l$, and make $l a$ equal to $m \epsilon$; join a and d , and a and d ; divide $a d$ and $a d$, each into a like number of equal parts, as at 1, 2, 3, &c.; join 1 and 1, 2 and 2, &c., and the parabola will be completed



123.—*To describe an hyperbola by intersection of lines.*
 Let $r o$, (Fig. 94,) be the height, $p p$ the base, and $n r$ the transverse axis. (See Fig. 79.) Through r , draw $a a$, parallel to $p p$; from p , draw $a p$, parallel to $r o$; divide $a p$ and $p o$, each into a like number of equal parts; from each of the points of divisions in the base, draw lines to n ; from each of the points of division in $a p$, draw lines to r ; then a curve traced through the points of intersection, o, o , &c., will be that of an hyperbola.

The parabola and hyperbola afford handsome curves for various moldings.

DEMONSTRATIONS.

129.—To impress more deeply upon the mind of the learner some of the more important of the preceding problems, and to indulge a very common and praiseworthy curiosity to discover the cause of things, are some of the reasons why the following exercises are introduced. In all reasoning, definitions are necessary; in order to insure, in the minds of the proponent and respondent, identity of ideas. A *corollary* is an inference deduced from a previous course of reasoning. An *axiom* is a proposition evident at first sight. In the following demonstrations, there are many axioms taken for granted; (such as, things equal to the same thing are equal to one another, &c. ;) these it was thought not necessary to introduce in form.




Fig. 95.

130.—*Definition.* If a straight line, as $a b$, (*Fig. 95*), stand upon another straight line, as $c d$, so that the two angles made at

8

the point, b , are equal— $a b c$ to $a b d$, (see note to *Art. 27*.) then each of the two angles is called a *right angle*.

131.—*Definition*. The circumference of every circle is supposed to be divided into 360 equal parts, called *degrees*; hence a semi-circle contains 180 degrees, a quadrant 90, &c.




Fig. 96.

132.—*Definition*. The *measure of an angle* is the number of degrees contained between its two sides, using the angular point as a centre upon which to describe the arc. Thus the arc, $c e$, (*Fig. 96*.) is the measure of the angle, $c b e$; $e a$, of the angle, $e b a$; and $a d$, of the angle, $a b d$.

133.—*Corollary*. As the two angles at b , (*Fig. 95*.) are right angles, and as the semi-circle, $c a d$, contains 180 degrees, (*Art. 131*.) the measure of two right angles, therefore, is 180 degrees; of one right angle, 90 degrees; of half a right angle, 45; of one-third of a right angle, 30, &c.

134.—*Definition*. In measuring an angle, (*Art. 132*.) no regard is to be had to the length of its sides, but only to the degree of their inclination. Hence *equal angles* are such as have the same degree of inclination, without regard to the length of their sides.




Fig. 97.

135.—*Axiom*. If two straight lines, parallel to one another,

as $a b$ and $c d$, (*Fig. 97*,) stand upon another straight line, as $e f$, the angles, $a b f$ and $c d f$; are equal; and the angle, $a b e$, is equal to the angle, $c d e$.

136.—*Definition.* If a straight line, as $a b$, (*Fig. 96*,) stand obliquely upon another straight line, as $c d$, then one of the angles, as $a b c$, is called an *obtuse angle*, and the other, as $a b d$, an *acute angle*.

137.—*Axiom.* The two angles, $a b d$ and $a b c$, (*Fig. 96*,) are together equal to two right angles, (*Art. 130, 133*;) also, the three angles, $a b d$, $e b a$ and $c b e$, are together equal to two right angles.

138.—*Corollary.* Hence all the angles that can be made upon one side of a line, meeting in a point in that line, are together equal to two right angles.

139.—*Corollary.* Hence all the angles that can be made on both sides of a line, at a point in that line, or all the angles that can be made about a point, are together equal to four right angles.




Fig 98.

140.—*Proposition.* If to each of two equal angles a third angle be added, their sums will be equal. Let $a b c$ and $d e f$, (*Fig. 98*,) be equal angles, and the angle, $i j k$, the one to be added. Make the angles, $g b a$ and $h e d$, each equal to the given angle, $i j k$; then the angle, $g b c$, will be equal to the angle, $h e f$; for, if $a b c$ and $d e f$ be angles of 90 degrees, and $i j k$, 30, then the angles, $g b c$ and $h e f$, will be each equal to 90 and 30 added, viz: 120 degrees.




Fig. 99.

141.—*Proposition.* Triangles that have two of their sides and the angle contained between them respectively equal, have also their third sides and the two remaining angles equal; and consequently one triangle will every way equal the other. Let abc , (Fig. 99,) and def be two given triangles, having the angle at a equal to the angle at d , the side, ab , equal to the side, de , and the side, ac , equal to the side, df ; then the third side of one, bc , is equal to the third side of the other, ef ; the angle at b is equal to the angle at e , and the angle at c is equal to the angle at f . For, if one triangle be applied to the other, the three points, b, a, c , coinciding with the three points, e, d, f , the line, bc , must coincide with the line, ef ; the angle at b with the angle at e ; the angle at c with the angle at f ; and the triangle, bac , be every way equal to the triangle, edf .




Fig. 100.

142.—*Proposition.* The two angles at the base of an isosceles triangle are equal. Let abc , (Fig. 100,) be an isosceles triangle, of which the sides, ab and ac , are equal. Bisect the angle, (*Art.*

77,) $b a c$, by the line, $a d$. Then the line, $b a$, being equal to the line, $a c$; the line, $a d$, of the triangle, A , being equal to the line, $a d$, of the triangle, B , being common to each; the angle, $b a d$, being equal to the angle, $d a c$; the line, $b d$, must, according to *Art.* 141, be equal to the line, $d c$; and the angle at b must be equal to the angle at c .




Fig. 101.

143.—*Proposition.* A diagonal crossing a parallelogram divides it into two equal triangles. Let $a b c d$, (*Fig.* 101,) be a given parallelogram, and $b c$, a line crossing it diagonally. Then, as $a c$ is equal to $b d$, and $a b$ to $c d$, the angle at a to the angle at d , the triangle, A , must, according to *Art.* 141, be equal to the triangle, B .




Fig. 102.

144.—*Proposition.* Let $a b c d$, (*Fig.* 102,) be a given parallelogram, and $b c$ a diagonal. At any distance between $a b$ and $c d$, draw $e f$, parallel to $a b$; through the point, g , the intersection of the lines, $b c$ and $e f$, draw $h i$, parallel to $b d$. In every parallelogram thus divided, the parallelogram, A , is equal to the parallelogram, B . According to *Art.* 143, the triangle, $a b c$, is equal to the triangle, $b c d$; the triangle, C , to the triangle, D ; and E to F ; this being the case, take D and F from the triangle, $b c d$, and C and E from the triangle, $a b c$, and what remains

in one must be equal to what remains in the other; therefore, the parallelogram, A , is equal to the parallelogram, B .




Fig. 103.

145.—*Proposition.* Parallelograms standing upon the same base and between the same parallels, are equal. Let $abcd$ and $efcd$, (*Fig. 103*,) be given parallelograms, standing upon the same base, cd , and between the same parallels, af and cd . Then, ab and ef being equal to cd , are equal to one another; be being added to both ab and ef , ae equals bf ; the line, ac , being equal to bd , and ae to bf , and the angle, cae , being equal, (*Art. 135*,) to the angle, dbf , the triangle, aec , must be equal, (*Art. 141*,) to the triangle, bfd ; these two triangles being equal, take the same amount, the triangle, beg , from each, and what remains in one, agc , must be equal to what remains in the other, fdg ; these two quadrangles being equal, add the same amount, the triangle, cgd , to each, and they must still be equal; therefore, the parallelogram, $abcd$, is equal to the parallelogram, $efcd$.

146.—*Corollary.* Hence, if a parallelogram and triangle stand upon the same base and between the same parallels, the parallelogram will be equal to double the triangle. Thus, the parallelogram, ad , (*Fig. 103*,) is double, (*Art. 143*,) the triangle, ced .

147.—*Proposition.* Let $abcd$, (*Fig. 104*,) be a given quadrangle with the diagonal, ad . From b , draw be , parallel to ad , extend cd to e ; join a and e ; then the triangle, aec , will be equal in area to the quadrangle, $abcd$. Since the triangles, adb and ade , stand upon the same base, ad , and between the same paral-




Fig. 104.

les, ad and be , they are therefore equal, (*Art.* 145, 146;) and since the triangle, C , is common to both, the remaining triangles, A and B , are therefore equal; then B being equal to A , the triangle, aec , is equal to the quadrangle, $abcd$.




Fig. 105.

148.—*Proposition.* If two straight lines cut each other, as ab and cd , (*Fig.* 105,) the vertical, or opposite angles, A and C , are equal. Thus, ae , standing upon cd , forms the angles, B and C , which together amount, (*Art.* 137,) to two right angles; in the same manner, the angles, A and B , form two right angles; since the angles, A and B , are equal to B and C , take the same amount, the angle, B , from each pair, and what remains of one pair is equal to what remains of the other; therefore, the angle, A , is equal to the angle, C . The same can be proved of the opposite angles, B and D .

149.—*Proposition.* The three angles of any triangle are equal to two right angles. Let abc , (*Fig.* 106,) be a given triangle, with its sides extended to f , e , and d , and the line, cg ,




Fig. 106.

drawn parallel to $b e$. As $g c$ is parallel to $e b$, the angle, $g c a$, is, equal, (*Art. 135*), to the angle, $e b d$; as the lines, $f c$ and $b e$, cut one another at a , the opposite angles, $f a e$ and $b a c$, are equal, (*Art. 148*); as the angle, $f a e$, is equal, (*Art. 135*), to the angle, $a c g$, the angle, $a c g$, is equal to the angle, $b a c$; therefore, the three angles meeting at c , are equal to the three angles of the triangle, $a b c$; and since the three angles at c are equal, (*Art. 137*), to two right angles, the three angles of the triangle, $a b c$, must likewise be equal to two right angles. Any triangle can be subjected to the same proof.

150.—*Corollary.* Hence, if one angle of a triangle be a right angle, the other two angles amount to just one right angle.

151.—*Corollary.* If one angle of a triangle be a right angle, and the two remaining angles are equal to one another, these are each equal to half a right angle.

152.—*Corollary.* If any two angles of a triangle amount to a right angle, the remaining angle is a right angle.

153.—*Corollary.* If any two angles of a triangle are together equal to the remaining angle, that remaining angle is a right angle.

154.—*Corollary.* If any two angles of a triangle are each equal to two-thirds of a right angle, the remaining angle is also equal to two-thirds of a right angle.

155.—*Corollary.* Hence, the angles of an equi-lateral triangle, are each equal to two-thirds of a right angle.




Fig. 107.

156.—*Proposition.* If from the extremities of the diameter of a semi-circle, two straight lines be drawn to any point in the circumference, the angle formed by them at that point will be a right angle. Let abc , (*Fig. 107.*) be a given semi-circle, and ab and bc , lines drawn from the extremities of the diameter, a c , to the given point, b ; the angle formed at that point by these lines, is a right angle. Join the point, b , and the centre, d ; the lines, da , db and dc , being radii of the same circle, are equal; the angle at a is therefore equal, (*Art. 142.*) to the angle, abd , also, the angle at c is, for the same reason, equal to the angle, dbc ; the angle, abc , being equal to the angles at a and c taken together, must therefore, (*Art. 153.*) be a right angle.




Fig. 108.

157.—*Proposition.* The square of the hypotenuse of a right-angled triangle, is equal to the squares of the two remaining sides. Let abc , (*Fig. 108.*) be a given right-angled triangle, having a square formed on each of its sides: then, the square, be , is equal to the squares, hc and gb , taken together. This can be

proved by showing that the parallelogram, bl , is equal to the square, gb ; and that the parallelogram, cl , is equal to the square, hc . The angle, cbd , is a right angle, and the angle, abf , is a right angle; add to each of these the angle, abc ; then the angle, fbc , will evidently be equal, (*Art.* 140,) to the angle, abd ; the triangle, fbc , and the square, gb , being both upon the same base, fb , and between the same parallels, fb and gc , the square, gb , is equal, (*Art.* 146,) to twice the triangle, fbc ; the triangle, abd , and the parallelogram, bl , being both upon the same base, bd , and between the same parallels, bd and al , the parallelogram, bl , is equal to twice the triangle, abd ; the triangles, fbc and abd , being equal to one another, (*Art.* 141,) the square, gb , is equal to the parallelogram, bl , either being equal to twice the triangle, fbc or abd . The method of proving hc equal to cl is exactly similar—thus proving the square, be , equal to the squares, hc and gb , taken together.

This problem, which is the 47th of the First Book of Euclid is said to have been demonstrated first by Pythagoras. It is stated, (but the story is of doubtful authority,) that as a thank-offering for its discovery he sacrificed a hundred oxen to the gods. From this circumstance, it is sometimes called the *hecatomb* problem. It is of great value in the exact sciences, more especially in Mensuration and Astronomy, in which many otherwise intricate calculations are by it made easy of solution.

158.—*Proposition.* In a segment of a circle, the versed sine equals the radius, less the square root of the difference of the squares of the radius and half-chord. That is, the versed sine, ac , (*Fig.* 109,) equals ab , less cb . Now ab is radius, hence the radius, minus cb , equals ac , the versed sine. To find the value of cb , it will be observed that cb is the side of the square, cf , while the radius bd is the side of the square, bh , and the half-chord, cd , is the side of the square, ce ; also, that these three squares are made upon the three sides of the right angled




Fig 109.

triangle, $b c d$, and the square, $b h$, is therefore equal to the two squares, $c e$ and $c f$, (*Art. 157*;) therefore, the square, $c f$, is equal to the square, $b h$, minus the square, $c e$;—or, is equal to the difference of the squares on $b d$ and $c d$. Consequently the square root of $c f$ is equal to the square root of the difference of the squares on $b d$ and $c d$; and since $c b$ is the square root of $c f$, therefore $c b$ equals the square root of the difference of the squares on $b d$ and $c d$ —or, equals the square root of the difference of the squares of the radius and the half-chord. Having found an expression for the value of $c b$, it remains merely to deduct this value from the radius, and the residue equals the versed sine; for, as before stated, the versed sine, $a c$, equals the radius, $a b$, minus $c b$; therefore, the versed sine equals the radius, minus the square root of the difference of the squares on the radius and half-chord. The rule expressed algebraically is $v=r-\sqrt{r^2-a^2}$, where v is the versed sine, r the radius, and a the half-chord. It is read, v equals r , minus the square root of the difference of the squares of r and a .

159.—*Proposition.* In an equilateral octagon the semi-diagonal of a circumscribed square, having its sides coincident with four of the sides of the octagon, equals the distance along




Fig. 110.

a side of the square from its corner to the more remote angle of the octagon occurring on that side of the square. To prove this, it need only to be shown that the triangle, $a o d$, (*Fig. 110*.) is an isosceles triangle having its sides $a o$ and $a d$, equal. The octagon being equi-lateral, it is also equi-angular, therefore the angles, $b c o$, $e c o$, $a d o$, &c., are all equal. Of the right-angled triangle, $f e c$, $f c$ and $f e$ being equal, the two angles, $f e c$ and $f c e$ are equal, (*Art. 142*.) and are therefore, (*Art. 151*.) each equal to half a right angle. In like manner it may be shown that $f a b$ and $f b a$ are also each equal to half a right angle. And since $f e c$ and $f a b$ are equal angles, therefore the lines $e c$ and $a b$ are parallel, (*Art. 135*.) and hence the angles, $e c o$ and $a o d$, are equal. These being equal, and the angles $e c o$ and $a d o$ being, by construction, equal, as before shown, therefore the angles $a o d$ and $a d o$ are equal, and consequently the lines $a o$ and $a d$ are equal. (*Art. 142*.)

160.—*Proposition.* An angle at the circumference of a circle is measured by half the arc that subtends it: that is, the angle $a b c$, (*Fig. 111*.) is equal to half the angle $a d c$. Through the centre, d , draw the diameter, $b e$. The triangle $a b d$ is an isosceles triangle, $a d$ and $b d$ being radii, and therefore equal; hence the two angles, $d a b$ and $d b a$, are equal,




Fig. 111.

(*Art.* 142,) and the sum of these two angles is equal to the angle $a d e$, (*Art.* 149,) and therefore one of them, $a b d$, is equal to the half of $a d e$. The angles $a d e$ and $a b d$ (or $a b e$) are both subtended by the arc $a e$. Now, since the angle, $a d e$, is measured by the arc $a e$, which subtends it, therefore the half of the angle, $a d e$, would be measured by the half of the arc $a e$; and since $a b d$ is equal to the half of $a d e$, therefore $a b d$, or $a b e$, is measured by the half of the arc $a e$. It may be shown in like manner that the angle $e b c$ is measured by half the arc $e c$, and hence it follows that the angle, $a b c$, is measured by half the arc, $a c$, that subtends it.

161.—*Proposition.* In a circle, all the inscribed angles, $a b c$, (*Fig.* 112,) which stand upon the same side of the chord $a c$, are equal. For each angle is measured by half the arc $a c$, (*Art.* 160,) hence the angles are all equal.

162.—*Corollary.* Equal chords, in the same circle, subtend equal angles.

163.—*Proposition.* The angle formed by a chord and tangent is equal to any inscribed angle in the opposite segment




Fig. 112.




Fig. 113.

of the circle ; that is, the angle D , (*Fig. 113*), equals the angle A . Let cf be the chord, and ab the tangent ; draw the diameter, dc ; then dcb is a right angle, also dfc is a right angle. (*Art. 156.*) The angles A and B together equal a right angle, (*Art. 150*;) also the angles B and D together equal a right angle, (equal the angle dcb ;) therefore the sum of A and B equals the sum of B and D . From each of these two equals, taking the like quantity B , the remainders, A and

D , are equal. Thus, it is proved for the angle at d ; it is also true for any other angle; for, since all other inscribed angles on that side of the chord line, cf , equal the angle A , (*Art.* 161,) therefore the angle formed by a chord and tangent equals any angle in the opposite segment of the circle. This being proved for the acute angle, D , it is also true for the obtuse




Fig. 114.

angle, $a c f$; for, from any point, n , (*Fig.* 114,) in the arc $c n f$, draw lines to d, f and c ; now, if it can be proved that the angle $a c f$ equals the angle $f n c$, the entire proposition is proved, for the angle $f n c$ equals any of all the inscribed angles that can be drawn on that side of the chord. (*Art.* 161.) To prove, then, that $a c f$ equals $c n f$: the angle $a c f$ equals the sum of the angles A and B ; also the angle $c n f$ equals the sum of the angles C and D . The angles B and D , being inscribed angles on the same chord, $d f$, are equal. The angles C and A being right angles, (*Art.* 156,) are likewise equal. Now, since A equals C , and B equals D , therefore the sum of A and B equals the sum of C and D —or the angle $a c f$ equals the angle $c n f$.

164.—*Proposition.* Two chords, $a b$ and $c d$, (*Fig.* 115,) intersecting, the parallelogram or rectangle formed by the two parts of one is equal to the rectangle formed by the two parts of the other. That is, $c e$ multiplied by $e d$, the product is




Fig. 115.

equal to the product of $a e$ multiplied by $e b$. The triangle A is similar to the triangle B , because it has corresponding angles. The angle i equals the angle e , (*Art.* 148;) the angle at c equals the angle at a because they stand upon the same chord, $d b$, (*Art.* 161;) for the same reason the angle b equals the angle d , for each stands upon the same chord, $a c$. Therefore, the triangle A having the same angles as the triangle B , the length of the sides of one are in like proportion as the length of the sides in the other. So, $e d : a e :: e b : c e$. Hence, $a e$ multiplied by $e b$ is equal to $e d$ multiplied by $c e$ —or the product of the means equals the product of the extremes.

165.—*Proposition.* In any circle, when a segment is given, the radius is equal to the sum of the squares of half the chord and of the versed sine, divided by twice the versed sine. Let $a b$, (*Fig.* 116,) be the chord line, and v the versed sine of the segment. By the preceding article the triangle A is shown to be like the triangle B , having equal angles and proportionate




Fig. 116.

length of sides. Therefore, $v : n :: m : i$, or $\frac{n^2}{v} = i$; that is, i is equal to the square of n (or $n \times n$) divided by v . This result being added to v equals the diameter ox , which may be indicated by the letter d ; thus, $\frac{n^2}{v} + v = i + v = d$; and the half

of this, or $\frac{\frac{n^2}{v} + v}{2} = \frac{d}{2} = r =$ the radius. Reducing this expression by multiplying the numerator and denominator each by the like quantity, viz. v , there results, $\frac{n^2 + v^2}{2v} = r$; and where c represents the chord, the expression is, $\frac{(\frac{c}{2})^2 + v^2}{2v} = r$: that is, as stated above, the radius is equal to the sum of the squares of half the chord and of the versed sine, divided by twice the versed sine.

166.—*Proposition.* Any ordinate, mn , (*Fig. 117*), in the segment of a circle, is equal to the square root of the difference




Fig. 117.

of the squares of the radius and abscissa, ($d n$), less the difference of the radius and versed sine. So, if the chord $a b$, and the versed sine $c d$, be given, the length of any number of ordinates may be found by which to describe the arc. Find the radius, $c e$, by the preceding Article. It will be observed that $e m$ is also radius. Then, to find the length of the ordinate, $m n$, make $e o$ equal to $d n$: now, according to Article 157, the square of $e o$ taken from the square of $e m$, the residue equals the square of $o m$, and the square root of this residue will be the length of the line $o m$. Then from $o m$ take $o n$ equal to $e d$, and the result will be the length of $m n$. That is, the ordinate is equal to the square root of the difference of the squares of the radius and abscissa, less the difference of the radius and versed sine. This may be expressed algebraically thus: $y = \sqrt{r^2 - x^2} - (r - v)$, where y is the ordinate, r the radius, x the abscissa, and v the versed sine;— $d n$ being the abscissa of the ordinate $n m$, $d g$ the abscissa of the ordinate

gf , &c.: the abscissa being in each case the distance from the foot of the versed sine, $c d$, to the foot of the ordinate whose length is sought.




Fig. 118.

167.—*Proposition.* The sides of any quadrangle being bisected, and lines drawn joining the points of bisection in the adjacent sides, these lines will form a parallelogram. Draw the diagonals, $a b$ and $c d$, (*Fig.* 118.) It will here be perceived that the two triangles, $a c o$ and $a c d$, are homologous, having like angles and proportionate sides. Two of the sides of one triangle lie coincident with the two corresponding sides of the other triangle, therefore the contained angles between these sides in each triangle are identical. By construction, these corresponding sides are proportionate; $a c$ being equal to twice $a e$, and $a d$ being equal to twice $a o$; therefore the remaining sides are proportionate, $c d$ being equal to twice $e o$, hence the remaining corresponding angles are equal. Since, then, the angles $a e o$ and $a c d$ are equal, therefore the line $e o$ is parallel with the diagonal $c d$ —so, likewise, the line $m n$ is parallel to the same diagonal, $c d$. If, therefore, these two lines, $e o$ and $m n$, are parallel to the same line, $c d$, they must be parallel to each other. In the same manner the lines $o n$ and $e m$ are proved parallel to the diagonal, $a b$, and to each

other ; therefore the inscribed figure, *m e o n*, is a parallelogram. It may be remarked also, that the parallelogram so formed will contain just one-half the area of the circumscribing quadrangle.

These demonstrations, which relate mostly to the problems previously given, are introduced to satisfy the learner in regard to their mathematical accuracy. By studying and thoroughly understanding them, he will soonest arrive at a knowledge of their importance, and be likely the longer to retain them in memory. Should he have a relish for such exercises, and wish to continue them farther, he may consult Euclid's Elements, in which the whole subject of theoretical geometry is treated of in a manner sufficiently intelligible to be understood by the young mechanic. The house-carpenter, especially, needs information of this kind, and were he thoroughly acquainted with the principles of geometry, he would be much less liable to commit mistakes, and be better qualified to excel in the execution of his often difficult undertakings.

SECTION II.—ARCHITECTURE.

HISTORY OF ARCHITECTURE.

168.—Architecture has been defined to be—“the art of building;” but, in its common acceptation, it is—“the art of designing and constructing buildings, in accordance with such principles as constitute stability, utility and beauty.” The literal signification of the Greek word *archi-tecton*, from which the word *architect* is derived, is chief-carpenter; but the architect has always been known as the chief *designer* rather than the chief *builder*. Of the three classes into which architecture has been divided—viz., Civil, Military, and Naval, the first is that which refers to the construction of edifices known as dwellings, churches and other public buildings, bridges, &c., for the accommodation of civilized man—and is the subject of the remarks which follow.

169.—This is one of the most ancient of the arts: the scriptures inform us of its existence at a very early period. Cain, the son of Adam,—“built a city, and called the name of the city after the name of his son, Enoch”—but of the peculiar style or manner of building we are not informed. It is presumed that it was not remarkable for beauty, but that utility and perhaps stability were its characteristics. Soon after the deluge—that me-

morable event, which removed from existence all traces of the works of man—the Tower of Babel was commenced. This was a work of such magnitude that the gathering of the materials, according to some writers, occupied three years; the period from its commencement until the work was abandoned, was twenty-two years; and the bricks were like blocks of stone, being twenty feet long, fifteen broad and seven thick. Learned men have given it as their opinion, that the tower in the temple of Belus at Babylon was the same as that which in the scriptures is called the Tower of Babel. The tower of the temple of Belus was square at its base, each side measuring one furlong, and consequently half a mile in circumference. Its form was that of a pyramid, and its height was 660 feet. It had a winding passage on the outside from the base to the summit, which was wide enough for two carriages.

170.—Historical accounts of ancient cities, of which there are now but few remains—such as Babylon, Palmyra and Ninevah of the Assyrians; Sidon, Tyre, Aradus and Serepta of the Phœnicians; and Jerusalem, with its splendid temple, of the Israelites—show that architecture among them had made great advances. Ancient monuments of the art are found also among other nations; the subterraneous temples of the Hindoos upon the islands, Elephanta and Salsetta; the ruins of Persepolis in Persia; pyramids, obelisks, temples, palaces and sepulchres in Egypt—all prove that the architects of those early times were possessed of skill and judgment highly cultivated. The principal characteristics of their works, are gigantic dimensions, immovable solidity, and, in some instances, harmonious splendour. The extraordinary size of some is illustrated in the pyramids of Egypt. The largest of these stands not far from the city of Cairo: its base, which is square, covers about $11\frac{1}{4}$ acres, and its height is nearly 500 feet. The stones of which it is built are immense—the smallest being full thirty feet long.

171.—Among the Greeks. architecture was cultivated as a *fine*

art, and rapidly advanced towards perfection. Dignity and grace were added to stability and magnificence. In the Doric order, their first style of building, this is fully exemplified. Phidias, Ictinus and Callicrates, are spoken of as masters in the art at this period: the encouragement and support of Pericles stimulated them to a noble emulation. The beautiful temple of Minerva, erected upon the acropolis of Athens, the Propyleum, the Odeum and others, were lasting monuments of their success. The Ionic and Corinthian orders were added to the Doric, and many magnificent edifices arose. These exemplified, in their chaste proportions, the elegant refinement of Grecian taste. Improvement in Grecian architecture continued to advance, until perfection seems to have been attained. The specimens which have been partially preserved, exhibit a combination of elegant proportion, dignified simplicity and majestic grandeur. Architecture among the Greeks was at the height of its glory at the period immediately preceding the Peloponnesian war; after which the art declined. An excess of enrichment succeeded its former simple grandeur; yet a strict regularity was maintained amid the profusion of ornament. After the death of Alexander, 323 B. C., a love of gaudy splendour increased: the consequent decline of the art was visible, and the Greeks afterwards paid but little attention to the science.

172.—While the Greeks were masters in architecture, which they applied mostly to their temples and other public buildings, the Romans gave their attention to the science in the construction of the many aqueducts and sewers with which Rome abounded; building no such splendid edifices as adorned Athens, Corinth and Ephesus, until about 200 years B. C., when their intercourse with the Greeks became more extended. Grecian architecture was introduced into Rome by Sylla; by whom, as also by Marius and Cæsar, many large edifices were erected in various cities of Italy. But under Cæsar Augustus, at about the beginning of the christian era, the art arose to the greatest perfection it ever at-

tained in Italy. Under his patronage, Grecian artists were encouraged, and many emigrated to Rome. It was at about this time that Solomon's temple at Jerusalem was rebuilt by Herod—a Roman. This was 46 years in the erection, and was most probably of the Grecian style of building—perhaps of the Corinthian order. Some of the stones of which it was built were 46 feet long, 21 feet high and 14 thick; and others were of the astonishing length of 82 feet. The porch rose to a great height; the whole being built of white marble exquisitely polished. This is the building concerning which it was remarked—"Master, see what manner of stones, and what buildings are here." For the construction of private habitations also, finished artists were employed by the Romans: their dwellings being often built with the finest marble, and their villas splendidly adorned. After Augustus, his successors continued to beautify the city, until the reign of Constantine; who, having removed the imperial residence to Constantinople, neglected to add to the splendour of Rome; and the art, in consequence, soon fell from its high excellence.

Thus we find that Rome was indebted to Greece for what she possessed of architecture—not only for the knowledge of its principles, but also for many of the best buildings themselves; these having been originally erected in Greece, and stolen by the unprincipled conquerors—taken down and removed to Rome. Greece was thus robbed of her best monuments of architecture. Touched by the Romans, Grecian architecture lost much of its elegance and dignity. The Romans, though justly celebrated for their scientific knowledge as displayed in the construction of their various edifices, were not capable of appreciating the simple grandeur, the refined elegance of the Grecian style; but sought to improve upon it by the addition of luxurious enrichment, and thus deprived it of true elegance. In the days of Nero, whose palace of gold is so celebrated, buildings were lavishly adorned. Adrian did much to encourage the art; but not satisfied with the simplicity of the Grecian style, the artists of his time aimed at

inventing new ones, and added to the already redundant embellishments of the previous age. Hence the origin of the pedestal, the great variety of intricate ornaments, the convex frieze, the round and the open pediments, &c. The rage for luxury continued until Alexander Severus, who made some improvement; but very soon after his reign, the art began rapidly to decline, as particularly evidenced in the mean and trifling character of the ornaments.

173.—The Goths and Vandals, when they overran the countries of Italy, Greece, Asia and Africa, destroyed most of the works of ancient architecture. Cultivating no art but that of war, these savage hordes could not be expected to take any interest in the beautiful forms and proportions of their habitations. From this time, architecture assumed an entirely different aspect. The celebrated styles of Greece were unappreciated and forgotten; and modern architecture took its first step on the platform of existence. The Goths, in their conquering invasions, gradually extended it over Italy, France, Spain, Portugal and Germany, into England. From the reign of Gallienus may be reckoned the total extinction of the arts among the Romans. From his time until the 6th or 7th century, architecture was almost entirely neglected. The buildings which were erected during this suspension of the arts, were very rude. Being constructed of the fragments of the edifices which had been demolished by the Visigoths in their unrestrained fury, and the builders being destitute of a proper knowledge of architecture, many sad blunders and extensive patchwork might have been seen in their construction—entablatures inverted, columns standing on their wrong ends, and other ridiculous arrangements characterized their clumsy work. The vast number of columns which the ruins around them afforded, they used as piers in the construction of arcades—which by some is thought, after having passed through various changes, to have been the origin of the plan of the Gothic cathedral. Buildings generally, which are not of the classical styles, and which were

erected after the fall of the Roman empire, have by some been indiscriminately included under the term *Gothic*. But the changes which architecture underwent during the dark ages, show that there were several distinct modes of building.

174.—Theodoric, king of the Ostrogoths, a friend of the arts, who reigned in Italy from A. D. 493 to 525, endeavoured to restore and preserve some of the ancient buildings; and erected others, the ruins of which are still seen at Verona and Ravenna. Simplicity and strength are the characteristics of the structures erected by him; they are, however, devoid of grandeur and elegance, or fine proportions. These are properly of the *GOthic* style; by some called the *old Gothic* to distinguish it from the pointed style, which is generally called *modern Gothic*.

175.—The Lombards, who ruled in Italy from A. D. 568, had no taste for architecture nor respect for antiquities. Accordingly, they pulled down the splendid monuments of classic architecture which they found standing, and erected in their stead huge buildings of stone which were greatly destitute of proportion, elegance or utility—their characteristics being scarcely any thing more than stability and immensity combined with ornaments of a puerile character. Their churches were disfigured with rows of small columns along the cornice of the pediment, small doors and windows with circular heads, roofs supported by arches having arched buttresses to resist their thrust, and a lavish display of incongruous ornaments. This kind of architecture is called, the *LOMBARD* style, and was employed in the 7th century in Pavia, the chief city of the Lombards; at which city, as also at many other places, a great many edifices were erected in accordance with its inelegant forms.

176.—The Byzantine architects, from Byzantium, Constantinople, erected many spacious edifices; among which are included the cathedrals of Bamberg, Worms and Mentz, and the most ancient part of the minster at Strasburg; in all of these they combined the Roman-Ionic order with the *Gothic* of the Lombards.

This style is called the **LOMBARD-BYZANTINE**. To the last style there were afterwards added cupolas similar to those used in the east, together with numerous slender pillars with tasteless capitals, and the many minarets which are the characteristics of the proper *Byzantine*, or *Oriental* style.

177.—In the eighth century, when the Arabs and Moors destroyed the kingdom of the Goths, the arts and sciences were mostly in possession of the Musselmen-conquerors; at which time there were three kinds of architecture practised; viz: the Arabian, the Moorish and the modern-Gothic. The **ARABIAN** style was formed from Greek models, having circular arches added, and towers which terminated with globes and minarets. The **MOORISH** is very similar to the Arabian, being distinguished from it by arches in the form of a horse-shoe. It originated in Spain in the erection of buildings with the ruins of Roman architecture, and is seen in all its splendour in the ancient palace of the Mohammedan monarchs at Grenada, called the *Alhambra*, or *red-house*. The **MODERN-GOTHIC** was originated by the Visigoths in Spain by a combination of the Arabian and Moorish styles; and introduced by Charlemagne into Germany. On account of the changes and improvements it there underwent, it was, at about the 13th or 14th century, termed the *German*, or *romantic* style. It is exhibited in great perfection in the towers of the minster of Strasburgh, the cathedral of Cologne and other edifices. The most remarkable features of this lofty and aspiring style, are the lancet or pointed arch, clustered pillars, lofty towers and flying buttresses. It was principally employed in ecclesiastical architecture, and in this capacity introduced into France, Italy, Spain, and England.

178.—The Gothic architecture of England is divided into the *Norman*, the *Early-English*, the *Decorated*, and the *Perpendicular* styles. The Norman is principally distinguished by the character of its ornaments—the *chevron*, or *zigzag*, being the most common. Buildings in this style were erected in the 12th

century. The Early-English is celebrated for the beauty of its edifices, the chaste simplicity and purity of design which they display, and the peculiarly graceful character of its foliage. This style is of the 13th century. The Decorated style, as its name implies, is characterized by a great profusion of enrichment, which consists principally of the crocket, or feathered-ornament, and ball-flower. It was mostly in use in the 14th century. The Perpendicular style, which dates from the 15th century, is distinguished by its high towers, and parapets surmounted with spires similar in number and grouping to oriental minarets.

179.—Thus these several styles, which have been erroneously termed *Gothic*, were distinguished by peculiar characteristics as well as by different names. The first symptoms of a desire to return to a pure style in architecture, after the ruin caused by the Goths, was manifested in the character of the art as displayed in the church of St. Sophia at Constantinople, which was erected by Justinian in the 6th century. The church of St. Mark at Venice, which arose in the 10th or 11th century, was the work of Grecian architects, and resembles in magnificence the forms of ancient architecture. The cathedral at Pisa, a wonderful structure for the age, was erected by a Grecian architect in 1016. The marble with which the walls of this building were faced, and of which the four rows of columns that support the roof are composed, is said to be of an excellent character. The Campanile, or leaning-tower as it is usually called, was erected near the cathedral in the 12th century. Its inclination is generally supposed to have arisen from a poor foundation; although by some it is said to have been thus constructed originally, in order to inspire in the minds of the beholder sensations of sublimity and awe. In the 13th century, the science in Italy was slowly progressing; many fine churches were erected, the style of which displayed a decided advance in the progress towards pure classical architecture. In other parts of Europe, the Gothic, or pointed style, was prevalent. The cathedral at Strasburg, designed by Irwin Steinbeck, was erected

in the 13th and 14th centuries. In France and England during the 14th century, many very superior edifices were erected in this style.

180.—In the 14th and 15th centuries, and particularly in the latter, architecture in Italy was greatly revived. The masters began to study the remains of ancient Roman edifices; and many splendid buildings were erected, which displayed a purer taste in the science. Among others, St. Peter's of Rome, which was built about this time, is a lasting monument of the architectural skill of the age. Giocondo, Michael Angelo, Palladio, Vignola, and other celebrated architects, each in their turn, did much to restore the art to its former excellence. In the edifices which were erected under their direction, however, it is plainly to be seen that they studied not from the pure models of Greece, but from the remains of the deteriorated architecture of Rome. The high pedestal, the coupled columns, the rounded pediment, the many curved-and-twisted enrichments, and the convex frieze, were unknown to pure Grecian architecture. Yet their efforts were serviceable in correcting, to a good degree, the very impure taste that had prevailed since the overthrow of the Roman empire.

181.—At about this time, the Italian masters and numerous artists who had visited Italy for the purpose, spread the Roman style over various countries of Europe; which was gradually received into favor in place of the modern-Gothic. This fell into disuse; although it has of late years been again cultivated. It requires a building of great magnitude and complexity for a perfect display of its beauties. In America, the pure Grecian style was at first more or less studied; and perhaps the simplicity of its principles would be better adapted to a republican country, than the intricacy and extent of those of the Gothic; but at the present time the latter style is being introduced, especially for ecclesiastical structures.

STYLES OF ARCHITECTURE.

182.—It is generally acknowledged that the various styles in architecture, were originated in accordance with the different pursuits of the early inhabitants of the earth ; and were brought by their descendants to their present state of perfection, through the propensity for imitation and desire of emulation which are found more or less among all nations. Those that followed agricultural pursuits, from being employed constantly upon the same piece of land, needed a permanent residence, and the wooden *hut* was the offspring of their wants ; while the shepherd, who followed his flocks and was compelled to traverse large tracts of country for pasture, found the *tent* to be the most portable habitation ; again, the man devoted to hunting and fishing—an idle and vagabond way of living—is naturally supposed to have been content with the *cavern* as a place of shelter. The latter is said to have been the origin of the Egyptian style ; while the curved roof of Chinese structures gives a strong indication of their having had the tent for their model ; and the simplicity of the original style of the Greeks, (the Doric,) shows quite conclusively, as is generally conceded, that its original was of wood. The modern-Gothic, or pointed style, which was most generally confined to ecclesiastical structures, is said by some to have originated in an attempt to imitate the bower, or grove of trees, in which the ancients performed their idol-worship.

183.—There are numerous styles, or orders, in architecture ; and a knowledge of the peculiarities of each is important to the student in the art. An ORDER, in architecture, is composed of three principal parts, viz : the Stylobate, the Column and the Entablature.

184.—The STYLOBATE is the substructure, or basement, upon which the columns of an order are arranged. In Roman architecture—especially in the interior of an edifice—it frequently occurs that each column has a separate substructure ; this is

called a *pedestal*. If possible, the pedestal should be avoided in all cases; because it gives to the column, the appearance of having been originally designed for a small building, and afterwards pieced-out to make it long enough for a larger one.

185.—The COLUMN is composed of the base, shaft and capital.

186.—The ENTABLATURE, above and supported by the columns, is horizontal; and is composed of the architrave, frieze and cornice. These principal parts are again divided into various members and mouldings. (See *Sect. III.*)

187.—The BASE of a column is so called from *basis*, a foundation, or footing.

188.—The SHAFT, the upright part of a column standing upon the base and crowned with the capital, is from *shafto*, to dig—in the manner of a well, whose inside is not unlike the form of a column.

189.—The CAPITAL, from *kephale* or *caput*, the head, is the uppermost and crowning part of the column.

190.—The ARCHITRAVE, from *archi*, chief or principal, and *trahs*, a beam, is that part of the entablature which lies in immediate connection with the column.

191.—The FRIEZE, from *fibron*, a fringe or border, is that part of the entablature which is immediately above the architrave and beneath the cornice. It was called by some of the ancients, *zophorus*, because it was usually enriched with sculptured animals.

192.—The CORNICE, from *corona*, a crown, is the upper and projecting part of the entablature—being also the uppermost and crowning part of the whole order.

193.—The PEDIMENT, above the entablature, is the triangular portion which is formed by the inclined edges of the roof at the end of the building. In Gothic architecture, the pediment is called, a *gable*.

194.—The TYMPANUM is the perpendicular triangular surface which is enclosed by the cornice of the pediment.

195.—The *Attic* is a small order, consisting of pilasters and entablature, raised above a larger order, instead of a pediment. An attic story is the upper story, its windows being usually square.

196.—An order, in architecture, has its several parts and members proportioned to one another by a scale of 60 equal parts, which are called minutes. If the height of buildings were always the same, the scale of equal parts would be a fixed quantity—an exact number of feet and inches. But as buildings are erected of different heights, the column and its accompaniments are required to be of different dimensions. To ascertain the scale of equal parts, it is necessary to know the height to which the whole order is to be erected. This must be divided by the number of diameters which is directed for the order under consideration. Then the quotient obtained by such division, is the length of the scale of equal parts—and is, also, the diameter of the column next above the base. For instance, in the Grecian Doric order the whole height, including column and entablature, is 8 diameters. Suppose now it were desirable to construct an example of this order, forty feet high. Then 40 feet divided by 8, gives 5 feet for the length of the scale; and this being divided by 60, the scale is completed. The upright columns of figures, marked *H* and *P*, by the side of the drawings illustrating the orders, designate the height and the projection of the members. The projection of each member is reckoned from a line passing through the axis of the column, and extending above it to the top of the entablature. The figures represent minutes, or 60ths, of the major diameter of the shaft of the column.

197.—*GRECIAN STYLES.* The original method of building among the Greeks, was in what is called the *Doric* order: to this were afterwards added the *Ionic* and the *Corinthian*. These three were the only styles known among them. Each is distinguished from the other two, by not only a peculiarity of

some one or more of its principal parts, but also by a particular destination. The character of the Doric is robust, manly and Herculean-like; that of the Ionic is more delicate, feminine, matronly; while that of the Corinthian is extremely delicate, youthful and virgin-like. However they may differ in their general character, they are alike famous for grace and dignity, elegance and grandeur, to a high degree of perfection.

198.—The DORIC ORDER, (*Fig. 120*,) is so ancient that its origin is unknown—although some have pretended to have discovered it. But the most general opinion is, that it is an improvement upon the original wooden buildings of the Grecians. These no doubt were very rude, and perhaps not unlike the following figure.




Fig. 119.

The trunks of trees, set perpendicularly to support the roof, may be taken for columns; the tree laid upon the tops of the perpendicular ones, the architrave; the ends of the cross-beams which rest upon the architrave, the triglyphs; the tree laid on the cross-beams as a support for the ends of the rafters, the bed-moulding of the cornice; the ends of the rafters which project beyond the bed-moulding, the mutules; and perhaps the projection of the roof in front, to screen the entrance from the weather, gave origin to the portico.

The peculiarities of the Doric order are the triglyphs—those parts of the frieze which have perpendicular channels cut in




Fig. 120

their surface; the absence of a base to the column—as also of fillets between the flutings of the column, and the plainness of the capital. The triglyphs are to be so disposed that the width of the metopes—the spaces between the triglyphs—shall be equal to their height.

199.—The *intercolumniation*, or space between the columns, is regulated by placing the centres of the columns under the centres of the triglyphs—except at the angle of the building; where, as may be seen in *Fig. 120*, one edge of the triglyph must be over the centre of the column.* Where the columns are so disposed that one of them stands beneath every other triglyph, the arrangement is called, *mono-triglyph*, and is most common. When a column is placed beneath every third triglyph, the arrangement is called *diastyle*; and when beneath every fourth, *arcæostyle*. This last style is the worst, and is seldom adopted.

200.—The Doric order is suitable for buildings that are destined for national purposes, for banking-houses, &c. Its appearance, though massive and grand, is nevertheless rich and graceful. The Patent Office at Washington, and the Custom-House at New York, are good specimens of this order.

* GRECIAN DORIC ORDER. When the width to be occupied by the whole front is limited; to determine the diameter of the column.

The relation between the parts may be expressed thus:

$$x = \frac{60 a}{d(b+c) + (60-c)}$$

Where a equals the width in feet occupied by the columns, and their intercolumniations taken collectively, measured at the base; b equals the width of the metope, in minutes; c equals the width of the triglyphs in minutes; d equals the number of metopes, and x equals the diameter in feet.

Example.—A front of six columns—hexastyle—61 feet wide; the frieze having one triglyph over each intercolumniation, or mono-triglyph. In this case, there being five intercolumniations and two metopes over each, therefore there are $5 \times 2 = 10$ metopes. Let the metope equal 42 minutes and the triglyph equal 28. Then $a = 61$; $b = 42$; $c = 28$; and $d = 10$; and the formula above becomes,

$$x = \frac{60 \times 61}{10(42+28) + (60-28)} = \frac{60 \times 61}{10 \times 70 + 32} = \frac{3660}{732} = 5 \text{ feet} = \text{the diameter required.}$$

Example.—An octastyle front, 8 columns, 184 feet wide, three metopes over each intercolumniation, 21 in all, and the metope and triglyph 42 and 28, as before. Then,

$$x = \frac{60 \times 184}{21(42+28) + (60-28)} = \frac{11040}{1502} = 7 \frac{35}{1502} \text{ feet} = \text{the diameter required.}$$

IONIC ORDER.




Fig. 121.

201.—The IONIC ORDER. (*Fig.* 121.) The Doric was for some time the only order in use among the Greeks. They gave their attention to the cultivation of it, until perfection seems to have been attained. Their temples were the principal objects upon which their skill in the art was displayed; and as the Doric order seems to have been well fitted, by its massive proportions, to represent the character of their male deities rather than the female, there seems to have been a necessity for another style which should be emblematical of feminine graces, and with which they might decorate such temples as were dedicated to the goddesses. Hence the origin of the Ionic order. This was invented, according to historians, by Hermogenes of Alabanda; and he being a native of Caria, then in the possession of the Ionians, the order was called, the Ionic.

202.—The distinguishing features of this order are the *volutes*, or spirals of the capital; and the *dentils* among the bed-mouldings of the cornice: although in some instances, dentils are wanting. The volutes are said to have been designed as a representation of curls of hair on the head of a matron, of whom the whole column is taken as a semblance.

203.—The intercolumniation of this and the other orders—both Roman and Grecian, with the exception of the Doric—are distinguished as follows. When the interval is one and a half diameters, it is called, *pyncostyle*, or columns thick-set; when two diameters, *systyle*; when two and a quarter diameters, *eustyle*; when three diameters, *diastyle*; and when more than three diameters; *arcæostyle*, or columns thin-set. In all the orders, when there are four columns in one row, the arrangement is called, *tetrastyle*; when there are six in a row, *hexastyle*; and when eight, *octastyle*.

204.—The Ionic order is appropriate for churches, colleges, seminaries, libraries, all edifices dedicated to literature and the arts, and all places of peace and tranquillity. The front of the




Fig. 123.

at *Fig. 123.* The several centres in rotation are at the angles formed by the heavy lines, as figured, 1, 2, 3, 4, 5, 6, &c. The position of these angles is determined by commencing at the point, 1, and making each heavy line one part less in length than the preceding one. No. 1 is the centre for the arc, *a b*, (*Fig. 122*;) 2 is the centre for the arc, *b c*; and so on to the last. The inside spiral line is to be described from the centres, *x, x, x, &c.*, (*Fig. 123*;) being the centre of the first small square towards the middle of the eye from the centre for the outside arc. The breadth of the fillet at *a j*, is to be made equal to $2\frac{3}{16}$ min. This is for a spiral of *three* revolutions; but one of any number of revolutions, as 4 or 6, may be drawn, by dividing *of*, (*Fig. 123*;) into a corresponding number of equal parts. Then divide the part nearest the centre, *o*, into two parts, as at *h*; join *o* and 1, also *o* and 2; draw *h 3*, parallel to *o 1*, and *h 4*, parallel to *o 2*; then the lines, *o 1*, *o 2*, *h 3*, *h 4*, will determine the length of the heavy lines, and the place of the centres. (See *Art. 489*.)

206.—The CORINTHIAN ORDER, (*Fig. 125*), is in general like the Ionic, though the proportions are lighter. The Corinthian displays a more airy elegance, a richer appearance; but its distinguishing feature is its beautiful capital. This is generally supposed to have had its origin in the capitals of the columns of Egyptian temples; which, though not approaching it in elegance, have yet a similarity of form with the Corinthian. The oft-repeated story of its origin which is told by Vitruvius—an architect who flourished in Rome, in the days of Augustus Cæsar—though pretty generally considered to be fabulous, is nevertheless worthy of being again recited. It is this: a young lady of Corinth was sick, and finally died. Her nurse gathered into a doep basket, such trinkets and keepsakes as the lady had been fond of when alive, and placed them upon her grave; covering the basket with a flat stone or tile, that its contents might not be disturbed. The basket was placed accidentally upon the stem of an acanthus plant, which, shooting forth, enclosed the basket with its foliage; some of which, reaching the tile, turned gracefully over in the form of a volute.





Fig. 124.

A celebrated sculptor, Calimachus, saw the basket thus decorated, and from the hint which it suggested, conceived and constructed a capital for a column. This was called Corinthian from the fact that it was invented and first made use of at Corinth.

207.—The Corinthian being the gayest, the richest, and most lovely of all the orders, it is appropriate for edifices which are dedicated to amusement, banqueting and festivity—for all places where delicacy, gayety and splendour are desirable.

208.—In addition to the three regular orders of architecture,



CORINTHIAN ORDER.—FIG. 125.

it was sometimes customary among the Greeks—and afterwards among other nations—to employ representations of the human form, instead of columns, to support entablatures; these were called *Persians* and *Caryatides*.

209.—**PERSIANS** are statues of men, and are so called in commemoration of a victory gained over the Persians by Pausanias. The Persian prisoners were brought to Athens and condemned to abject slavery; and in order to represent them in the lowest state of servitude and degradation, the statues were loaded with the heaviest entablature, the Doric.

210.—**CARYATIDES** are statues of women dressed in long robes after the Asiatic manner. Their origin is as follows. In a war between the Greeks and the Caryans, the latter were totally vanquished, their male population extinguished, and their females carried to Athens. To perpetuate the memory of this event, statues of females, having the form and dress of the Caryans, were erected, and crowned with the Ionic or Corinthian entablature. The caryatides were generally formed of about the human size, but the persians much larger; in order to produce the greater awe and astonishment in the beholder. The entablatures were proportioned to a statue in like manner as to a column of the same height. '

211.—These semblances of slavery have been in frequent use among moderns as well as ancients; and as a relief from the stateliness and formality of the regular orders, are capable of forming a thousand varieties; yet in a land of liberty such marks of human degradation ought not to be perpetuated.

212.—**ROMAN STYLES.** Strictly speaking, Rome had no architecture of her own—all she possessed was borrowed from other nations. Before the Romans exchanged intercourse with the Greeks, they possessed some edifices of considerable extent and merit, which were erected by architects from Etruria; but Rome was principally indebted to Greece for what she acquired of the art. Although there is no such thing as




Fig. 126.

an architecture of Roman invention, yet no nation, perhaps, ever was so devoted to the cultivation of the art as the Roman. Whether we consider the number and extent of their structures, or the lavish richness and splendour with which they were adorned, we are compelled to yield to them our admiration and praise. At one time, under the consuls and emperors, Rome employed 400 architects. The public works—such as theatres, circuses, baths, aqueducts, &c.—were, in extent and grandeur, beyond any thing attempted in modern times. Aqueducts were built to convey water from a distance of 60 miles or more. In the prosecution of this work, rocks and mountains were tunnelled, and valleys bridged. Some of the latter descended 200 feet below the level of the water; and in passing them the canals were supported by an arcade, or succession of arches. Public baths are spoken of as large as cities; being fitted up with numerous conveniences for exercise and amusement. Their decorations were most splendid; indeed, the exuberance of the ornaments alone was offensive to good taste. So overloaded with enrichments were the baths of Diocletian, that on an occasion of public festivity, great quantities of sculpture fell from the ceilings and entablatures, killing many of the people.

213.—The three orders of Greece were introduced into Rome in all the richness and elegance of their perfection. But the luxurious Romans, not satisfied with the simple elegance of their refined proportions, sought to improve upon them by lavish displays of ornament. They transformed in many instances, the true elegance of the Grecian art into a gaudy splendour, better suited to their less refined taste. The Romans remodelled each of the orders: the Doric, (*Fig. 126*), was modified by increasing the height of the column to 8 diameters; by changing the echinus of the capital for an ovolo, or quarter round, and adding an astragal and neck below it; by placing the *centre*, instead of one edge, of the first triglyph




Fig. 127.

over the centre of the column; and introducing horizontal instead of inclined mutules in the cornice, and in some instances dispensing with them altogether. The Ionic was modified by diminishing the size of the volutes, and, in some specimens, introducing a new capital in which the volutes were diagonally arranged, (*Fig.* 127.) This new capital has been termed *modern* Ionic. The favorite order at Rome and her colonies was the Corinthian, (*Fig.* 128.) But this order, the Roman artists in their search for novelty, subjected to many alterations—especially in the foliage of its capital. Into the upper part of this, they introduced the modified Ionic capital; thus combining the two in one. This change was dignified with the importance of an *order*, and received the appellation, *COMPOSITE*, or *Roman*: the best specimen of which is found in the Arch of Titus, (*Fig.* 129.) This style was not much used among the Romans themselves, and is but slightly appreciated now.

214.—The *TUSCAN ORDER* is said to have been introduced to the Romans by the Etruscan architects, and to have been the only style used in Italy before the introduction of the Grecian orders. However this may be, its similarity to the Doric order gives strong indications of its having been a rude imitation of that style: this is very probable, since history informs us that the Etruscans held intercourse with the Greeks at a remote period. The rudeness of this order prevented its extensive use in Italy. All that is known concerning it is from Vitruvius—no remains of buildings in this style being found among ancient ruins.

215.—For mills, factories, markets, barns, stables, &c., where utility and strength are of more importance than beauty, the improved modification of this order, called the *modern* Tuscan, (*Fig.* 130,) will be useful; and its simplicity recommends it where economy is desirable.

216.—*EGYPTIAN STYLE.* The architecture of the ancient




Fig. 128.




Fig. 129.




Fig. 180.

Egyptians—to which that of the ancient Hindoos bears some resemblance—is characterized by boldness of outline, solidity and grandeur. The amazing labyrinths and extensive artificial lakes, the splendid palaces and gloomy cemeteries, the gigantic pyramids and towering obelisks, of the Egyptians, were works of immensity and durability; and their extensive remains are enduring proofs of the enlightened skill of this once-powerful, but long since extinct nation. The principal features of the Egyptian Style of architecture are—uniformity of plan, never deviating from right lines and angles; thick walls, having the outer surface slightly deviating inwardly from the perpendicular; the whole building low; roof flat, composed of stones reaching in one piece from pier to pier, these being supported by enormous columns, very stout in proportion to their height; the shaft sometimes polygonal, having no base but with a great variety of handsome capitals, the foliage of these being of the palm, lotus and other leaves; entablatures having simply an architrave, crowned with a huge cavetto ornamented with sculpture; and the intercolumniation very narrow, usually $1\frac{1}{2}$ diameters and seldom exceeding $2\frac{1}{2}$. In the remains of a temple, the walls were found to be 24 feet thick; and at the gates of Thebes, the walls at the foundation were 50 feet thick and perfectly solid. The immense stones of which these, as well as Egyptian walls generally, were built, had both their inside and outside surfaces faced, and the joints throughout the body of the wall as perfectly close as upon the outer surface. For this reason, as well as that the buildings generally partake of the pyramidal form, arise their great solidity and durability. The dimensions and extent of the buildings may be judged from the temple of Jupiter at Thebes, which was 1400 feet long and 300 feet wide—exclusive of the porticos, of which there was a great number.

It is estimated by Mr. Gliddon, U. S. consul in Egypt, that not less than 25,000,000 tons of hewn stone were employed in the erection of the Pyramids of Memphis alone,—or enough to construct 3,000 Bunker-Hill monuments. Some of the blocks are 40




Fig. 181.

feet long, and polished with emery to a surprising degree. It is conjectured that the stone for these pyramids was brought, by rafts and canals, from a distance of 6 or 7 hundred miles.

217.—The general appearance of the Egyptian style of architecture is that of solemn grandeur—amounting sometimes to sepulchral gloom. For this reason it is appropriate for cemeteries, prisons, &c.; and being adopted for these purposes, it is gradually gaining favour.

A great dissimilarity exists in the proportion, form and general features of Egyptian columns. In some instances, there is no uniformity even in those of the same building, each differing from the others either in its shaft or capital. For practical use in this country, *Fig. 131* may be taken as a standard of this style. The Halls of Justice in Centre-street, New-York city, is a building in general accordance with the principles of Egyptian architecture.

Buildings in General.

218.—That style of architecture is to be preferred in which utility, stability and regularity, are gracefully blended with grandeur and elegance. But as an arrangement designed for a warm country would be inappropriate for a colder climate, it would seem that the style of building ought to be modified to suit the wants of the people for whom it is designed. High roofs to resist the pressure of heavy snows, and arrangements for artificial heat, are indispensable in northern climes; while they would be regarded as entirely out of place in buildings at the equator.

219.—Among the Greeks, architecture was employed chiefly upon their temples and other large buildings; and the proportions of the orders, as determined by them, when executed to such large dimensions, have the happiest effect. But when used for small buildings, porticos, porches, &c., especially in country-places, they are rather heavy and clumsy; in such cases, more slender proportions will be found to produce a better effect. The

English cottage-style is rather more appropriate, and is becoming extensively practised for small buildings in the country.

220.—Every building should bear an expression suited to its destination. If it be intended for national purposes, it should be magnificent—grand; for a private residence, neat and modest; for a banqueting-house, gay and splendid; for a monument or cemetery, gloomy—melancholy; or, if for a church, majestic and graceful. By some it has been said—“somewhat dark and gloomy, as being favourable to a devotional state of feeling;” but such impressions can only result from a misapprehension of the nature of true devotion. “Her ways are ways of *pleasantness*, and all her paths are peace.” The church should rather be a type of that brighter world to which it leads.

221.—However happily the several parts of an edifice may be disposed, and however pleasing it may appear as a whole, yet much depends upon its *site*, as also upon the character and style of the structures in its immediate vicinity, and the degree of cultivation of the adjacent country. A splendid country-seat should have the out-houses and fences in the same style with itself, the trees and shrubbery neatly trimmed, and the grounds well cultivated.

222.—Europeans express surprise that so many houses in this country are built of wood. And yet, in a new country, where wood is plenty, that this should be so is no cause for wonder. Still, the practice should not be encouraged. Buildings erected with brick or stone are far preferable to those of wood; they are more durable; not so liable to injury by fire, nor to need repairs; and will be found in the end quite as economical. A wooden house is suitable for a temporary residence only; and those who would bequeath a dwelling to their children, will endeavour to build with a more durable material. Wooden cornices and gutters, attached to brick houses, are objectionable—not only on account of their frail nature, but also because they render the building liable to destruction by fire.




Fig. 132
Under-Cellar.




Fig. 133.
Basement.

223.—Dwelling houses are built of various dimensions and styles, according to their destination ; and to give designs and directions for their erection, it is necessary to know their situation and object. A dwelling intended for a gardener, would require very different dimensions and arrangements from one intended for a retired gentleman—with his servants, horses, &c. ; nor would a house designed for the city be appropriate for the country. For city houses, arrangements that would be convenient for one family might be very inconvenient for two or more. *Fig.* 132, 133, 134, 135, 136, and 137, represent the *ichnographical projection*, or ground-plan, of the floors of an ordinary city house, designed to be occupied by one family only. *Fig.* 139 is an *elevation*, or front-view, of the same house : all these plans are drawn at the same scale—which is that at the bottom of *Fig.* 139.

Fig. 132 is a Plan of the Under-Cellar.

- a*, is the coal-vault, 6 by 10 feet.
- b*, is the furnace for heating the house.
- c*, *d*, are front and rear areas.

Fig. 133 is a Plan of the Basement.

- a*, is the library, or ordinary dining-room, 15 by 20 feet.
- b*, is the kitchen, 15 by 22 feet.
- c*, is the store-room, 6 by 9 feet.
- d*, is the pantry, 4 by 7 feet.
- e*, is the china closet, 4 by 7 feet.
- f*, is the servants' water-closet.
- g*, is a closet.
- h*, is a closet with a dumb-waiter to the first story above.
- i*, is an ash closet under the front stoop.
- j*, is the kitchen-range.
- k*, is the sink for washing and drawing water
- l*, are wash trays.




Fig. 134.
First Story




Fig. 135.
Second Story.

Fig. 134 is a Plan of the First Story.

a, is the parlor, 15 by 34 feet.

b, is the dining-room, 16 by 23 feet.

c, is the vestibule.

e, is the closet containing the dumb-waiter from the basement.

f, is the closet containing butler's sink.

g, g, are closets.

h, is a closet for hats and cloaks.

i, j, are front and rear balconies.

Fig. 135 is the Second Story.

a, a, are chambers, 15 by 19 feet.

b, is a bed-room, $7\frac{1}{2}$ by 13 feet.

c, is the bath-room, $7\frac{1}{2}$ by 13 feet.

d, d, are dressing-rooms, 6 by $7\frac{1}{2}$ feet.

e, e, are closets.

f, f, are wardrobes.

g, g, are cupboards.

Fig. 136 is the Third Story.

a, a, are chambers, 15 by 19 feet.

b, b, are bed-rooms, $7\frac{1}{2}$ by 13 feet.

c, c, are closets.

d, is a linen closet, 5 by 7 feet.

e, e, are dressing-closets.

f, f, are wardrobes.

g, g, are cupboards.

Fig. 137 is the Fourth Story.

a, a, are chambers, 14 by 17 feet.

b, b, are bed-rooms, $8\frac{1}{2}$ by 17 feet.

c, c, c, are closets.

d, is the step-ladder to the roof.




Fig. 136.
Third Story.




Fig. 137.
Fourth Story.

Fig. 138 is the Section of the House showing the heights of the several stories.

Fig. 139 is the Front Elevation.

The size of the house is 25 feet front by 55 feet deep ; this is about the average depth, although some are extended to 60 and 65 feet in depth.

These are introduced to give some general ideas of the principles to be followed in designing city houses. In placing the chimneys in the parlours, set the chimney-breasts equi-distant from the ends of the room. The basement chimney-breasts may be placed nearly in the middle of the side of the room, as there is but one flue to pass through the chimney-breast above ; but in the second story, as there are two flues, one from the basement and one from the parlour, the breast will have to be placed nearly perpendicular over the parlour breast, so as to receive the flues within the jambs of the fire-place. As it is desirable to have the chimney-breast as near the middle of the room as possible, it may be placed a few inches towards that point from over the breast below. So in arranging those of the stories above, always make provision for the flues from below.

224.—In placing the stairs, there should be at least as much room in the passage at the side of the stairs, as upon them ; and in regard to the length of the passage in the second story, there must be room for the doors which open from each of the principal rooms into the hall, and more if the stairs require it. Having assigned a position for the stairs of the second story, now generally placed in the centre of the depth of the house, let the winders of the other stories be placed perpendicularly over and under them ; and be careful to provide for head-room. To ascertain this, when it is doubtful, it is well to draw a vertical section of the whole stairs ; but in ordinary cases, this is not necessary. To dispose the windows properly, the




Fig. 138.
Section.




Fig. 139.
Elevation.



middle window of each story should be exactly in the middle of the front; but the pier between the two windows which light the parlour, should be in the centre of that room; because when chandeliers or any similar ornaments, hang from the centre-pieces of the parlour ceilings, it is important, in order to give the better effect, that the pier-glasses at the front and rear, be in a range with them. If both these objects cannot be attained, an approximation to each must be attempted. The piers should in no case be less in width than the window openings, else the blinds or shutters when thrown open will interfere with one another; in general practice, it is well to make the outside piers $\frac{2}{3}$ of the width of one of the middle piers. When this is desirable, deduct the amount of the three openings from the width of the front, and the remainder will be the amount of the width of all the piers; divide this by 10, and the product will be $\frac{1}{3}$ of a middle pier; and then, if the parlour arrangements do not interfere, give twice this amount to each corner pier, and three times the same amount to each of the middle piers.

PRINCIPLES OF ARCHITECTURE.

225.—In the construction of the first habitations of men, frail and rude as they must have been, the first and principal object was, doubtless, utility—a mere shelter from sun and rain. But as successive storms shattered the poor tenement, man was taught by experience the necessity of building with an idea to durability. And when in his walks abroad, the symmetry, proportion and beauty of nature met his admiring gaze, contrasting so strangely with the misshapen and disproportioned work of his own hands, he was led to make gradual changes; till his abode was rendered not only commodious and durable, but pleasant in its appearance; and building became a fine art, having utility for its basis.

226.—In all designs for buildings of importance, utility, durability and beauty, the first great principles of architecture, should be pre-eminent. In order that the edifice be useful, commodious and comfortable, the arrangement of the apartments should be such as to fit them for their several destinations; for public assemblies, oratory, state, visitors, retiring, eating, reading, sleeping, bathing, dressing, &c.—these should each have its own peculiar form and situation. To accomplish this, and at the same time to make their relative situation agreeable and pleasant, producing regularity and harmony, require in some instances much skill and sound judgment. Convenience and regularity are very important, and each should have due attention; yet when both cannot be obtained, the latter should in most cases give place to the former. A building that is neither convenient nor regular, whatever other good qualities it may possess, will be sure of disapprobation.

227.—The utmost importance should be attached to such arrangements as are calculated to promote health: among these, *ventilation* is by no means the least. For this purpose, the ceilings of the apartments should have a respectable height; and the sky-light, or any part of the roof that can be made moveable, should be arranged with cord and pullies, so as to be easily raised and lowered. Small openings near the ceiling, that may be closed at pleasure, should be made in the partitions that separate the rooms from the passages—especially for those rooms which are used for sleeping apartments. All the apartments should be so arranged as to secure their being easily kept *dry* and *clean*. In dwellings, suitable apartments should be fitted up for *bathing* with all the necessary apparatus for conveying the water.

228.—To insure stability in an edifice, it should be designed upon well-known geometrical principles: such as science has demonstrated to be necessary and sufficient for firmness and dura

bility. It is well, also, that it have the *appearance* of stability as well as the *reality*; for should it seem tottering and unsafe, the sensation of fear, rather than those of admiration and pleasure, will be excited in the beholder. To secure certainty and accuracy in the application of those principles, a knowledge of the strength and other properties of the materials used, is indispensable; and in order that the whole design be so made as to be capable of execution, a practical knowledge of the requisite mechanical operations is quite important.

229.—The elegance of an architectural design, although chiefly depending upon a just proportion and harmony of the parts, will be promoted by the introduction of ornaments—provided this be judiciously performed. For enrichments should not only be of a proper character to suit the style of the building, but should also have their true position, and be bestowed in proper quantity. The most common fault, and one which is prominent in Roman architecture, is an excess of enrichment: an error which is carefully to be guarded against. But those who take the Grecian models for their standard, will not be liable to go to that extreme. In ornamenting a cornice, or any other assemblage of mouldings, at least every alternate member should be left plain; and those that are near the eye should be more finished than those which are distant. Although the characteristics of good architecture are utility and elegance, in connection with durability, yet some buildings are designed expressly for use, and others again for ornament: in the former, utility, and in the latter, beauty, should be the governing principle.

230.—The builder should be intimately acquainted with the principles upon which the essential, elementary parts of a building are founded. A scientific knowledge of these will insure certainty and security, and enable the mechanic to erect the most extensive and lofty edifices with confidence. The more important parts are the foundation, the column, the wall, the lintel, the arch, the vault, the dome and the roof. A separate description of the

peculiarities of each, would seem to be necessary; and cannot perhaps be better expressed than in the following language of a modern writer on this subject.

231.—“In laying the FOUNDATION of any building, it is necessary to dig to a certain depth in the earth, to secure a solid basis, below the reach of frost and common accidents. The most solid basis is rock, or gravel which has not been moved. Next to these are clay and sand, provided no other excavations have been made in the immediate neighbourhood. From this basis a stone wall is carried up to the surface of the ground, and constitutes the foundation. Where it is intended that the superstructure shall press unequally, as at its piers, chimneys, or columns, it is sometimes of use to occupy the space between the points of pressure by an inverted arch. This distributes the pressure equally, and prevents the foundation from springing between the different points. In loose or muddy situations, it is always unsafe to build, unless we can reach the solid bottom below. In salt marshes and flats, this is done by depositing timbers, or driving wooden piles into the earth, and raising walls upon them. The preservative quality of the salt will keep these timbers unimpaired for a great length of time, and makes the foundation equally secure with one of brick or stone.

232.—The simplest member in any building, though by no means an essential one to all, is the COLUMN, or *pillar*. This is a perpendicular part, commonly of equal breadth and thickness, not intended for the purpose of enclosure, but simply for the support of some part of the superstructure. The principal force which a column has to resist, is that of perpendicular pressure. In its shape, the shaft of a column should not be exactly cylindrical, but, since the lower part must support the weight of the superior part, in addition to the weight which presses equally on the whole column, the thickness should gradually decrease from bottom to top. The outline of columns should be a little curved, so as to represent a portion of a very long spheroid, or paraboloid,

rather than of a cone. This figure is the joint result of two calculations, independent of beauty of appearance. One of these is, that the form best adapted for stability of base is that of a cone; the other is, that the figure, which would be of equal strength throughout for supporting a superincumbent weight, would be generated by the revolution of two parabolas round the axis of the column, the vertices of the curves being at its extremities. The swell of the shafts of columns was called the *entasis* by the ancients. It has been lately found, that the columns of the Parthenon, at Athens, which have been commonly supposed straight, deviate about an inch from a straight line, and that their greatest swell is at about one third of their height. Columns in the antique orders are usually made to diminish one sixth or one seventh of their diameter, and sometimes even one fourth. The Gothic pillar is commonly of equal thickness throughout.

233.—The WALL, another elementary part of a building, may be considered as the lateral continuation of the column, answering the purpose both of enclosure and support. A wall must diminish as it rises, for the same reasons, and in the same proportion, as the column. It must diminish still more rapidly if it extends through several stories, supporting weights at different heights. A wall, to possess the greatest strength, must also consist of pieces, the upper and lower surfaces of which are horizontal and regular, not rounded nor oblique. The walls of most of the ancient structures which have stood to the present time, are constructed in this manner, and frequently have their stones bound together with bolts and cramps of iron. The same method is adopted in such modern structures as are intended to possess great strength and durability, and, in some cases, the stones are even dove-tailed together, as in the light-houses at Eddystone and Bell Rock. But many of our modern stone walls, for the sake of cheapness, have only one face of the stones squared, the inner half of the wall being completed with brick; so that they can,

in reality, be considered only as brick walls faced with stone. Such walls are said to be liable to become convex outwardly, from the difference in the shrinking of the cement. *Rubble* walls are made of rough, irregular stones, laid in mortar. The stones should be broken, if possible, so as to produce horizontal surfaces. The *coffer* walls of the ancient Romans were made by enclosing successive portions of the intended wall in a box, and filling it with stones, sand, and mortar, promiscuously. This kind of structure must have been extremely insecure. The Pantheon, and various other Roman buildings, are surrounded with a double brick wall, having its vacancy filled up with loose bricks and cement. The whole has gradually consolidated into a mass of great firmness.

The *reticulated* walls of the Romans, having bricks with oblique surfaces, would, at the present day, be thought highly unphilosophical. Indeed, they could not long have stood, had it not been for the great strength of their cement. Modern brick walls are laid with great precision, and depend for firmness more upon their position than upon the strength of their cement. The bricks being laid in horizontal courses, and continually overlaying each other, or *breaking joints*, the whole mass is strongly interwoven, and bound together. Wooden walls, composed of timbers covered with boards, are a common, but more perishable kind. They require to be constantly covered with a coating of a foreign substance, as paint or plaster, to preserve them from spontaneous decomposition. In some parts of France, and elsewhere, a kind of wall is made of earth, rendered compact by ramming it in moulds or cases. This method is called building in *pisé*, and is much more durable than the nature of the material would lead us to suppose. Walls of all kinds are greatly strengthened by angles and curves, also by projections, such as pilasters, chimneys and buttresses. These projections serve to increase the breadth of the foundation, and are always to be made use of in large buildings, and in walls of considerable length.

234.—The LINTEL, or *beam*, extends in a right line over a vacant space, from one column or wall to another. The strength of the lintel will be greater in proportion as its transverse vertical diameter exceeds the horizontal, the strength being always as the square of the depth. The *floor* is the lateral continuation or connection of beams by means of a covering of boards.

235.—The ARCH is a transverse member of a building, answering the same purpose as the lintel, but vastly exceeding it in strength. The arch, unlike the lintel, may consist of any number of constituent pieces, without impairing its strength. It is, however, necessary that all the pieces should possess a uniform shape,—the shape of a portion of a wedge,—and that the joints, formed by the contact of their surfaces, should point towards a common centre. In this case, no one portion of the arch can be displaced or forced inward; and the arch cannot be broken by any force which is not sufficient to crush the materials of which it is made. In arches made of common bricks, the sides of which are parallel, any *one* of the bricks might be forced inward, were it not for the adhesion of the cement. Any *two* of the bricks, however, by the disposition of their mortar, cannot collectively be forced inward. An arch of the proper form, when complete, is rendered stronger, instead of weaker, by the pressure of a considerable weight, provided this pressure be uniform. While building, however, it requires to be supported by a centring of the shape of its internal surface, until it is complete. The upper stone of an arch is called the *key-stone*, but is not more essential than any other. In regard to the shape of the arch, its most simple form is that of the semi-circle. It is, however, very frequently a smaller arc of a circle, and, still more frequently, a portion of an ellipse. The simplest theory of an arch supporting itself only, is that of Dr. Hooke. The arch, when it has only its own weight to bear, may be considered as the inversion of a chain, suspended at each end. The chain hangs in such a form, that the weight of each link or portion is held in equilibrium by

the result of two forces acting at its extremities; and these forces, or tensions, are produced, the one by the weight of the portion of the chain below the link, the other by the same weight increased by that of the link itself, both of them acting originally in a vertical direction. Now, supposing the chain inverted, so as to constitute an arch of the same form and weight, the relative situations of the forces will be the same, only they will act in contrary directions, so that they are compounded in a similar manner, and balance each other on the same conditions.

The arch thus formed is denominated a *catenary* arch. In common cases, it differs but little from a circular arch of the extent of about one third of a whole circle, and rising from the abutments with an obliquity of about 30 degrees from a perpendicular. But though the catenary arch is the best form for supporting its own weight, and also all additional weight which presses in a vertical direction, it is not the best form to resist lateral pressure, or pressure like that of fluids, acting equally in all directions. Thus the arches of bridges and similar structures, when covered with loose stones and earth, are pressed sideways, as well as vertically, in the same manner as if they supported a weight of fluid. In this case, it is necessary that the arch should arise more perpendicularly from the abutment, and that its general figure should be that of the longitudinal segment of an ellipse. In small arches, in common buildings, where the disturbing force is not great, it is of little consequence what is the shape of the curve. The outlines may even be perfectly straight, as in the tier of bricks which we frequently see over a window. This is, strictly speaking, a real arch, provided the surfaces of the bricks tend towards a common centre. It is the weakest kind of arch, and a part of it is necessarily superfluous, since no greater portion can act in supporting a weight above it, than can be included between two curved or arched lines.

Besides the arches already mentioned, various others are in use. The *acute* or *lancet* arch, much used in Gothic architecture, is

described usually from two centres outside the arch. It is a strong arch for supporting vertical pressure. The *rampant* arch is one in which the two ends spring from unequal heights. The *horse-shoe* or *Moorish* arch is described from one or more centres placed above the base line. In this arch, the lower parts are in danger of being forced inward. The *ogee* arch is concavo-convex, and therefore fit only for ornament. In describing arches, the upper surface is called the *extrados*, and the inner, the *intrados*. The springing lines are those where the intrados meets the abutments, or supporting walls. The *span* is the distance from one springing line to the other. The wedge-shaped stones, which form an arch, are sometimes called *voussoirs*, the uppermost being the key-stone. The part of a pier from which an arch springs is called the *impost*, and the curve formed by the upper side of the voussoirs, the *archivolt*. It is necessary that the walls, abutments and piers, on which arches are supported, should be so firm as to resist the lateral *thrust*, as well as vertical pressure, of the arch. It will at once be seen, that the lateral or sideway pressure of an arch is very considerable, when we recollect that every stone, or portion of the arch, is a wedge, a part of whose force acts to separate the abutments. For want of attention to this circumstance, important mistakes have been committed, the strength of buildings materially impaired, and their ruin accelerated. In some cases, the want of lateral firmness in the walls is compensated by a bar of iron stretched across the span of the arch, and connecting the abutments, like the tie-beam of a roof. This is the case in the cathedral of Milan and some other Gothic buildings.

In an arcade, or continuation of arches, it is only necessary that the outer supports of the terminal arches should be strong enough to resist horizontal pressure. In the intermediate arches, the lateral force of each arch is counteracted by the opposing lateral force of the one contiguous to it. In bridges, however, where individual arches are liable to be destroyed by accident, it is desi

rable that each of the piers should possess sufficient horizontal strength to resist the lateral pressure of the adjoining arches.

236.—The VAULT is the lateral continuation of an arch, serving to cover an area or passage, and bearing the same relation to the arch that the wall does to the column. A simple vault is constructed on the principles of the arch, and distributes its pressure equally along the walls or abutments. A complex or *groined* vault is made by two vaults intersecting each other, in which case the pressure is thrown upon springing points, and is greatly increased at those points. The groined vault is common in Gothic architecture.

237.—The DOME, sometimes called *cupola*, is a concave covering to a building, or part of it, and may be either a segment of a sphere, of a spheroid, or of any similar figure. When built of stone, it is a very strong kind of structure, even more so than the arch, since the tendency of each part to fall is counteracted, not only by those above and below it, but also by those on each side. It is only necessary that the constituent pieces should have a common form, and that this form should be somewhat like the frustum of a pyramid, so that, when placed in its situation, its four angles may point toward the centre, or axis, of the dome. During the erection of a dome, it is not necessary that it should be supported by a centring, until complete, as is done in the arch. Each circle of stones, when laid, is capable of supporting itself without aid from those above it. It follows that the dome may be left open at top, without a key-stone, and yet be perfectly secure in this respect, being the reverse of the arch. The dome of the Pantheon, at Rome, has been always open at top, and yet has stood unimpaired for nearly 2000 years. The upper circle of stones, though apparently the weakest, is nevertheless often made to support the additional weight of a lantern or tower above it. In several of the largest cathedrals, there are two domes, one within the other, which contribute their joint support to the lantern, which rests upon the top. In these buildings, the dome

rests upon a circular wall, which is supported, in its turn, by arches upon massive pillars or piers. This construction is called building upon *pendentives*, and gives open space and room for passage beneath the dome. The remarks which have been made in regard to the abutments of the arch, apply equally to the walls immediately supporting a dome. They must be of sufficient thickness and solidity to resist the lateral pressure of the dome, which is very great. The walls of the Roman Pantheon are of great depth and solidity. In order that a dome in itself should be perfectly secure, its lower parts must not be too nearly vertical, since, in this case, they partake of the nature of perpendicular walls, and are acted upon by the spreading force of the parts above them. The dome of St. Paul's church, in London, and some others of similar construction, are bound with chains or hoops of iron, to prevent them from spreading at bottom. Domes which are made of wood depend, in part, for their strength, on their internal carpentry. The Halle du Bled, in Paris, had originally a wooden dome more than 200 feet in diameter, and only one foot in thickness. This has since been replaced by a dome of iron (See *Art.* 389.)

238.—The Roof is the most common and cheap method of covering buildings, to protect them from rain and other effects of the weather. It is sometimes flat, but more frequently oblique, in its shape. The flat or platform-roof is the least advantageous for shedding rain, and is seldom used in northern countries. The *pent* roof, consisting of two oblique sides meeting at top, is the most common form. These roofs are made steepest in cold climates, where they are liable to be loaded with snow. Where the four sides of the roof are all oblique, it is denominated a *hipped* roof, and where there are two portions to the roof, of different obliquity, it is a *curb*, or *mansard* roof. In modern times, roofs are made almost exclusively of wood, though frequently covered with incombustible materials. The internal structure or carpentry of roofs is a subject of considerable mechanical contrivance,

The roof is supported by *rafters*, which abut on the walls on each side, like the extremities of an arch. If no other timbers existed, except the rafters, they would exert a strong lateral pressure on the walls, tending to separate and overthrow them. To counteract this lateral force, a *tie-beam*, as it is called, extends across, receiving the ends of the rafters, and protecting the wall from their horizontal thrust. To prevent the tie-beam from *sagging*, or bending downward with its own weight, a *king-post* is erected from this beam, to the upper angle of the rafters, serving to connect the whole, and to suspend the weight of the beam. This is called *trussing*. *Queen-posts* are sometimes added, parallel to the king-post, in large roofs; also various other connecting timbers. In Gothic buildings, where the vaults do not admit of the use of a tie-beam, the rafters are prevented from spreading, as in an arch, by the strength of the buttresses.

In comparing the lateral pressure of a high roof with that of a low one, the length of the tie-beam being the same, it will be seen that a high roof, from its containing most materials, may produce the greatest pressure, as far as weight is concerned. On the other hand, if the weight of both be equal, then the low roof will exert the greater pressure; and this will increase in proportion to the distance of the point at which perpendiculars, drawn from the end of each rafter, would meet. In roofs, as well as in wooden domes and bridges, the materials are subjected to an internal strain, to resist which, the cohesive strength of the material is relied on. On this account, beams should, when possible, be of one piece. Where this cannot be effected, two or more beams are connected together by *splicing*. Spliced beams are never so strong as whole ones, yet they may be made to approach the same strength, by affixing lateral pieces, or by making the ends overlay each other, and connecting them with bolts and straps of iron. The tendency to separate is also resisted, by letting the two pieces into each other by the process called *scarfing*. *Mortices*, in-


tended to *truss* or suspend one piece by another, should be formed upon similar principles.


Roofs in the United States, after being boarded, receive a secondary covering of shingles. When intended to be incombustible, they are covered with slates or earthen tiles, or with sheets of lead, copper or tinned iron. Slates are preferable to tiles, being lighter, and absorbing less moisture. Metallic sheets are chiefly used for flat roofs, wooden domes, and curved and angular surfaces, which require a flexible material to cover them, or have not a sufficient pitch to shed the rain from slates or shingles. Various artificial compositions are occasionally used to cover roofs, the most common of which are mixtures of tar with lime, and sometimes with sand and gravel."—*Ency. Am.* (See *Art.* 354.)


SECTION III.—MOULDINGS, CORNICES, &c.


MOULDINGS.


239.—A moulding is so called, because of its being of the same determinate shape along its whole length, as though the whole of it had been cast in the same mould or form. The regular mouldings, as found in remains of ancient architecture, are eight in number ; and are known by the following names :

 Annulet, band, cincture, fillet, listel or square.
Fig. 140.

 Astragal or bead.
Fig. 141.

 Torus or tore.
Fig. 142.

 Scotia, trochilus or mouth.
Fig. 143.


 Ovolo, quarter-round or echinus.
Fig. 144.



Cavetto, cove or hollow.



Cymatium, or cyma-recta.



Inverted cymatium, or cyma-reversa



Some of the terms are derived thus: fillet, from the French word *fil*, thread. Astragal, from *astragalos*, a bone of the heel—or the curvature of the heel. Bead, because this moulding, when properly carved, resembles a string of beads. Torus, or tore, the Greek for *rope*, which it resembles, when on the base of a column. Scotia, from *shotia*, darkness, because of the strong shadow which its depth produces, and which is increased by the projection of the torus above it. Ovolo, from *ovum*, an egg, which this member resembles, when carved, as in the Ionic capital. Cavetto, from *cavus*, hollow. Cymatium, from *kumaton* a wave.

240.—Neither of these mouldings is peculiar to any one of the orders of architecture, but each one is common to all; and although each has its appropriate use, yet it is by no means confined to any certain position in an assemblage of mouldings. The use of the fillet is to bind the parts, as also that of the astragal and torus, which resemble ropes. The ovolo and cyma-reversa are strong at their upper extremities, and are therefore used to support projecting parts above them. The cyma-recta and cavetto, being weak at their upper extremities, are not used as supporters, but are placed uppermost to cover and shelter the other parts. The scotia is introduced in the base of a column, to

separate the upper and lower torus, and to produce a pleasing variety and relief. The form of the bead, and that of the torus, is the same; the reasons for giving distinct names to them are, that the torus, in every order, is always considerably larger than the bead, and is placed among the base mouldings, whereas the bead is never placed there, but on the capital or entablature; the torus, also, is seldom carved, whereas the bead is; and while the torus among the Greeks is frequently elliptical in its form, the bead retains its circular shape. While the scotia is the reverse of the torus, the cavetto is the reverse of the ovolo, and the cyma-recta and cyma-reversa are combinations of the ovolo and cavetto.

241.—The curves of mouldings, in Roman architecture, were most generally composed of parts of circles; while those of the Greeks were almost always elliptical, or of some one of the conic sections, but rarely circular, except in the case of the bead, which was always, among both Greeks and Romans, of the form of a semi-circle. Sections of the cone afford a greater variety of forms than those of the sphere; and perhaps this is one reason why the Grecian architecture so much excels the Roman. The quick turnings of the ovolo and cyma-reversa, in particular, when exposed to a bright sun, cause those narrow, well-defined streaks of light, which give life and splendour to the whole.

242.—A *profile* is an assemblage of essential parts and mouldings. That profile produces the happiest effect which is composed of but few members, varied in form and size, and arranged so that the plane and the curved surfaces succeed each other alternately.

243.—*To describe the Grecian torus and scotia.* Join the extremities, *a* and *b*, (*Fig.* 148;) and from *f*, the given projection of the moulding, draw *f o*, at right angles to the fillets; from *b*, draw *b h*, at right angles to *a b*; bisect *a b* in *c*; join *f* and *c*, and upon *c*, with the radius, *c f*, describe the arc, *f h*, cutting *b h* in *h*; through *c*, draw *d e*, parallel with the fillets; make *d c* and *c e*, each equal to *b h*; then *d e* and *a b* will be conjugate diame-




Fig. 148.

ters of the required ellipse. To describe the curve by intersection of lines, proceed as directed at *Art. 118* and *note*; by a trammel, see *Art. 116*; and to find the foci, in order to describe it with a string, see *Art. 115*.




Fig. 149.




Fig. 150.

244.—*Fig. 149* to *156* exhibit various modifications of the Grecian ovolo, sometimes called echinus. *Fig. 149* to *153* are




Fig. 151.




Fig. 152.




Fig. 153.




Fig. 154.




Fig. 155.




Fig. 156.

elliptical, $a b$ and $b c$ being given tangents to the curve; parallel to which, the semi-conjugate diameters, $a d$ and $d c$, are drawn. In *Fig. 149* and *150*, the lines, $a d$ and $d c$, are semi-axes, the tangents, $a b$ and $b c$, being at right angles to each other. To draw the curve, see *Art. 118*. In *Fig. 153*, the curve is parabolical, and is drawn according to *Art. 127*. In *Fig. 155* and *156*, the curve is hyperbolical, being described according to *Art. 128*. The length of the transverse axis, $a b$, being taken at pleasure in order to flatten the curve, $a b$ should be made short in proportion to $a c$.




Fig. 157.




Fig. 58

245.—To describe the Grecian cavetto, (Fig. 157 and 158,) having the height and projection given, see Art. 118.




Fig. 159.




Fig. 160.

246.—To describe the Grecian cyma-recta. When the projection is more than the height, as at Fig. 159, make ab equal to the height, and divide $abcd$ into 4 equal parallelograms; then proceed as directed in note to Art. 118. When the projection is less than the height, draw da , (Fig. 160,) at right angles to ab ; complete the rectangle, $abcd$; divide this into 4 equal rectangles, and proceed according to Art. 118.




Fig. 161.




Fig. 162.

247.—To describe the Grecian cyma-reversa. When the

projection is more than the height, as at *Fig. 161*, proceed as directed for the last figure; the curve being the same as that, the position only being changed. When the projection is less than the height, draw *a d*, (*Fig. 162*,) at right angles to the fillet; make *a d* equal to the projection of the moulding: then proceed as directed for *Fig. 159*.

248.—Roman mouldings are composed of parts of circles, and have, therefore, less beauty of form than the Grecian. The bead and torus are of the form of the semi-circle, and the scotia, also, in some instances; but the latter is often composed of two quadrants, having different radii, as at *Fig. 163* and *164*, which resemble the elliptical curve. The ovolo and cavetto are generally a quadrant, but often less. When they are less, as at *Fig. 167*, the centre is found thus: join the extremities, *a* and *b*, and bisect *a b* in *c*; from *c*, and at right angles to *a b*, draw *c d*, cutting a level line drawn from *a* in *d*; then *d* will be the centre. This moulding projects less than its height. When the projection is more than the height, as at *Fig. 169*, extend the line from *c* until




Fig. 163.




Fig. 164.




Fig. 165.




Fig. 166.




Fig. 167.




Fig. 168.




Fig. 169.




Fig. 170.




Fig. 171.




Fig. 172.




Fig. 173.




Fig. 174.




Fig. 175.




Fig. 176.




Fig. 177.




Fig. 178.

it cuts a perpendicular drawn from a , as at d ; and that will be the centre of the curve. In a similar manner, the centres are found for the mouldings at *Fig.* 164, 168, 170, 173, 174, 175, and 176. The centres for the curves at *Fig.* 177 and 178, are found thus: bisect the line, ab , at c ; upon a, c and b , successively, with ac or cb for radius, describe arcs intersecting at d and d ; then those intersections will be the centres.

249.—*Fig.* 179 to 186 represent mouldings of modern invention. They have been quite extensively and successfully used in inside finishing. *Fig.* 179 is appropriate for a bed-moulding under a low projecting shelf, and is frequently used under mantle-shelves. The tangent, ih , is found thus: bisect the line, ab , at c , and bc at d ; from d , draw de , at right angles to eb ; from b , draw bf , parallel to ed ; upon b , with bd for radius, describe the arc, df ; divide this arc into 7 equal parts, and set one of the parts from s , the limit of the projection, to o ; make oh equal to oe ; from h , through c , draw the tangent, hi ; divide bh , hc , ci and ia , each into a like number of equal parts, and draw the in-




Fig. 179.




Fig. 180.




Fig. 181.




Fig. 182.




Fig. 183.




Fig 184.




Fig. 185.




Fig. 186.

tersecting lines as directed at *Art.* 89. If a bolder form is desired, draw the tangent, *i h*, nearer horizontal, and describe an elliptic curve as shown in *Fig.* 148 and 181. *Fig.* 180 is much used on base, or skirting of rooms, and in deep panelling. The curve is found in the same manner as that of *Fig.* 179. In this case, however, where the moulding has so little projection

in comparison with its height, the point, *e*, being found as in the last figure, *h s* may be made equal to *s e*, instead of *o e* as in the last figure. *Fig.* 181 is appropriate for a crown moulding of a cornice. In this figure the height and projection are given; the direction of the diameter, *a b*, drawn through the middle of the diagonal, *e f*, is taken at pleasure; and *d c* is parallel to *a e*. To find the length of *d c*, draw *b h*, at right angles to *a b*; upon *o*, with *o f* for radius, describe the arc, *f h*, cutting *b h* in *h*; then make *o c* and *o d*, each equal to *b h*.* To draw the curve, see note to *Art.* 118. *Fig.* 182 to 186 are peculiarly distinct from ancient mouldings, being composed principally of straight lines; the few curves they possess are quite short and quick




Fig. 187.




Fig. 188.

250.—*Fig.* 187 and 188 are designs for antæ caps. The

* The manner of ascertaining the length of the conjugate diameter, *d c*, in this figure, and also in *Fig.* 148, 198 and 199 is new, and is important in this application. It is founded upon well-known mathematical principles, viz: All the parallelograms that may be circumscribed about an ellipse are equal to one another, and consequently any one is equal to the rectangle of the two axes. And again: the sum of the squares of every pair of conjugate diameters is equal to the sum of the squares of the two axes.

diameter of the antæ is divided into 20 equal parts, and the height and projection of the members. are regulated in accordance with those parts, as denoted under *H* and *P*, height and projection. The projection is measured from the middle of the antæ. These will be found appropriate for porticos, doorways, mantel-pieces, door and window trimmings, &c. The height of the antæ for mantel-pieces, should be from 5 to 6 diameters, having an entablature of from 2 to $2\frac{1}{4}$ diameters. This is a good proportion, it being similar to the Doric order. But for a portico these proportions are much too heavy; an antæ, 15 diameters high, and an entablature of 3 diameters, will have a better appearance.

CORNICES.

251.—*Fig.* 189 to 197 are designs for eave cornices, and *Fig.* 198 and 199 are for stucco cornices for the inside finish of rooms. In some of these the projection of the uppermost member from the fascia, is divided into twenty equal parts,




Fig 189.

and the various members are proportioned according to those parts, as figured under *H* and *P*.




Fig. 190.




Fig. 191.




Fig. 192.




Fig. 183.




Fig. 194.




Fig. 195.




Fig. 196.




Fig. 197.




Fig. 198.




Fig. 199.




Fig. 200.

252.—*To proportion an eave cornice in accordance with the height of the building.* Draw the line, $a c$, (*Fig. 200*,) and make $b c$ and $b a$, each equal to 36 inches; from b , draw $b d$, at right angles to $a c$, and equal in length to $\frac{3}{4}$ of $a c$; bisect $b d$ in e , and from a , through e , draw $a f$; upon a , with $a c$ for radius, describe the arc, $c f$, and upon e , with $e f$ for radius, describe the arc, $f d$; divide the curve, $d f c$, into 7 equal parts, as at 10, 20, 30, &c., and from these points of division, draw lines to $b c$, parallel to $d b$; then the distance, $b 1$, is the projection of a cornice for a building 10 feet high; $b 2$, the projection at 20 feet high; $b 3$, the projection at 30 feet, &c. If the projection of a cornice for a building 34 feet high, is required, divide the arc between 30 and 40 into 10 equal parts, and from the fourth point from 30, draw a line to the base, $b c$, parallel with $b d$; then the distance of the point, at which that line cuts the base, from b , will be the projection required. So proceed for a cornice of any height within 70 feet. The above is based on the supposition that 36 inches is the proper projection for a cornice 70 feet high. This, for general purposes, will be found correct; still, the length of the line, $b c$, may be varied to suit the judgment of those who think differently.

Having obtained the projection of a cornice, divide it into 20 equal parts, and apportion the several members according to its destination—as is shown at *Fig. 195, 196, and 197*.




Fig. 201.

253.—*To proportion a cornice according to a smaller given one.* Let the cornice at *Fig. 201* be the given one. Upon any point in the lowest line of the lowest member, as at *a*, with the height of the required cornice for radius, describe an intersecting arc across the uppermost line, as at *b*; join *a* and *b*; then *b 1* will be the perpendicular height of the upper fillet for the proposed cornice, *1 2* the height of the crown moulding—and so of all the members requiring to be enlarged to the sizes indicated on this line. For the projection of the proposed cornice, draw *a d*, at right angles to *a b*, and *c d*, at right angles to *b c*; parallel with *c d*, draw lines from each projection of the given cornice to the line, *a d*; then *e d* will be the required projection for the proposed cornice, and the perpendicular lines falling upon *e d* will indicate the proper projection for the members.

254.—*To proportion a cornice according to a larger given one.* Let *A*, (*Fig. 202*,) be the given cornice. Extend *a o* to *b*, and draw *c d*, at right angles to *a b*; extend the horizontal lines of the cornice, *A*, until they touch *o d*; place the height of the proposed cornice from *o* to *e*, and join *f* and *e*; upon *o*, with the projection of the given cornice, *o a*, for radius, describe the quadrant, *a d*; from *d*, draw *d b*, parallel to *f e*; upon *o*, with *o b* for radius, describe the quadrant, *b c*; then *o c* will be the proper projection for the proposed cornice. Join *a* and *c*; draw lines from the




Fig. 208.




Fig. 204.

lel with the wall, $f d$, draw the line, $a b$; make $e c$ equal $a f$, and through c , draw $c b$, parallel with $e d$; join d and b , and from the several angular points in B , draw ordinates to cut $d b$ in 1, 2 and 3; at those points erect lines perpendicular to $d b$; from h , draw $h g$, parallel to $f a$; take the ordinates, $1 o$, $2 o$, &c., at B , and transfer them to C , and the angle-bracket, C , will be defined. In the same manner, the angle-bracket for an internal cornice, or the angle-rib of a coved ceiling, or of groins, as at *Fig. 204*, can be found.

256.—*A level crown moulding being given, to find the raking moulding and a level return at the top.* Let A , (*Fig. 205*), be the given moulding, and $A b$ the rake of the roof. Divide the curve of the given moulding into any number of parts, equal or unequal, as at 1, 2, and 3; from these points, draw horizontal lines to a perpendicular erected from c ; at any convenient place on the rake, as at B , draw $a c$, at right angles to $A b$; also, from b , draw the horizontal line, $b a$; place the thickness, $d a$, of the moulding at A , from b to a , and from a , draw the perpendicular line, $a e$; from the points, 1, 2, 3, at A , draw lines to C , parallel to $A b$; make $a 1$, $a 2$ and $a 3$, at B and at C , equal to $a 1$, &c., at A ; through the points, 1, 2 and 3, at B , trace the curve—this will be the proper form for the raking moulding. From 1, 2 and




Fig 205.

3, at *C*, drop perpendiculars to the corresponding ordinates from 1, 2 and 3, at *A*; through the points of intersection, trace the curve—this will be the proper form for the *return* at the top.

SECTION IV.—FRAMING.

257.—This subject is, to the carpenter, of the highest importance ; and deserves more attention and a larger place in a volume of this kind, than is generally allotted to it. Something, indeed, has been said upon the geometrical principles, by which the several lines for the joints and the lengths of timber, may be ascertained ; yet, besides this, there is much to be learned. For however precise or workmanlike the joints may be made, what will it avail, should the system of framing, from an erroneous position of its timbers, &c., change its form, or become incapable of sustaining even its own weight ? Hence the necessity for a knowledge of the laws of pressure and the strength of timber. These being once understood, we can with confidence determine the best position and dimensions for the several timbers which compose a floor or a roof, a partition or a bridge. As systems of framing are more or less exposed to heavy weights and strains, and, in case of failure, cause not only a loss of labour and material, but frequently that of life itself, it is very important that the materials employed be of the proper quantity and quality to serve their destination. And, on the other hand, any superfluous material is not only useless, but a positive injury, it being an unnecessary load upon the points of support. It is necessary, therefore, to know

the *least* quantity of timber that will suffice for strength. The greatest fault in framing is that of using an excess of material. Economy, at least, would seem to require that this evil be abated.

Before proceeding to consider the principles upon which a system of framing should be constructed, let us attend to a few of the elementary laws in *Mechanics*, which will be found to be of great value in determining those principles.

258.—LAWS OF PRESSURE. (1.) A heavy body always exerts a pressure equal to its own weight in a vertical direction. Example: Suppose an iron ball, weighing 100 lbs., be supported upon the top of a perpendicular post, (*Fig. 220*;) then the pressure exerted upon that post will be equal to the weight of the ball; viz., 100 lbs. (2.) But if two inclined posts, (*Fig. 206*;) be substituted for the perpendicular support, the united pressures upon these posts will be more than equal to the weight, and will be in proportion to their position. The farther apart their feet are spread the greater will be the pressure, and *vice versa*. Hence tremendous strains may be exerted by a comparatively small weight. And it follows, therefore, that a piece of timber intended for a strut or post, should be so placed that its axis may coincide, as near as possible, with the direction of the pressure. The direction of the pressure of the weight, W , (*Fig. 206*;) is in the vertical line, $b d$; and the weight, W , would fall in that line, if the two posts were removed, hence the best position for a support




Fig. 206.

for the weight would be in that line. But, as it rarely occurs in systems of framing that weights can be supported by any single resistance, they requiring generally two or more supports, (as in the case of a roof supported by its rafters,) it becomes important, therefore, to know the exact amount of pressure any certain weight is capable of exerting upon oblique supports. Now it has been ascertained that the three lines of a triangle, drawn parallel with the direction of three concurring forces in equilibrium, are in proportion respectively to these forces. For example, in *Fig. 206*, we have a representation of three forces concurring in a point, which forces are in equilibrium and at rest; thus, the weight, W , is one force, and the resistance exerted by the two pieces of timber are the other two forces. The direction in which the first force acts is vertical—downwards; the direction of the two other forces is in the axis of each piece of timber respectively. These three forces all tend towards the point, b .

Draw the axes, ab and bc , of the two supports; make bd vertical, and from d draw de and df parallel with the axes, bc and ba , respectively. Then the triangle, bde , has its lines parallel respectively with the direction of the three forces; thus, bd is in the direction of the weight, W , de parallel with the axis of the timber bc , and eb is in the direction of the timber ab . In accordance with the principle above stated, the lengths of the sides of the triangle, bde , are in proportion respectively to the three forces aforesaid; thus—

As the length of the line, bd ,

Is to the number of pounds in the weight, W ,

So is the length of the line, be ,

To the number of pounds' pressure resisted by the timber,
 ab .

Again—

As the length of the line, bd ,

Is to the number of pounds in the weight, W ,

So is the length of the line, $d e$,
 To the number of pounds' pressure resisted by the timber,
 $b c$.

And again—

As the length of the line, $b e$,
 Is to the pounds' pressure resisted by $a b$,
 So is the length of the line, $d e$,
 To the pounds' pressure resisted by $b c$.

These proportions are more briefly stated thus—

$$1st. \quad b d : W :: b e : P,$$

P being used as a symbol to represent the number of pounds' pressure resisted by the timber, $a b$.

$$2nd. \quad b d : W :: d e : Q,$$

Q representing the number of pounds' pressure resisted by the timber, $b c$.

$$3d. \quad b e : P :: d e : Q.$$

259.—This relation between lines and pressures is important, and is of extensive application in ascertaining the pressures induced by known weights throughout any system of framing. The parallelogram, $b e d f$, is called the *Parallelogram of Forces*; the two lines, $b e$ and $b f$, being called the *components*, and the line $b d$ the *resultant*. Where it is required to find the *components* from a given resultant, (*Fig.* 206,) it is not needed to draw the fourth line, $d f$, for the triangle, $b d e$, gives the desired result. But when the *resultant* is to be ascertained from given components, (*Fig.* 212,) it is more convenient to draw the fourth line.

260.—*The Resolution of Forces* is the finding of two or more forces, which, acting in different directions, shall exactly balance the pressure of any given *single* force. To make a practical application of this, let it be required to ascertain the oblique pressure in *Fig.* 206. In this *Fig.* the line $b d$ measures half an inch, (0.5 inch,) and the line $b e$ three-tenths of an inch, (0.3 inch.) Now if the weight, W , be sup-

posed to be 1200 pounds, then the first stated proportion above,

$$b d : W :: b e : P,$$

becomes

$$0.5 : 1200 :: 0.3 : P:$$

And since the product of the means divided by one of the extremes gives the other extreme, this proportion may be put in the form of an *equation*, thus—

$$\frac{1200 \times 0.3}{0.5} = P.$$

Performing the arithmetical operation here indicated, that is, multiplying together the two quantities above the line, and dividing the product by the quantity under the line, the quotient will be equal to the quantity represented by P , viz., the pressure resisted by the timber, $a b$. Thus—

$$\begin{array}{r} 1200 \\ 0.3 \\ \hline 0.5 \overline{)360.0} \\ \hline 720 = P. \end{array}$$

The strain upon the timber, $a b$, is, therefore, equal to 720 pounds; and the strain upon the other timber, $b c$, is also 720 pounds; for in this case, the two timbers being inclined equally from the vertical, the line $e d$ is therefore equal to the line $b e$.




Fig. 207.

261.—In *Fig.* 207, the two supports are inclined at different angles, and the pressures are proportionately unequal. The supports are also unequal in length. The length of the supports does not alter the amount of pressure from the concentrated load supported; but generally long timbers are not so capable of resistance as shorter ones. They yield more readily laterally, as they are not so stiff, and shorten more, as the compression is in proportion to the length. To ascertain the pressures in *Fig.* 207, let the weight suspended from $b d$ be equal to two and three-quarter tons, (2.75 tons.) The line $b d$ measures five and a half tenths of an inch, (0.55 inch,) and the line $b e$ half an inch, (0.5 inch.) Therefore, the proportion

$b d : W :: b e : P$, becomes $0.55 : 2.75 :: 0.5 : P$,

$$\text{and } \frac{2.75 \times 0.5}{0.55} = P.$$

$$\frac{2.75}{0.5}$$

$$0.55)1.375(2.5 = P.$$

$$\frac{275}{275}$$

The strain upon the timber, $b e$, is, therefore, equal to two and a half tons.

Again, the line $e d$ measures four-tenths of an inch, (0.4 inch;) therefore, the proportion

$b d : W :: e d : Q$, becomes $0.55 : 2.75 :: 0.4 : Q$,

$$\text{and } \frac{2.75 \times 0.4}{0.55} = Q.$$

$$\frac{2.75}{0.4}$$

$$0.55)1.100(2 = Q.$$

$$\frac{110}{110}$$

The strain upon the timber, $b f$, is, therefore, equal to two tons.

262.—Thus it is seen that the united pressures exerted by a weight upon two inclined supports always exceed the weight. In the last case $2\frac{3}{4}$ tons exerts a pressure of $2\frac{1}{2}$ and two tons, equal together to $4\frac{1}{2}$ tons; and in the former case, 1200 pounds exerts a pressure of twice 720 pounds, equal to 1440 pounds. The smaller the angle of inclination to the horizontal, the greater will be the pressure upon the supports. So, in the frame of a roof, the strain upon the rafters decreases gradually with the increase of the angle of inclination to the horizon, the length of the rafter remaining the same.

263.—This is true in comparing systems of framing with each other; but in a system where the concentrated weight to be supported is not in the middle, (see *Fig.* 207,) and, in consequence, the supports are not inclined equally, the strain will be *greatest* upon the support that has the greatest inclination to the horizon.

264.—In ordinary cases, in roofs for example, the load is not concentrated but is that of the framing itself. Here the *amount* of the load will be in proportion to the length of the rafter, and the rafter increases in length with the increase of the angle of inclination, the span remaining the same. So it is seen that in enlarging the angle of inclination to the horizon in order to lessen the oblique thrust, the load is increased in consequence of the elongation of the rafter, thus increasing the oblique thrust. Hence there is a limit to the angle of inclination. A rafter will have the least oblique thrust when its angle of inclination to the horizon is $35^{\circ} 16'$ nearly. This angle is attained very nearly when the rafter rises $8\frac{1}{2}$ inches per foot; or, when the height, $B C$, (*Fig.* 216,) is to the base, $A C$, as $8\frac{1}{2}$ is to 12, or as 0.7071 is to 1.0.

265.—Correct ideas of the comparative pressures exerted upon timbers, according to their position, will be readily

formed by drawing various designs of framing, and estimating the several strains in accordance with the parallelogram of forces, always drawing the triangle, $b d e$, so that the three lines shall be parallel with the three forces, or pressures; respectively. The *length* of the lines forming this triangle is unimportant, but it will be found more convenient if the line drawn parallel with the *known* force is made to contain as many inches as the known force contains pounds, or as many tenths of an inch as pounds, or as many inches as tons, or tenths of an inch as tons: or, in general, as many divisions of any convenient scale as there are units of weight or pressure in the known force. If drawn in this manner, then the number of divisions of the same scale found in the other two lines of the triangle will equal the units of pressure or weight of the other two forces respectively, and the pressures sought will be ascertained simply by applying the scale to the lines of the triangle.

For example, in *Fig. 207*, the vertical line, $b d$, of the triangle, measures fifty-five hundredths of an inch, (0.55 inch;) the line, $b e$, fifty-hundredths, (0.50 inch;) and the line, $e d$, forty, (0.40 inch.) Now, if it be supposed that the vertical pressure, or the weight suspended below $b d$, is equal to 55 pounds, then the pressure on $b e$ will equal 50 pounds, and that on $e d$ will equal 40 pounds; for, by the proportion above stated,

$$\begin{aligned} b d : W :: b e : P, \\ 55 : 55 :: 50 : 50 ; \end{aligned}$$

and so of the other pressure.

266.—If a scale cannot be had of equal proportions with the forces, the arithmetical process will be shortened somewhat by making the line of the triangle that represents the *known* weight equal to unity of a decimally divided scale, then the other lines will be measured in tenths or hundredths; and in the numerical statement of the proportions between the lines and forces, the first term being unity, the fourth term will be

ascertained simply by multiplying the second and third terms together.

For example, if the three lines are 1, 0·7 and 1·3, and the known weight is 6 tons, then

$$b d : W :: b e : P, \text{ becomes}$$

$$1 : 6 :: 0\cdot7 : P = 4\cdot2,$$

equals four and two-tenths tons. Again—

$$b d : W :: e d : Q, \text{ becomes}$$

$$1 : 6 :: 1\cdot3 : Q = 7\cdot8,$$

equals seven and eight-tenths tons.




Fig. 208.

267.—In *Fig.* 208 the weight, W , exerts a pressure on the struts in the direction of their length; their feet, $n n$, have, therefore, a tendency to move in the direction $n o$, and would so move, were they not opposed by a sufficient resistance from the blocks, A and A . If a piece of each block be cut off at the horizontal line, $a n$, the feet of the struts would slide away from each other along that line, in the direction, $n a$; but if, instead of these, two pieces were cut off at the vertical line, $n b$, then the struts would descend vertically. To estimate the horizontal and the vertical pressures exerted by the struts, let $n o$ be made equal (upon any scale of equal parts) to the num-

ber of tons with which the strut is pressed; construct the parallelogram of forces by drawing oe parallel to an , and of parallel to bn ; then nf , (by the same scale,) shows the number of tons pressure that is exerted by the strut in the direction na , and ne shows the amount exerted in the direction nb . By constructing designs similar to this, giving various and dissimilar positions to the struts, and then estimating the pressures, it will be found in every case that the horizontal pressure of one strut is exactly equal to that of the other, however much one strut may be inclined more than the other; and also, that the united vertical pressure of the two struts is exactly equal to the weight, W . (In this calculation the weight of the timbers has not been taken into consideration, simply to avoid complication to the learner. In practice it is requisite to include the weight of the framing with the load upon the framing.)




Fig. 209.

268.—Suppose that the two struts, B and B , (*Fig. 208*;) were rafters of a roof, and that instead of the blocks, A and A , the walls of a building were the supports: then, to prevent the walls from being thrown over by the thrust of B and B , it would be desirable to remove the horizontal pressure. This

may be done by uniting the feet of the rafters with a rope, iron rod, or piece of timber, as in *Fig. 209*. This figure is similar to the truss of a roof. The horizontal strains on the tie-beam, tending to pull it asunder in the direction of its length, may be measured at the foot of the rafter, as was shown at *Fig. 208*; but it can be more readily and as accurately measured, by drawing from f and e horizontal lines to the vertical line, $b d$, meeting it in o and o ; then $f o$ will be the horizontal thrust at B , and $e o$ at A ; these will be found to equal one another. When the rafters of a roof are thus connected, all tendency to thrust the walls horizontally is removed, the only pressure on them is in a vertical direction, being equal to the weight of the roof and whatever it has to support. This pressure is beneficial rather than otherwise, as a roof having trusses thus formed, and the trusses well braced to each other, tends to steady the walls.




Fig. 210.





Fig. 211.

269.—*Fig. 210* and *211* exhibit methods of framing for supporting the equal weights, W and W . Suppose it be required

to measure and compare the strains produced on the pieces, $A B$ and $A C$. Construct the parallelogram of forces, $e b f d$, according to *Art.* 258. Then $b f$ will show the strain on $A B$, and $b e$ the strain on $A C$. By comparing the figures, $b d$ being equal in each, it will be seen that the strains in *Fig.* 210 are about three times as great as those in *Fig.* 211: the position of the pieces, $A B$ and $A C$, in *Fig.* 211, is therefore far preferable.



C Fig. 212.

270.—The *Composition of Forces* consists in ascertaining the direction and amount of *one* force, which shall be just capable of balancing *two or more* given forces, acting in different directions. This is only the reverse of the resolution of forces, and the two are founded on one and the same principle, and may be solved in the same manner. For example, let A and B , (*Fig.* 212,) be two pieces of timber, pressed in the direction of their length towards b — A by a force equal to 6 tons weight, and B equal to 9. To find the *direction* and *amount* of pressure they would unitedly exert, draw the lines, $b e$ and $b f$, in a line with the axes of the timbers, and make $b e$ equal to the pressure exerted by B , viz., 9; also make $b f$ equal to the pressure on A , viz., 6, and complete the parallelogram of forces, $e b f d$; then $b d$, the diagonal of the parallelogram, will be the *direction*, and its length, 9.25, will be the *amount*,

of the united pressures of A and of B . The line, $b d$, is termed the *resultant* of the two forces, $b f$ and $b a$. If A and B are to be supported by one post, C , the best position for that post will be in the direction of the diagonal, $b d$; and it will require to be sufficiently strong to support the united pressures of A and of B , which are equal to 9.25 or $9\frac{1}{4}$ tons.




Fig. 213.

271.—Another example: let *Fig. 213* represent a piece of framing commonly called a crane, which is used for hoisting heavy weights by means of the rope, $B b f$, which passes over a pulley at b . This is similar to *Fig. 210* and *211*, yet it is materially different. In those figures, the strain is in one direction only, viz., from b to d ; but in this there are two strains, from A to B and from A to W . The strain in the direction $A B$ is evidently equal to that in the direction $A W$. To ascertain the best position for the strut, $A C$, make $b e$ equal to $b f$, and complete the parallelogram of forces, $e b f d$; then draw the diagonal, $b d$, and it will be the position required. Should the foot, C , of the strut be placed either higher or lower, the strain on $A C$ would be increased. In constructing cranes, it is advisable, in order that the piece, $B A$, may be under a gentle pressure, to place the foot of the

strut a trifle lower than where the diagonal, $b d$, would indicate, but never higher.




Fig. 214.

272.—*Ties and Struts.* Timbers in a state of tension are called *ties*, while such as are in a state of compression are termed *struts*. This subject can be illustrated in the following manner:

Let A and B , (*Fig. 214*), represent beams of timber supporting the weights, W , W and W ; A having but one support, which is in the middle of its length, and B two, one at each end. To show the nature of the strains, let each beam be sawed in the middle from a to b . The effects are obvious: the cut in the beam, A , will open, whereas that in B will close. If the weights are heavy enough, the beam, A , will break at b ; while the cut in B will be closed perfectly tight at a , and the beam be very little injured by it. But if, on the other hand, the cuts be made in the bottom edge of the timbers, from c to b , B will be seriously injured, while A will scarcely be affected. By this it appears evident that, in a piece of timber subject to a pressure across the direction of its length, the fibres are exposed to contrary strains. If the timber is supported at both ends, as at B , those from the top edge down to the middle are compressed in the direction of their length, while those from the middle to the bottom edge are in a state of tension; but if the beam is supported as at A , the contrary effect is produced; while the fibres at the middle of either beam are not at all strained. The strains in a framed

truss are of the same nature as those in a single beam. The truss for a roof, being supported at each end, has its tie-beam in a state of tension, while its rafters are compressed in the direction of their length. By this, it appears highly important that pieces in a state of tension should be distinguished from such as are compressed, in order that the former may be preserved continuous. A strut may be constructed of two or more pieces; yet, where there are many joints, it will not resist compression so well.

273.—*To distinguish ties from struts.* This may be done by the following rule. In *Fig. 206*, the timbers, $a b$ and $b c$, are the *sustaining* forces, and the weight, W , is the *straining* force; and, if the support be removed, the straining force would move from the point of support, b , towards d . Let it be required to ascertain whether the sustaining forces are *stretched* or *pressed* by the straining force. *Rule:* upon the direction of the straining force, $b d$, as a diagonal, construct a parallelogram, $e b f d$, whose sides shall be parallel with the direction of the sustaining forces, $a b$ and $c d$; through the point, b , draw a line, parallel to the diagonal, $e f$; this may then be called the dividing line between ties and struts. Because all those supports which are on that side of the dividing line, which the straining force would occupy if unresisted, are compressed, while those on the other side of the dividing line are stretched.

In *Fig. 206*, the supports are both compressed, being on that side of the dividing line which the straining force would occupy if unresisted. In *Fig. 210* and *211*, in which $A B$ and $A C$ are the sustaining forces, $A C$ is compressed, whereas $A B$ is in a state of tension; $A C$ being on that side of the line, $h i$, which the straining force would occupy if unresisted, and $A B$ on the opposite side. The place of the latter might be supplied by a chain or rope. In *Fig. 209*, the foot of the rafter at A is sustained by two forces, the wall and the tie-

beam, one perpendicular and the other horizontal: the direction of the straining force is indicated by the line, $b a$. The dividing line, $h i$, ascertained by the rule, shows that the wall is pressed and the tie-beam stretched.




Fig. 215.

274.—Another example: let $E A B F$, (*Fig. 215*,) represent a gate, supported by hinges at A and E . In this case, the *straining force* is the weight of the materials, and the direction of course *vertical*. Ascertain the dividing line at the several points, G, B, I, J, H and F . It will then appear that the force at G is sustained by $A G$ and $G E$, and the dividing line shows that the former is stretched and the latter compressed. The force at H is supported by $A H$ and $H E$ —the former stretched and the latter compressed. The force at B is opposed by $H B$ and $A B$, one pressed, the other stretched. The force at F is sustained by $G F$ and $F E$, $G F$ being stretched and $F E$ pressed. By this it appears that $A B$ is in a state of tension, and $E F$, of compression; also, that $A H$ and $G F$ are stretched, while $B H$ and $G E$ are compressed: which shows the necessity of having $A H$ and $G F$, each in one whole length, while $B H$ and $G E$ may be, as they are shown, each in two pieces. The force at J is sustained by $G J$ and $J H$, the former stretched and the latter compressed.

The piece, CD , is neither stretched nor pressed, and could be dispensed with if the joinings at J and I could be made as effectually without it. In case AB should fail, then CD would be in a state of tension.

275.—*The centre of gravity.* The centre of gravity of a uniform prism or cylinder, is in its axis, at the middle of its length; that of a triangle, is in a line drawn from one angle to the middle of the opposite side and at one-third of the length of the line from that side; that of a right-angled triangle, at a point distant from the perpendicular equal to one-third of the base, and distant from the base equal to one-third of the perpendicular; that of a pyramid or cone, in the axis and at one-quarter of the height from the base.

276.—The centre of gravity of a trapezoid, (a four-sided figure having only two of its sides parallel,) is in a line joining the centres of the two parallel sides, and at a distance from the longest of the parallel sides equal to the product of the length into the sum of twice the shorter added to the longer of the parallel sides, divided by three times the sum of the two parallel sides. Algebraically thus—

$$d = \frac{l(2a + b)}{3(a + b)}$$

where d equals the distance from the longest of the parallel sides, l the length of the line joining the two parallel sides, and a the shorter and b the longer of the parallel sides.

Example.—A rafter, 25 feet long, has the larger end 14 inches wide, and the smaller end 10 inches wide, how far from the larger end is the centre of gravity located?

Here, $l = 25$, $a = \frac{10}{12}$, and $b = \frac{14}{12}$,

$$\text{hence } d = \frac{l(2a + b)}{3(a + b)} = \frac{25(2 \times \frac{10}{12} + \frac{14}{12})}{3(\frac{10}{12} + \frac{14}{12})} = \frac{25 \times \frac{34}{12}}{3 \times \frac{24}{12}} =$$

$$\frac{25 \times 34}{3 \times 24} = \frac{850}{72} = 11.8 = 11 \text{ feet } 9\frac{1}{2} \text{ inches nearly.}$$

In irregular bodies with plain sides, the centre of gravity

may be found by balancing them upon the edge of a prism—upon the edge of a table—in two positions, making a line each time upon the body in a line with the edge of the prism, and the intersection of those lines will indicate the point required. Or suspend the article by a cord or thread attached to one corner or edge; also, from the same point of suspension, hang a plumb-line, and mark its position on the face of the article; again, suspend the article from another corner or side, (nearly at right angles to its former position,) and mark the position of the plumb-line upon its face; then the intersection of the two lines will be the centre of gravity.




Fig. 216.

277.—*The effect of the weight of inclined beams.* An inclined post or strut, supporting some heavy pressure applied at its upper end, as at *Fig. 209*, exerts a pressure at its foot in the direction of its length, or nearly so. But when such a beam is loaded uniformly over its whole length, as the rafter of a roof, the pressure at its foot varies considerably from the direction of its length. For example, let *AB*, (*Fig. 216*), be a beam leaning against the wall, *Bc*, and supported at its foot by the abutment, *A*, in the beam, *Ae*, and let *o* be the centre of gravity of the beam. Through *o*, draw the vertical line, *bd*, and from *B*, draw the horizontal line, *Bb*, cutting *bd* in *b*; join *b* and *A*, and *ba* will be the *direction* of the thrust. To prevent the beam from losing its footing, the joint at *A* should be made at right angles to *ba*. The *amount* of pressure will be found thus: let *bd*, (by any scale of equal

parts,) equal the number of tons upon the beam, $A B$; draw $d e$, parallel to $B b$; then $b e$, (by the same scale,) equals the pressure in the direction, $b A$; and $e d$, the pressure against the wall at B —and also the horizontal thrust at A , as these are always equal in a construction of this kind.

278.—The horizontal thrust of an inclined beam, (*Fig.* 216,)—the effect of its own weight—may be calculated thus :

Rule.—Multiply the weight of the beam in pounds by its base, $A C$, in feet, and by the distance in feet of its centre of gravity, o , (see *Art.* 275 and 276,) from the lower end, at A ; and divide this product by the product of the length, $A B$, into the height, $B C$, and the quotient will be the horizontal thrust in pounds. This may be stated thus: $H = \frac{d b w}{h l}$, where

d equals the distance of the centre of gravity, o , from the lower end; b equals the base, $A C$; w equals the weight of the beam; h equals the height, $B C$; l equals the length of the beam; and H equals the horizontal thrust.

Example.—A beam, 20 feet long, weighs 300 pounds; its centre of gravity is at 9 feet from its lower end; it is so inclined that its base is 16 feet and its height 12 feet; what is the horizontal thrust?

Here $\frac{d b w}{h l}$ becomes $\frac{9 \times 16 \times 300}{12 \times 20} = \frac{9 \times 4 \times 25}{5} = 9 \times 4 \times 5$
 $= 180 = H =$ the horizontal thrust.

This rule is for cases where the centre of gravity does not occur at the middle of the length of the beam, although it is applicable when it *does* occur at the middle; yet a shorter rule will suffice in this case,—and it is thus:—

Rule.—Multiply the weight of the rafter in pounds by the base, $A C$, (*Fig.* 216,) in feet, and divide the product by twice the height, $B C$, in feet; and the quotient will be the horizontal thrust, when the centre of gravity occurs at the middle of the beam.

If the inclined beam is loaded with an equally distributed load, add this load to the weight of the beam, and use this *total* weight in the rule instead of the weight of the beam. And generally, if the centre of gravity of the combined weights of the beam and load does not occur at the centre of the length of the beam then the former rule is to be used.




Fig. 217.

279.—In *Fig. 217*, two equal beams are supported at their feet by the abutments in the tie-beam. This case is similar to the last; for it is obvious that each beam is in precisely the position of the beam in *Fig. 216*. The horizontal pressures at *B*, being equal and opposite, balance one another; and their horizontal thrusts at the tie-beam are also equal. (See *Art. 268—Fig. 209*.) When the height of a roof, (*Fig. 217*), is one-fourth of the span, or of a shed, (*Fig. 216*), is one-half the span, the horizontal thrust of a rafter, whose centre of gravity is at the middle of its length, is exactly equal to the weight distributed uniformly over its surface.




Fig. 218.

280.—In shed, or *lean-to* roofs, as *Fig.* 216, the horizontal pressure will be entirely removed, if the bearings of the rafters, as *A B*, (*Fig.* 218,) are made horizontal—provided, however, that the rafters and other framing do not bend between the points of support. If a beam or rafter have a natural curve, the convex or rounding edge should be laid uppermost.

281.—A beam laid horizontally, supported at each end and uniformly loaded, is subject to the greatest strain at the middle of its length. Hence mortices, large knots and other defects, should be kept as far as possible from that point; and, in resting a load upon a beam, as a partition upon a floor beam, the weight should be so adjusted, if possible, that it will bear at or near the ends.

Twice the weight that will break a beam, acting at the centre of its length, is required to break it when equally distributed over its length; and precisely the same deflection or *sag* will be produced on a beam by a load equally distributed, that five-eighths of the load will produce if acting at the centre of its length.

282.—When a beam, supported at each end on horizontal bearings, (the beam itself being either horizontal or inclined,) has its load equally distributed, the amount of pressure caused by the load on each point of support is equal to one half the load; and this is also the case, when the load is concentrated at the middle of the beam, or has its centre of gravity at the middle of the beam; but, when the load is unequally distributed or concentrated, so that its centre of gravity occurs at some other point than the middle of the beam, then the amount of pressure caused by the load on one of the points of support is unequal to that on the other. The precise amount on each may be ascertained by the following rule.

Rule.—Multiply the weight *w*, (*Fig.* 219,) by its distance, *CB*, from its nearest point of support, *B*, and divide the product by the length, *AB*, of the beam, and the quotient will be the




Fig. 219.

amount of pressure on the *remote* point of support, *A*. Again, deduct this amount from the weight, *w*, and the remainder will be the amount of pressure on the *near* point of support, *B*; or, multiply the weight, *w*, by its distance, *AC*, from the remote point of support, *A*, and divide the product by the length, *AB*, and the quotient will be the amount of pressure on the *near* point of support, *B*.

When *l* equals the length, *AB*; *a* = *AC*; *b* = *CB*, and *w* = the load, then

$$\frac{w b}{l} = A = \text{the amount of pressure at } A, \text{ and}$$

$$\frac{w a}{l} = B = \text{the amount of pressure at } B.$$

Example.—A beam, 20 feet long between the bearings, has a load of 100 pounds concentrated at 3 feet from one of the bearings, what is the portion of this weight sustained by each bearing?

Here *w* = 100; *a*, 17; *b*, 3; and *l*, 20.

$$\text{Hence } A = \frac{w b}{l} = \frac{100 \times 3}{20} = 15.$$

$$\text{And } B = \frac{w a}{l} = \frac{100 \times 17}{20} = 85.$$

Load on *A* = 15 pounds.

Load on *B* = 85 pounds.

Total weight = 100 pounds.

RESISTANCE OF MATERIALS.

283.—Before a roof truss, or other piece of framing, can be properly designed, two things are required to be known. The one is, the effect of gravity acting upon the various parts of the intended structure; the other, the power of resistance possessed by the materials of which the framing is to be constructed. In the preceding pages, the former subject having been treated of, it remains now to call attention to the latter.

284.—Materials used in construction are constituted in their structure either of fibres (threads) or of grains, and are termed, the former fibrous, the latter granular. All woods and wrought metals are fibrous, while cast iron, stone, glass, &c., are granular. The strength of a granular material lies in the power of attraction, acting among the grains of matter of which the material is composed, by which it resists any attempt to separate its grains or particles of matter. A fibre of wood or of wrought metal has a strength by which it resists being compressed or shortened, and finally crushed; also a strength by which it resists being extended or made longer, and finally sundered. There is another kind of strength in a fibrous material; it is the adhesion of one fibre to another along their sides, or the lateral adhesion of the fibres.

285.—In the strain applied to a piece of timber, as a post supporting a weight imposed upon it, (*Fig.* 220,) we have an instance of an attempt to shorten the fibres of which the timber is composed. The strength of the timber in this case is termed the *resistance to compression*. In the strain on a piece of timber like a king-post or suspending piece, (*A*, *Fig.* 221,) we have an instance of an attempt to extend or lengthen the fibres of the material. The strength here exhibited is termed the *resistance to tension*. When a piece of timber is strained like a floor beam, or any horizontal piece carrying a load, (*Fig.* 222,) we have an instance in which the two strains of




Fig. 220.




Fig. 221.




Fig. 222.

compression and tension are brought into action; the fibres of the upper portion of the beam being compressed, and those of the under part being stretched. This kind of strength of timber is termed *resistance to cross strains*. In each of these three kinds of strain to which timber is subjected, the power of resistance is in a measure due to the *lateral* adhesion of the fibres, not so much perhaps in the simple tensile strain, yet to a considerable degree in the compressive and cross strains. But the power of timber, by which it resists a pressure acting compressively in the direction of the length of the fibres, tending to separate the timber by splitting off a part, as in the case of the end of a tie beam, against which the foot of the rafter presses—is wholly due to the lateral adhesion of the fibres.

286.—The *strength* of materials is that power by which they resist *fracture*, while the *stiffness* of materials is that quality which enables them to resist *deflection* or sagging. A knowledge of their *strength* is useful, in order to determine their

limits of size to sustain given weights safely ; but a knowledge of their *stiffness* is more important, as in almost all constructions it is desirable not only that the load be safely sustained, but that no appearance of weakness be manifested by any sensible deflection or sagging.

I.—RESISTANCE TO COMPRESSION.

287.—The resistance of materials to the force of compression may be considered in four several ways, viz. :

1st. When the pressure is applied to the fibres longitudinally, and on short pieces.

2d. When the pressure is applied to the fibres longitudinally, and on long pieces.

3d. When the pressure is applied to the fibres longitudinally, and so as to split off the part pressed against, causing the fibres to separate by sliding.

4th. When the pressure is applied to the fibres transversely.

Posts having their height less than ten times their least side will crush before bending ; these belong to the first case : while posts, whose height is ten times their least side, or more than ten times, will bend before crushing ; these belong to the second case.

288.—In the above first and fourth cases of compression, experiment has shown that the resistance is in proportion to the number of fibres pressed, that is, in proportion to the area. For example, if 5,000 pounds is required to crush a prism with a base 1 inch square, it will require 20,000 pounds to crush a prism having a base of 2 by 2 inches, equal to 4 inches area ; because 4 times 5,000 equals 20,000. Experiment has also shown that, in the third case, the resistance is in proportion to the area of the surface separated without regard to the form of the surface.

289.—In the second case of compression, the resistance is in

proportion to the area of the cross section of the piece, multiplied by the square of its thickness, and inversely in proportion to the square of the length, multiplied by the weight. When the piece is square, it will bend and break in the direction of its diagonal ; here, the resistance is in proportion to the square of the diagonal multiplied by the square of the diagonal, and inversely proportional to the square of the length multiplied by the weight. If the piece is round or cylindrical, its resistance will be in accordance with the square of the diameter multiplied by the square of the diameter, and inversely proportional to the square of the length, multiplied by the weight.

290.—These relations between the dimensions of the piece strained and its resistance, have resulted from the discussion of the subject by various authors, and rules based upon these relations are in general use, yet their accuracy is not fully established. Some experiments, especially those by Prof. Hodgkinson, have shown that the resistance is in proportion to a less power of the diameter, and inversely to a less power of the height ; yet the variance is not great, and inasmuch as the material is restricted in the rules to a strain decidedly within its limits of resistance, no serious error can be made in the use of rules based on the aforesaid relations.

291.—*Experiments.* In the investigation of the laws applicable to the resistance of materials, only such of the relations of the parts have been considered as apply alike to wood and metal, stone and glass, or other material, leaving to experiment the task of ascertaining the compactness and cohesion of particles, and the tenacity and adhesion of fibres ; those qualities upon which depend the superiority of one kind of material over another, and which is represented in the rules by a *constant* number, each specific kind of material having its own special *constant*, obtained by experimenting on specimens of that peculiar material.

292.—The following table exhibits the results of experiments on such woods as are in most common use in this country for the purpose of construction. The resistance of timber of the

TABLE I.—COMPRESSION.

Kind of Material.	Specific Gravity.	To crush Fibres longitudinally.	Value of <i>C</i> in the Rules.	Pressure applied longitudinally to separate Fibres.	Value of <i>H</i> in the Rules.	To crush Fibres transversely $\frac{7}{16}$ inch deep.	Value of <i>P</i> in the Rules. Sensible Impression.
		Pounds per in.		Pounds per in.		Pounds per in.	
White wood,397	2432	600			600	300
Mahogany (Baywood),439	3527	880			1300	650
Ash,517	4175	1040			2300	1150
Spruce,369	4199	1050	470	160	500	250
Chestnut,491	4791	1200	690	230	950	475
White pine,388	4806	1200	490	160	600	300
Ohio pine,586	4809	1200	388	130	1250	625
Oak,612	5316	1330	780	260	1900	950
Hemlock,423	5400	1350	540	180	600	300
Black walnut,421	5594	1400			1600	800
Maple,574	6061	1515			2050	1025
Cherry,494	6477	1620			1900	950
White oak,774	6660	1665			2000	1000
Georgia pine,613	6767	1700	510	170	1700	850
Locust,762	7652	1910	1180	400	2100	1050
Live oak,916	7936	1980			5100	2550
Mahogany (St. Domingo),837	8280	2070			4300	2150
Lignum vitæ,	1.282	8650	2160			5800	2900
Hickory,877	9817	2450			3100	1550

same name varies much ; depending as it obviously must on the soil in which it grew, on its age before and after cutting, on the time of year when cut, and on the manner in which it has been kept since it was cut. And of wood from the same tree, much depends upon its location, whether at the butt or towards the limbs, and whether at the heart or at the sap, or at a point midway from the centre to the circumference of the tree. The pieces submitted to experiment were of ordinary good quality, such as would be deemed proper to be used in framing. The prisms crushed were 2 inches long, and from 1 inch to $1\frac{1}{2}$ inches square ; some were wider one way than the

other, but all containing in area of cross section from 1 to 2 inches. There were generally three specimens of each kind. The weight given in the table is the average crushing weight per superficial inch.

In the preceding table the first column contains the specific gravity of the several kinds of wood, showing their comparative density. The weight in pounds of a cubic foot of any kind of wood or other material, is equal to its specific gravity multiplied by 62.5; this number being the weight in pounds of a cubic foot of water. The second column contains the weight in pounds required to crush a prism having a base of one inch square; the pressure applied to the fibres longitudinally. The third column contains the value of C in the rules; C being equal to one-fourth of the crushing weight in the preceding column. The fourth column contains the weight in pounds, which, applied to the fibres longitudinally, is required to force off a part of the piece, causing the fibres to separate by sliding, the surface separated being one inch square. The fifth column contains the value of H in the rules, H being equal to one third of the weight in the preceding column. The sixth column contains the weight in pounds required to crush the piece when the pressure is applied to the fibres transversely, the piece being one inch thick, and the surface crushed being one inch square, and depressed one twentieth of an inch deep. The seventh column contains the value of P in the rules; P being the weight in pounds applied to the fibres transversely, which is required to make a sensible impression one inch square on the side of the piece, this being the greatest weight that would be proper for a post to be loaded with per inch surface of bearing, resting on the side of the kind of wood set opposite in the table. A greater weight would, in proportion to the excess, crush the side of the wood under the post, and proportionably derange the framing, if not cause a total failure. It will be observed that the measure of

this resistance is useful in limiting the load on a post according to the kind of material contained, not in the *post*, but in the *timber upon which* the post presses.

293.—In Table II. are the results of experiments made to test the resistance of materials to flexure: first, the flexure produced by compression, the force acting on the ends of the fibres longitudinally; secondly, the flexure arising from the effects of a cross strain, the force acting on the side of the fibres transversely, the beams being laid on chairs or rests. Of white oak, No. 1, there were eight specimens, of 2 by 4 inches, and $3\frac{1}{2}$ feet long, seasoned more than a year after they were prepared for experiment. Of the other kinds of wood there were from three to five specimens of each, of $1\frac{1}{4}$ by $2\frac{1}{4}$ inches, and from $1\frac{1}{2}$ to $2\frac{1}{4}$ feet long. Of the cast iron there were six specimens, of 1 inch square and 1 foot long; and of the wrought iron there were five specimens of American, three of $\frac{3}{4}$ by 2 inches, and two of $1\frac{1}{8}$ inches square, and three specimens of common English, $\frac{1}{2}$ by 2 inches; the eight specimens being each 19 inches long, clear bearing. In each case the result is the average of the stiffness of the several specimens. The numbers contained in the second column are the weights producing the first degree of flexure in a post or strut, where the post or strut is one foot long and one inch square; so, likewise, the numbers in the fifth column, and which are represented in the rules by E , are the weights required to deflect a beam one inch, where the beam is one foot long, clear bearing, and one inch square.—(See remarks upon this, Art. (321.) The numbers in the third column are equal to one-half of those in the second. The numbers contained in the fourth column, and represented by n in the rules, show the greatest *rate* of deflection that the material may be subjected to without injury. This rate multiplied by the length in feet, equals the total deflection within the limits of elasticity.

TABLE II.—FLEXURE.

Kind of Material.	Specific Gravity.	Under Compression.		Under Cross Strain.	
		Pounds producing the first degree of flexure.	Value of <i>B</i> in the Rules.	Value of <i>n</i> in the Rules.	Value of <i>E</i> in the Rules
Hemlock,	0·402	2640	1320	0·08794	1240
Spruce,	·432	4190	2095	0·09197	1550
White pine,	·407	2350	1175	0·1022	1750
Ohio yellow pine,	·586	6000	3000	0·049	1970
Chestnut,	·52	7720	3860	0·07541	2380
White oak, No. 1,	·82			0·09152	2520
White oak, No. 2,	·803	6950	3475	0·0567	2590
Georgia pine,	·755	9660	4830	0·07723	2970
Locust,	·863	10920	5460	0·06615	3280
Cast iron,	7·042			0·0148	30500
Wrought iron, common English,	7·576			0·03717	45500
Wrought iron, American,	7·576			0·04038	51400

PRACTICAL RULES FOR COMPRESSION.

First Case.

294.—To find the weight that can be safely sustained by a post, when the height of the post is less than ten times the diameter if round, or ten times the thickness if rectangular, and the direction of the pressure coinciding with the axis.

Rule I.—Multiply the area of the cross-section of the post, in inches, by the value of *C* in Table I., the product will be the required weight in pounds.

$$A C = w. \quad (1.)$$

Example.—A Georgia pine post is 6 feet high, and in cross-section, 8 × 12 inches, what weight will it safely sustain? The area = 8 × 12 = 96 inches; this multiplied by 1700, the value of *C*, in the table, set opposite Georgia pine, the result, 163,200, is the weight in pounds required. It will be observed that the weight would be the same for a Georgia pine post of any height less than 10 times 8 inches = 80 inches = 6 feet 8

inches, provided its breadth and thickness remain the same, 12 and 8 inches.

295.—To find the area of the cross-section of a post to sustain a given weight safely, the height of the post being less than ten times the diameter if round, or ten times the least side if rectangular; the pressure coinciding with the axis.

Rule II.—Divide the given weight in pounds by the value of C , in Table I., and the product will be the required area in inches

$$\frac{w}{C} = A. \quad (2.)$$

Example.—A weight of 38,400 pounds is to be sustained by a white pine post 4 feet high, what must be its area of section in order to sustain the weight safely? Here, 38,400 divided by 1200, the value of C , in Table I., set opposite white pine, gives a quotient of 32; this, therefore, is the required area, and such a post may be 5×6.4 inches. To find the least side, so that it shall not be less than one-tenth of the height, divide the height, reduced to inches, by 10, and make the least side to exceed this quotient. The area, divided by the least side so determined, will give the wide side. If, however, by this process, the first side found should prove to be the greatest, then the size of the post is to be found by Rule VII., VIII., or IX.

296.—If the post is to be round, by reference to the Table of Circles in the Appendix, the diameter will be found in the column of diameters, set opposite to the area of the post found in the column of areas, or opposite to the next nearest area. For example, suppose the required area, as just found by the example under Rule II., is 32; by reference to the column of areas, 33.183 is the nearest to 32, and the diameter set opposite is 6.5. The post may, therefore, be $6\frac{1}{2}$ inches diameter.

Second Case.

297.—To ascertain the weight that can be sustained safely

by a post whose height is, at least, ten times its least side if rectangular, or ten times its diameter if round, the direction of the pressure coinciding with the axis.

Rule III.—When the post is round the weight may be found by this rule: Multiply the square of the diameter in inches by the square of the diameter in inches, and multiply the product by 0.589 times the value of B , in Table II., divide this product by the square of the height in feet, and the quotient will be the required weight in pounds.

$$w = \frac{0.589 B D^2 D^2}{h^2} = \frac{0.589 B D^4}{h^2} \quad (3.)$$

Example.—What weight will a Georgia pine post sustain safely, whose diameter is 10 inches and height 10 feet? The square of the diameter is 100; $100 \times 100 = 10,000$. And 10,000 by 0.589 times 4830, the value of B , Table II., set opposite Georgia pine, = 28,448,700, and this divided by 100, the square of the height, equals 284,487, the weight required, in pounds.

Rule IV.—If the post be rectangular the weight is found by this rule: Multiply the area of the cross-section of the post by the square of the thickness, both in inches, and by the value of B , Table II. Divide the product by the square of the height in feet, and the quotient will be the required weight in pounds.

$$w = \frac{A t^2 B}{h^2} = \frac{b t^3 B}{h^2} \quad (4.)$$

Example.—What weight will a white pine post sustain safely, whose height is 12 feet, and sides 8 and 12 inches respectively? The area = $8 \times 12 = 96$ inches; the square of the thickness, 8, = 64. The area by the square of the thickness, 96×64 , = 6144; and this by 1175, the value of B , for white pine, equals 7,219,200. This, divided by 144, the square of the height = 50,133 $\frac{1}{3}$, the required weight in pounds.

Rule V.—If the post be square, the weight is found by this rule: Multiply the value of B , Table II., by the square of the area of the post in inches, and divide the product by the square of the height in feet, and the quotient will be the required weight in pounds.

$$w = \frac{A^2 B}{h^2} = \frac{D^4 B}{h^2}. \quad (5.)$$

Example.—What weight will a white oak post sustain safely, whose height is 9 feet, and sides each 6 inches? The value of B , set opposite white oak, is 3475; this, by $(36 \times 36 =) 1296$, the square of the area, equals 4,503,600. This product, divided by 81, the square of the height, gives for quotient, 55,600, the required weight in pounds.

298.—To ascertain the size of a post to sustain safely a given weight when the height of the post is at least ten times the least side or diameter.

Rule VI.—When the post is to be round or cylindrical, the size may be obtained by this rule: Divide the weight in pounds by 0.589 times the value of B , Table II., and extract the square root of the product; multiply the square root by the height in feet, and the square root of this product will be the diameter of the post in inches.

$$D = \sqrt{h \sqrt{\frac{w}{.589 B}}} = \sqrt[4]{\frac{h^2 w}{.589 B}}. \quad (6.)$$

Example.—What must be the diameter of a locust post, 10 feet high, to sustain safely 40,000 pounds? Here 0.589 times 5,460, the value of B for locust, Table II., equals 3215.9. The weight, 40,000, divided by 3215.9, equals 12.438. The square root of this, 3.5268, multiplied by 10, the height, equals 35.268, and the square root of this is 5.9386 or $5\frac{1}{2}$ inches, the required diameter of the post.

Rule VII.—If the post is to be rectangular, the size may be obtained by this rule: Multiply the square of the height in

feet by the weight in pounds, and divide the product by the value of B , Table II. Now, if the breadth is known, divide the quotient by the breadth in inches, and the cube root of this quotient will be the thickness in inches. But if the thickness is known, and the breadth desired, divide, instead, by the cube of the thickness in inches, and the quotient will be the breadth in inches.

$$t = \sqrt[3]{\frac{h^2 w}{B b}} \quad (7.)$$

$$b = \frac{h^2 w}{B t^3} \quad (8.)$$

Example.—What thickness must a hemlock post have, whose breadth is 4 inches and height 12 feet, to sustain safely 1,000 pounds? The square of the height equals 144; this, by 1,000, the weight, equals 144,000. This, divided by 1,320, the value of B for hemlock, Table II., equals 109.091. This, divided by 4, the breadth, equals 27.273, and the cube root of this is 3.01, a trifle over 3 inches, and this is the thickness required.

Another Example.—What breadth must a spruce post have, whose thickness is 4 inches and height 10 feet, to sustain safely 10,000 pounds? The square of the height, 100, by 10,000, the weight, equals 1,000,000. This, divided by 2095, the value of B , Table II., for spruce, equals 477.09; and this, divided by 64, the cube of the thickness, equals 7.45, nearly $7\frac{1}{2}$ inches, the breadth required.

Rule VIII.—If the post is to be square, the size may be obtained by this rule. Divide the weight in pounds by the value of B , Table II., and multiply the square root of the product by the height in feet, and the square root of this product will be the dimension of a side of the post in inches.

$$t = \sqrt{h \sqrt{\frac{w}{B}}} = \sqrt{\frac{h^2 w}{B}} \quad (9.)$$

Example.—What dimension must the side of a square post

have, whose height is 15 feet, the post being of Georgia pine, to sustain safely 50,000 pounds? The weight 50,000, divided by 4830, the value of B , Table II., for Georgia pine, equals 10.352. The square root of this, 3.2175, multiplied by 15, the height, equals 48.362, and the square root of this is 6.9472, nearly 7 inches, the size of a side of the required post.

299.—A square post is not the stiffest that can be made from a given amount of material. The stiffest rectangular post is that whose sides are in proportion as 6 is to 10. When this proportion is desired it may be obtained by the following rule.

Rule IX.—Divide six-tenths of the weight in pounds by the value of B , Table II., and extract the square root of the quotient; multiply the square root by the height in feet, and then the square root of this product will be the thickness in inches. The breadth is equal to the thickness divided by 0.6.

$$t = \sqrt{h \sqrt{\frac{0.6 w}{B}}} = \sqrt[4]{\frac{0.6 h^2 w}{B}} \quad (10.)$$

$$b = \frac{t}{0.6} \quad (11.)$$

Example.—What must be the breadth and thickness of a white pine post, 10 feet high, to sustain safely 25,000 pounds. Here $\frac{6}{10}$ of 25,000, the weight, divided by 1175, the value of B , Table II., for white pine, equals 12.766. The square root of this, 3.5729, multiplied by 10, the height, equals 35.729, and the square root of this is 5.977, nearly 6 inches, the thickness required. This, divided by 0.6, equals 10, equals the breadth in inches required.

300.—The sides of a post may be obtained in any desirable proportion by Rule IX., simply by changing the decimal 0.6 to such decimal as will be in proportion to unity as one side is to be to the other. For example, if it be desired to have the sides in proportion as 10 is to 9, then 0.9 is the required decimal; if as 10 is to 8, then 0.8 is the decimal; if as 10

is to 7, then 0·7 is the decimal to be used in place of 0·6 in the rule. And generally let b equal the broad side and t the narrow side, or let these letters represent respectively the numbers that the sides are to be in proportion to; then, where x equals the decimal sought, $b : t :: 1 : x = \frac{t}{b}$ = the required decimal, or *fraction*. For a fraction may be used in place of the decimal, where it would be more convenient, as is the case when the sides are desired to be in proportion as 3 to 2. Here $3 : 2 :: 1 : x = \frac{2}{3}$. This fraction should be used in the rule in place of the decimal 0·6—rather than its equivalent decimal; simply because the decimal contains many figures, and therefore would not be convenient. The decimal equivalent to $\frac{2}{3}$ is 0·666666 +.

Third Case.

301.—To ascertain what weight may be sustained safely by the resistance of a given area of surface, when the weight tends to split off the part pressed against by causing one surface to slide on the other, in case of fracture.

Rule X.—Multiply the area of the surface by the value of H , in Table I., and the product will be the weight required in pounds.

$$A H = w. \qquad (12.)$$

Example.—The foot of a rafter is framed into the end of its tie-beam, so that the uncut substance of the tie-beam is 15 inches long from the end of the tie-beam to the joint of the rafter; the tie-beam is of white pine, and is six inches thick; what amount of horizontal thrust will this end of the tie-beam sustain, without danger of having the end of the tie-beam split off? Here the area of surface that sustains the pressure is 6 by 15 inches, equal to 90 inches. This, multiplied by 160, the value of H , set opposite to white pine, Table I., gives a product of 14,400, and this is the required weight in pounds.

302.—To ascertain the area of surface that is required to sustain a given weight safely, when the weight tends to split off the part pressed against, by causing one surface to slide on the other, in case of fracture.

Rule XI.—Divide the given weight in pounds by the value of H , Table I., and the quotient will be the required area in inches.

$$A = \frac{w}{H}. \quad (13.)$$

Example.—The load on a rafter causes a horizontal thrust at its foot of 40,000 pounds, tending to split off the end of the tie-beam, what must be the length of the tie-beam beyond the line, where the foot of the rafter is framed into it, the tie-beam being of Georgia pine, and nine inches thick? The weight, or horizontal thrust, 40,000, divided by 170, the value of H , Table I., set opposite Georgia pine, gives a quotient of 235.3. This, the area of surface in inches, divided by 9, the breadth of the surface strained, (equal to the thickness of the tie-beam,) the quotient, 26.1, is the length in inches from the end of the tie-beam to the rafter joint, say 26 inches.

303.—A knowledge of this kind of resistance of materials is useful, also, in ascertaining the length of framed tenons, so as to prevent the pin, or key, with which they are fastened from tearing out; and, also, in cases where tie-beams, or other timber under a tensile strain, are spliced, this rule gives the length of the joggle on each end of the splice.

Fourth Case.

304.—To ascertain what weight a post may be loaded with, so as not to crush the surface against which it presses.

Rule XII.—Multiply the area of the post in inches by the value of P , Table I., and the product is the weight required in pounds,

$$w = A P. \quad (14.)$$

Example.—A post, 8 by 10 inches, stands upon a white pine girder; the area equals $8 \times 10 = 80$ inches. This, by 300, the value of P , Table I., set opposite white pine, the product, 24,000, is the required weight in pounds.

305.—To ascertain what area a post must have in order to prevent the post, loaded with a given weight, from crushing the surface against which it presses.

Rule XIII.—Divide the given weight in pounds by the value of P , Table I., and the quotient will be the area required in inches.

$$A = \frac{w}{P}. \quad (15.)$$

Example.—A post standing on a Georgia pine girder is loaded with 100,000 pounds, what must be its area? The weight, 100,000, divided by 850, the value of P , Table I., set opposite Georgia pine, the quotient, 117.65, is the required area in inches. The post may be 10 by $11\frac{3}{4}$, or 10×12 inches, or, if square, each side will be 10.84 inches, or $12\frac{1}{2}$ inches diameter, if round.

II.—RESISTANCE TO TENSION.

306.—The resistance of materials to the force of stretching, as exemplified in the case of a rope from which a weight is suspended, is termed the *resistance to tension*. In fibrous materials, this force will be different in the same specimen, in accordance with the *direction* in which the force acts, whether in the direction of the length of the fibres, or at right angles to the direction of their length. It has been found that, in hard woods, the resistance in the former direction is about 8 to 10 times what it is in the latter; and in soft woods, straight grained, such as white pine, the resistance is from 16 to 20 times. A knowledge of the resistance in the direction of the fibres is the most useful in practice.

307.—In the following table, the experiments recorded were

to test this resistance in such woods, also iron, as are in common use. Each specimen was turned cylindrical, and about 2 inches diameter, and then the middle part for 10 inches in length reduced to $\frac{5}{8}$ ths of an inch diameter, at the middle of the reduced part, and gradually increased toward each end, where it was about an eighth of an inch larger at its junction with the enlarged end.

TABLE III.—TENSION.

Kind of Material.	Specific Gravity.	Weight producing fracture per square inch.	Value of T in the Rules.
		Pounds.	
Hickory,	0.751	20,700	3,450
Locust,794	15,900	2,650
Maple,694	15,400	2,567
White pine,458	14,200	2,367
Ash,608	11,700	1,950
Oak,728	10,000	1,667
White oak,774	17,000	2,833
Georgia pine,650	17,000	2,833
Cast iron, { from	7.200	17,000	2,833
{ to	7.600	30,000	5,000
American wrought iron, 2 in. diam.,	7.000	30,000	5,000
Do. do. $\frac{5}{8}$ and $\frac{1}{2}$ do.,	7.800	55,000	9,166
Do. do. wire, No. 3,		102,000	17,000
Do. do. do. No. 0,		74,500	12,416
Do. annealed do. No. 0,		53,000	8,833

308.—The value of T in the rules, as contained in the last column of the above table, is one-sixth of the weight producing fracture per square inch of cross section, as recorded in the preceding column. This proportion of the breaking weight is deemed the proper one, from the fact that in practice, through defects in workmanship, the attachments *may* be so made as to cause the strain to act along *one side* of the piece, instead of through its axis; and as in this case it has been found, that fracture will be produced with $\frac{1}{2}$ of the strain that can be sustained through the axis, therefore one half of this reduced strain, (equal to $\frac{1}{4}$ of the strain through the axis), is the largest that a due regard to security will permit to be

used. And in some cases it may be deemed advisable to load the material with even a still smaller strain.

309.—To ascertain the weight or pressure that may be safely applied to a beam as a tensile strain.

Rule XIV.—Multiply the area of the cross section of the beam in inches by the value of T , Table III., and the product will be the required weight in pounds. The cross section here intended is that taken at the smallest part of the beam or rod. A beam is usually cut with mortices in framing; the area will probably be smallest at the severest cutting: the area used in the rule must be only of the uncut fibres.

$$A T = w. \quad (16.)$$

Example.—A tie-beam of a roof truss is of white pine, and 6×10 inches; the cutting for the foot of the rafter reduces the uncut area to 40 inches: what amount of horizontal thrust from the foot of the rafter will this tie-beam safely sustain? Here 40 times 2,367, the value of T , equals 94,680, the required weight in pounds.

310.—To ascertain the sectional area of a beam or rod that will sustain a given weight safely, when applied as a tensile strain.

Rule XV.—Divide the given weight in pounds by the value of T , Table III., and the quotient will be the area required in inches: this will be the smallest area of uncut fibres. If the piece is to be cut for mortices, or for any other purpose, then a sufficient addition is to be made to the result found by the rule.

$$\frac{w}{T} = A. \quad (17.)$$

Example.—A rafter produces a thrust horizontally of 80,000 pounds; the tie-beam is to be of oak: what must the area of the cross section of the tie-beam be, in order to sustain the rafter safely? The given weight, 80,000, divided by 1,667, the value of T , the quotient, 48, is the area of uncut

fibres. This should have usually one-half of its amount added to it as an allowance for cutting; therefore $48 + 24 = 72$. The tie-beam may be 6×12 inches.

311.—In these rules nothing has been said of an allowance for the weight of the beam itself, in cases where the beam is placed vertically, and the weight suspended from the end. Usually, in timber, this is small in comparison with the load, and may be neglected; although in very long timbers, and where accuracy is decidedly essential, it may form a part of the rule.

312.—Taking the effect of the weight of the beam into account, the relation existing between the weights and parts of the beam, may be stated algebraically thus:—

$$A T = w + k \quad (18.)$$

Where A equals the area of the section of uncut fibres, T equals the tabular constant in the rules, which is equal to the load that may be safely trusted on a rod of like material with the beam and one inch square; w equals the load, and k equals the weight of the beam. Now, the weight of the beam equals its cubical contents in feet, multiplied by the weight of a cubic foot of like material; and a cubic foot of the material equals 62.5 times its specific gravity, while the cubical contents of the beam in feet equals $\frac{R}{144} l$, where R equals the sectional area in inches, and l equals the length in feet. Hence—

$$k = 62.5 f \frac{R}{144} l, \quad (19.)$$

where f equals the specific gravity. It will be observed that A equals the sectional area of the uncut fibres, while R equals the sectional area of the entire beam; and, where the excess of R over A may be stated as a proportional part of A , or when $A + n A = R$, (n being a decimal in proportion to unity, as the excess of R over A is to A), or

$$\frac{R - A}{A} = n. \quad \text{Then, [from (18.)] —}$$

$$\begin{aligned}
 A T &= w + l, \\
 &= w + 62.5 \frac{A + n A}{144} f l \\
 &= w + \frac{62.5}{144} A (1 + n) f l, \\
 &= w + 0.434 (n + 1) A f l;
 \end{aligned}$$

$$\begin{aligned}
 \text{and } w &= A T - 0.434 (n + 1) A f l, \\
 w &= A (T - 0.434 (n + 1) f l); \quad (20.)
 \end{aligned}$$

$$\text{and } A = \frac{w}{T - 0.434 (n + 1) f l}. \quad (21.)$$

When A is found, to find R , we have from

$$\begin{aligned}
 R &= A + n A, \\
 R &= A (n + 1). \quad (22.)
 \end{aligned}$$

As the excess of R over A decreases, n also decreases, until finally, when $R = A$, n becomes zero. For—

$$n = \frac{R - A}{A},$$

and when $A = R$, then

$$n = \frac{R - R}{R} = \frac{0}{R} = 0.$$

When n equals zero, it disappears from the rules, and (20) becomes

$$w = A (T - 0.434 f l) \quad (23.)$$

and (21) becomes

$$A = \frac{w}{T - 0.434 f l}, \quad (24.)$$

and (22) becomes

$$R = A, \quad (25.)$$

313.—These rules stated in words at length are as follows:—

To ascertain the weight that may be suspended safely from a vertical beam, when the weight of the beam itself is to be taken into account, and when a portion of the fibres are cut in framing.

Rule XVI.—From the sectional area of the beam, deduct

the sectional area of uncut fibres, and divide the remainder by the sectional area of the uncut fibres, and to the quotient add unity; multiply this sum by 0.434 times the specific gravity of the beam, and by its length in feet; subtract this product from the value of T , Table III., and the remainder, multiplied by the sectional area of the uncut fibres, will be the required weight in pounds.

$$w = A (T - 0.434 (n + 1) f l) \quad (20.)$$

Example.—A white pine beam, set vertically, 5 × 9 inches and 30 feet long, is so cut by mortices as to have remaining only 5 × 6 inches sectional area of uncut fibres: what weight will such a beam sustain safely, as a tensile strain? The uncut fibres, 5 × 6 = 30, deducted from the area of the beam, 5 × 9 = 45, there remains 15. This remainder, divided by 30, the area of the uncut fibres, the quotient is 0.5. This added to unity, the sum is 1.5. This, by 0.434 times 0.458, the specific gravity set opposite white pine in Table III., and by 30, the length of the beam in feet, the product is 8.95. This product, deducted from 2,367, the value of T set opposite white pine in Table III., the remainder is 2,358.05. This remainder multiplied by 30, the sectional area of the uncut fibres, the product, 70,741.5, is the required weight in pounds.

314.—When the beam is uncut for mortices or other purposes, the former part of the rule is not needed; the weight will then be found by the following rule.

Rule XVII.—Deduct 0.434 times the specific gravity of the beam, multiplied by its length in feet, from the value of T , Table III.; the remainder, multiplied by the sectional area of the beam in inches, will be the required weight in pounds.

$$w = A (T - 0.434 f l) \quad (23.)$$

Example.—A Georgia pine beam, set vertically, is 25 feet long and 7 × 9 inches in sectional area: what weight will it sustain safely, as a tensile strain? By the rule, 0.434 times

0.65, the specific gravity of Georgia pine, as in Table III., multiplied by 25, the length in feet, the product is 7.05. This product, deducted from 2,833, the value of T , Table III., set opposite Georgia pine, and the remainder, 2,825.95, multiplied by 63, the sectional area, the product, 178,034.85, is the required weight in pounds.

315.—To ascertain the sectional area of a vertical beam that will safely sustain a given tensile strain, where the weight of the beam itself is to be considered.

Rule XVIII.—Where the beam is cut for mortices or other purposes, let the relative proportion of the uncut fibres to those that are cut, be as 1 is to n , (n being a decimal to be fixed on at pleasure.) Then to the value of n add unity, and multiply ing the sum by 0.434 times the specific gravity in Table III., and by the length in feet. Deduct this product from the value of T , Table III., divide the given weight in pounds by this remainder, and the quotient will be the area of the uncut fibres in inches. Add unity to the value of n , as above, and multiply the sum by the area of the uncut fibres; the product will be the required area of the beam in inches.

$$A = \frac{w}{T - 0.434 (n + 1) f l}, \quad (21.)$$

$$R = A (n + 1), \quad (22.)$$

Example.—A vertical beam of white oak, 30 feet long, is required to resist effectually a tensile strain of 80,000 pounds: what must be its sectional area? The relative proportion of the uncut fibres is to be to those that are cut as 1 is to 0.4. To 0.4, the value of n , add 1; the sum is 1.4. This, by 0.434 times .774, the specific gravity of white oak in Table III., and by 30, the length, the product is 14.109. This, deducted from 2,833, the value of T for white oak in Table III., the remainder is 2,818.891. The given weight, 80,000, divided by 2,818.891, the remainder, as above, the quotient, 28.38, is the area of the uncut fibres. This multiplied by the sum of 0.4 and 1; (or

the value of n and unity = 1.4,) the product, 39.732, is the required area of the beam in inches.

316.—When the fibres are uncut, then their sectional area equals the area of the beam, and may be found by the following rule.

Rule XIX.—Deduct 0.434 times the specific gravity in Table III., multiplied by the length in feet, from the value of T , Table III., and divide the weight in pounds by the remainder. The quotient will be the required area in inches.

$$A = \frac{w}{T - 0.434 f l}. \quad (24.)$$

Example.—A vertical beam of locust, 15 feet long; fibres all uncut, is required to sustain a tensile strain equal to 25,000 pounds: what must be its area? Here 0.434 times .794, the specific gravity for locust in Table III., multiplied by 15, the length in feet, is 5.17. This, from 2,650, the value of T for locust, Table III., the remainder is 2,644.83. The given weight, 25,000, divided by 2,644.83, the remainder, as above, the quotient, 9.45, will be the required area in inches.

III.—RESISTANCE TO CROSS-STRAINS.

317.—A load placed upon a beam, laid horizontal or inclined, tends to bend it, and if the weight be proportionally large, to break it. The power in the material that resists this bending or breaking, is termed the *resistance to cross-strains*, or transverse strains. While in posts or struts the material is compressed or shortened, and in ties and suspending-pieces it is extended or lengthened; in beams subjected to cross-strains the material is both compressed and extended. (See *Art.* 254.) When the beam is bent, the fibres on the concave side are compressed, while those on the convex side are extended. The line where these two portions of the beam meet—that is, the portion compressed and the portion extended—the horizontal line of juncture, is termed the *neutral* line or plane. It

is so called because at this line the fibres are neither compressed nor extended, and hence are under no strain whatever. The location of this line or plane is not far from the middle of the depth of the beam, when the strain is not sufficient to injure the elasticity of the material; but it removes towards the concave or convex side of the beam as the strain is increased, until, at the period of rupture, its distance from the top of the beam is in proportion to its distance from the bottom of the beam as the tensile strength of the material is to its compressive strength.

318.—In order that the strength of a beam be injured as little as possible by the cutting required in framing, all mortices should be located at or near the middle of the depth. There is a prevalent idea among some, who are aware that the upper fibres of a beam are compressed when subject to cross-strains, that it is not injurious to cut these top fibres, provided that the cutting be for the insertion of another piece of timber—as in the case of *gaining* the ends of beams into the side of a girder. They suppose that the piece filled in will as effectually resist the compression as the part removed would have done, had it not been taken out. Now, besides the effect of shrinkage, which of itself is quite sufficient to prevent the proper resistance to the strain, there is the mechanical difficulty of fitting the joints perfectly throughout; and, also, a great loss in the power of resistance, as the material is so much less capable of resistance when pressed at right angles to the direction of the fibres, than when directly with them, as the results of the experiments in the tables show.

319.—In treating upon the resistance to cross-strains, the subject is divided naturally into two parts, viz. *stiffness* and *strength*: the former being the power to resist deflection or bending, and the latter the resistance to rupture.

320.—*Resistance to Deflection.* When a load is placed upon a beam supported at each end, the beam bends more or

less ; the distance that the beam descends under the operation of the load, measured at the middle of its length, is termed its *deflection*. In an investigation of the laws of deflection it has been demonstrated, and experiments have confirmed it, that while the elasticity of the material remains uninjured by the pressure, or is injured in but a small degree, the amount of deflection is directly in proportion to the weight producing it, and is as the cube of the length ; and, in pieces of rectangular sections, it is inversely proportional to the breadth and the cube of the depth : or, inversely proportional to the fourth power of the *side* of a square beam or of the *diameter* of a cylindrical one. Or, when l equals the length between the supports, w the weight or pressure, b the breadth, d the depth, and p the deflection ; then—

$$\frac{l^3 w}{b d^3 p} = E, \quad (26.)$$

equals a *constant quantity* for beams of all dimensions made from a *like material*. Also,

$$\frac{l^3 w}{s^4 p} = E, \quad (27.)$$

where s equals a side of a square beam ; and

$$\frac{l^3 w}{0.589 D^4 p} = E, \quad (28.)$$

where D equals the diameter of a cylindrical beam. The constant here is less than in the case of the square and of the rectangular beams. It is as much less as the circular beam is less stiff than a square beam whose side is equal to the diameter of the cylindrical one. The constant, E , is therefore multiplied by the decimal 0.589.

321.—It may be observed that E in (26) and (27) would be equal to w , in case the dimensions of the beam and the amount of deflection were each made equal to unity ; and in (28) equal to w divided by 0.589. That is, when in (26) the length is 1, the breadth 1, and the depth 1, then E would be

equal to the weight that would depress the beam from its original line equal to 1. Thus—

$$E = \frac{l^3 w}{b d^3 p} = \frac{1^3 \times w}{1 \times 1^3 \times 1} = w,$$

the dimensions all taken in inches except the length, and this taken in feet. This is an extreme state of the case, for in most kinds of material this amount of depression would exceed the limits of elasticity; and hence the rule would here fail to give the correct relation among the dimensions and pressure. For the law of deflection as above stated, (the deflection being equal for equal weights,) is true only while the depressions are small in comparison with the length. Nothing useful is, therefore, derived from this position of the question, except to give an idea of the nature of the quantity represented by the constant, E ; it being in reality a measure of the stiffness of the kind of material used in comparing one material with another. Whatever may be the dimensions of the beam, E , calculated by (26,) will always be the same quantity for the same material; but when various materials are used, E will vary according to the flexibility or stiffness of each particular material. For example, E will be much greater for iron than for wood; and again, among the various kinds of wood, it will be larger for the stiff woods than for those that are flexible.

322.—If the amount of deflection that would be proper in beams used in framing generally, (such as floor beams, girders and rafters,) were agreed upon, the rules would be shortened, and the labor of calculation abridged. Tredgold proposed to make the deflection in proportion to the length of the beam, and the amount at the rate of one-fortieth of an inch (= 0.025 inch) for every foot of length. He was undoubtedly right in the manner and probably so in the rate; yet, as this is a matter of opinion, it were better perhaps to leave the rate of deflection open for the decision of those who use the rules, and then it may be varied to suit the peculiarities of each case

that may arise. Any deflection within the limits of the elasticity of the material, may be given to beams used for some purposes, while others require to be restricted to that amount of deflection that shall not be perceptible to a casual observer. Let n represent, in the decimal of an inch, the rate of deflection per foot of the length of the beam; then the product of n , multiplied by the number of feet contained in the length of the beam, will equal the total deflection, $= n l$. Now, if $n l$ be substituted for p in the formulas, (26,) (27) and (28,) they will be rendered more available for general use. For example, let this substitution be made in (26,) and there results—

$$E = \frac{l^3 w}{b d^3 n l} = \frac{l^2 w}{b d^3 n}, \quad (29.)$$

where l is in feet, and b , d and n in inches; and for (27)—

$$E = \frac{l^3 w}{s^4 n l} = \frac{l^2 w}{s^4 n}; \quad (30.)$$

also for (28)—

$$E = \frac{l^3 w}{0.589 D^4 n l} = \frac{l^2 w}{0.589 D^4 n}, \quad (31.)$$

where the notation is as before, with also s and D in inches. In these formulas, w represents the weight in pounds *concentrated* at the middle of the length of the beam. If the weight, instead thereof, is *equally distributed* over the length of the beam, then, since $\frac{5}{8}$ of it concentrated at the middle will deflect a beam to the same depth that the whole does when equally distributed, (*Art.* 281,) therefore—

$$E = \frac{\frac{5}{8} w l^3}{b d^3 n}, \quad (32.)$$

$$E = \frac{\frac{5}{8} w l^3}{s^4 n}, \quad (33.)$$

$$E = \frac{\frac{5}{8} w l^3}{0.589 D^4 n}, \quad (34.)$$

where w equals the whole of the equally distributed load. Again, if the load is borne by more beams than one, laid parallel to each other—as, for example, a series or tier of floor

beams—and the load is equally distributed over the supported surface or floor; then, if f represents the number of pounds of the load contained on each square foot of the floor, or the pounds' weight per foot superficial, and c represents the distance in feet between each two beams, or rather the distance from their centres, and l the length of the beam in feet, in the clear, between the supports at the ends; then $c l$ will equal the area of surface supported by one of the beams, and $f c l$ will represent the load borne by it, equally distributed over its length. Now, if this representation of the load be substituted for w in (32,) (33) and (34) there results—

$$E = \frac{\frac{5}{8} f c l l^2}{b d^3 n} = \frac{\frac{5}{8} f c l^3}{b d^3 n}, \quad (35.)$$

$$E = \frac{\frac{5}{8} f c l l^2}{s^4 n} = \frac{\frac{5}{8} f c l^3}{s^4 n}, \quad (36.)$$

$$E = \frac{\frac{5}{8} f c l l^2}{0.589 D^4 n} = \frac{\frac{5}{8} f c l^3}{0.589 D^4 n} \quad (37.)$$

Practical Rules and Examples.

323.—To ascertain the weight, placed upon the middle of a beam, that will cause a given deflection.

Rule XX.—Multiply the area of the cross-section of the beam by the square of the depth and by the rate of the deflection, all in inches; multiply the product by the value of E , Table II., and divide this product by the square of the length in feet, and the quotient will be the weight in pounds required.

Example.—What weight can be supported upon the middle of a Georgia pine girder, ten feet long, eight inches broad, and ten inches deep, the deflection limited to three-tenths of an inch, or at the rate of 0.03 of an inch per foot of the length? Here the area equals $8 \times 10 = 80$; the square of the depth equals $10 \times 10 = 100$; $80 \times 100 = 8,000$; this by 0.03, the rate of deflection, the product is 240; and this by 2970, the value of E for Georgia pine, Table II., equals 712,800. This

product, divided by 100, the square of the length, the quotient, 7,128, is the weight required in pounds.

Rule XXI.—Where the beam is square the weight may be found by the preceding rule or by this:—Multiply the square of the area of the cross-section by the rate of deflection, both in inches, and the product by the value of E , Table II., and divide this product by the square of the length in feet, and the quotient will be the weight required in pounds.

Example.—What weight placed on the middle of a spruce beam will deflect it seven-tenths of an inch, the beam being 20 feet long, 6 inches broad, and 6 inches deep? Here the area is $6 \times 6 = 36$, and its square is $36 \times 36 = 1296$; the rate of deflection is equal to the total deflection divided by the length, $= \frac{0.7}{20} = 0.035$; therefore, $1296 \times 0.035 = 45.36$, and this by 1550, the value of E for spruce, Table II., equals 70,308. This, divided by 400, the square of the length, equals 175.77, the required weight in pounds.

Rule XXII.—When the beam is round find the weight by this rule:—Multiply the square of the diameter of the cross-section by the square of the diameter, and the product by the rate of deflection, all in inches, and this product by 0.589 times the value of E , Table II. This last product, divided by the square of the length in feet, will give the required weight in pounds.

Example.—What weight on the middle of a round white pine beam will cause a deflection of 0.028 of an inch per foot, the beam being 10 inches diameter and 20 feet long? The square of the diameter equals $10 \times 10 = 100$; $100 \times 100 = 10,000$; this by the rate, 0.028, = 280, and this by 0.589×1750 , the value of E , Table II., for white pine, equals 288,610. This last product, divided by 400, the square of the length, equals 721.5, the required weight in pounds.

324.—To ascertain the weight that will produce a given de

flection, when the weight is equally distributed over the length of the beam.

Rule XXIII.—The rules for this are the same as the three preceding rules, with this modification, viz., instead of the square of the length, divide by five-eighths of the square of the length.

325.—In a series or tier of beams, to ascertain the weight per foot, equally distributed over the supported surface, that will cause a given deflection in the beam.

Rule XXIV.—The rules for this are the same as Rules XX., XXI., and XXII., with this modification, viz., instead of the square of the length, divide by the product of the distance apart in feet between each two beams, (measured from the centres of their breadths,) multiplied by five-eighths of the cube of the length, and the quotient will be the required weight in pounds that may be placed upon each superficial foot of the floor or other surface supported by the beams. In this and all the other rules, the weight of the material composing the beams, floor, and other parts of the constructions is understood to be a part of the load. Therefore from the ascertained weight deduct the weight of the framing, floor, plastering, or other parts of the construction, and the remainder will be the neat load required.

Example.—In a tier of white pine beams, 4×12 inches, 20 feet long, placed 16 inches or $1\frac{1}{3}$ feet from centres, what weight per foot superficial may be equally distributed over the floor covering said beams—the rate of deflection to be not more than 0.025 of an inch per foot of the length of the beams. Proceeding by Rule XX. as above modified, the area of the cross-section, 4×12 , equals 48; this by 144, the square of the depth, equals 6912, and this by 0.025 , the rate of deflection, equals 172.8. Then this product, multiplied by 1750, the value of E , Table II., for white pine, equals 302,400. The distance between the centres of the beams is $1\frac{1}{3}$ feet, the cube

of the length is 8,000, and $\frac{1}{3}$ by $\frac{3}{8}$ of 8,000 equals 6,666 $\frac{2}{3}$. The above 302,400, divided by 6,666 $\frac{2}{3}$, the quotient, 45·36, equals the required weight in pounds per foot superficial. The weight of beams, floor plank, cross-furring, and plastering occurring under every square foot of the surface of the floor, is now to be ascertained. Of the timber in every 16 inches by 12 inches, there occurs 4 × 12 inches, one foot long; this equals one-third of a cubic foot. Now, by proportion, if 16 inches in width contains $\frac{1}{3}$ of a cubic foot, what will 12 inches in width contain? $\frac{\frac{1}{3} \times 12}{16} = \frac{12}{3 \times 16} = \frac{1}{4}$ of a cubic foot.

The floor plank (Georgia pine) is 12 × 12 inches, and $1\frac{1}{4}$ inches thick, equal to $\frac{1\frac{1}{4}}{12}$ of a cubic foot, equals $\frac{5}{12}$, equals $\frac{5}{48}$. Of the furring strips, 1 × 2 inches, placed 12 inches from centres, there will occur one of a foot long in every superficial foot. Now, since in a cubic foot there is 144 rods, one inch square and one foot long, therefore, this furring strip, 1 × 2 × 12 inches, equals $\frac{1 \times 2 \times 12}{144} = \frac{1}{6}$ of a cubic foot. The weight of the timber and furring strips, being of white pine, may be estimated together: $\frac{1}{4} + \frac{1}{6} = \frac{3}{12} + \frac{2}{12} = \frac{5}{12}$ of a cubic foot. White pine varies from 23 to 30 pounds. If it be taken at 30 pounds, the beam and furring together will weigh $30 \times \frac{5}{12}$ pounds, equals 7·92 pounds. Georgia pine may be taken at 50 pounds per cubic foot;* the weight of the floor plank, then, is $50 \times \frac{5}{48} = 5·21$ pounds. A superficial foot of lath and plastering will weigh about 10 lbs. Thus, the white pine, 7·92, Georgia pine, 5·21, and the plastering, 10, together equal 23·13 pounds; this from 45·36, as before ascertained, leaves 22·23, say 22 $\frac{1}{4}$ pounds, the neat weight per foot superficial that may be equally distributed over the floor as its load.

* To get the weight of wood or any other material, multiply its specific gravity by 62·5. For Specific Gravities see Tables I, II, and III, and the Appendix for Weight of Materials.

326.—To ascertain the weight when the beam is laid not horizontal, but *inclined*.

Rule XXV.—In each of the foregoing rules, multiply the result there obtained by the length in feet, and divide the product by the horizontal distance between the supports in feet, and the quotient will be the required weight in pounds.

The foregoing Rules, stated algebraically, are placed in the following table:—

TABLE IV.—STIFFNESS OF BEAMS ; WEIGHT.

When the beam is laid	When the weight is	When the beam is		
		Rectangular.	Square.	Round.
Horizontal	Concentrated at middle, w , in pounds, equals	(38.) $\frac{E n b d^3}{l^2}$	(39.) $\frac{E n s^4}{l^2}$	(40.) $\frac{.589 E n D^4}{l^2}$
Horizontal	Equally distributed, w , in pounds, equals	(41.) $\frac{E n b d^3}{\frac{3}{8} l^2}$	(42.) $\frac{E n s^4}{\frac{3}{8} l^2}$	(43.) $\frac{.9424 E n D^4}{l^2}$
Horizontal	By the foot superficial, f , in pounds, equals	(44.) $\frac{E n b d^3}{\frac{3}{8} c l^2}$	(45.) $\frac{E n s^4}{\frac{3}{8} c l^2}$	(46.) $\frac{.9424 E n D^4}{c l^2}$
Inclining	Concentrated at middle, w , in pounds, equals	(47.) $\frac{E n b d^3}{l h}$	(48.) $\frac{E n s^4}{l h}$	(49.) $\frac{.589 E n D^4}{l h}$
Inclining	Equally distributed, w , in pounds, equals	(50.) $\frac{E n b d^3}{\frac{3}{8} l h}$	(51.) $\frac{E n s^4}{\frac{3}{8} l h}$	(52.) $\frac{.9424 E n D^4}{l h}$
Inclining	By the foot superficial, f , in pounds, equals	(53.) $\frac{E n b d^3}{\frac{3}{8} c l^2 h}$	(54.) $\frac{E n s^4}{\frac{3}{8} c l^2 h}$	(55.) $\frac{.9424 E n D^4}{c l^2 h}$

In the above table, b equals the breadth, and d equals the depth of cross-section of beam ; s equals the breadth of a side of a square beam, and D equals the diameter of a round beam ; n equals the rate of deflection per foot of the length ;

D, s, b, d and n , all in inches; l equals the length, c equals the distance between two parallel beams measured from the centres of their breadth; h equals the horizontal distance between the supports of an inclined beam; l, c and h in feet; w equals the weight in pounds on the beam; f equals the weight upon each superficial foot of a floor or roof supported by two or more beams laid parallel and at equal distances apart; E is a constant, the value of which is found in Table II.; r is any decimal, chosen at pleasure, in proportion to unity, as b is to d , from which proportion b equals $d r$.

327.—To ascertain the dimensions of the cross-section of a beam to support the required weight with a given deflection.

Rule XXVI.—Preliminary. When the weight is concentrated at the middle of the length. Multiply the weight in pounds by the square of the length in feet, and divide the product by the product of the rate of deflection multiplied by the value of E , Table II., and the quotient equals a quantity which may be represented by M —referred to in succeeding rules.

$$\frac{w l^2}{E n} = M. \quad (56.)$$

Rule XXVII.—Preliminary. When the weight is equally distributed over the length. Multiply five-eighths of the weight in pounds by the square of the length in feet, and divide the product by the rate of deflection multiplied by the value of E , Table II., and the quotient equals a quantity which may be represented by N —referred to in succeeding rules.

$$\frac{\frac{5}{8} w l^2}{E n} = N. \quad (57.)$$

Rule XXVIII.—Preliminary. When the weight is given per foot superficial and supported by two or more beams. Multiply the distance apart between two of the beams, (measured from the centres of their breadth,) by the cube of the length, both in feet, and multiply the product by five-eighths of the weight per foot superficial; divide this product by the

product of the rate of deflection, multiplied by the value of E Table II., and the quotient equals a quantity which may be represented by U —referred to in succeeding rules.

$$\frac{\frac{5}{8} f c l^3}{E n} = U. \quad (58.)$$

Rule XXIX.—Preliminary. *When the beam is laid not horizontal, but inclining.* In Rules XXVI. and XXVII., instead of the *square of the length* multiply by the length, and by the *horizontal distance* between the supports, in feet. And in Rule XXVIII., instead of the *cube of the length*, multiply by the *square of the length*, and by the *horizontal distance* between the supports, in feet.

From (56)

$$\frac{w l h}{E n} = M_2. \quad (59.)$$

From (57)

$$\frac{\frac{5}{8} w l h}{E n} = N_2. \quad (60.)$$

From (58)

$$\frac{\frac{5}{8} f c l^3 h}{E n} = U_2. \quad (61.)$$

Rule XXX.—*When the beam is rectangular to find the dimensions of the cross-section.* Divide the quantity represented by M , N or U , (in preceding preliminary rules,) by the breadth in inches, and the cube root of the quotient will equal the required depth in inches. Or, divide the quantity represented by M , N or U , by the cube of the depth in inches, and the quotient will equal the required breadth in inches. Or, again, if it be desired to have the breadth and depth in proportion, as r is to unity, (where r equals any required decimal,) divide the quantity represented by M , N or U , by the value of r , and extract the square root of the quotient: and the square root extracted the second time, will equal the depth in inches. Multiply the depth thus found by the value of r , and the product will equal the breadth in inches.

Example.—To find the depth. A beam of spruce, laid on supports with a clear bearing of 20 feet, is required to support a load of 1674 pounds at the middle, and the deflection not to exceed 0.05 of an inch per foot; what must be the depth when the breadth is 5 inches. By Rule XXVI. for load at middle: the product of 1674, the weight, by 400, the square of the length, equals 669,600. The product of 0.05, the rate of deflection, multiplied by 1550, the value of E , from Table II., set opposite spruce, is 77.5. The aforesaid product, 669,600, divided by 77.5, equals 8640, the value of M . Then by Rule XXX., 8640, the value of M , divided by 5, the breadth, the quotient is 1728, and 12, the cube root of this, found in the table of the Appendix, equals the required depth in inches.

Example.—To find the breadth. Suppose that in the last example it were required to have the depth 13 inches; in that case what must be the breadth? The value of M , 8640, as just found, divided by 2197, the cube of the depth, equals 3.9326, the required breadth—nearly 4 inches.

Example.—To find both breadth and depth, and in a certain proportion. Suppose, in the above example, that neither the breadth nor the depth are given, but that they are desired to be in proportion as 0.5 is to 1.0. Now, having ascertained the value of M , by Rule XXVI., to be 8640, as above, then, by Rule XXX., 8640, divided by 0.5, the ratio, gives for quotient 17,280. The square root of this (by the table in the Appendix,) is 131.45, and the square root of this square root is 11.465, the required depth. The breadth equals 11.465×0.5 , which equals 5.7325. The depth and breadth may be $11\frac{1}{2}$ by $5\frac{3}{4}$ inches. In cases where the load is *equally distributed* over the length of the beam, the process is precisely the same as set forth in the three preceding examples, except that *five-eighths* of the weight is to be used in place of the *whole* weight; and hence it would be a useless repetition to give examples to illustrate such cases.

Example.—When the weight is per foot superficial to find the depth. A floor is to be constructed to support 500 pounds on every superficial foot of its surface. The beams to be of white pine, 16 feet long in the clear of the supports or walls, placed 16 inches apart, from centres, to be 4 inches thick, and the amount of deflection not objectionable provided it be within the limits of elasticity. Proceeding by Rule XXVIII., the product of $1\frac{1}{2}$ feet, (equal to 16 inches,) multiplied by 4096, the cube of the length, equals $5461\frac{1}{2}$. This, multiplied by 312·5, (equal to $\frac{5}{8}$ of the weight,) equals 1,706,666. The largest rate of deflection within the limits of the elasticity of white pine is 0·1022, as per Table II. This, multiplied by 1750, the value of E for white pine, Table II., equals 178·85. The former product, 1,706,666, divided by the latter, 178·85, equals 9,542·5, the value of U . Now, by Rule XXX., this value of U , 9,542·5, divided by 4, the breadth, equals 2385·6, the cube root of which, 13·362, is the required depth—nearly $13\frac{3}{8}$ inches.

Example.—To find the breadth. Suppose, in the last example, that the depth is known but not the breadth, and that the depth is to be 13 inches. Having found the value of U , as before, to be 9542·5, then by Rule XXX., dividing 9542·5, the value of U , by 2197, the cube of the depth, gives a quotient of 4·3434 and this equals the breadth—nearly $4\frac{3}{8}$ inches.

Example.—To find the depth and breadth in a given proportion. Suppose, in the above example, that the breadth and depth are both unknown, and that it is desired to have them in proportion as 0·7 is to 1·0. Having found the value of U , as before, to be 9542·5, then by Rule XXX., dividing 9542·5, the value of U , by 0·7, the quotient is 13,632, the square root of which is 116·75, and the square root of this is 10·805, the depth in inches. Then 10·805, multiplied by 0·7, the product, 7·5635, is the breadth in inches. The size may be $7\frac{9}{16}$ by $10\frac{1}{2}$ inches.

328.—*Example.*—In the case of inclined beams to find the

Depth. A beam of white pine, 10 feet long in the clear of the bearing, and laid at such an inclination that the *horizontal* distance between the supports is 9 feet, is required to support 12,000 pounds at the centre of its length, with the greatest allowable deflection within the limits of elasticity; what must be its depth when its breadth is fixed at 6 inches? By reference to Table II. it is seen that the greatest value of n , within the limits of elasticity, is 0.1022. By Rule XXVI., for concentrated load, and Rule XXIX., for inclined beams, 12,000, the weight, multiplied by 10, the length, and by 9, the horizontal distance, equals 1,080,000. The product of 0.1022, the greatest rate of deflection, by 1750, the value of E , Table II., for white pine, equals 178.85. Dividing 1,080,000 by 178.85, the quotient is 6038.58, the value of M . Now, by Rule XXX., for rectangular beams, 6038.58, the value of M , divided by 6, the breadth, the quotient is 1006.43. The cube root of this, 10.02, a trifle over 10 inches, is the depth required.

Example.—In case of inclined beams to find the breadth. In the last example suppose the depth fixed at 12 inches; then by Rule XXX., 6038.58, the value of M , as above found, divided by 1728, the cube of the depth, equals 3.4945, or nearly $3\frac{1}{2}$ inches—the breadth required.

Example.—Again, in case the breadth and depth are to be in a certain proportion; as, for example, as 0.4 is to unity. Then by Rule XXX., 6038.58, the value of M , found as above, divided by 0.4, equals 15,096.45, the square root of which is 122.87, and the square root of this square root is 11.0843, a trifle over 11 inches—the depth required. Again, 11 multiplied by the decimal 0.4, (as above,) equals 4.4, a little over $4\frac{1}{2}$ inches—the breadth required.

In the three preceding examples, the weight is understood to be concentrated at the middle. If, however, the weight had been equally distributed, the same process would have been used to obtain the dimensions of the cross-section, with

only one exception; viz. $\frac{5}{8}$ of the weight instead of the whole weight would have been used. (See Rule XXVII.)

Example.—*In case of inclined beams; the weight per foot superficial, and borne by two or more beams.* A tier of spruce beams, laid with a clear bearing of 10 feet, and at 20 inches apart from centres, and laid so inclining that the horizontal distance between bearings is 8 feet, are required to sustain 40 pounds per superficial foot, with a deflection not to exceed 0.02 inch per foot of the length; what must be the depth when the breadth is 3 inches? Proceeding by Rule XXIX. for inclined beams, and by Rule XXVIII., $1\frac{2}{3}$, (= 20 inches,) the distance from centres, multiplied by 100, the square of the length, and by 8, the horizontal distance between bearings, equals $1,333\frac{1}{3}$; this, by $\frac{5}{8} \times 40$, five-eighths of the weight, equals $33,333\frac{1}{3}$. This, divided by 0.02×1550 , the rate of deflection, by the value of E , Table II., for spruce, equal to 31, equals 1075.27 , the value of U . Now by Rule XXX. for rectangular beams, 1075.27 , divided by 3, the breadth, equals 358.42 , the cube root of which, 7.1 , is the required depth in inches.

Example.—*The same as the preceding; but to find the breadth, when the depth is fixed at 8 inches.* By Rule XXX., 1075.27 , the value of U , divided by 512, the cube of the depth, equals 2.1 —the breadth required in inches.

Example.—*The same as the next but one preceding; but to find the breadth and depth in the proportion of 0.3 to 1.0, or 3 to 10.* By Rule XXX., 1075.27 , the value of U , divided by 0.3, the value of r , equals 3584.23 . The square root of this is 59.869 , and the square root of this square root is 7.737 —the depth required in inches. This 7.737 , multiplied by 0.3, the value of r , equals 2.3211 —the required breadth in inches. The dimensions may, therefore, be $2\frac{5}{16}$ by $7\frac{3}{4}$ inches.

Rule XXXI.—*When the beam is square to find the side.* Extract the square root of the quantity represented by M , N

or U , in preliminary Rules XXVI., XXVII. and XXVIII., and the square root of this square root will equal the side required.

Example.—A beam of chestnut, having a clear bearing of 8 feet, is required to sustain at the middle a load of 1500 pounds; what must be the size of its sides in order that the deflection shall not exceed 0.03 inch per foot of its length? By Rule XXVI., 1500, the load, multiplied by 64, the square of the length, equals 96,000. This product divided by 0.03 times 2330, the value of E , Table II., for chestnut, gives a quotient of 1373.4, the quantity represented by M . Now by Rule XXXI., the square root of 1373.4 is 37.05, and the square root of this is 6.087. The beam must, therefore, be 6 inches square. In this example, had the load, instead of being concentrated at the middle, been equally distributed over its length, the side would have been equal to the side just found, multiplied by the fourth root of $\frac{5}{8}$ or of 0.625, equal to 6.087 \times 0.889 = 5.4 inches. (See Rules XXVII. and XXXI.)

Example.—In the case where the weight is per foot superficial and borne by two or more beams. A floor, the beams of which are of oak, and placed 20 inches or $1\frac{2}{3}$ feet apart from centres, and which have a clear bearing of 20 feet, is required to sustain 200 pounds per superficial foot, the deflection not to exceed 0.025 inch per foot of the length, and the beam to be square. By Rule XXVIII., $1\frac{2}{3}$, the distance from centres, multiplied by 8000, the cube of the length, equals 13,333 $\frac{1}{3}$; and this by 125, (being $\frac{1}{8}$ of 200 pounds,) equals 1,666,666 $\frac{2}{3}$. Dividing this by 0.025 times 2520, the value of E , Table II., for oak, the quotient is 26,455—a number represented by U . Now by Rule XXXI., the square root of this number is 162.65. and the square root of this square root is 12.753—the required side. The beam may be $12\frac{3}{4}$ inches square.

Example.—Inclined square beams, load at middle. A bar of cast-iron, 6 feet long in the clear of bearings, and laid

inclining so that the horizontal distance between the bearings is 5 feet, is required to sustain at the middle 3000 pounds, and the deflection not to exceed 0.01 inch per foot of its length; what must be the size of its sides?

By Rule XXVI. for load at middle, modified by Rule XXIX. for inclined beams; 3000, the weight, multiplied by 6, the length, and by 5, the horizontal distance between bearings, equals 90,000. The rate of deflection, 0.01, by 30,500, the value of E , Table II., for cast-iron, equals 305; and 9000 divided by 305, equals 295.082, the value of M . Now by Rule XXXI. for square beams, the square root of 295.082 is 17.18, the square root of which is 4.145—the size of the side required; a trifle over $4\frac{1}{8}$, the bar may, therefore, be $4\frac{1}{8}$ inches square.

Example.—Same as preceding, but the weight equally distributed. By Rule XXVII. $\frac{5}{8}$ of the weight is to be used instead of the weight; therefore 295.082, the value of M , as above, multiplied by $\frac{5}{8}$, will equal 184.426, the value of N . By Rule XXXI. the square root of 184.426 is 13.58, the square root of which is 3.685—the size of the side required; equal to nearly $3\frac{1}{2}$ inches square.

Example.—Same as preceding case, but the weight per foot superficial, and sustained by 2 or more bars, placed 2 feet from centres, the load being 250 pounds per foot superficial. By Rule XXVIII., modified by Rule XXIX., the distance from centres, 2, multiplied by 36, the square of the length, and by 5, the horizontal distance, equals 360. This by $156\frac{25}{8}$, five-eighths of the weight, equals 56,250. The rate of deflection, 0.01, by 30,500, the value of E , Table II., for cast-iron, equals 305. The above 56,250, divided by 305, equals 184.426, the value of U . Now by Rule XXXI. the square root of 184.426, the value of U , is 13.58, the square root of which is 3.685—the size of the side required. It will be observed that this result is precisely like that in the last example. This is as it should be, for each beam has to sustain the weight on 2×6

= 12 superficial feet, equal to 12×250 , equal 3000 pounds; and all the other conditions are parallel.

Rule XXXII.—When the beam is round to find the diameter. Divide the value of M , N or U , found by Rules XXVI., XXVII. or XXVIII., by the decimal 0.589, and extract the square root: and the square root of this square root will be the diameter required.

Example.—In the case of a concentrated load at middle A round bar of American iron, of 5 feet clear bearing, is required to sustain 800 pounds at the middle, with a deflection not to exceed 0.02 inch per foot; what must be its diameter? By Rule XXVI. for load at middle, 800, the weight, multiplied by 25, the square of the length, equals 20,000. The rate of deflection, 0.02, by 51,400, the value of E , Table II., for American wrought iron, equals 1028. The above 20,000, divided by 1028, equals 19.4552, the value of M . Now, by Rule XXXII., 19.4552, the value of M , divided by 0.589 equals 33.03, the square root of which is 5.747, and the square root of this is 2.397, nearly 2.4, the diameter required in inches, equal to $2\frac{2}{3}$ large.

Example.—Same case as the preceding, but the load equally distributed. By Rule XXVII., five-eighths of the weight is to be used instead of the whole weight; therefore the above 33.03, multiplied by $\frac{5}{8}$, equals 20.64375, the square root of which is 4.544, and the square root of this square root is 2.132, the diameter required in inches, $2\frac{1}{8}$ inches large.

Example.—When the weight is per foot superficial, and sustained by two or more bars or beams. The conditions being the same as in the preceding examples, but the weight, 100 pounds per foot, is to be sustained on a series of round rods, placed 18 inches apart from centres, equal 1.5 feet. By Rule XXVIII., for weight per foot superficial, 1.5, the distance from centres, multiplied by 125, the cube of the length, and by 62.5, five-eighths of the weight, equals 11,718.75. This

divided by 1028, the product of the rate of deflection by the value of E , as found in the preceding example, equals 11.4, the value of U . Now by Rule XXVII., 11.4, the value of U , divided by 0.589, equals 19.42, the square root of which is 4.407, and the square root of this square root is 2.099, the diameter required—very nearly $2\frac{1}{8}$ inches.

Example.—When the beam is round and laid inclining, the weight concentrated at the middle. A round beam of white pine, 20 feet long between bearings, and laid inclining so that the horizontal distance between bearings is 18 feet, is required to support 1250 pounds at the middle, with a deflection not to exceed 0.05 inch per foot; what must be its diameter? By Rule XXVI. for load at middle, modified by Rule XXIX. for inclined beams, 1250, the weight, multiplied by 20, the length, and by 18, the horizontal distance, equals 450,000. The rate of deflection, 0.05, multiplied by 1750, the value of E , Table II., for white pine, equals 87.5. The above 450,000 divided by 87.5, equals 5142.86, the value of M . Now by Rule XXXII. for round beams, 5142.86, the value of M , divided by 0.589, equals 8731.5, the square root of which is 93.44, and the square root of this square root is 9.667, the diameter required—equal to $9\frac{2}{3}$ inches.

Example.—Same as in preceding example, but the weight equally distributed. By Rule XXVII., five-eighths of the weight is to be used instead of the whole weight, therefore 8731.5, the result in the last example just previous to taking the square root, multiplied by $\frac{5}{8}$, equals 5457.2, the square root of which is 73.87, and the square root of this square root is 8.59, the diameter required—nearly $8\frac{5}{8}$ inches.

Example.—Same as in the next but one preceding example, but the weight per foot superficial, and supported by two or more beams. A series of round hemlock poles or beams, 10 feet long clear bearing, laid inclining so as that the horizontal distance between the supports equals 7 feet, and laid 2 feet

and 6 inches apart from centres, are required to support 20 pounds per superficial foot without regard to the amount of deflection, provided that the elasticity of the material be not injured; what must be their diameter? By Rule XXVIII. for weight per foot superficial, modified by Rule XXIX. for inclined beams, 2·5, the distance from centres, multiplied by 100, the square of the length, and by 7, the horizontal distance between bearings, and by five-eighths of the weight, 12·5, equals 21,875. The greatest value of n , Table II., for hemlock, 0·08794, multiplied by 1240, the value of E , Table II., for hemlock, equals 109·0456. The above 21,875, divided by 109·0456, equals 200·6, the value of U . Now by Rule XXXII., the above 200·6, divided by 0·589, equals 340·6, the square root of which is 18·46, and the square root of this square root is 4·296, the diameter required—equal to $4\frac{5}{16}$ inches nearly.

329.—The greater the depth of a beam in proportion to the thickness, the greater the strength. But when the difference between the depth and the breadth is great, the beam must be stayed, (as at *Fig. 228*,) to prevent its falling over and breaking sideways. Their shrinking is another objection to deep beams; but where these evils can be remedied, the advantage of increasing the depth is considerable. The following rule is, *to find the strongest form for a beam out of a given quantity of timber.*

Rule.—Multiply the length in feet by the decimal, 0·6, and divide the given area in inches by the product; and the square of the quotient will give the depth in inches.

Example.—What is the strongest form for a beam whose given area of section is 48 inches, and length of bearing 20 feet? The length in feet, 20, multiplied by the decimal, 0·6, gives 12; the given area in inches, 48, divided by 12, gives a quotient of 4, the square of which is 16—this is the depth in inches; and the breadth must be 3 inches. A beam 16 inches

by 3 would bear twice as much as a square beam of the same area of section ; which shows how important it is to make beams deep and thin. In many old buildings, and even in new ones, in country places, the very reverse of this has been practised ; the principal beams being oftener laid on the broad side than on the narrower one.

The foregoing rules, stated algebraically, are placed in the following table.

TABLE V.—STIFFNESS OF BEAMS ; DIMENSIONS.

When the beam is laid	When the weight is	Rectangular.			Square.	Round.
		Value of depth.	Value of breadth.	When $b=dr$, value of d .	Value of a side.	Value of the diameter.
Horizontal	Concentrated at middle	(62.) $\sqrt[3]{\frac{wl^2}{Enb}}$	(63.) $\frac{wl^2}{En d^2}$	(64.) $\sqrt[3]{\frac{wl^2}{Enr}}$	(65.) $\sqrt[3]{\frac{wl^2}{En}}$	(66.) $\sqrt[3]{\frac{wl^2}{589 En}}$
	Equally distributed	(67.) $\sqrt[3]{\frac{5}{8}\frac{wl^2}{Enb}}$	(68.) $\frac{5}{8}\frac{wl^2}{En d^2}$	(69.) $\sqrt[3]{\frac{5}{8}\frac{wl^2}{Enr}}$	(70.) $\sqrt[3]{\frac{5}{8}\frac{wl^2}{En}}$	(71.) $\sqrt[3]{\frac{wl^2}{9424 En}}$
	By the foot superficial	(72.) $\sqrt[3]{\frac{5}{8}\frac{fc l^2}{Enb}}$	(73.) $\frac{5}{8}\frac{fc l^2}{En d^2}$	(74.) $\sqrt[3]{\frac{5}{8}\frac{fc l^2}{Enr}}$	(75.) $\sqrt[3]{\frac{5}{8}\frac{fc l^2}{En}}$	(76.) $\sqrt[3]{\frac{fc l^2}{9424 En}}$
Inclining	Concentrated at middle	(77.) $\sqrt[3]{\frac{wlh}{Enb}}$	(78.) $\frac{wlh}{En d^2}$	(79.) $\sqrt[3]{\frac{wlh}{Enr}}$	(80.) $\sqrt[3]{\frac{wlh}{En}}$	(81.) $\sqrt[3]{\frac{wlh}{589 En}}$
	Equally distributed	(82.) $\sqrt[3]{\frac{5}{8}\frac{wlh}{Enb}}$	(83.) $\frac{5}{8}\frac{wlh}{En d^2}$	(84.) $\sqrt[3]{\frac{5}{8}\frac{wlh}{Enr}}$	(85.) $\sqrt[3]{\frac{5}{8}\frac{wlh}{En}}$	(86.) $\sqrt[3]{\frac{wlh}{9424 En}}$
	By the foot superficial	(87.) $\sqrt[3]{\frac{5}{8}\frac{fc l^2 h}{Enb}}$	(88.) $\frac{5}{8}\frac{fc l^2 h}{En d^2}$	(89.) $\sqrt[3]{\frac{5}{8}\frac{fc l^2 h}{Enr}}$	(90.) $\sqrt[3]{\frac{5}{8}\frac{fc l^2 h}{En}}$	(91.) $\sqrt[3]{\frac{fc l^2 h}{9424 En}}$

In the above table, b equals the breadth, and d the depth of cross-section of beam ; n equals the rate of deflection per foot of the length ; b , d and n , all in inches. Also, l equals the length, c the distance between two parallel beams measured from the

centres of their breadth, and h equals the horizontal distance between the supports of an inclined beam; l , c and h , all in feet. Again, w equals the weight on the beam, f equals the weight upon each superficial foot of a floor or roof, supported by two or more beams laid parallel and at equal distances apart; w and f in pounds. And r is any decimal, chosen at pleasure, in proportion to unity, as b is to d —from which proportion $b = dr$. E is a constant the value of which is found in Table II.

330.—*To ascertain the scantling of the stiffest beam that can be cut from a cylinder.* Let $d a c b$, (Fig. 223,) be the section, and e the centre, of a given cylinder. Draw the diameter, $a b$; upon a and b , with the radius of the section, describe the arcs, $d e$ and $e c$; join d and a , a and e , e and b , and b and d ; then the rectangle, $d a c b$, will be a section of the beam required.




Fig. 223.

331.—*Resistance to Rupture.*—The resistance to deflection having been treated of in the preceding articles, it now remains to speak of the other branch of resistance to cross strains, namely, the resistance to *rupture*. When a beam is laid horizontally and supported at each end, its strength to resist a cross strain, caused by a weight or vertical pressure at the middle of its length, is directly as the breadth and square of the depth and inversely as the length. If the beam is square, or the depth equal to the breadth, then the strength is directly

as the cube of a side of the beam and inversely as the length, and if the beam is round the strength is directly as the cube of the diameter and inversely as the length.

When the weight is concentrated at any point in the length, the strength of the beam is directly as the length, breadth, and square of the depth, and inversely as the product of the two parts into which the length is divided by the point at which the weight is located.

When the beam is laid not horizontal but inclining, the strength is the same as in each case above stated, and also in proportion, inversely as the cosine of the angle of inclination with the horizon, or, which is the same thing, directly as the length and inversely as the horizontal distance between the points of support.

When the weight is equally diffused over the length of a beam, it will sustain just twice the weight that could be sustained at the middle of its length.

A beam secured at one end only, will sustain at the other end just one-quarter of the weight that could be sustained at its middle were the beam supported at each end.

These relations between the strain and the strength exist in all materials. For any particular kind of material,

$$\frac{wl}{b^2d^3} = S; \quad (92.)$$

S , representing a constant quantity for all materials of like strength. The superior strength of one kind of material over another is ascertained by experiment; the value of S being ascertained by a substitution of the dimensions of the piece tried for the symbols in the above formula. Having thus obtained the value of S , the formula, by proper inversion, becomes useful in ascertaining the dimensions of a beam that will require a certain weight to break it; or to ascertain the weight that will be required to break a certain beam. It will be observed in the preceding formula, that if each of the dimensions of the

beam equal unity, then $w = S$. Hence, S is equal to the weight required to break a beam one inch square and one foot long. The values of S , for various materials, have been ascertained from experiment, and are here recorded:—

TABLE VI.—STRENGTH.

Materials.	Value of S .	Number of Experiments.
Green plate-glass	178	4
Spruce	345	5
Hemlock	363	7
Soft white pine	390	9
Hard white pine	449	1
Ohio yellow pine	454	2
Chestnut	508	2
Georgia pine	510	7
Oak	574	2
Locust	742	2
Cast-iron (from 1550 to 2280)	1926	29

The specimens broken were of various dimensions, from one foot long to three feet, and from one inch square to one by three inches. The cast-iron specimens were of the various kinds of iron used in this country in the mechanic arts. S may be taken at 2,000 for a good quality of cast-iron. It is usual in determining the dimensions of a beam to suppose it capable of sustaining safely one-third of the breaking weight, and yet Tredgold asserts that one-fifth of the breaking weight will in time injure the beam so as to give it a permanent set or bend, and Hodgkinson says that cast-iron is injured by any weight however small, or, in other words, that it has no elastic power. However this may be, experience has proved cast-iron quite reliable in sustaining safely immense weights for a long period. Practice has shown that beams will sustain safely from one-third to one-sixth of their breaking weight. If the load is laid on quietly, and is to remain where laid, at rest, beams may be trusted with one-third of their breaking weight, but if the load is moveable, or subject to vibration,

one-quarter, one-fifth, or even, in some cases, one-sixth is quite a sufficient proportion of the breaking load.

332.—The dimensions of beams should be ascertained only by means of the rules for the *stiffness* of materials, (*Arts.* 320, 323, *et seq.*), as these rules show more accurately the amount of pressure the material is capable of sustaining without injury. Yet owing to the fact that the rules for the *strength* of materials are somewhat shorter, they are more frequently used than those for the *stiffness* of materials. In order that the *proportion* of the breaking weight may be adjusted to suit circumstances it is well to introduce into the formula a symbol to represent it. The proportion represented by the symbol may then be varied at discretion. Let this symbol be a , a decimal in proportion to unity as the safe load is to the breaking load, then $S a$ will equal the safe load. Hence,

$$w = \frac{S a b d^2}{l} \quad (93.)$$

for a safe load at middle on a horizontal beam supported at both ends; and

$$w = \frac{2 S a b d^2}{l} \quad (94.)$$

for a safe load equally diffused over the length of the beam; and

$$f = \frac{2 S a b d^2}{c l^2} \quad (95.)$$

for the load, per superficial foot, that can be sustained safely upon a floor supported by two or more beams, c being the distance in feet from centres between each two beams, and f the load in pounds per superficial foot of the floor. Generally, in (93,) (94,) and (95,) w equals the load in pounds; S , a constant, the value of which is found in Table VI.; a a decimal, in proportion to unity as the safe load is to the breaking load; l the length in feet between the bearings; and b and d the breadth and depth in inches.

TO FIND THE WEIGHT.

333.—The formulas for ascertaining the weight in the several cases are arranged in the following table, where c , f , w , S , a , l , b and d represent as above; and also s equals a side of a square beam; D equals the diameter of a cylindrical beam; m and n equal respectively the two parts into which the length is divided by the point at which the weight is located; and h equals the horizontal distance between the supports of an inclined beam.

TABLE VII.—STRENGTH OF BEAMS; SAFE WEIGHT.

When the beam is laid	When the weight is	When the beam is		
		Rectangular.	Square.	Round.
Horizontal	Concentrated at middle, w , in pounds, equals	(96.) $\frac{S a b d^2}{l}$	(97.) $\frac{S a s^3}{l}$	(98.) $\frac{.589 D^3 S a}{l}$
	Equally distributed, w , in pounds, equals	(99.) $\frac{2 S a b d^2}{l}$	(100.) $\frac{2 S a s^3}{l}$	(101.) $\frac{1.178 D^3 S a}{l}$
	By the foot superficial, f , in pounds, equals	(102.) $\frac{2 S a b d^2}{c l^2}$	(103.) $\frac{2 S a s^3}{c l^2}$	(104.) $\frac{1.178 D^3 S a}{c l^2}$
	Concentrated at any point in the length, w , in pounds, equals	(105.) $\frac{S a b d^2 l}{4 m n}$	(106.) $\frac{S a l s^3}{4 m n}$	(107.) $\frac{.147 D^3 S a l}{m n}$
Inclining	Concentrated at middle, w , in pounds, equals	(108.) $\frac{S a b d^2}{h}$	(109.) $\frac{S a s^3}{h}$	(110.) $\frac{.589 D^3 S a}{h}$
	Equally distributed, w , in pounds, equals	(111.) $\frac{2 S a b d^2}{h}$	(112.) $\frac{2 S a s^3}{h}$	(113.) $\frac{1.178 D^3 S a}{h}$
	By the foot superficial, f , in pounds, equals	(114.) $\frac{2 S a b d^2}{c h l}$	(115.) $\frac{2 S a s^3}{c h l}$	(116.) $\frac{1.178 D^3 S a}{c h l}$
	Concentrated at any point in the length, w , in pounds, equals	(117.) $\frac{S a b d^2 l^2}{4 h m n}$	(118.) $\frac{S a l^2 s^3}{4 h m n}$	(119.) $\frac{.147 D^3 S a l^2}{h m n}$

Practical Rules and Examples.

Rule XXXIII.—To find the weight that may be *supported safely* at the *middle* of a beam laid *horizontally*. Multiply the value of *S*, Table VI., by a decimal that is in proportion to unity as the safe weight is to the breaking weight, and divide the product by the length in feet. Then, if the beam is rectangular, multiply this quotient by the breadth and by the square of the depth, and the product will be the required weight in pounds; or, if the beam is square, multiply the said quotient, instead, by the cube of a side of the beam and the product will be the required weight in pounds; but, if the beam is round, multiply the aforesaid quotient, instead, by $\cdot 589$ times the cube of the diameter, and the product will be the required weight in pounds.

Example.—What weight will a *rectangular* white pine beam, 20 feet long, and 3 by 10 inches, sustain safely at the middle, the portion of the breaking weight allowable being 0·3? By the above rule, 390, the value of *S* for white pine, Table VI., multiplied by 0·3, the decimal referred to, equals 117, and this divided by 20, the length, the quotient is 5·85. Now the beam being rectangular, this quotient multiplied by 3 and by 100, the breadth and the square of the depth, the product, 1755, is the desired weight in pounds.

Example.—If the above beam had been *square*, and 6 by 6 inches, then the quotient, 5·85, multiplied by 216, the cube of 6, a side, the product, 1263·6, is the weight required in pounds.

Example.—If the above beam had been *round*, and 6 inches diameter, then the above quotient, 5·85, multiplied by $\cdot 589$ times 216, the cube of the diameter, the product, 744·26, would be the required weight in pounds.

Rule XXXIV.—To find the weight that may be *supported safely* when *equally distributed* over the length of a beam, laid *horizontally*. Multiply the result obtained, by Rule

XXXIII., by 2, and the product will be the required weight in pounds.

Example.—In the example, under Rule XXXIII., the safe weight at middle of *rectangular* beam is found to be 1755 pounds. This multiplied by 2, the product, 3510, is the weight the beam will bear safely if equally distributed over its length.

Example.—So in the case of the *square* beam, 2527·2 pounds is the weight, equally distributed, that may be safely sustained.

Example.—And for the *round* beam 1488·52 is the required weight.

Rule XXXV.—To ascertain the weight *per superficial foot* that may be *safely sustained* on a floor resting on two or more beams laid *horizontally* and parallel. Multiply twice the value of *S*, Table VI., by the decimal that is in proportion to unity, as the safe weight is to the breaking weight, and divide the product by the square of the length, in feet, multiplied by the distance apart, in feet, between the beams measured from their centres. Now, if the beams are *rectangular*, multiply this quotient by the breadth and by the square of the depth, both in inches, and the product will be the required weight in pounds; or if the beams are *square*, multiply said quotient, instead, by the cube of a side of a beam and the product will be the required weight in pounds. But if the beams are *round*, multiply the aforesaid quotient, instead, by ·589 times the cube of the diameter, and the product will be the weight required in pounds.

Example.—What weight may be safely sustained on each foot superficial of a floor resting on spruce beams, 10 feet long, 3 by 9 inches, placed 16 inches, or $1\frac{1}{3}$ feet, from centres: the portion of the breaking weight allowable being 0·25? By the Rule, 690, twice the value of spruce, Table VI., multiplied by 0·25, the decimal aforesaid, equals 172·5. This product divided by 100, the square of the length, multiplied by $1\frac{1}{3}$, the distance

from centres, equals 1.294. Now this quotient multiplied by 3, the breadth, and by 81, the square of the depth, the product 314.44 is the required weight in pounds.

Had these beams been *square*, and 6 by 6 inches, the required weight would be 279.5 pounds.

Or, if *round*, and 6 inches diameter, 164.63 pounds.

Rule XXXVI.—To ascertain the weight that may be *sustained safely* on a beam when *concentrated at any point* of its length. Multiply the value of *S*, Table VI., by the decimal in proportion to unity, as the safe weight is to the breaking weight, and by the length in feet, and divide the product by four times the product of the two parts, in feet, into which the length is divided, by the point at which the weight is concentrated. Then, if the beam is *rectangular*, multiply this quotient by the breadth and by the cube of the depth, both in inches, and the product will be the required weight in pounds. Or, if the beam is *square*, multiply the said quotient, instead, by the cube of a side of the beam, and the product will be the required weight in pounds. But if the beam is *round*, multiply the aforesaid quotient by .589 times the cube of the diameter, and the product will be the weight required.

Example.—What weight may be safely supported on a Georgia pine beam, 5 by 12 inches, and 20 feet long; the weight placed at 5 feet from one end, and the proportion of the breaking weight allowable being 0.2? By the rule, 510, the value of *S* for Georgia pine, Table VI., multiplied by 0.2, the decimal referred to, equals 102; this by 20, the length, equals 2040; this divided by 300, ($= 4 \times 5 \times 15$), or 4 times the product of the two parts into which the length is divided by the point at which the weight is located, equals 6.8. The beam being *rectangular*, this quotient multiplied by 5, the breadth, and by 144, the square of the depth, equals 4896, the required weight.

A beam, 8 inches *square*, other conditions being the same as in the preceding case, would sustain safely 3481.6 pounds.

And a *round* beam, 8 inches diameter, will sustain safely, under like conditions, 2050·66 pounds.

Rule XXXVII.—To find the weight that may be *safely sustained on inclined beams*. Multiply the result found for horizontal beams in preceding rules, by the length, in feet, and divide the product by the horizontal distance between the supports, in feet, and the quotient will be the required weight.

Example.—What weight may be safely sustained at the middle of an oak beam, 6 × 10 inches, and 10 feet long, (set inclining, so that the horizontal distance between the supports is 8 feet,) the portion of the breaking weight allowable being 0·3? The result for a horizontal beam, by Rule XXXIII., is 10,332 pounds. This, multiplied by 10, the length, and divided by 8, the horizontal distance, equals 12,915 pounds, the required weight.

TO FIND THE DIMENSIONS.

334.—The following table exhibits, algebraically, rules for ascertaining the dimensions of beams required to support given weights; where b equals the breadth, and d the depth of a rectangular beam, in inches; l the length between supports; h the horizontal distance between the supports of an inclined beam, and c the distance apart of two parallel beams, measured from the centres of their breadth, l , h , and c , in feet; w equals the weight on a beam; f the weight on each superficial foot of a floor resting on two or more parallel beams; R equals a load on a beam, and m and n the distances, respectively, at which R is located from the two supports; also P is a weight, and g and k the distances, respectively, at which P is located from the two supports; also $m + n = l = g + k$; w , f , R , and P , all in pounds; m , n , g , and k , in feet. S is a constant, the value of which is found in Table VI.; a is a decimal in proportion to unity as the safe load is to the break

ing load; r is a decimal in proportion to unity as b is to d ; from which $b = d r$; a and r to be chosen at discretion.

TABLE VIII.—STRENGTH

When the beam is laid	When the weight is	Rectangular.	
		Value of depth.	Value of breadth.
Horizontal.	Concentrated at middle	(120.) $\sqrt{\frac{w l}{S a b}}$	(121.) $\frac{w l}{S a d^2}$
	Equally distributed	(125.) $\sqrt{\frac{w l}{2 S a b}}$	(126.) $\frac{w l}{2 S a d^2}$
	By the foot superficial	(130.) $\sqrt{\frac{f c l^2}{2 S a b}}$	(181.) $\frac{f c l^2}{2 S a d^2}$
	Concentrated at any point in the length	(135.) $\sqrt[4]{\frac{w m n}{S a b l}}$	(186.) $\frac{4 w m n}{S a d^2 l}$
	At two or more points in the length	(140.) $\sqrt[4]{\frac{R m n + P g k + \&c.}{S a b l}}$	(141.) $\frac{4 (R m n + P g k + \&c.)}{S a d^2 l}$
Inclining	Concentrated at middle	(145.) $\sqrt{\frac{w h}{S a b}}$	(146.) $\frac{w h}{S a d^2}$
	Equally distributed	(150.) $\sqrt{\frac{w h}{2 S a b}}$	(151.) $\frac{w h}{2 S a d^2}$
	By the foot superficial	(155.) $\sqrt{\frac{f c h l}{2 S a b}}$	(156.) $\frac{f c h l}{2 S a d^2}$
	Concentrated at any point in the length	(160.) $\sqrt[4]{\frac{h w m n}{S a b l^2}}$	(161.) $\frac{4 h w m n}{S a d^2 l^2}$
	At two or more points in the length	(165.) $\sqrt[4]{\frac{h (R m n + P g k + \&c.)}{S a b l^2}}$	(166.) $\frac{4 h (R m n + P g k + \&c.)}{S a d^2 l^2}$

OF BEAMS ; DIMENSIONS.

	Square.	Round.
When $b = d$ r. value of d .	Value of a side.	Value of the diameter.
(122.) $\sqrt[3]{\frac{w l}{S a r}}$	(123.) $\sqrt[3]{\frac{w l}{S a}}$	(124.) $\sqrt[3]{\frac{w l}{.589 S a}}$
(127.) $\sqrt[3]{\frac{w l}{2 S a r}}$	(128.) $\sqrt[3]{\frac{w l}{2 S a}}$	(129.) $\sqrt[3]{\frac{w l}{1.178 S a}}$
(132.) $\sqrt[3]{\frac{f c l^2}{2 S a r}}$	(133.) $\sqrt[3]{\frac{f c l^2}{2 S a}}$	(134.) $\sqrt[3]{\frac{f c l^2}{1.178 S a}}$
(137.) $\sqrt[3]{\frac{4 w m n}{S a r l}}$	(138.) $\sqrt[3]{\frac{4 w m n}{S a l}}$	(139.) $\sqrt[3]{\frac{w m n}{.147 S a l}}$
(142.) $\sqrt[3]{\frac{(R m n + P g k + \&c.)}{S a r l}}$	(143.) $\sqrt[3]{\frac{(R m n + P g k + \&c.)}{S a l}}$	(144.) $\sqrt[3]{\frac{(R m n + P g k + \&c.)}{.147 S a l}}$
(147.) $\sqrt[3]{\frac{w h}{S a r}}$	(148.) $\sqrt[3]{\frac{w h}{S a}}$	(149.) $\sqrt[3]{\frac{w h}{.589 S a}}$
(152.) $\sqrt[3]{\frac{w h}{2 S a r}}$	(153.) $\sqrt[3]{\frac{w h}{2 S a}}$	(154.) $\sqrt[3]{\frac{w h}{1.178 S a}}$
(157.) $\sqrt[3]{\frac{f c h l}{2 S a r}}$	(158.) $\sqrt[3]{\frac{f c h l}{2 S a}}$	(159.) $\sqrt[3]{\frac{f c h l}{1.178 S a}}$
(162.) $\sqrt[3]{\frac{4 h w m n}{S a r l}}$	(163.) $\sqrt[3]{\frac{4 h w m n}{S a l}}$	(164.) $\sqrt[3]{\frac{h w m n}{.147 S a l}}$
(167.) $\sqrt[3]{\frac{4 h (R m n + P g k + \&c.)}{S a r l}}$	(168.) $\sqrt[3]{\frac{4 h (R m n + P g k + \&c.)}{S a l}}$	(169.) $\sqrt[3]{\frac{h (R m n + P g k + \&c.)}{.147 S a l}}$

Practical Rules and Examples.

Rule XXXVIII.—Preliminary. *When the weight is concentrated at the middle.* Multiply the weight, in pounds, by the length, in feet, and divide the product by the value of S , Table VI., multiplied by a decimal that is in proportion to unity as the safe weight is to the breaking weight, and the quotient is a quantity which may be represented by J , referred to in succeeding rules.

$$\frac{w l}{S a} = J \quad (170.)$$

Rule XXXIX.—Preliminary. *When the weight is equally distributed.* One-half of the quotient obtained by the preceding rule is a quantity which may be represented by K , referred to in succeeding rules.

$$\frac{w l}{2 S a} = K \quad (171.)$$

Rule XL.—Preliminary. *When the weight is per foot superficial.* Multiply the weight per foot superficial, in pounds, by the square of the length, in feet, and by the distance apart from centres between two parallel beams, and divide the product by twice the value of S , Table VI., multiplied by a decimal in proportion to unity as the safe weight is to the breaking weight, and the quotient is a quantity which may be represented by L , referred to in succeeding rules.

$$\frac{f c^2}{2 S a} = L \quad (172.)$$

Rule XLI.—Preliminary. *When the weight is concentrated at any point in the length.* Multiply the distance, in feet, from the loaded point to one support, by the distance, in feet, from the same point to the other support, and by four times the weight in pounds, and divide the product by the value of S , Table VI., multiplied by a decimal in proportion to unity as the safe weight is to the breaking weight, and by the length,

in feet; and the quotient is a quantity which may be represented by Q , referred to in the rules.

$$\frac{4 w m n}{S a l} = Q \quad (173.)$$

Rule XLII.—Preliminary. When two or more weights are concentrated at any points in the length of the beams. Multiply each weight by each of the two parts, in feet, into which the length is divided by the point at which the weight is located, and divide four times the sum of these products by the value of S , Table VI., multiplied by a decimal in proportion to unity as the safe weight is to the breaking weight, and by the length, in feet, and the quotient is a quantity which may be represented by V , referred to in the rules.

$$\frac{4 (R m n + P g k + \text{&c.})}{S a l} = V \quad (174.)$$

Rule XLIII.—Preliminary. When the beam is not laid horizontal, but inclining. In the five preceding preliminary rules, multiply the result there obtained by the horizontal distance between the supports, in feet, and divide the product by the length, in feet, and the quotient in each case is to be used for beams when inclined, as referred to in succeeding rules.

TO FIND THE DIMENSIONS.

*Rule XLIV.—*When the beam is *rectangular*. To find the *depth*. Divide the quantity represented in preceding rules by J , K , L , Q , or V , by the breadth, in inches, and the square root of the quotient will be the depth required in inches.

To find the *breadth*. Divide the quantity represented by J , K , L , Q , or V , by the square of the depth, and the quotient will be the required breadth, in inches.

To find both *breadth* and *depth*, when they are to be in a given proportion. Divide the quantity represented by J , K , L , Q , or V , by a decimal in proportion to unity as the breadth.

is to be to the depth, and the cube root of the quotient will be the *depth* in inches. Multiply the depth by the aforesaid decimal and the quotient will be the *breadth* in inches.

Example.—A locust beam, 10 feet long in the clear of the supports, is required to sustain safely 3,000 pounds at the middle of its length, the portion of the breaking weight allowable being 0·3; what is the required breadth and depth? Proceeding by the rule for weight concentrated at middle, (Rule XXXVIII.,) 3,000, the weight, by 10, the length, equals 30,000. The value of *S*, Table VI., for locust, is 742: this by 0·3 the decimal, as above, equals 222·6; the 30,000 aforesaid divided by this 222·6 equals 134·77, equals the quantity represented by *J*. Now to find the depth when the breadth is 4 inches, 134·77 divided by 4, the breadth, as above required, the quotient is 33·69, and the square root of this, 5·8, is the required depth in inches. But to find the breadth, when the depth is known, let the depth be 6 inches, then 134·77 divided by 36, the square of the depth, equals 3·74, the breadth required in inches. Again, to find both breadth and depth in a given proportion, say, as 0·6 is to 1·0. Here 134·77 divided by 0·6 equals 224·617, the cube root of which is 6·08, the required depth in inches, and 6·08 by 0·6 equals 3·648, the required breadth in inches.

Thus it is seen, in this example, that a piece of locust timber, 10 feet long, having 3,000 pounds *concentrated* at the middle of its length, as $\frac{3}{10}$ of its breaking load, is required to be 4 by $5\frac{1}{2}$ inches, or $3\frac{3}{4}$ by 6 inches, or $3\frac{1}{2}$ by $6\frac{1}{8}$ inches. If this load were *equally diffused* over the length, the dimensions required would be found to be 4 by 4·1, or 1·87 by 6, or 2·895 by 4·825 inches, in the three cases respectively.

Example.—A tier of chestnut beams, 20 feet long, placed one foot apart from centres, is required to sustain 100 pounds per superficial foot upon the floor laid upon them: this load to be 0·2 of the breaking weight; what is the required dimen-

sions of the cross-section? By Rule XL., the rule for a load per foot superficial, 100 by 20×20 and by 1 equals $40,000$. Twice 503 , the value of S for chestnut, Table VI., by 0.2 equals 201.2 . The above $40,000$ divided by 201.2 equals 198.8 , the value of L . Now if the breadth is known, and is 3 inches, 198.8 divided by 3 equals 66.27 , the square root of which is 8.14 , the required depth. But if the depth is known and is 9 inches, 198.8 divided by $(9 \times 9 =) 81$ equals 2.454 inches, the required breadth. Again, when the breadth and depth are required in the proportion of 0.25 to 1.0 , then 198.8 divided by 0.25 equals 795.2 , the cube root of which is 9.265 , the required depth in inches, and 9.265 by 0.25 equals 2.316 , the required breadth in inches.

Example.—A cast-iron bar, 10 feet long, is required to sustain safely $5,000$ pounds placed at 3 feet from one end, and consequently at 7 feet from the other end, the portion of the breaking load allowable being 0.3 ; what must be the size of the cross-section? By Rule XLI., the rule for a concentrated load at any point in the length of the beam, $3 \times 7 \times 4 \times 5000 = 420,000$. And 1926 , the value of S for cast-iron, Table VI., by 0.3 and by 10 equals 5778 . The aforesaid $420,000$ divided by this, 5778 , equals 72.689 , the value of Q . Now if the breadth is fixed at 1.5 then 72.689 divided by 1.5 equals 48.459 , the square root of which is 6.96 , the required depth in inches. But if the depth is fixed at 6 inches, then 72.689 , the value of Q , divided by 36 , the square of 6 , equals 2.019 , the required breadth in inches. Again, if the breadth and depth are required in the proportion 0.2 to 1.0 ; then Q , 72.689 , divided by 0.2 , equals 363.445 , the cube root of which is 7.136 , the required depth in inches; and 7.136 by 0.2 equals 1.427 , the required breadth in inches.

Rule XLV.—When the beam is *square* to find the breadth of a side. The cube root of the quantity represented by J , K , L , Q , or V , in preceding rules, is the breadth of the side required

Example.—A Georgia pine beam, 10 feet long, is required to sustain, as 0·3 of the breaking load, a weight of 30,000 pounds equally distributed over its length, and the beam to be square, what must be the breadth of the side of such a beam? By the rule for an equally distributed load, (Rule XXXIX.,) $30,000 \times 10 = 300,000$, and 510 (the value of S , for Georgia pine, Table VI.) $\times 0\cdot3 = 153$. 300,000 divided by 153 equals 1960·784, and one-half of this equals 980·392, the value of K . Now the cube root of this is 9·93± inches, or $9\frac{1}{2}$, the required side. Had the weight been concentrated at the middle 1960·784 would be the value of J , and the cube root of this 12·515, or $12\frac{1}{2}$ inches, would be the size of a side of the beam.

Example.—A square oak beam, 20 feet long, is required to sustain, as 0·25 of the breaking strength, three loads, one of 8,000 pounds at 5 feet from one end, one of 7,000 pounds at 14 feet, and one of 5,000 pounds at 8 feet from one end, what must be the breadth of a side of the beam? The value of S , for oak, Table VI., is 574. By the rule for this case, (Rule XLII.,) $8000 \times 5 \times 15$ equals 600,000; and $7000 \times 14 \times 6$ equals 588,000; and $5000 \times 8 \times 12$ equals 480,000. The sum of these products is 1,668,000; this by 4 equals 6,672,000. Now $574 \times 0\cdot25 \times 20$ equals 2870, and the 6,672,000 divided by the 2870 equals 2325, the number represented by V ; the cube root of which is 13·25, the required size of a side of the beam, $13\frac{1}{4}$ inches. This is for a horizontal beam. Now if this beam be laid inclining, so that the horizontal distance between the bearings is 15 feet, then to find the size by the rule for this case, viz. XLIII., the above number V , equal to 2325, multiplied by 15, the horizontal distance, equals 34,875, and this divided by 20, the length, equals 1743·75. Now by Rule XLV., the cube root of this is 12·04, the required size of a side—12 inches full.

Rule XLVI.—When the beam is *round*. Divide the quan-

tity represented by J , K , L , Q , or V by the decimal 0.589, and the cube root of the quotient will be the required diameter.

Example.—A white pine beam or pole, 10 feet long, is required to sustain, as the 0.2 of the breaking strength, a load of 5,000 pounds concentrated at the middle, what must be the diameter? The value of S , for white pine, Table VI., is 390. Now by the rule for load at middle, (XXXVIII.,) $5000 \times 10 = 50,000$; and $390 \times 0.2 = 78$; and $50,000 \div 78 = 641 = J$. By this rule, $641 \div 0.589 = 1088.28$, the cube root of which, 10.28, is the required diameter. If this beam be inclined, so that the horizontal distance between the supports is 7 feet, then to find the diameter, by Rule XLIII., value of J as above, 641 multiplied by 7 and divided by 10 equals 448.7. Now by this rule, $448.7 \div 0.589 = 761.796$, the cube root of which, 9.133, is the required diameter.

Example.—A spruce pole, 10 feet long, is required to sustain, as the $0.33\frac{1}{2}$ or $\frac{1}{3}$ of the breaking weight, a load of 1,000 pounds at 3 feet from one end, what must be the diameter? The value of S for spruce, Table VI., is 345. By the rule for this case, (Rule XLI.,) $3 \times 7 \times 4 \times 1000 = 84,000$; and $345 \times \frac{1}{3} \times 10 = 1150$; and $84,000 \div 1150 = 93.04$, the value of Q . Now by this rule, $93.04 \div 0.589 = 124$, the cube root of which, 4.9866, is the required diameter in inches.

335.—*Systems of Framing.* In the various parts of framing known as floors, partitions, roofs, bridges, &c., each has a specific object; and, in all designs for such constructions, this object should be kept clearly in view; the various parts being so disposed as to serve the design with the least quantity of material. The simplest form is the best, not only because it is the most economical, but for many other reasons. The great number of joints, in a complex design, render the construction liable to derangement by multiplied compressions, shrinkage, and, in consequence, highly increased oblique strains; by which its stability and durability are greatly lessened.

FLOORS.

336.—Floors are most generally constructed *single*, that is, simply a series of parallel beams, each spanning the width of




Fig 224.

the floor, as seen at *Fig. 224*. Occasionally floors are con




Fig. 225.

structed *double*, as at *Fig. 225*; and sometimes *framed*, as at




Fig. 226.

Fig. 226; but these methods are seldom practised, inasmuch as either of these require more timber than the single floor. Where lathing and plastering is attached to the floor beams to form a ceiling below, the springing of the beams, by customary use, is liable to crack the plastering. To obviate this in good dwellings, the double and framed floors have been resorted to, but more in former times than now, as the *cross-furring* (a series of narrow strips of board or plank, nailed transversely to the underside of the beams to receive the lathing for the plastering,) serves a like purpose very nearly as well.

337.—In single floors the dimensions of the beams are to be ascertained by the preceding rules for the *stiffness* of materials. These rules give the required dimensions for the various kinds of material in common use. The rules may be somewhat abridged for ordinary use, if some of the quantities represented in the formula be made constant within certain limits. For example, if the load per foot superficial, and the rate of deflection, be fixed, then these, together with the $\frac{5}{8}$, and the

constant represented by E' , may be reduced to one constant. For dwellings, the load per foot may be taken at 66 pounds, as this is the weight, that has been ascertained by experiment, to arise from a crowd of people on their feet. To this add 20 for the weight of the material of which the floor is composed, and the sum, 86, is the value of f , or the weight per foot superficial for dwellings. The rate of deflection allowable for this load may be fixed at 0.03 inch per foot of the length. Then (44) transposed,

$$\frac{5 f c l^3}{8 E' n} = b d^3$$

becomes

$$\frac{5 \times 86}{8 \times 0.03} \times \frac{c l^3}{E'} = b d^3$$

which, reduced, is

$$\frac{1800}{E'} \times c l^3 = b d^3 \quad (175.)$$

Reducing $\frac{1800}{E'}$ for five of the most common woods, and there results, rejecting small decimals, and putting $\frac{1800}{E'} = x$, x equal, for

Georgia pine	0.6
Oak	0.7
White pine	1.0
Spruce	1.15
Hemlock	1.45

Therefore, the rule is reduced to $x c l^3 = b d^3$. And for *white pine*, the wood most used for floor beams, $x = 1.0$, and therefore disappears from the formula, rendering it still more simple, thus,

$$c l^3 = b d^3 \quad (176.)$$

The dimensions of beams for stores, for all ordinary business, may also be calculated by this modified rule, (175.) for it will require about $3\frac{1}{2}$ times the weight used in this rule, or about

300 pounds, to increase the deflection to the limit of elasticity in white pine, and nearly that in the other woods. But for warehouses, taking the rate of deflection at its limit, and fixing the weight per foot at 500 pounds, including the weight of the material of which the floor is constructed, and letting y represent the constant, then

$$y c l^3 = b d^3 \quad (177.)$$

and y equals, for

Georgia pine	1.35
Oak	1.35
White pine	1.75
Spruce	2.2
Hemlock	2.85

338.—Hence to find the dimensions of floor beams for *dwellings* when the rate of deflection is 0.03 inch per foot, or for *ordinary stores* when the load is about 300 pounds per foot, and the deflection caused by this weight is within the limits of the elasticity of the material, we have the following rule :

Rule XLVII.—Multiply the cube of the length by the distance apart between the beams, (from centres,) both in feet, and multiply the product by the value of w , (*Art.* 337.) Now to find the breadth, divide this product by the cube of the depth in inches, and the quotient will be the breadth in inches. But if the depth is sought, divide the said product by the breadth in inches, and the cube root of the quotient will be the depth in inches ; or, if the breadth and depth are to be in proportion, as r is to unity, r representing any required decimal, then divide the aforesaid product by the value of r , and extract the square root of the quotient, and the square root of this square root will be the depth required in inches, and the depth multiplied by the value of r will be the breadth in inches.

Example.—*To find the breadth.* In a dwelling or ordinary store what must be the breadth of the beams, when placed 15

inches from centres, to support a floor covering a span of 16 feet, the depth being 11 inches, the beams of oak? By the rule, 4096, the cube of the length, by $1\frac{1}{4}$, the distance from centres, and by 0.7, the value of x , for oak, equals 3584. This divided by 1331, the cube of the depth, equals 2.69 inches, or $2\frac{11}{16}$ inches, the required breadth.

Example.—To find the depth. The conditions being the same as in the last example, what must be the depth when the breadth is 3 inches. The product, 3584, as above, divided by 3, the breadth, equals $1194\frac{2}{3}$; the cube root of this is 10.61, or $10\frac{5}{8}$ inches nearly.

Example.—To find the breadth and depth in proportion, say, as 0.3 to 1.0. The aforesaid product, 3584, divided by 0.3, the value of r , equals $11,946\frac{2}{3}$, the square root of which is 109.3, and the square root of this is 10.45, the required depth. This multiplied by 0.3, the value of r , equals 3.135, the required breadth, the beam is therefore to be $3\frac{1}{8}$ by $10\frac{1}{2}$ inches.

339.—And to find the breadth and depth of the beams for a floor of a *warehouse* sufficient to sustain 500 pounds per foot superficial, (including weight of the material in the floor,) with a deflection not exceeding the limits of the elasticity of the material, we have the following rule :

Rule XLVIII.—The same as XLVII., with the exception that the value of y (*Art.* 337) is to be used instead of the value of x .

Example.—To find the breadth. The beams of a warehouse floor are to be of Georgia pine, with a clear bearing between the walls of 15 feet, and placed 14 inches from centres, what must be the breadth when the depth is 11 inches? By the rule, 3375, the cube of the length, and $1\frac{1}{4}$, the distance from centres, and 1.35, the value of y , for Georgia pine, all multiplied together, equals 5315.625; and this product divided by 1331, the cube of the depth, equals 3.994, the required depth, or 4 inches.

Example.—To find the depth. The conditions remaining, as in last example, what must be the depth when the breadth is 3 inches? 5315·625, the said product, divided by 3, the breadth, equals 1771·875, and the cube root of this, 12·1, or 12 inches, is the depth required.

Example.—To find the breadth and depth in a given proportion, say, 0·35 to 1·0. 5315·625 aforesaid, divided by 0·35, the value of r , equals 15187·5, the square root of which is 121·8, and the square root of this square root is 11·04, or 11 inches, the required depth. And 11·04 multiplied by 0·35, the value of r , equals 3·864, the required breadth—3 $\frac{7}{8}$ inches.

340.—It is sometimes desirable, when the breadth and depth of the beams are fixed, or when the beams have been sawed and are now ready for use, to know the distance from centres at which such beams should be placed, in order that the floor be sufficiently stiff. In this case, (175,) transposed, and putting $x = \frac{1800}{E}$, there results

$$c = \frac{b d^3}{x l^3} \quad (178.)$$

This in words, at length, is, as follows :

Rule XLIX.—Multiply the cube of the depth by the breadth, both in inches, and divide the product by the cube of the length, in feet, multiplied by the value of x , for dwellings, and for ordinary stores, or by y for warehouses ; and the quotient will be the distance apart from centres in feet.

Example.—A span of 17 feet, in a dwelling, is to be covered by white pine beams, 3 × 12 inches, at what distance apart from centres must they be placed? By the rule, 1728, the cube of the depth, multiplied by 3, the breadth, equals 5184. The cube of 17 is 4913, this by 1·0, the value of x , for white pine, equals 4913. The aforesaid 5184, divided by this, 4913, equals 1·055 feet, or 1 foot and $\frac{2}{3}$ of an inch.

341.—Where chimneys, flues, stairs, etc., occur to interrupt




Fig. 227.

the bearing, the beams are framed into a piece, *b*, (Fig. 227,) called a *header*. The beams, *a a*, into which the header is framed, are called *trimmers* or *carriage-beams*. These framed beams require to be made thicker than the common beams. The header must be strong enough to sustain one-half of the weight that is sustained upon the *tail* beams, *c c*, (the wall at the opposite end or another header there sustaining the other half,) and the trimmers must each sustain one-half of the weight sustained by the header in *addition* to the weight it supports as a common beam. It is usual in practice to make these framed beams one inch thicker than the common beams for dwellings, and two inches thicker for heavy stores. This practice in ordinary cases answers very well, but in extreme cases these dimensions are not proper. Rules applicable generally must be deduced from the conditions of the case—the load to be sustained and the strength of the material.

342.—For the header, formula (68,) Table V., is applicable. The weight, represented by *w*, is equal to the superficial area of the floor supported by the header, multiplied by the load on every superficial foot of the floor. This is equal to the length of the header multiplied by half the length of the tail beams, and by 86 pounds for dwellings and ordinary stores, or

by 500 pounds for warehouses. Calling the length of the tail beams, in feet, g , formula (68,) becomes

$$b = \frac{f g l^3}{15 E d^3 n}$$

Then if f equals 86, and n equals 0.03, there results

$$b = \frac{900 g l^3}{E d^3} \quad (179.)$$

This in words, is, as follows:

Rule L.—Multiply 900 times the length of the tail beams by the cube of the length of the header, both in feet. The product, divided by the cube of the depth, multiplied by the value of E , Table II., will equal the breadth, in inches, for *dwelling*s or *ordinary* stores.

Example.—A header of white pine, for a dwelling, is 10 feet long, and sustains tail beams 20 feet long, its depth is 12 inches, what must be its breadth? By the rule, $900 \times 20 \times 10^3 = 18,000,000$. This, divided by $(12^3 \times 1750 =) 3,024,000$, equals 5.95, say 6 inches, the required breadth.

For heavy *warehouses* the rule is the same as the above, only using 1550 in the place of the 900. This constant may be varied, at discretion, to anything between 900 and 5000, in accordance with the use to which the floor is to be put.

343.—In regard to the trimmer or carriage beam, formula (136,) Table VIII., is applicable. The load thrown upon the trimmer, in *addition* to its load as a common beam, is equal to one-half of the load on the header, and therefore, as has been seen in last article, is equal to one-half of the superficial area of the floor, supported by the tail beams, multiplied by the weight per superficial foot of the load upon the floor; therefore, when the length of the header, in feet, is represented by j , and the length of the tail beam by n , w equals $\frac{j}{2} \times \frac{n}{2} \times f$, equals $\frac{1}{4} f j n$, and therefore (136,) of Table VIII., becomes

$$b = \frac{f j m n^2}{S a d^3 l}$$

equals the *additional* thickness to be given to a common beam when used as a trimmer, and for *dwellings* when f equals 86 and a equals 0.3, this part of the formula reduces to $286\frac{2}{3}$, or, for simplicity, call it 300, which would be the same as fixing f at 90 instead of 86. Then we have

$$b = \frac{300 \cdot j \cdot m \cdot n^2}{S \cdot d^2 \cdot l} \quad (180.)$$

This, in words, is as follows :

Rule LI.—For dwellings. Multiply 300 times the length of the header by the square of the length of the tail beams, and by the difference in length of the trimmer and tail beams, all in feet. Divide this product by the square of the depth in inches, multiplied by the length of the trimmer in feet, and by the value of S , Table VI., and the quotient added to the thickness of a common beam of the floor, will equal the required thickness of the trimmer beam.

Example.—A tier of 3×12 inch beams of white pine, having a clear bearing of 20 feet, has a framed well-hole at one side, of 5 by 12 feet, the header being 12 feet long, what must be the thickness of the trimmer beams? By the rule, $300 \times 12 \times 15^2 \times 5$, divided by the product of $12^2 \times 20 \times 390$, equals 3.6, and this added to 3, the thickness of one of the common beams, equals 6.6, the breadth required, $6\frac{1}{2}$ inches.

For *stores* and *warehouses* the rule is the same as the above, only the constant, 300, must be enlarged in proportion to the load intended for the floor, making it as high as 1600 for heavy warehouses.

344.—When a framed opening occurs at any point removed from the wall, requiring two headers, then the load from the headers rest at two points on the carriage beam, and here formula (141,) Table VIII., is applicable. In this special case this formula reduces to

$$b = \frac{300 \cdot j \cdot (m^2 \cdot n + k^2 \cdot g)}{S \cdot d^2 \cdot l} \quad (181.)$$

where b equals the *additional* thickness, in inches, to be given to the carriage beam over the thickness of the common beams; j , the length of the header, in feet; m and k the length, in feet, respectively, of the two sets of tail beams, and $m + n = k + g = l$.

The constant in the above, (181,) is for *dwelling*s; if the floor is to be loaded more than dwelling floors, then it must be increased in proportion to the increase of load up to as high as 1600 for *warehouses*.

Rule LII.—Trimmer beams for framed openings occurring so as to require two headers. Multiply the square of the length of each tail beam by the difference of length of the tail beam and trimmer, all in feet, and add the products; multiply their sum by 300 times the length, in feet, of the header, and divide this product by the product of the square of the depth, in inches, by the length, in feet, and by the value of S , Table VI.; and the quotient, added to the thickness of a common beam of the tier, will equal the thickness of the trimmer beams.

Example.—A tier of white pine beams, 4×14 inches, 20 feet long, is to have an opening of 5×10 feet, framed so that the length of one series of tail beams is 7 feet, the other 8 feet, what must be the breadth of the trimmers? Here, $(7^2 \times 13) + (8^2 \times 12)$ equals 1405. This by 300×10 equals 4,215,000. This divided by 1,528,800 ($= 14^2 + 20 \times 390$) equals 2.75, and this added to 4, the breadth, equals 6.75, or $6\frac{3}{4}$, the breadth required, in inches.

345.—Additional stiffness is given to a floor by the insertion of *bridging* strips, or struts, as at a , (*Fig.* 228.) These prevent the turning or twisting of the beams, and when a weight is placed upon the floor, concentrated over one beam, they prevent this beam from descending below the adjoining beams to the injury of the plastering upon the underside. It is usual to insert a course of bridging at every 5 to 8 feet of the length




Fig. 228.

of the beam. Strips of board or plank nailed to the underside of the floor beams to receive the lathing, are termed *cross-furring*, and should not be over 2 inches wide, and placed 12 inches from centres. It is desirable that all furring be narrow, in order that the *clinch* of the mortar be interrupted but little. When it is desirable to prevent the passage of sound, the openings between the beams, at about 3 inches from the upper edge, are closed by short pieces of boards, which rest on cleats, nailed to the beam along its whole length. This forms a floor, on which mortar is laid from 1 to 2 inches deep. This is called *deafening*.

346.—When the distance between the walls of a building is great, it becomes requisite to introduce girders, as an additional support, beneath the beams. The dimensions of girders may be ascertained by the general rules for stiffness. Formulas (72,) (73,) and (74,) Table V., are applicable, taking f , at 86, for dwellings and ordinary stores, and increased in proportion to the load, up to 500, for heavy warehouses. When but one girder occurs, in the length of the beam, the distance from centres, c , is equal to one-half the length of the beam.

347.—When the breadth of a girder is more than about 12 inches, it is recommended to divide it by sawing from end to end, vertically through the middle, and then to bolt it to

gether with the sawn sides outwards. This is not to strengthen the girder, as some have supposed, but to reduce the size of the timber, in order that it may dry sooner. The operation affords also an opportunity to examine the heart of the stick—a necessary precaution; as large trees are frequently in a state of decay at the heart, although outwardly they are seemingly sound. When the halves are bolted together, thin slips of wood should be inserted between them at the several points at which they are bolted, in order to leave sufficient space for the air to circulate between. This tends to prevent decay; which will be found first at such parts as are not exactly tight, nor yet far enough apart to permit the escape of moisture.

348.—When girders are required for a long bearing, it is usual to truss them; that is, to insert between the halves two pieces of oak which are inclined towards each other, and which meet at the centre of the length of the girder, like the rafters of a roof-truss, though nearly if not quite concealed within the girder. This, and many similar methods, though extensively practised, are generally worse than useless; since it has been ascertained that, in nearly all such cases, the operation has positively *weakened* the girder.

A girder may be strengthened by mechanical contrivance, when its depth is required to be greater than any one piece of




Fig. 229.

timber will allow. *Fig. 229* shows a very simple yet invaluable method of doing this. The two pieces of which the girder is composed are bolted, or pinned together, having keys inserted between to prevent the pieces from sliding. The keys should be of hard wood, well seasoned. The two pieces should be about equal in depth, in order that the joint between them may be in the neutral line. (See *Art. 317*.) The thickness of the keys should be about half their breadth, and the amount of their united thicknesses should be equal to a trifle over the depth and one-third of the depth of the girder. Instead of bolts or pins, iron hoops are sometimes used; and when they can be procured, they are far preferable. In this case, the girder is diminished at the ends, and the hoops driven from each end towards the middle.

349.—Beams may be spliced, if none of a sufficient length can be obtained, though not at or near the middle, if it can be avoided. (See *Art. 281*.) Girders should rest from 9 to 12 inches on the wall, and a space should be left for the air to circulate around the ends, that the dampness may evaporate. Floor-timbers are supported at their ends by walls of considerable height. They should not be permitted to rest upon intervening partitions, which are not likely to settle as much as the walls; otherwise the unequal settlements will derange the level of the floor. As all floors, however well-constructed, settle in some degree, it is advisable to frame the beams a little higher at the middle of the room than at its sides,—as also the ceiling-joists and cross-furring, when either are used. In single floors, for the same reason, the rounded edge of the stick, if it have one, should be placed uppermost.

If the floor-plank are laid down temporarily at first, and left to season a few months before they are finally driven together and secured, the joints will remain much closer. But if the edges of the plank are planed after the first laying, they will

shrink again; as it is the nature of wood to shrink after *every* planing however dry it may have been before.

PARTITIONS.

350.—Too little attention has been given to the construction of this part of the frame-work of a house. The settling of floors and the cracking of ceilings and walls, which disfigure to so great an extent the apartments of even our most costly houses, may be attributed almost solely to this negligence. A square of partitioning weighs nearly a ton, a greater weight, when added to its customary load, such as furniture, storage, &c., than any ordinary floor is calculated to sustain. Hence the timbers bend, the ceilings and cornices crack, and the whole interior part of the house settles; showing the necessity for providing adequate supports independent of the floor-timbers. A partition should, if practicable, be supported by the walls with which it is connected, in order, if the walls settle, that it may settle with them. This would prevent the separation of the plastering at the angles of rooms. For the same reason, a firm connection with the ceiling is an important object in the construction of a partition.

351.—The joists in a partition should be so placed as to discharge the weight upon the points of support. All oblique pieces in a partition, that tend not to this object, are much better omitted. *Fig.* 230 represents a partition having a door in the middle. Its construction is simple but effective. *Fig.* 231 shows the manner of constructing a partition having doors near the ends. The truss is formed above the door-heads, and the lower parts are suspended from it. The posts, *a* and *b*, are halved, and nailed to the tie, *c d*, and the sill, *e f*. The braces in a trussed partition should be placed so as to form, as near as possible, an angle of 40 degrees with the horizon. In partitions that are intended to support only their own weight,




Fig. 230.




Fig. 231.

the principal timbers may be 3×4 inches for a 20 feet span, $3\frac{1}{2} \times 5$ for 30 feet, and 4×6 for 40. The thickness of the filling-in stuff may be regulated according to what is said at *Art.* 345, in regard to the width of furring for plastering. The filling-in pieces should be stiffened at about every three feet by short struts between.

All superfluous timber, besides being an unnecessary load upon the points of support, tends to injure the stability of the plastering; for, as the strength of the plastering depends, in a great measure, upon its clinch, formed by pressing the mortar

through the space between the laths, the narrower the surface, therefore, upon which the laths are nailed, the less will be the quantity of plastering unclinched, and hence its greater security from fractures. For this reason, the principal timbers of the partition should have their edges reduced, by chamfering off the corners.




Fig. 232.

352.—When the principal timbers of a partition require to be large for the purpose of greater strength, it is a good plan to omit the upright filling-in pieces, and in their stead, to place a few horizontal pieces; in order, upon these and the principal timbers, to nail upright battens at the proper distances for lathing, as in *Fig. 232*. A partition thus constructed requires a little more space than others; but it has the advantage of insuring greater stability to the plastering, and also of preventing to a good degree the conversation of one room from being heard in the other. When a partition is required to support, in addition to its own weight, that of a floor or some other burden resting upon it, the dimensions of the timbers may be ascertained, by applying the principles which regulate the laws of pressure and those of the resistance of timber, as explained at the first part of this section. The following data, however, may assist in calculating the amount of pressure upon partitions :

White pine timber weighs from 22 to 32 pounds per cubic foot, varying in accordance with the amount of seasoning it has had. Assuming it to weigh 30 pounds, the weight of the beams and floor plank in every superficial foot of the flooring will be, when the beams are

3 × 8 inches, and placed 20 inches from centres,	6 pounds.
3 × 10 " " " 18 " " " "	7½ "
3 × 12 " " " 16 " " " "	9 "
3 × 12 " " " 12 " " " "	11 "
4 × 12 " " " 12 " " " "	13 "
4 × 14 " " " 14 " " " "	13 "

In addition to the beams and plank, there is generally the *plastering* of the ceiling of the apartments beneath, and sometimes the *deafening*. Plastering may be assumed to weigh 9 pounds per superficial foot, and deafening 11 pounds.

Hemlock weighs about the same as white pine. A partition of 3 × 4 joists of hemlock, set 12 inches from centres, therefore, will weigh about 2½ pounds per foot superficial, and when plastered on both sides, 20½ pounds.

353.—When floor beams are supported at the extremities, and by a partition or girder at any point between the extremities, one-half of the weight of the whole floor will then be supported by the partition or girder. As the settling of partitions and floors, which is so disastrous to plastering, is frequently owing to the shrinking of the timber and to ill-made joints, it is very important that the timber be seasoned and the work well executed. Where practicable, the joists of a partition ought to extend down between the floor beams to the plate of the partition beneath, to avoid the settlement consequent upon the shrinkage of the floor beams.

ROOFS.*

354.—In ancient buildings, the Norman and the Gothic, the

* See also *Art.* 238.

walls and buttresses were erected so massive and firm, that it was customary to construct their roofs without a tie-beam; the walls being abundantly capable of resisting the lateral pressure exerted by the rafters. But in modern buildings, the walls are so slightly built as to be incapable of resisting scarcely any oblique pressure; and hence the necessity of constructing the roof so that all oblique and lateral strains may be removed; as, also, that instead of having a tendency to separate the walls, the roof may contribute to bind and steady them.

355.—In estimating the pressures upon any certain roof, for the purpose of ascertaining the proper sizes for the timbers, calculation must be made for the pressure exerted by the wind, and, if in a cold climate, for the weight of snow, in addition to the weight of the materials of which the roof is composed. The weight of snow will be of course according to the depth it acquires. Snow weighs 8 lbs. per cubic foot, and more when saturated with water. In a severe climate, roofs ought to be constructed steeper than in a milder one, in order that the snow may have a tendency to slide off before it becomes of sufficient weight to endanger the safety of the roof. The inclination should be regulated in accordance with the qualities of the material with which the roof is to be covered. The following table may be useful in determining the smallest inclination, and in estimating the weight of the various kinds of covering :

Material.	Inclination.	Weight upon a square foot.
Tin	Rise 1 inch to a foot	$\frac{5}{8}$ to $1\frac{1}{2}$ lbs.
Copper	" 1 " " "	1 to $1\frac{1}{2}$ "
Lead	" 2 inches " "	4 to 7 "
Zinc	" 3 " " "	$1\frac{1}{2}$ to 2 "
Short pine shingles	" 5 " " "	$1\frac{1}{2}$ to 2 "
Long cypress shingles	" 6 " " "	2 to 3 "
Slate	" 6 " " "	5 to 9 "

The weight of the covering, as above estimated, is that of the material only, with the weight of whatever is used to fix it to the roof, such as nails, &c. What the material is laid on, such as plank, boards or lath, is not included. The weight of plank is about 3 pounds per foot superficial; of boards, 2 pounds; and lath, about a half pound.

356.—The weights and pressures on a roof arise from the roofing, the truss, the ceiling, wind and snow, and may be stated as follows:

First, the Roofing.—On each foot superficial of the inclined surface,

Slating	will weigh about 7 lbs.
Roof plank, 1½ inches thick	“ “ “ 27 “
Roof beams or jack rafters	“ “ “ 23 “
	Total, 12 lbs.

This is the weight per foot on the *inclined* surface; but it is desirable to know how much per foot, measured *horizontally*, this is equal to. The horizontal measure of one foot of the inclined surface is equal to the cosine of the angle of inclination. Therefore,

$$\cos. : 1 :: p : w = \frac{p}{\cos.};$$

where p represents the pressure on a foot of the inclined surface, and w the weight of the roof per foot, measured horizontally. The cosine of an angle is equal to the base of the right-angled triangle divided by the hypotenuse, which in this case would be half the span divided by the length of the rafter, or $\frac{s}{2l}$, where s is the span, and l the length of the rafter. Hence,

$$\frac{p}{\cos.} = \frac{p}{\frac{s}{2l}} = \frac{2lp}{s};$$

or, twice the pressure per foot of *inclined* surface, multiplied

by the length of the rafter, and divided by the span, will give the weight per foot measured horizontally; or,

$$2\frac{1}{2} \frac{l}{s} = w \quad (182.)$$

equals the weight per foot, measured horizontally, of the roof beams, plank, and covering for a slate roof.

Second, the Truss.—The weight of the framed truss is nearly in proportion to the length of the truss, and to the distance apart at which the trusses are placed.

$$w = 5.2 cs \quad (183.)$$

equals the weight, in pounds, of a white pine truss with iron suspension rods and a horizontal tie beam, near enough for the requirements of our present purpose; where s equals the length or span of the truss, and c the distance apart at which the trusses are placed, both in feet. It is desirable to know how much this is equal to per foot of the area over which the truss is to sustain a covering. This is found by dividing the weight of the truss by the span, and by the distance apart from centres at which the trusses are placed; or,

$$\frac{5.2 cs}{cs} = 5.2 = w \quad (184.)$$

equals the weight in pounds per foot to be allowed for the truss.

Third, the Ceiling.—The weight supported by the tie beams, viz.: that of the ceiling beams, furring and plastering, is about 9 pounds per superficial foot.

Fourth, the Wind.—The force of wind has been known as high as 50 pounds per superficial foot against a vertical surface. The effect of a horizontal force on an inclined surface is in proportion to the sine of the angle of inclination, the effect produced being in the direction at right angles to the inclined surface. The force thus acting may be resolved into forces acting in two directions—the one horizontal, the other vertical; the former tending, in the case of a roof, to thrust

aside the walls on which the roof rests, and the latter acting directly on the materials of which the roof is constructed—this latter force being in proportion to the sine of the angle of inclination multiplied by the cosine. This is the *vertical* effect of the wind upon a roof, without regard to the *surface* it acts upon. The wind, acting horizontally through one foot superficial of vertical section, acts on an area of inclined surface equal to the reciprocal of the sine of inclination, and the horizontal measurement of this inclined surface is equal to the cosine of the angle of inclination divided by the sine. This is the horizontal measurement of the inclined surface, and the vertical force acting on this surface is, as above stated, in proportion to the sine multiplied by the cosine. Combining these, it is found that the vertical power of the wind is in proportion to the square of the sine of the angle of inclination. Therefore, if the power of wind against a vertical surface be taken at 50 pounds per superficial foot, then the vertical effect on a roof is equal to

$$w = 50 \sin.^2 = 50 \frac{h^2}{l^2} \quad (185.)$$

for each piece of the inclined surface, the horizontal measurement of which equals one foot; where l equals the length of the rafter, and h the height of the roof.

Fifth, Snow.—The weight of snow will be in proportion to the depth it acquires, and this will be in proportion to the rigour of the climate of the place at which the building is to be erected. Upon roofs of most of the usual inclinations, snow, if deposited in the absence of wind, will not slide off. When it has acquired some depth, and not till then, it will have a tendency, in proportion to the angle of inclination, to slide off in a body. The weight of snow may be taken, therefore, at its weight per cubic foot, 8 pounds, multiplied by the depth it is usual for it to acquire. This, in the latitude of New York, may be stated at about $2\frac{1}{2}$ feet. Its weight would,

therefore, be 20 pounds per foot superficial, measured horizontally.

357.—There is one other cause of strain upon a roof; namely, the load that may be deposited in the roof when used as a room for storage, or for dormitories. But this seldom occurs. When a case of this kind does occur, allowance is to be made for it as shown in the article on floors. But in the *general* rule, now under consideration, it may be omitted.

358.—The following, therefore, comprehends all the pressures or weights that occur on roofs generally, per foot superficial;

For roof beams, plank, and slate (182)	$24 \frac{l}{s}$ lbs.
“ the truss (184)	5·2 “
“ ceiling	9 “
“ wind (185)	$50 \frac{h^2}{l^2}$ “
“ snow, latitude of New York	20 “

Having found the weight per foot, the total weight for any part of the roof is found by multiplying the weight per foot by the area of that part. This process will give the weight supported by braces and suspension rods, and also that supported by the rafters and tie beam. But in these last two, only *half* of the pressure of the *wind* is to be taken, for the wind will act only on one side of the roof at the same time.

The vertical pressure on the head of a brace, then, equals

$$W = 4cn \left(6 \frac{l}{s} + 8.55 + 12.5 \frac{h^2}{l^2} \right) \quad (186.)$$

And $W = cpn$, where p equals $4 \left(6 \frac{l}{s} + 8.55 + 12.5 \frac{h^2}{l^2} \right)$, equals the weight per foot.

And the aggregate load of the roof on each truss equals

$$W = 4cs \left(6 \frac{l}{s} + 8.55 + 6.25 \frac{h^2}{l^2} \right) \quad (187.)$$

And $W = cqs$, where $q = 4 \left(6 \frac{l}{s} + 8.55 + 6.25 \frac{h^2}{l^2} \right)$, equals the

weight per foot; where c equals the distance apart from centres at which the trusses are placed; n the distance horizontally between the heads of the braces, or, if these are not located at equal distances, then n is the distance horizontally from a point half-way to the next brace on one side to a point half-way to the next brace on the other side; l the length of the rafter; s the span, and h the height—all in feet.

359.—By the parallelogram of forces, the weight of the roof is in proportion to the oblique thrust or pressure in the axis of the rafter, as twice the height of the roof is to the length of the rafter; or,

$$W : R :: 2h : l, \text{ or}$$

$$2h : l :: W : R = \frac{Wl}{2h}, \quad (188.)$$

where R equals the pressure in the axis of the rafter. And the weight of the roof is in proportion to the horizontal thrust in the tie beam, as twice the height of the roof is to half the span; or,

$$W : H :: 2h : \frac{s}{2}, \text{ or}$$

$$2h : \frac{s}{2} :: W : H = \frac{Ws}{4h}, \quad (189.)$$

where H equals the horizontal thrust in the tie beam; the value of W in (188) and (189) being shown at (187), and (187) being compounded as explained in *Art.* 356. The weight is that for a slate roof. If other material is used for covering, or should there be other conditions modifying the weight in any particular case, an examination of *Art.* 356 will show how to modify the formula accordingly.

360.—The pressures may be obtained geometrically, as shown in *Fig.* 233, where AB represents the axis of the tie beam, AC the axis of the rafter, DE and FB the axes of the braces, and DG , FE , and CB , the axes of the suspension rods. In this design for a truss, the distance AB is divided into three

equal parts, and the rods located at the two points of division, G and E . By this arrangement the rafter AC is supported at equi-distant points, D and F . The point D supports the rafter for a distance extending half-way to A and half-way to F , and the point F sustains half-way to D and half-way to C . Also, the point C sustains half-way to F and, on the other rafter, half-way to the corresponding point to F . And because these points of support are located at equal distances apart, therefore the load on each is the same in amount. On DG make Da equal to 100 of any decimally divided scale, and let Da represent the load on D , and draw the parallelogram $abDc$. Then, by the same scale, Db represents (*Art.* 258) the pressure in the axis of the rafter by the load at D ; also, Dc the pressure in the brace DE . Draw cd horizontal; then Dd is the vertical pressure exerted by the brace DE at E . The point F sustains, besides the common load represented by 100 of the scale, also the vertical pressure exerted by the brace DE ; therefore, since Da represents the common load on D , F , or C , make Fe equal to the sum of Da and Dd , and draw the parallelogram $Fgef$. Then Fg , measured by the scale, is the pressure in the axis of the rafter caused by the load at F , and Ff is the load in the axis of the brace FB . Draw fh horizontal; then Fh is the vertical pressure exerted by the brace FB at B . The point C , besides the common load represented by Da , sustains the vertical pressure Fh caused by the brace FB , and a like amount from the corresponding brace on the opposite side. Therefore, make Cj equal to the sum of Da and twice Fh , and draw jk parallel to the opposite rafter. Then Ck is the pressure in the axis of the rafter at C . This is not the only pressure in the rafter, although it is the total pressure at its head C . At the point F , besides the pressure Ck , there is Fg . At the point D , besides these two pressures, there is the pressure Db . At the foot, at A , there is still an additional pressure: while the point D sustains the load half-

way to F and half-way to A , the point A sustains the load half-way to D . This load is, in this case, just half the load at D . Therefore draw $A m$ vertical, and equal to 50 of the scale, or half of $D a$. Extend $C A$ to l ; draw $m l$ horizontal. Then $A l$ is the pressure in the rafter at A caused by the weight of the roof from A half-way to D . Now the total of the pressures in the rafter is equal to the sum of $A l + D b + F g$ added to $C k$. Therefore make $k n$ equal to the sum of $A l + D b + F g$, and draw $n o$ parallel with the opposite rafter, and $n j$ horizontal. Then $C o$, measured by the same scale, will be found equal to the total weight of the roof on both sides of $C B$. If $D a = 100$ represent the portion of the weight borne by the point D , then $C o$, representing the whole weight of the roof, should equal 600, (as it does by the scale,) for D supports just one-sixth of the whole load. As $C n$ is the total oblique thrust in the axis of the rafter at its foot, therefore $n j$ is the horizontal thrust in the tie beam.

361.—In stating the amount of pressures in the above as being equal to certain lines, it was so stated with the understanding that the lines were simply in proportion to the weights. To obtain the weight represented by a line, multiply its length (measured by the scale used) by the load resting at D , (or at F or C , as these are all equal in this example,) and divide the product by 100, and the quotient will be the weight required. For, as 100 of the scale is to the load it represents, so is any other dimension on the same scale to the load it represents.

362.—*Example.* Let $A B$ (Fig. 233) equal 26 feet, $C B$ 13 feet, and $A C$ 29 feet, and $A G$, $G E$, and $E B$, each $8\frac{2}{3}$ feet. Let the trusses be placed 10 feet apart. Then the weight on D , for the use of the braces and rods, is, per (186), equal to

$$4 c n \left(6 \frac{l}{s} + 8.55 + 12\frac{1}{2} \frac{h^2}{l^2} \right)$$

$$= 4 \times 10 \times 8\frac{2}{3} \left(6 \times \frac{29}{52} + 8.55 + 12\frac{1}{2} \times \frac{13^2}{29^2} \right)$$

$$= 346\frac{2}{3} \times 14.398$$

$$= 4991.3.$$

This is the common load at the points D , F , and C , and each of the lines denoting pressures multiplied by it and divided by 100, or multiplied by the quotient of $\frac{4991.3}{100} = 49.913$, the product will be the weight required. 49.913 may be called 50, for simplicity; therefore the pressure in the brace DE equals $112 \times 50 = 5600$ pounds, and in the brace FB , $140 \times 50 = 7000$ pounds, and in like manner for any other strain. For the rafters and tie beam the total weight, as per (187), equals

$$4cs \left(6\frac{l}{s} + 8.55 + 6\frac{1}{2} \frac{h^2}{l^2} \right)$$

$$= 4 \times 10 \times 52 \left(6 \times \frac{29}{52} + 8.55 + 6\frac{1}{2} \times \frac{13^2}{29^2} \right)$$

$$= 2080 \times 13.148$$

$$= 27343.68 \text{ pounds.}$$

This is the total weight of the roof supported by one truss. The oblique thrust in the rafter AC is, per (188), equal to

$$\frac{lW}{2h} = \frac{29 \times 27343.68}{2 \times 13}$$

$$= 30498.72 \text{ pounds.}$$

To obtain this oblique thrust geometrically: Co (*Fig. 233*) represents the weight of the roof, and measures 600 by the scale; and the line Cn , representing the oblique thrust, measures 670. By the proportion, $600 : 670 :: 27343.68 : 30533.8$, = the oblique thrust. The result here found is a few pounds more than the other. This is owing to the fact that the line Cn is not *exactly* 670, nor is the length of the rafter precisely 29 feet. Were the exact dimensions used in each case the results would be identical; but the result in either case is near enough for the purpose.

The horizontal strain is, per (189), equal to

$$\frac{W_s}{4h} = \frac{27343.68 \times 52}{4 \times 13}$$

$$= 27343.68 \text{ pounds.}$$

The result gives the horizontal thrust precisely equal to the weight. This is as it should be in all cases where the height of the roof is equal to one-fourth of the span, but not otherwise; for the result depends (189) upon this relation of the height to the span. Geometrically, the result is the same, for Co and nj (*Fig. 233*), representing the weight and horizontal thrust, are precisely equal by measurement.

363.—The weight at the head of a brace is sustained partly at the foot of the brace and partly at the foot of the rafter. The *sum* of the vertical effects at these two points is just equal to the weight at the head of the brace. The portion of the weight sustained at either point is in proportion, inversely, to the horizontal distance of that point from the weight; therefore,

$$V = W \frac{g}{a}, \quad (190.)$$

where V equals the vertical effect at the foot of the brace; W , the weight at the head of the brace; g , the horizontal distance from the foot of the rafter to the *head* of the brace; and a , the distance from the same point to the *foot* of the brace.

364.—For the oblique thrust in the brace: from the triangle Ffh (*Fig. 233*),

$$Fh : Ff :: \sin. : \text{rad.}$$

$$\sin. : \text{rad.} :: V : T;$$

therefore,

$$T = \frac{V}{\sin.} = V \frac{l}{h}, \quad (191.)$$

where T equals the oblique thrust in the brace; V , the vertical pressure caused by T at the foot of the brace (190); l and h the length and height respectively of the brace.

365.—*Example.* Brace DE , *Fig. 233*. In this case, equals the product of the weight per superficial foot, multiplied by

plied by the area supported at the point D , equals 5000 pounds, (*Art.* 362.) The length g equals $8\frac{2}{3}$ feet, and a equals $17\frac{1}{3}$ feet. Therefore (190),

$$V = W \frac{g}{a} = 5000 \times \frac{8\frac{2}{3}}{17\frac{1}{3}} = 2500 \text{ pounds}$$

equals the vertical pressure at E caused by the brace DE . Then for the oblique thrust, l equals 9.6 feet, and h equals 4.3 feet. Therefore, from (191),

$$T = V \frac{l}{h} = 2500 \times \frac{9.6}{4.3} = 5581.4 \text{ pounds}$$

equals the oblique thrust in the brace DE . In *Art.* 362 it was found to be 5600. The discrepancy is owing to like causes of want of accuracy in the case of the rafter, as explained in *Art.* 362.

Another Example.—Brace FB , *Fig.* 233. In this case, W equals the product of the weight per superficial foot, multiplied by the area supported by the point F , added to the vertical strain caused by the brace DE . From *Art.* 362 the weight of roof on F equals 5000 pounds, and the vertical strain from brace DE is, as just ascertained, = 2500, total 7500, equals W . The length, g , equals two-thirds of 26 feet, equals $17\frac{1}{3}$, and a equals 26 feet. Therefore, from (190),

$$V = W \frac{g}{a} = 7500 \times \frac{17\frac{1}{3}}{26} = 5000$$

equals the vertical effect at B caused by the brace FB . Then, for the oblique thrust in the brace, l equals 12.2, and h equals $8\frac{2}{3}$. Therefore, from (191)

$$T = V \frac{l}{h} = 5000 \times \frac{12.2}{8\frac{2}{3}} = 7038.5$$

equals the oblique thrust or strain in the axis of the brace. It was 7000 by the geometrical process, (*Art.* 362.)

366.—The strain upon the first rod, DG , equals simply the weight of the ceiling supported by it, added to the part of the tie beam it sustains. The weight of the tie beam will equal




Fig. 288.

about one pound per superficial foot of the ceiling. The weight per foot for the ceiling is stated (see *Art. 356 third*, and 358,) at 9 pounds. To this add 1 pound for the tie beam, and the sum is 10. Then

$$N = 10 \text{ } c n. \quad (192.)$$

The strain on the second tie rod equals the weight of ceiling supported, = N , added to the vertical effect of the strain in the brace it sustains, [see (190)] or equal to

$$O = 10 \text{ } c n + V. \quad (193.)$$

The strain on the third rod is equal to N , added to the vertical effect of the strain in the brace it sustains, and this is the strain on any rod. The first rod has no brace to sustain, and the middle rod sustains two braces. In this case the strain equals

$$U = 10 \text{ } c n + 2 V. \quad (194.)$$

It may be observed that V represents the vertical strain caused by that brace that is sustained by the rod under consideration; and, as the vertical strain caused by any one brace is more than that caused by any other brace nearer the foot of the rafter, therefore the V of (193) is not equal to the V of (194). Hence a necessity for care lest the two be confounded and thus cause error.

367.—*Examples.* The rod DG (*Fig. 233*) has a strain which equals (192)

$$N = 10 \text{ } c n = 10 \times 10 \times 8\frac{1}{2} = 867 \text{ pounds.}$$

The strain on rod FE equals (193)

$$O = 10 \text{ } c n + V = 867 + 2500 = 3367 \text{ pounds.}$$

The strain on rod CB , the middle rod, equals (194)

$$U = 10 \text{ } c n + 2 V = 867 + 2 \times 5000 = 10867 \text{ pounds.}$$

368.—The load, and the strains caused thereby, having been discussed, it remains to speak of the resistance of the materials.

First, of the Rafter.—Generally this piece of timber is so pinioned by the roof beams or purlins as to prevent any late-

ral movement, and the braces keep it from deflection; therefore it is not liable to yield by flexure. Hence the manner of its yielding, when overloaded, will be by crushing at the ends, or it will crush the tie beam against which it presses. The fibres of timber yield much more readily when pressed together by a force acting at *right angles* to the direction of their length, than when it acts in a *line* with their length.

The value of timber subjected to pressure in these two ways is shown in *Art. 292*, Table I., the value per square inch of the first stated resistance being expressed by P , and that of the other by C . Timber pressed in an oblique direction yields with a force exceeding that expressed by P , and less than that by C . When the angle of inclination at which the force acts is just 45° , then the force will be an average between P and C . And for any angle of inclination, the force will vary inversely as the angle; approaching P as the angle is enlarged, and approaching C as the angle is diminished. It will be equal to C when the angle becomes zero, and equal P when the angle becomes 90° . The resistance of timber per square inch to an oblique force is therefore expressed by

$$M = P + \frac{A^\circ}{90}(C - P), \quad (195.)$$

where A° equals the complement of the angle of inclination. In a roof, A° is the acute angle formed by the rafter with a vertical line. If no convenient instrument be at hand to measure the angle, describe an arc upon the plan of the truss—thus: with CB (*Fig. 233*) for radius, describe the arc Bg , and get the length of this arc by stepping it off with a pair of dividers. Then

$$\frac{A^\circ}{90} = 0.63\frac{2}{3} \frac{a}{h},$$

where a equals the length of the arc, and h equals BC , the height of the roof. Therefore,

$$M = P + 0.63\frac{2}{8}\frac{a}{h}(C - P) \quad (196.)$$

equals the value of timber per square inch in a tie beam, C and P being obtained from Table I., *Art.* 292. When C for the kind of wood in the tie beam exceeds C set opposite the kind of wood in the rafter, then the latter is to be used in the rules instead of the former.

369.—Having obtained the strain to which the material is subjected in a roof, and the capability of the material to resist that strain, it only remains now to state the rules for determining the dimensions of the material.

370.—To obtain the dimensions of the rafter:—It has been shown that the strain in the axis of the rafter equals (188),

$$R = W \frac{l}{2h}.$$

This is the strain in pounds. Timber is capable of resisting effectually, in every square inch of the surface pressed (196),

$$P + 0.63\frac{2}{8}\frac{a}{h}(C - P) \text{ pounds.}$$

And when the strain and resistance are equal,

$$R = b d [P + 0.63\frac{2}{8}\frac{a}{h}(C - P)],$$

where b and d are respectively the breadth and depth of the rafter. Hence

$$b d = \frac{R}{P + 0.63\frac{2}{8}\frac{a}{h}(C - P)}. \quad (197.)$$

Example.—(*Fig.* 233.) The strain in the axis of the rafter in this example, ascertained in *Art.* 362, is 30498.72 pounds. If the timber used be white pine, then $P = 300$ and $C = 1200$. The length of the arc Bg is $14\frac{1}{2}$ feet, and $h = 13$. Therefore

$$b d = \frac{30498.72}{300 + (0.63\frac{2}{8} \times \frac{14.25}{13} \times 900)} = 32.8.$$

This is the area of the abutting surface at the tie beam—say 6 by $5\frac{1}{2}$ inches. At least half this amount should be added

to allow for the shoulder, and for cutting at the joints for braces, &c. The rafter may therefore be 6 by 9 inches.

The above method is based upon the supposition that the rafter is effectually secured from flexure by the braces and roof beams. Should this not be the case, then the dimensions of the rafter are to be obtained by rules in *Art.* 298, for posts. Nevertheless, the abutting surface in the joint is to be determined by the above formula (197).

371.—To obtain the dimensions of the braces:—Usually, braces are so slender as to require their dimensions to be obtained by rules in *Art.* 298; the strain in the axis of the brace having been obtained by formula (191), or geometrically as in *Art.* 360.

The abutting surface of the joint of the brace is to be obtained, as in the case of the rafter, by formula (195); A° being the number of degrees contained in the acute angle formed by the brace and a vertical line, for the joint at the tie beam; but for the joint at the rafter, A° is the number of degrees contained in the acute angle formed by the brace and a line perpendicular to the rafter, or it is 90, diminished by the number of degrees contained in the acute angle formed by the rafter and brace.

Example.—*Fig.* 233, Brace DE , of white pine. In this brace the strain was found (*Art.* 362) to be 5600 pounds, the length of the brace is 9.6 feet. By *Art.* 298, the brace is therefore required to be 4.18×6 inches. For the abutting surface at the joints, for white pine, P equals 300 and, C 1200. The angle DEF equals $63^\circ 26'$. By (197) and (195),

$$\begin{aligned} bd &= \frac{T}{P + \frac{A^\circ}{90}(C - P)} = \frac{5600}{300 + \left[\frac{30^\circ 26'}{90} \times (1200 - 300)\right]} \\ &= \frac{5600}{934.5} = 6 \text{ inches.} \end{aligned}$$

This is the area of the abutting surface of the joint at the tie

beam. To obtain the joint at the rafter, the angle $F D F$ equals $53^{\circ} 8'$, and hence

$$\begin{aligned} b d &= \frac{T}{P + \frac{A}{90}(C - P)} = \frac{5600}{300 + \left[\frac{90^{\circ} - 53^{\circ} 8'}{90} \times (1200 - 300) \right]} \\ &= \frac{5600}{300 + \left(\frac{36^{\circ} 52'}{90} \times 900 \right)} = 8.375 \text{ inches.} \end{aligned}$$

This is the area of the abutting surface of the joint at the rafter.

Another Example.—Brace $F B$, *Fig. 233*, of white pine, 12.2 feet long. The strain in its axis is (*Art. 362*) 7000 pounds. By *Art. 298*, the brace is required to be $5\frac{1}{4} \times 6$ inches. For the abutting surface of the joints, P equals 300, C equals 1200, and the angle $F B C$ equals 45° ; therefore,

$$b d = \frac{7000}{300 + \left[\frac{45}{90} \times (1200 - 300) \right]} = 9\frac{1}{3} \text{ inches.}$$

This is the area of the abutting surface at the tie beam. For the surface at the rafter, the angle $C F B$ equals 71° , and $90 - 71 = 19$, equals the angle to be used in the formula; therefore,

$$b d = \frac{7000}{300 + \left[\frac{19}{90} \times (1200 - 300) \right]} = 14.3 \text{ inches, nearly.}$$

This is the area of the abutting surface of the joint at the rafter.

372.—To obtain the dimensions of the tie beam:—A tie beam must be of such dimensions as will enable it to resist effectually the tensile strain caused by the horizontal thrust of the rafter and the cross strains arising from the weight of the ceiling, and from any load that may be placed upon it in the roof. From (17), *Art. 310*,

$$A = \frac{w}{T} = \frac{H}{T}$$

where H equals the horizontal thrust, and from (189),

$$H = \frac{W s}{4 h};$$

therefore,

$$A = \frac{H}{T} = \frac{W s}{4 h T},$$

where W equals the weight of the roof in pounds, as shown at (187); s , the span; h , the height, both in feet; and T , a constant set opposite the kind of material, in Table III.; and A equals the area of uncut fibres in the tie beam. About one-half of this should be added to allow for the requisite cutting at the joints; or, the area of the cross section of the tie beam should be equal to at least $\frac{2}{3}$ of the area of uncut fibres; or, when $b d$ equals the area of the tie beam, then

$$b d = \frac{2}{3} \frac{W s}{h T}. \quad (198).$$

Example.—The weight on the truss at *Fig. 233* is shown to be (*Art. 362*) 27343·68 pounds, say 27500 pounds; the span is 52 feet, the height 13, and the value of T for white pine is (*Table III.*) 2367, therefore

$$b d = \frac{2}{3} \frac{W s}{h T} = \frac{2}{3} \times \frac{27500 \times 52}{13 \times 2367} = 17\cdot4 \text{ inches}$$

equals the area of cross section of the tie beam requisite to resist the tensile strain. This is smaller, as will be shown, than what is required to resist the cross strains, and this will be found to be the case generally. The weight of the ceiling is 9 pounds per superficial foot; the length of the longest unsupported part of the tie beam is $8\frac{2}{3}$ feet; then, if the deflection per lineal foot be allowed at 0·015 inch, the depth of the tie beam will be required ((72), *Table V.*) to be 6·14 inches. But in order effectually to resist the strains tie beams are subjected to at the hands of the workmen, in the process of framing and elevating, the area of cross section in inches should be at least equal to the length in feet. Were it possible to guard against this cause of strain, the size ascertained by the rule, 6

by 6·14, would be sufficient; but to resist this strain, the size should be 6 by 9.

There is yet one other dimension for the tie beam required, and that is, the distance at which the joint for the rafter must be located from the end of the tie beam, in order that the thrust of the rafter may not split off the part against which it presses. This may be ascertained by Rule XI., *Art.* 302, for all cases where no iron strap or bolt is used to secure the joint; but where these fastenings are used the abutment may be of any convenient length. And in using irons here, care should be exercised to have the surface of pressure against the iron of sufficient area to prevent indentation.

373.—To obtain the dimensions of the iron suspension rods. By *Art.* 310, (17),

$$A = \frac{w}{T},$$

and T varies (Table III.) from 5000 to 17000, according to the diameter inversely; for the smaller rods are stronger in proportion than the larger ones.

Example.—Taking T equal 5000, then the area of the rod $D G$ (*Fig.* 233) requires (*Art.* 367) to be equal to

$$A = \frac{867}{5000} = 0\cdot173 \text{ inch,}$$

corresponding to 0·469 inch diameter. This rod may be half inch diameter.

Another Example.—The rod $F E$ (*Fig.* 233) is loaded with (*Art.* 367) 3367 pounds, therefore

$$A = \frac{3367}{5000} = 0\cdot673 \text{ inch}$$

equals the area of the rod, the corresponding diameter of which is 0·925. This rod may be one inch diameter.

Again, a third example; the rod $C B$. This rod is loaded with (*Art.* 367) 10867 pounds, therefore

$$A = \frac{10867}{5000} = 2.173 \text{ inch}$$

equals the required area of the rod, the diameter corresponding to which is 1.66. This rod may therefore be $1\frac{3}{4}$ inches diameter.

374.—While discussing the principles of strains in roofs and deducing rules therefrom, the truss indicated in *Fig. 233* has been examined throughout. The result is as follows: rafter, 6×9 ; tie beam, (6×6 , or) 6×9 ; the first brace from the wall, $4\frac{1}{4} \times 6$ inches, with an abutting surface at the lower end of 6 inches, and at the upper end of $8\frac{3}{8}$ inches; the other brace, $5\frac{1}{4} \times 6$ inches, with an abutting surface at the lower end of $9\frac{1}{8}$ inches, and at the upper end of $14\frac{3}{8}$ inches; the shortest rod, $\frac{1}{2}$ inch diameter; the next, 1 inch diameter; and the middle rod, $1\frac{3}{4}$ inches diameter.

PRACTICAL RULES AND EXAMPLES.

For Roofs Loaded as per Art. 356.

375.—*Rule LIII.* To obtain the dimensions of the rafter Multiply the value of *R* (Table IX., *Art. 376*) by the span of the roof, by the length of the rafter, and by the distance apart from centres at which the roof trusses are placed, all in feet, and divide the product by the sum of twice the height of the roof multiplied by the value of *P*, Table I., set opposite the kind of wood used in the tie beam, added to the difference of the values of *C* and *P* in said table multiplied by $1\frac{1}{4}$ times the length of the arc that measures the acute angle formed between the rafter and a vertical line, the arc having the height of the roof for radius (see arc *B G*, *Fig. 233*), and the quotient will be the area of the abutting surface of the joint at the foot of the rafter. To the abutting surface add its half, and the sum will be the area of the cross section of the rafter

This rule is upon the presumption that the rafter is secured from flexure by the roof beams and by braces and ties at short intervals, as in *Fig. 233*. In roofs where the rafter does not extend up to the ridge of the roof but abuts against a horizontal straining beam (*c*, *Fig. 237*), in the rule for rafters, take for the length of the rafter the distance from the foot of the rafter to the ridge of the roof; or, a distance equal to what the rafter would be in the absence of a straining beam. The area of cross section of the straining beam should be made equal to that of the rafter, as found by the rule so modified.

Example.—Find the dimensions of a rafter for a roof truss whose span is 52 feet, and height 13; the length of the rafter being 29 feet, the trusses placed 10 feet apart from centres, and the arc measuring the angle at the head of the rafter (having the height of the roof for radius) being $14\frac{1}{2}$ feet, white pine being used in the tie beam. The height of this roof being in proportion to the span as 1 to 4, the value of R in Table IX. is 52.6; multiplying this, in accordance with the rule, by 52, the span of the roof, and by 29, the length of the rafter, and by 10, the distance between the roof trusses, the product is 793208. The value of P for white pine in Table I. is 300; multiplying this by $2 \times 13 = 26$, twice the height of the roof, the product is 7800. The value of C for white pine, (Table I.) is 1200, hence the difference of the values of C and P is $1200 - 300 = 900$; this multiplied by $1\frac{1}{2}$, and by $14\frac{1}{2}$, the length of the arc, the product is 16031; this added to the 7800 aforesaid, the sum is 23831. The aforesaid product of 793208, divided by this 23831, the quotient, 33.3, equals the area in inches of the abutting surface of the joint at the tie beam. To this add 16.7, its half, and the sum, 50, equals the area of cross section of the rafter. This divided by the thickness of the rafter, say 6 inches, the quotient, $8\frac{1}{2}$, is the breadth. The rafter is therefore to be $6 \times 8\frac{1}{2}$ inches. It may be made 6×9 , avoiding the fractions.

376.—The following table, calculated upon data in *Art.* 358, presents the weight per foot for roofs of various inclinations, and covered with slate.

TABLE IX.

When height of roof is to span as	The vertical strain per foot of surfaces supported, measured horizontally,	
	on rafters = R =	on braces = Q =
1 to 8	48 pounds	49.5 pounds.
1 " 7	48.6 "	50.5 "
1 " 6	49.4 "	51.9 "
1 " 5	50.6 "	54. "
1 " 4	52.6 "	57.6 "
1 " 3	56.3 "	64. "
1 " 2	63.7 "	76.2 "
1 " 1	81. "	101. "

To get the proportion that the height bears to the span, divide the span by the height; then unity will be to the quotient as the height is to the span. In case the quotient is not a whole number, the required value of R or Q will not be found in the above table, but may be obtained thus: multiply the decimal part of the quotient by the difference of the values of R set opposite the two proportions, between which the given proportion occurs as an intermediate, and subtract the product from the larger of the two said values of R ; the remainder will be the value of R required. The process is the same for the values of Q .

Example.—A roof whose span is 60 feet, has a height of 25 feet. Then 60 divided by 25 equals 2.4. The proportion, therefore, between the height and span is 1 to 2.4. This proportion is an intermediate between 1 to 2 and 1 to 3. The values of R , opposite these two, are 63.7 and 56.3. The difference between these values is 7.4; this multiplied by 0.4, the decimal portion of the quotient, equals 2.96; this subtracted from 63.7, the larger value of R , the remainder, 60.74, is the required value of R .

The values of R and Q are those for a roof covered with slate weighing 7 pounds per superficial foot of the roof surface. When the roof covering is either lighter or heavier, subtract from or add to the table values, the difference of weight between 7 pounds and the weight of the covering used, and the remainder, or sum, will be the value of R or Q required.

377.—*Rule LIV.* To obtain the dimensions of braces. Multiply the value of Q (Table IX., *Art.* 376) by the distance apart in feet at which the roof trusses are placed, and by the *horizontal* distance in feet from a point half-way to the next point of support of the rafter on one side of the brace, to a corresponding point on the other side. The product will be the weight in pounds sustained at the head of the brace. To this add the vertical strain (*Art.* 360) on the suspension rod located at the head of the brace, and make a vertical line dropped from the head of the brace, as $F'e$, *Fig.* 233, equal, by any convenient scale, to this sum, and draw the parallelogram $F'feg$. Then $F'f$, measured by the same scale, equals the pressure in the axis of the brace $F'B$. Multiply this pressure in pounds by the square of the length of the brace in feet, and divide the product by the breadth of the brace in inches multiplied by the value of B (Table II., *Art.* 293). The cube root of the quotient will be the thickness of the brace in inches. If this cube root should exceed the *breadth* of the brace, the result is not correct, and the calculation will have to be made anew, taking a larger dimension for the breadth.

Example.—The brace $F'B$ (*Fig.* 233) is of white pine, and is required to sustain a pressure in its axis of 7000 pounds (*Art.* 362). The length of the brace is 12 feet and its breadth 6 inches, what must be its thickness? Here 7000, the pressure, multiplied by 144, the square of the length, equals 1008000. The value of B is 1175; this by 6, the breadth of the brace, equals 7050. The product 1008000 divided by the product 7050 equals 143, the cube root of which, 5.23, is the required

thickness of the brace in inches. The brace will therefore be 5·23 by 6 inches, or 5¼ by 6.

378.—*Rule LV.* To obtain the area of the abutting surface of the ends of braces. Divide the number of degrees contained in the complement of the angle of inclination by 90, and multiply the quotient by the difference of the values of C and P , set opposite the kind of wood in the tie beam or rafter, in Table I., *Art.* 292; and to the product add the said value of P , and by the sum divide the pressure in the axis of the brace, and the quotient will be the area of the abutting surface.

The complement of the angle of inclination referred to is, for the foot of the brace, the acute angle contained between the brace and a vertical line; and for the head of the brace, the acute angle contained between the brace and a line perpendicular to the rafter.

Example.—To find the abutting surface of the ends of the brace FB (*Fig.* 233). The complement of the angle of inclination, for the *foot* of the brace, is that contained between the lines FB and FE , and measures by the protractor, 45° . The tie beam is of white pine, and the values of P and C for this wood are 300 and 1200 respectively, and the pressure in the axis of the brace is 7000 pounds. Now by the rule, 45 divided by 90 equals 0·5, this by the 900, the difference of the values of C and P , equals 450; to this add 300, the value of P , and the sum is 750. The pressure in the axis of the brace, 7000, divided by this 750, equals $9\frac{1}{3}$, the required area of the abutting surface at the foot of the rafter. The complement of the angle of inclination for the *head* of the brace is that contained between the lines BF and Fp , and measures by the protractor 19° . The rafter being of white pine, the values of P and C are as before. By the rule, 19 divided by 90 equals $0\cdot2\frac{1}{5}$, and this multiplied by 900, the difference of the values of P and C , equals 190; to this add 300, the value of P , and

the sum is 490. The pressure, 7000, divided by this 490, equals 14.3 inches, the required area of the abutting surface at the head of the brace.

379.—To obtain the dimensions of the tie beam. Tie beams are subjected to two kinds of strain—tensile and transverse.

Rule LVI.—To guard against the tensile strain, multiply the value of R (Table IX., *Art.* 376) by three times the distance apart at which the trusses are placed, and by the square of the span of the truss, both in feet. Divide this product by the value of T , (Table III., *Art.* 308) set opposite the kind of wood in the tie beam, multiplied by 8 times the height of the roof in feet, and by the breadth of the tie beam in inches. The quotient will be the required depth in inches.

The result thus obtained is usually smaller than that required to resist the cross strain to which the tie beam is subjected. The dimensions required to resist this strain, where there is simply the weight of the ceiling to support, may be obtained by this rule:

Rule LVII.—Multiply the cube of the longest unsupported part of the tie beam by 400 times the distance apart at which the trusses are placed, both in feet; and divide the product by the breadth of the tie beam in inches, multiplied by the value of E , (Table II., *Art.* 293) set opposite the kind of wood in the tie beam, and the cube root of the quotient will be the required depth of the tie beam in inches.

The result thus obtained may not be sufficient, in some cases, to resist the strains to which the tie beam is subjected in the hands of the workmen during the process of framing.

Rule LVIII.—To resist these strains the area of cross section in inches should be at least equal to the length in feet.

Example.—The tie beam in *Fig.* 233. For this case we have the value of R 52.6, the trusses placed 10 feet from centres, the span 52 feet, the height 13 feet, the breadth 6 inches, and the value of T 2367. Then by the rule, $52.6 \times 3 \times 10 \times 52^3$

= 4266912, and $2367 \times 8 \times 13 \times 6 = 1477008$; the former product divided by the latter, the quotient equals 2·9, equals the required depth of the tie beam in inches. The other strains will require the depth to be more. To resist the cross strains, we have the longest unsupported part of the tie beam $8\frac{3}{4}$ feet, (this dimension is frequently greater than this,) distance from centres 10 feet, and breadth 6 inches. Then, by the rule, $8\frac{3}{4}^3 \times 400 \times 10 = 2603852$, and $6 \times 1750 = 10500$; the former product divided by the latter, the quotient is 248, the cube root of which, 6·28, equals the required depth in inches. The tie beam therefore is to be 6 by 6·28 inches, or 6 × 7 inches. But if not guarded against severe accidental strains from careless handling this size would be too small. It would, in this case, require to be 52 inches area of cross section, say 6 × 9 inches.

380.—To obtain the diameter of the suspension rods, when made of good wrought iron.

Rule LIX.—Divide the weight or vertical strain, in pounds, by 4000. The square root of the quotient will be the required diameter of the rod in inches.

Example.—A suspension rod is required to sustain 16000 pounds, what must be its diameter? Dividing by 4000, the quotient is 4; the square root of which, 2, is the required diameter.

The vertical strain on any rod is equal to the weight of so much of the ceiling as is supported by the rod, added to the vertical strain caused by each brace that is footed in the tie beam at the rod. The weight of the ceiling supported by a rod, is equal to ten times the distance apart in feet at which the trusses are placed, multiplied by half the distance in feet between the two next points of support, one on either side of the rod. The vertical strain caused by the braces can be ascertained geometrically, as in *Art.* 360.

381.—When the suspension rods are located as in *Fig.* 233, dividing the span into equal parts, the diameter of the rods

may be obtained without the preliminary calculation of the strain, as follows :

Rule LX.—For the first rod from the wall. Multiply the distance apart at which the trusses are placed by the distance apart between the suspension rods, and divide the product by 400. The square root of the quotient will be the required diameter of the rod.

Example.—Rod *D G*, *Fig.* 233. In this figure the rods are located at $8\frac{3}{8}$ feet apart, and the distance between the trusses is 10 feet. Therefore, $10 \times 8\frac{3}{8} = 86\frac{3}{8}$; this divided by 400, the quotient is 0.2167, the square root of which, 0.465, is the required diameter. The diameter may be half an inch.

Rule LXI.—For the second rod from the wall. To the value of *Q* (Table IX., *Art.* 376) add 20, and multiply the sum by the distance apart at which the trusses are placed and by the distance between the rods, both in feet, and divide the product by 8000. The square root of the quotient will be the required diameter.

Example.—Rod *F E*, *Fig.* 233. The distances apart in this case are as stated in last example. The value of *Q* is 57.6, and when added to 20 equals 77.6. Therefore, $77.6 \times 10 \times 8\frac{3}{8} = 6673\frac{3}{8}$; this divided by 8000, the quotient is 0.8341, the square root of which, 0.91, is the required diameter. This rod may be one inch diameter.

Rule LXII.—For the centre rod. To the value of *Q* (Table IX., *Art.* 376) add 5, and multiply the sum by the distance apart at which the trusses are placed and by the distance apart between the rods, both in feet, and divide the product by 2000. The square root of the quotient will equal the required diameter.

Example.—Rod *C B*, *Fig.* 233. The distances apart as before, and the value of *Q* the same. To *Q* add 5, and the sum is 62.6. Then $62.6 \times 10 \times 8\frac{3}{8} = 5425\frac{3}{8}$; this divided by 2000, the quotient is 2.7126, the square root of which, 1.647, equals the required diameter. This rod may be $1\frac{1}{2}$ inches diameter.

382.—For all wrought iron straps and bolts the dimensions may be found by this rule.

Rule LXIII.—Divide the tensile strain on the piece, in pounds, by 5000, and the quotient will be the area of cross section of the required bar or bolt, in inches.

383.—Roof-beams, jack-rafters, and purlins. All pieces of timber subject to cross strains will sustain safely much greater strains when extended in one piece over two, three, or more distances between bearings; therefore roof-beams, jack-rafters, and purlins should, if possible, be made in as long lengths as practicable; the roof-beams and purlins laid on, not framed into, the principal rafters, and extended over at least two spaces, the joints alternating on the trusses; and likewise the jack-rafters laid on the purlins in long lengths. The dimensions of these several pieces may be obtained by the following rule:

Rule LXIV.—From the value of Q (Table IX., *Art.* 376) deduct 10, and multiply the remainder by 33 times the distance from centres in feet at which the pieces are placed, and by the cube of the distance between bearings in feet; divide the product by the value of E (Table II., *Art.* 293) for the kind of wood used and extract the square root of the quotient. The square root of this square root will be the required depth in inches. Multiply the depth thus obtained by the decimal 0.6, and the product will be the required breadth in inches.

Example.—Roof-beams of white pine placed 2 feet from centres, resting on trusses placed 10 feet from centres, the height and the span of the roof being in proportion as 1 to 4. In this case the value of Q is 57.6. By the rule, $57.6 - 10 = 47.6$, and $47.6 \times 33 \times 2 \times 10^3 = 3141600$. This divided by 1750, the quotient is 1795.2, the square root of which is 42.37, and the square root of 42.37 is 6.5, the required depth. This multiplied by 0.6 equals 3.9, the required breadth. These roof beams may therefore be 4 by $6\frac{1}{2}$ inches.

384.—Five examples of roofs are shown at *Figs. 234, 235, 236, 237, and 238*. In *Fig. 234*, *a* is an iron suspension rod, *b b* are braces. In *Fig. 235*, *a, a*, and *b* are iron rods, and *d d, c c*, are braces. In *Fig. 236*, *a b* are iron rods, *d d* braces, and *c* the straining beam. In *Fig. 237*, *a a, b b*,




Fig. 234.




Fig. 235.




Fig. 236.

are iron rods, *e e, d d*, are braces, and *c* is a straining beam. In *Fig. 238*, purlins are located at *P P*, &c.; the inclined beam that lies upon them is the jack-rafter; the post at the ridge is the king post, the others are queen posts. In this design the tie beam is increased in height along the middle by a strengthening piece (*Art. 348*), for the purpose of sustaining additional weight placed in the room formed in the truss.

385.—*Fig. 239* shows a method of constructing a truss having a *built-rib* in the place of principal rafters. The proper form for the curve is that of a parabola, (*Art. 127*.) This curve,

when as flat as is described in the figure, approximates so near to that of the circle, that the latter may be used in its stead. The height, $a b$, is just half of $a c$, the curve to pass through the middle of the rib.





Fig. 237.

The rib is composed of two series of abutting pieces, bolted together. These pieces should be as long as the dimensions of the timber will admit, in order that there may be but few joints. The suspending pieces are in halves, notched and bolted to the tie-beam and rib, and a purlin is framed upon the upper end of each. A truss of this construction needs, for ordinary roofs, no diagonal braces between the suspending pieces, but if extra strength is required the braces may be added. The best place for the suspending pieces is at the joints of the rib. A rib of this kind will be sufficiently strong, if the area of its section contain about one-fourth more timber, than is required for that of a rafter for a roof of the same size. The proportion of the depth to the thickness should be about as 10 is to 7.


386—Some writers have given designs for roofs similar to *Fig. 240*, having the tie-beam omitted for the accommodation of an arch in the ceiling. This and all similar designs are se-

riously objectionable, and should always be avoided; as the small height gained by the omission of the tie-beam can never



37 feet.

Fig. 238.



38 feet.

Fig. 239.




Fig. 240.

compensate for the powerful lateral strains, which are exerted by the oblique position of the supports, tending to separate the

be the length of the jack-rafter. The length of each jack-rafter is found in the same manner—by extending its seat to cut the line, $b i$. From f , draw $f k$, at right angles to $f g$, also $f l$, at right angles to $b e$; make $f k$ equal to $f l$ by the arc, $l k$, or make $g k$ equal to $g j$ by the arc, $j k$; then the angle at j will be the *top-bevil* of the jack-rafters, and the one at k will be the *down-bevil*.*

388.—*To find the backing of the hip-rafter.* At any convenient place in $b e$, (*Fig. 241.*) as o , draw $m n$, at right angles to $b e$; from o , tangential to $b h$, describe a semi-circle, cutting $b e$ in s ; join m and s and n and s ; then these lines will form at s the proper angle for beviling the top of the hip-rafter.

DOMES.†




Fig. 242.




Fig. 248.

* The lengths and bevils of rafters for roof-valleys can also be found by the above process

† See also *Art. 237.*

389.—The most usual form for domes is that of the sphere, the base being circular. When the interior dome does not rise too high, a horizontal tie may be thrown across, by which any degree of strength required may be obtained. *Fig. 242* shows a section, and *Fig. 243* the plan, of a dome of this kind, *a b* being the tie-beam in both. Two trusses of this kind, (*Fig. 242*), parallel to each other, are to be placed one on each side of the opening in the top of the dome. Upon these the whole framework is to depend for support, and their strength must be calculated accordingly. (See the first part of this section, and *Art. 356*.) If the dome is large and of importance, two other trusses may be introduced at right angles to the foregoing, the tie-beams being preserved in one continuous length by framing them high enough to pass over the others.




Fig. 244.




Fig. 245.

390.—When the interior dome rises too high to admit of a leve,

tie-beam, the framing may be composed of a succession of ribs standing upon a continuous circular curb of timber, as seen at *Fig. 244* and *245*,—the latter being a plan and the former a section. This curb must be well secured, as it serves in the place of a tie-beam to resist the lateral thrust of the ribs. In small domes, these ribs may be easily cut from wide plank; but, where an extensive structure is required, they must be built in two thicknesses so as to *break joints*, in the same manner as is described for a roof at *Art. 385*. They should be placed at about two feet apart at the base, and strutted as at *a* in *Fig. 244*.

391.—The scantling of each thickness of the rib may be as follows :

For domes of 24 feet diameter,	1×8	inches.
“ “ 36	“	1½×10 “
“ “ 60	“	2×13 “
“ “ 90	“	2½×13 “
“ “ 108	“	3×13 “

392.—Although the outer and the inner surfaces of a dome may be finished to any curve that may be desired, yet the framing should be constructed of such a form, as to insure that the *curve of equilibrium* will pass through the middle of the depth of the framing. The nature of this curve is such that, if an arch or dome be constructed in accordance with it, no one part of the structure will be less capable than another of resisting the strains and pressures to which the whole fabric may be exposed. The curve of equilibrium for an arched vault or a roof, where the load is equally diffused over the whole surface, is that of a parabola, (*Art. 127*;) for a dome, having no *lantern*, tower or cupola above it, a *cubic parabola*, (*Fig. 246*;) and for one having a tower, &c., above it, a curve approaching that of an hyperbola must be adopted, as the greatest strength is required at its upper parts. If the curve of a dome be circular, (as in the vertical section, *Fig. 244*;) the pressure will have a tendency to burst the dome outwards at about one-third of its height. Therefore, when this form is used

in the construction of an extensive dome, an iron band should be placed around the framework at that height; and whatever may be the form of the curve, a band or tie of some kind is necessary around or across the base.

If the framing be of a form less convex than the curve of equilibrium, the weight will have a tendency to crush the ribs inwards, but this pressure may be effectually overcome by strutting between the ribs; and hence it is important that the struts be so placed as to form continuous horizontal circles.




Fig. 246.

393.—*To describe a cubic parabola.* Let $a b$, (Fig. 246,) be the base and $b c$ the height. Bisect $a b$ at d , and divide $a d$ into 100 equal parts; of these give $d e$ 26, $e f$ $18\frac{1}{4}$, $f g$ $14\frac{1}{2}$, $g h$ $12\frac{1}{4}$, $h i$ $10\frac{3}{4}$, $i j$ $9\frac{1}{2}$, and the balance, $8\frac{3}{4}$, to $j a$; divide $b c$ into 8 equal parts, and, from the points of division, draw lines parallel to $a b$, to meet perpendiculars from the several points of division in $a b$, at the points, o, o, o , &c. Then a curve traced through these points will be the one required.

394.—Small domes to light stairways, &c., are frequently made elliptical in both plan and section; and as no two of the ribs in one quarter of the dome are alike in form, a method for obtaining the curves is necessary.

395.—*To find the curves for the ribs of an elliptical dome* Let $a b c d$, (Fig. 247,) be the plan of a dome, and $e f$ the seat




Fig. 247.

or one of the ribs. Then take ef for the transverse *axis* and twice the rise, og , of the dome for the conjugate, and describe (according to *Art.* 115, 116, &c.,) the semi-ellipse, egf , which will be the curve required for the rib, egf . The other ribs are found in the same manner.




Fig. 248.

396.—*To find the shape of the covering for a spherical dome.* Let *A*, (*Fig.* 248,) be the plan and *B* the section of a given dome. From *a*, draw *ac*, at right angles to *ab*; find the stretch-out, (*Art.* 92,) of *ob*, and make *dc* equal to it; divide the arc, *ob*, and the line, *dc*, each into a like number of equal parts,

as 5, (a large number will insure greater accuracy than a small one;) upon c , through the several points of division in $c d$, describe the arcs, $o d o$, $1 e 1$, $2 f 2$, &c.; make $d o$ equal to half the width of one of the boards, and draw $o s$, parallel to $a c$; join s and a , and from the points of division in the arc, $o b$, drop perpendiculars, meeting $a s$ in $i j k l$; from these points, draw $i 4$, $j 3$, &c., parallel to $a c$; make $d o$, $e 1$, &c., on the lower side of $a c$, equal to $d o$, $e 1$, &c., on the upper side; trace a curve through the points, o , 1 , 2 , 3 , 4 , c , on each side of $d c$; then $o c o$ will be the proper shape for the board. By dividing the circumference of the base, A , into equal parts, and making the bottom, $o d o$, of the board of a size equal to one of those parts, every board may be made of the same size. In the same manner as the above, the shape of the covering for sections of another form may be found, such as an ogee, cove, &c.






Fig. 249.

397.—*To find the curve of the boards when laid in horizontal courses.* Let $A B C$, (Fig. 249,) be the section of a given dome, and $D B$ its axis. Divide $B C$ into as many parts as there are to be courses of boards, in the points, 1 , 2 , 3 , &c.; through 1 and 2 , draw a line to meet the axis extended at a ; then a will be the centre for describing the edges of the board, E . Through 3 and 2 , draw $3 b$; then b will be the centre for describing F . Through 4 and 3 , draw $4 d$; then d will be the centre for G . B is the centre for the arc, $1 o$. If this method is taken to find

the centres for the boards at the base of the dome, they would occur so distant as to make it impracticable : the following method is preferable for this purpose. G being the last board obtained by the above method, extend the curve of its inner edge until it meets the axis, DB , in e ; from 3, through e , draw $3f$, meeting the arc, AB , in f ; join f and 4, f and 5 and f and 6, cutting the axis, DB , in s , n and m ; from 4, 5 and 6, draw lines parallel to AC and cutting the axis in c , p and r ; make $c4$, (*Fig.* 250.)



equal to $c4$ in the previous figure, and cs equal to cs also in the previous figure; then describe the inner edge of the board, H , according to *Art.* 87: the outer edge can be obtained by gauging from the inner edge. In like manner proceed to obtain the next board—taking $p5$ for half the chord and pn for the height of the segment. Should the segment be too large to be described easily, reduce it by finding intermediate points in the curve, as at *Art.* 86.



398.—*To find the shape of the angle-rib for a polygonal dome.* Let AGH , (*Fig.* 251,) be the plan of a given dome, and

CD a vertical section taken at the line, ef . From 1, 2, 3, &c., in the arc, CD , draw ordinates, parallel to AD , to meet fG , from the points of intersection on fG , draw ordinates at right-angles to fG ; make $s1$ equal to $o1$, $s2$ equal to $o2$, &c.; then GfB , obtained in this way, will be the angle-rib required. The best position for the sheathing-boards for a dome of this kind is horizontal, but if they are required to be bent from the base to the vertex, their shape may be found in a similar manner to that shown at *Fig.* 248.

BRIDGES.

399.—Various plans have been adopted for the construction of bridges, of which perhaps the following are the most useful. *Fig.* 252 shows a method of constructing wooden bridges, where the banks of the river are high enough to permit the use of the tie-beam, ab . The upright pieces, cd , are notched and bolted on in pairs, for the support of the tie-beam. A bridge of this construction exerts no lateral pressure upon the abutments. This method may be employed even where the banks of the river are low, by letting the timbers for the roadway rest immediately upon the tie-beam. In this case, the framework above will serve the purpose of a railing.




Fig. 252.

400.—*Fig.* 253 exhibits a wooden bridge without a tie-beam. Where staunch buttresses can be obtained, this method may be recommended; but if there is any doubt of their stability, it




Fig. 253.

should not be attempted, as it is evident that such a system of framing is capable of a tremendous lateral thrust.




Fig. 254.

401.—*Fig. 254* represents a wooden bridge in which a *built-rib*, (see *Art. 385*), is introduced as a chief support. The curve of equilibrium will not differ much from that of a parabola: this, therefore, may be used—especially if the rib is made gradually a little stronger as it approaches the buttresses. As it is desirable that a bridge be kept low, the following table is given to show the least rise that may be given to the rib.

Span in feet.	Least rise in feet.	Span in feet.	Least rise in feet.	Span in feet.	Least rise in feet.
30	0.5	120	7	280	24
40	0.8	140	8	300	28
50	1.4	160	10	320	32
60	2	180	11	350	39
70	2½	200	12	380	47
80	3	220	14	400	53
90	4	240	17		
100	5	260	20		

The rise should never be made less than this, but in all cases

greater if practicable; as a small rise requires a greater quantity of timber to make the bridge equally strong. The greatest uniform weight with which a bridge is likely to be loaded is, probably, that of a dense crowd of people. This may be estimated at 66 pounds per square foot, and the framing and gravelled roadway at 234 pounds more; which amounts to 300 pounds on a square foot. The following rule, based upon this estimate, may be useful in determining the area of the ribs. *Rule LXV.*—Multiply the width of the bridge by the square of half the span, both in feet; and divide this product by the rise in feet, multiplied by the number of ribs; the quotient, multiplied by the decimal, 0·0011, will give the area of each rib in feet. When the roadway is only planked, use the decimal, 0·0007, instead of 0·0011. *Example.*—What should be the area of the ribs for a bridge of 200 feet span, to rise 15 feet, and be 30 feet wide, with 3 curved ribs? The half of the span is 100 and its square is 10,000; this, multiplied by 30, gives 300,000, and 15, multiplied by 3, gives 45; then 300,000, divided by 45, gives 6666 $\frac{2}{3}$, which, multiplied by 0·0011, gives 7·333 feet, or 1056 inches for the area of each rib. Such a rib may be 24 inches thick by 44 inches deep, and composed of 6 pieces, 2 in width and 3 in depth.




Fig. 255.

402.—The above rule gives the area of a rib, that would be requisite to support the greatest possible *uniform* load. But in large bridges, a *variable* load, such as a heavy wagon, is capable of exerting much greater strains; in such cases, therefore, the rib should be made larger. The greatest concentrated load a

bridge will be likely to encounter, may be estimated at from about 20 to 50 thousand pounds, according to the size of the bridge. This is capable of exerting the greatest strain, when placed at about one-third of the span from one of the abutments, as at b (*Fig. 255*.) The weakest point of the segment, $b g c$, is at g , the most distant point from the chord line. The pressure exerted at b by the above weight, may be considered to be in the direction of the chord lines, $b a$ and $b c$; then, by constructing the parallelogram of forces, $e b f d$, according to *Art. 258*, $b f$ will show the pressure in the direction, $b c$. Then the scantling for the rib may be found by the following rule.

Rule LXVI.—Multiply the pressure in pounds in the direction $b c$, by the distance $g h$, and by the square of the distance $b c$, both in feet; and divide the product by the united breadth in inches of the several ribs, multiplied by the value of B , (*Table II.*, *Art. 293*) for the kind of wood used; and the cube root of the quotient will be the required depth of the rib in inches.

Example.—A bridge is to have three white pine ribs each 20 inches wide; the pressure in the direction $b c$, (*Fig. 255*) is equal to 60,000 pounds, the distance $b c$ equals 60 feet, and the distance $g h$ equals 10 feet. What must be the depth of the ribs, the value of B (*Table II.*) being for white pine 1175? Here, by the rule, $60,000 \times 10 \times 60^2 = 2,160,000,000$. Then $1175 \times 3 \times 20 = 70,500$. The former product divided by the latter equals 30,638, the cube root of which, 31.29, equals the required depth in inches. The ribs are, therefore, to be 20 by $31\frac{1}{2}$ inches.

403.—In constructing these ribs, if the span be not over 50 feet, each rib may be made in two or three thicknesses of timber, (three thicknesses is preferable,) of convenient lengths bolted together; but, in larger spans, where the rib will be such as to render it difficult to procure timber of sufficient breadth, they may be constructed by bending the pieces to the proper curve

and bolting them together. In this case, where timber of sufficient length to span the opening cannot be obtained and scarfing is necessary, such joints must be made as will resist both tension and compression, (see *Fig. 264*) To ascertain the greatest depth for the pieces which compose the rib, so that the process of bending may not injure their elasticity, multiply the radius of curvature in feet by the decimal, 0.05, and the product will be the depth in inches. *Example.*—Suppose the curve of the rib to be described with a radius of 100 feet, then what should be the depth? The radius in feet, 100, multiplied by 0.05, gives a product of 5 inches. White pine or oak timber, 5 inches thick, would freely bend to the above curve; and, if the required depth of such a rib be 20 inches, it would have to be composed of at least 4 pieces. Pitch pine is not quite so elastic as white pine or oak—its thickness may be found by using the decimal, 0.046, instead of 0.05.




Fig. 256.

404.—When the span is over 250 feet, a *framed* rib, formed as in *Fig. 256*, would be preferable to the foregoing. Of this, the upper and the lower edges are formed as just described, by bending the timber to the proper curve. The pieces that tend to the centre of the curve, called *radials*, are notched and bolted on in pairs, and the cross-braces are halved together in the middle, and abut end to end between the radials. The distance between the ribs of a bridge should not exceed about 8 feet. The roadway

should be supported by vertical standards bolted to the ribs at about every 10 to 15 feet. At the place where they rest on the ribs, a double, horizontal tie should be notched and bolted on the back of the ribs, and also another on the under side; and diagonal braces should be framed between the standards, over the space between the ribs, to prevent lateral motion. The timbers for the roadway may be as light as their situation will admit, as all useless timber is only an unnecessary load upon the arch.

405.—It is found that if a roadway be 18 feet wide, two carriages can pass one another without inconvenience. Its width, therefore, should be either 9, 18, 27 or 36 feet, according to the amount of travel. The width of the foot-path should be 2 feet for every person. When a stream of water has a rapid current, as few piers as practicable should be allowed to obstruct its course; otherwise the bridge will be liable to be swept away by freshets. When the span is not over 300 feet, and the banks of the river are of sufficient height to admit of it, only one arch should be employed. The rise of the arch is limited by the form of the roadway, and by the height of the banks of the river (See *Art.* 401.) The rise of the roadway should not exceed one in 24 feet, but, as the framing settles about one in 72, the roadway should be framed to rise one in 18, that it may be one in 24 after settling. The commencement of the arch at the abutments—the *spring*, as it is termed, should not be below high-water mark: and the bridge should be placed at right angles with the course of the current.

406.—The best material for the abutments and piers of a bridge, is stone; and, if possible, stone should be procured for the purpose. The following rule is to determine the extent of the abutments, they being rectangular, and built with stone weighing 120 lbs. to a cubic-foot. *Rule LXVII.*—Multiply the square of the height of the abutment by 160, and divide this product by the weight of a square foot of the arch, and by the rise of the arch; add unity to the quotient, and extract the square-root. Diminish the square-root by unity, and multiply the root, so diminished, by

half the span of the arch, and by the weight of a square-foot of the arch. Divide the last product by 120 times the height of the abutment, and the quotient will be the thickness of the abutment.

Example.—Let the height of the abutment from the base to the springing of the arch be 20 feet, half the span 100 feet, the weight of a square foot of the arch, including the greatest possible load upon it, 300 pounds, and the rise of the arch 18 feet—what should be its thickness? The square of the height of the abutment, 400, multiplied by 160, gives 64,000, and 300 by 18, gives 5400; 64,000, divided by 5400, gives a quotient of 11·852, one added to this makes 12·852, the square-root of which is 3·6; this, less one, is 2·6; this, multiplied by 100, gives 260, and this again by 300, gives 78,000; this, divided by 120 times the height of the abutment, 2400, gives 32 feet 6 inches, the thickness required.

The dimensions of a pier will be found by the same rule. For, although the thrust of an arch may be balanced by an adjoining arch, when the bridge is finished, and while it remains uninjured; yet, during the erection, and in the event of one arch being destroyed, the pier should be capable of sustaining the entire thrust of the other.

407.—Piers are sometimes constructed of timber, their principal strength depending on piles driven into the earth, but such piers should never be adopted where it is possible to avoid them; for, being alternately wet and dry, they decay much sooner than the upper parts of the bridge. Spruce and elm are considered good for piles. Where the height from the bottom of the river to the roadway is great, it is a good plan to cut them off at a little below low-water mark, cap them with a horizontal tie, and upon this erect the posts for the support of the roadway. This method cuts off the part that is continually wet from that which is only occasionally so, and thus affords an opportunity for replacing the upper part. The pieces which are immersed will last a great length of time, especially when of elm; for it is a well-established fact, that timber is less durable when subject to

alternating dryness and moisture, than when it is either continually wet or continually dry. It has been ascertained that the piles under London bridge, after having been driven about 600 years, were not materially decayed. These piles are chiefly of elm, and wholly immersed.




Fig. 257.

408.—*Centres for stone bridges.* Fig. 257 is a design for a centre for a stone bridge where intermediate supports, as piles driven into the bed of the river, are practicable. Its timbers are so distributed as to sustain the weight of the arch-stones as they are being laid, without destroying the original form of the centre; and also to prevent its destruction or settlement, should any of the piles be swept away. The most usual error in badly-constructed centres is, that the timbers are disposed so as to cause the framing to rise at the crown, during the laying of the arch-stones up the sides. To remedy this evil, some have loaded the crown with heavy stones; but a centre properly constructed will need no such precaution.

Experiments have shown that an arch-stone does not press upon the centring, until its bed is inclined to the horizon at an angle of from 30 to 45 degrees, according to the hardness of the stone, and whether it is laid in mortar or not. For general purposes, the point at which the pressure commences, may be considered to be at that joint which forms an angle of 32 degrees with the horizon. At this point, the pressure is inconsiderable,

but gradually increases towards the crown. The following table gives the *portion* of the weight of the arch stones that presses upon the framing at the various angles of inclination formed by the bed of the stone with the horizon. The pressure perpendicular to the curve is equal to the weight of the arch stone multiplied by the decimal

·0, when the angle of inclination is 32 degrees.

·04	“	“	“	“	“	“	34	“
·08	“	“	“	“	“	“	36	“
·12	“	“	“	“	“	“	38	“
·17	“	“	“	“	“	“	40	“
·21	“	“	“	“	“	“	42	“
·25	“	“	“	“	“	“	44	“
·29	“	“	“	“	“	“	46	“
·33	“	“	“	“	“	“	48	“
·37	“	“	“	“	“	“	50	“
·4	“	“	“	“	“	“	52	“
·44	“	“	“	“	“	“	54	“
·48	“	“	“	“	“	“	56	“
·52	“	“	“	“	“	“	58	“
·54	“	“	“	“	“	“	60	“

From this it is seen that at the inclination of 44 degrees the pressure equals one-quarter the weight of the stone; at 57 degrees, half the weight; and when a vertical line, as ab , (*Fig. 258*), passing through the centre of gravity of the arch-stone, does not fall within its bed, $c\bar{d}$, the pressure may be considered equal to the whole weight of the stone. This will be the case at about 60 degrees, when the depth of the stone is double its breadth. The




Fig. 258.

direction of these pressures is considered in a line with the radius of the curve. The weight upon a centre being known, the pressure may be estimated and the timber calculated accordingly. But it must be remembered that the whole weight is never placed upon the framing at once—as seems to have

been the idea had in view by the designers of some centres. In building the arch, it should be commenced at each buttress at the same time, (as is generally the case,) and each side should progress equally towards the crown. In designing the framing, the effect produced by each successive layer of stone should be considered. The pressure of the stones upon one side should, by the arrangement of the struts, be counterpoised by that of the stones upon the other side.

409.—Over a river whose stream is rapid, or where it is necessary to preserve an uninterrupted passage for the purposes of navigation, the centre must be constructed without intermediate supports, and without a continued horizontal tie at the




Fig. 259.

base; such a centre is shown at *Fig. 259*. In laying the stones from the base up to *a* and *c*, the pieces, *b d* and *b d*, act as ties to prevent any rising at *b*. After this, while the stones are being laid from *a* and from *c* to *b*, they act as struts: the piece, *f g*, is added for additional security. Upon this plan, with some variation to suit circumstances, centres may be constructed for any span usual in stone-bridge building.

410.—In bridge centres, the principal timbers should abut, and not be intercepted by a suspension or radial piece between. These should be in halves, notched on each side and bolted. The timbers should intersect as little as possible, for the more

joints the greater is the settling; and halving them together is a bad practice, as it destroys nearly one-half the strength of the timber. Ties should be introduced across, especially where many timbers meet; and as the centre is to serve but a temporary purpose, the whole should be designed with a view to employ the timber afterwards for other uses. For this reason, all unnecessary cutting should be avoided.

411.—Centres should be sufficiently strong to preserve a stannch and steady form during the whole process of building; for any shaking or trembling will have a tendency to prevent the mortar or cement from *setting*. For this purpose, also, the centre should be lowered a trifle immediately after the key-stone is laid, in order that the stones may take their bearing before the mortar is set; otherwise the joints will open on the under side. The trusses, in centring, are placed at the distance of from 4 to 6 feet apart, according to their strength and the weight of the arch. Between every two trusses, diagonal braces should be introduced to prevent lateral motion.

412.—In order that the centre may be easily lowered, the frames, or trusses, should be placed upon wedge-formed sills; as is shown at *d*, (*Fig. 259*.) These are contrived so as to admit of the settling of the frame by driving the wedge, *d*, with a maul, or, in large centres, with a piece of timber mounted as a battering-ram. The operation of lowering a centre should be very slowly performed, in order that the parts of the arch may take their bearing uniformly. The wedge pieces, instead of being placed parallel with the truss, are sometimes made sufficiently long and laid through the arch, in a direction at right angles to that shown at *Fig. 259*. This method obviates the necessity of stationing men beneath the arch during the process of lowering; and was originally adopted with success soon after the occurrence of an accident, in lowering a centre, by which nine men were killed.

413.—To give some idea of the manner of estimating the pres

asures, in order to select timber of the proper scantling, calculate (*Art.* 408) the pressure of the arch-stones from i to b , (*Fig.* 259,) and suppose half this pressure concentrated at a , and acting in the direction af . Then, by the parallelogram of forces, (*Art.* 258,) the strain in the several pieces composing the frame, bda , may be computed. Again, calculate the pressure of that portion of the arch included between a and c , and consider half of it collected at b , and acting in a vertical direction; then, by the parallelogram of forces, the pressure on the beams, bd and bd , may be found. Add the pressure of that portion of the arch which is included between i and b to half the weight of the centre, and consider this amount concentrated at d , and acting in a vertical direction; then, by constructing the parallelogram of forces, the pressure upon dj may be ascertained.

414.—The strains having been obtained, the dimensions of the several pieces in the frames bad and bcd , may be found by computation, as directed in the case of roof trusses, from *Arts.* 375 to 380. The tie-beams bd , bd , if made of sufficient size to resist the compressive strain acting upon them from the load at b , will be more than large enough to resist the tensile strain upon them during the laying of the first part of the arch-stones below a and c .

415.—In the construction of arches, the *voussoirs*, or arch-stones, are so shaped that the joints between them are perpendicular to the curve of the arch, or to its tangent at the point at which the joint intersects the curve. In a circular arch, the joints tend toward the centre of the circle: in an elliptical arch, the joints may be found by the following process:






Fig. 260.

416.—*To find the direction of the joints for an elliptical arch.* A joint being wanted at a , (*Fig. 260*), draw lines from that point to the foci, f and f' ; bisect the angle, $f a f'$, with the line, $a b$; then $a b$ will be the direction of the joint.



417.—*To find the direction of the joints for a parabolic arch.* A joint being wanted at a , (*Fig. 261*), draw $a e$, at right angles to the axis, $e g$; make $c g$ equal to $c e$, and join a and g ; draw $a h$, at right angles to $a g$; then $a h$ will be the direction of the joint. The direction of the joint from b is found in the same manner. The lines, $a g$ and $b f$, are tangents to the curve at those points respectively; and any number of joints in the curve may be obtained, by first ascertaining the tangents, and then drawing lines at right angles to them.

JOINTS.



418.—*Fig. 262* shows a simple and quite strong method of lengthening a tie-beam; but the strength consists wholly in the bolts, and in the friction of the parts produced by screwing the pieces firmly together. Should the timber shrink to even a small degree, the strength would depend altogether on the bolts. It would be made much stronger by indenting the pieces together; as at the upper edge of the tie-beam in *Fig. 263*; or by placing keys in the joints, as at the lower edge in

the same figure. This process, however, weakens the beam in proportion to the depth of the indents.



Fig. 263.

419.—*Fig. 264* shows a method of scarfing, or splicing, a tie-beam without bolts. The keys are to be of well-seasoned,




Fig. 264.

hard wood, and, if possible, very cross-grained. The addition of bolts would make this a very strong splice, or even white-oak pins would add materially to its strength.



Fig. 265.

420.—*Fig. 265* shows about as strong a splice, perhaps, as can well be made. It is to be recommended for its simplicity; as, on account of there being no oblique joints in it, it can be readily and accurately executed. A complicated joint is the worst that can be adopted; still, some have proposed joints that seem to have little else besides complication to recommend them.

421.—In proportioning the parts of these scarfs, the depths of all the indents taken together should be equal to one-third of the depth of the beam. In oak, ash or elm, the whole length of the scarf should be six times the depth, or thickness, of the beam, when there are no bolts; but, if bolts instead of indents are used, then three times the breadth; and, when both methods are combined, twice the depth of the beam. The

length of the scarf in pine and similar soft woods, depending wholly on indents, should be about 12 times the thickness, or depth, of the beam; when depending wholly on bolts, 6 times the breadth; and, when both methods are combined, 4 times the depth.



Fig. 266.

422.—Sometimes beams have to be pieced that are required to resist cross strains—such as a girder, or the tie-beam of a roof when supporting the ceiling. In such beams, the fibres of the wood in the upper part are compressed; and therefore a simple butt joint at that place, (as in *Fig. 266*,) is far preferable to any other. In such case, an oblique joint is the very worst. The under side of the beam being in a state of tension, it must be indented or bolted, or both; and an iron plate under the heads of the bolts, gives a great addition of strength.

Scarving requires accuracy and care, as all the indents should bear equally; otherwise, one being strained more than another, there would be a tendency to splinter off the parts. Hence the simplest form that will attain the object, is by far the best. In all beams that are compressed endwise, abutting joints, formed at right angles to the direction of their length, are at once the simplest and the best. For a temporary purpose, *Fig. 262* would do very well; it would be improved, however, by having a piece bolted on all four sides. *Fig. 263*, and indeed each of the others, since they have no oblique joints, would resist compression well.

423.—In framing one beam into another for bearing purposes, such as a floor-beam into a trimmer, the best place to make the mortice in the trimmer is in the neutral line, (*Arts. 317, 318*,) which is in the middle of its depth. Some have thought that, as the fibres of the upper edge are compressed, a

mortice might be made there, and the tenon driven in tight enough to make the parts as capable of resisting the compression, as they would be without it; and they have therefore concluded that plan to be the best. This could not be the case, even if the tenon would not shrink; for a joint between two pieces cannot possibly be made to resist compression, so well as a solid piece without joints. The proper place, therefore, for the mortice, is at the middle of the depth of the beam; but the best place for the tenon, in the floor-beam, is at its bottom edge. For the nearer this is placed to the upper edge, the greater is the liability for it to splinter off; if the joint is




Fig. 267.

formed, therefore, as at *Fig. 267*, it will combine all the advantages that can be obtained. Double tenons are objectionable, because the piece framed into is needlessly weakened, and the tenons are seldom so accurately made as to bear equally. For this reason, unless the tusk at *a* in the figure fits exactly, so as to bear equally with the tenon, it had better be omitted. And in sawing the shoulders, care should be taken not to saw into the tenon in the least, as it would wound the beam in the place least able to bear it.

424.—Thus it will be seen that framing weakens both pieces, more or less. It should, therefore, be avoided as much as possible; and where it is practicable one piece should rest *upon* the other, rather than be framed into it. This remark applies to the bearing of floor-beams on a girder, to the purlins and jack-rafters of a roof, &c.

425.—In a framed truss for a roof, bridge, partition, &c., the joints should be so constructed as to direct the pressures

through the axes of the several pieces, and also to avoid every tendency of the parts to slide. To attain this object, the abut-




Fig. 268.




Fig. 269.




Fig. 270.

ting surface on the end of a strut should be at right angles to the direction of the pressure; as at the joint shown in *Fig.* 268 for the foot of a rafter, (see *Art.* 277,) in *Fig.* 269 for the head of a rafter, and in *Fig.* 270 for the foot of a strut or brace. The joint at *Fig.* 268 is not cut completely across the tie-beam, but a narrow lip is left standing in the middle, and a corresponding indent is made in the rafter, to prevent the parts from separating sideways. The abutting surface should be made as large as the attainment of other necessary objects will admit. The iron strap is added to prevent the rafter sliding out, should the end of the tie-beam, by decay or otherwise, splinter off. In making the joint shown at *Fig.* 269, it should be left a little open at *a*, so as to bring the parts to a fair bearing at the settling of the truss, which must necessarily take place from the shrinking of the king-post and other parts. If the joint is made fair at first, when the truss settles it will cause it to open at the under side of the rafter, thus throwing the whole pressure upon the sharp edge at *a*. This will cause an indentation in the king-post, by which the truss will be made to settle further; and this pressure not being in the axis of the rafter, it will be greatly increased, thereby rendering the rafter liable to split and break.

426.—If the rafters and struts were made to abut end to end, as in *Figs.* 271, 272 and 273, and the king or queen post notched on in halves and bolted, the ill effects of shrinking

would be avoided. This method has been practised with success, in some of the most celebrated bridges and roofs in Eu-




Fig. 271.



Fig. 272.





Fig. 273.

rope; and, were its use adopted in this country, the unseemly sight of a *hogged* ridge would seldom be met with. A plate of cast iron between the abutting surfaces will equalize the pressure.




Fig. 274.




Fig. 275.

427.—*Fig. 274* is a proper joint for a collar-beam in a small roof: the principle shown here should characterize all tie-joints. The dovetail joint, although extensively practised in the above and similar cases, is the very worst that can be employed. The shrinking of the timber, if only to a small degree, permits the tie to withdraw—as is shown at *Fig. 275*. The dotted line shows the position of the tie after it has shrunk.

428.—Locust and white-oak pins are great additions to the strength of a joint. In many cases they would supply the place of iron bolts; and, on account of their small cost, they should be used in preference wherever the strength of iron is

not requisite. In small framing, good cut nails are of great service at the joints; but they should not be trusted to bear any considerable pressure, as they are apt to be brittle. Iron straps are seldom necessary, as all the joinings in carpentry may be made without them. They can be used to advantage, however, at the foot of suspending-pieces, and for the rafter at the end of the tie-beam. In roofs for ordinary purposes, the iron straps for suspending-pieces may be as follows: When the longest unsupported part of the tie-beam is

10 feet, the strap may be 1 inch wide by $\frac{3}{16}$ thick.

15 " " " $1\frac{1}{2}$ " " $\frac{1}{2}$ "

20 " " " 2 " " $\frac{1}{4}$ "

In fastening a strap, its hold on the suspending-piece will be much increased by turning its ends into the wood. Iron straps should be protected from rust; for thin plates of iron decay very soon, especially when exposed to dampness. For this purpose, as soon as the strap is made, let it be heated to about a blue heat, and, while it is hot, pour over its entire surface raw linseed oil, or rub it with beeswax. Either of these will give it a coating which dampness will not penetrate.

IRON GIRDERS.



Fig. 276.



Fig. 277.

429.—*Fig. 276* represents the front view, and *Fig. 277* the cross section at middle, of a cast iron girder of proper form for sustaining a weight equally diffused over its length. The curve is that of a parabola: generally an arc of a circle is

used, and is near enough. Beams of this form are much used to sustain brick walls of buildings; the brickwork resting upon the bottom flange, and laid, not arching, but horizontal. In the cross section, the bottom flange is made to contain in area four times as much as the top flange. The strength will be in proportion to the area of the bottom flange, and to the height or depth. Hence, to obtain the greatest strength from a given amount of material, it is requisite to make the upright part, or the blade, rather thin; yet, in order to prevent injurious strains in the casting while it is cooling, the parts should be nearly equal in thickness. The thickness of the three parts—blade, top flange and bottom flange, may be made in proportion as 5, 6 and 8. For a beam of this form, the weight equally diffused over it equals

$$w = 9000 \frac{t a d}{l}. \quad (199.)$$

The depth equals

$$d = \frac{l w}{9000 t a}. \quad (200.)$$

The area of the bottom flange equals

$$a = \frac{l w}{9000 t d}. \quad (201.)$$

where w equals the weight in pounds equally diffused over the length; d , the depth, or height in inches of the cross section at middle; a , the area of the bottom flange in inches; l , the length of the beam in feet, in the clear between the bearings; and t , a decimal in proportion to unity as the safe weight is to the breaking weight. This is usually from 0.2 to 0.3, or from one-fifth to one-third, at discretion.

430.—Beams of this form, laid in series, are much used in sustaining brick arches turned over vaults and other fire-proof rooms, forming a roof to the vault or room, and a floor above; the arches springing from the flanges, one on either side of the beam, as in *Fig.* 278.




Fig. 278.

For this use the depth of cross section at middle equals

$$d = \frac{cfl^2}{9000t\alpha} \quad (202.)$$

The area of the bottom flange equals

$$\alpha = \frac{cfl^2}{9000td} \quad (203.)$$

where the symbols signify as before, and c equals the distance apart from centres in feet at which the beams are placed, and f the weight per superficial foot, in pounds, including the weight of the material of which the floor is constructed.

Practical Rules and Examples.

431.—For a single girder the dimensions may be found by the following rule, ((200) and (201):)

Rule LXVIII.—Divide the weight in pounds equally diffused over the length of the girder by a decimal in proportion to unity as the safe weight is to the breaking weight, multiply the quotient by the length in feet, and divide the product by 9000. Then this quotient, divided by the depth of the beam at middle, will give the area of the bottom flange; or, if divided by the area of the bottom flange, will give the depth—the area and depth both in inches.

Example.—Let the weight equally diffused over a girder equal 60000 pounds; the decimal that is in proportion to unity as the safe weight is to be to the breaking weight, equal 0·3

the length in the clear of the bearings equal 20 feet. Then 60000 divided by 0·3 equals 200000, and this by 20 equals 4000000; this divided by 9000 equals $444\frac{4}{9}$. Now if the *depth* is fixed, say at 20 inches, then $444\frac{4}{9}$, divided by 20, equals $22\frac{2}{9}$, equals the area of the bottom flange in inches. But if the *area* is given, say 24 inches, then to find the depth, divide $444\frac{4}{9}$ by 24, and the quotient, 18·5, equals the depth in inches; and such a girder may be made with a bottom flange of 2 by 12 inches, top flange, (equal to $\frac{1}{4}$ of bottom flange), $1\frac{1}{2}$ by 4 inches, and the blade $1\frac{1}{4}$ inches thick.

432.—For a series of girders or iron beams, the dimensions may be found by the following rule: (202) and (203).

Rule LXIX.—Divide the weight per superficial foot, in pounds, by a decimal in proportion to unity as the safe weight is to the breaking weight, and multiply the quotient by the square of the length of the beams and by the distance apart at which the beams are placed from centres, both in feet, and divide the product by 9000. Then this quotient, divided by the depth of the beams at middle, will give the area of the bottom flange; or, if divided by the area of the bottom flange, will give the depth of the beam—the depth and area both in inches.

Example.—Let the weight per superficial foot resting upon an arched floor be 200 pounds, and the weight of the arches, concrete, &c., equal 100 pounds, total 300 pounds per superficial foot. Let the proportion of the breaking weight to be trusted on the beams equal 0·3, the length of the beams in the clear of the bearings equal 12 feet, and the distance apart from centres at which they are placed equal 4 feet. Then 300 divided by 0·3 equals 1000; this multiplied by 144 (the square of 12), equals 144000, and this by 4, equals 576000; this divided by 9000, equals 64. Now if the depth is fixed, and at 8 inches, then 64 divided by 8 equals 8, equals the area of the bottom flange. But if the area of the bottom flange is fixed, and at 6 inches, then 64, divided by 6, equals $10\frac{2}{3}$, the depth

required. Such a beam may be made with the bottom flange 1 by 6 inches, the top flange, (equal to one-quarter of the bottom flange,) $\frac{3}{4}$ by 2 inches, and the blade $\frac{5}{8}$ inch thick.

433.—The kind of girder shown at *Fig.* 280, (a cast iron arch with a wrought iron tie rod,) is extensively used as a support upon which to build brick walls where the space below is required to be free. The objections to its use are, the disproportion between the material and the strains, and the enhanced cost over the cast iron girder formed as in *Figs.* 276 and 277. The material in the cast arch, (*Fig.* 280,) is greatly in *excess* over the amount needed to resist effectually the compressive strains induced by the load through the axis of the arch, while the wrought metal in the tie is usually much *less* than is required to resist the horizontal thrust of the arch; absolute failure being prevented, partly by the weight of the walls resting on the haunches, and partly by the presence of adjoining buildings, their walls acting as buttresses to the arch. Some instances have occurred where the tie has parted.

Where this arched girder is used it is customary to lay the first courses of brick in the form of an arch. This brick arch of itself is quite sufficient to sustain the compressive strain, and, were there proper resistance to the horizontal thrust provided, the brick arch would entirely supersede the necessity for the girder. Indeed, the instances are not rare where constructions of this nature have proved quite satisfactory, the horizontal thrust of the arch being sustained by a tie rod secured to a pair of cast iron heel plates, as in *Fig.* 279. The




Fig. 279.

brick arch, in this case, being built upon a wooden centre, which was afterwards removed.

The diameter of the rod required for an arch of this kind is equal to

$$D = \sqrt{\frac{w s}{3000 h}}, \quad (204.)$$

where w equals the weight in pounds equally diffused over the arch; s , the length of the rod, clear of the heel plates, in feet; and h , the height at the middle, or rise, of the arc, in inches; D , the diameter, being also in inches.

When the diameter found by formula (204) is impracticably large, this difficulty may be overcome by dividing the metal into two rods. In the bow-string girder, (*Fig.* 280,) two rods cannot be used with advantage, because of the difficulty in adjusting their lengths so as to ensure to each an equal amount of the strain. But in the case of the brick arch, the two heel plates being disconnected, any discrepancy of length in the rods is adjusted simply by the pressure of the arch acting on the plates. When there are to be two rods, the diameter of each rod equals

$$D = \sqrt{\frac{w s}{6000 h}}, \quad (205.)$$

Practical Rule and Example.

434.—To obtain the diameter of wrought iron tie-rods for heel plates, as in *Fig.* 279, proceed by this rule.

Rule LXX.—Multiply the weight in pounds equally distributed over the arch by the length of the tie-rod in feet, clear of the heel plates, and divide the product by the height of the arc in inches, (that is, the height at the middle, from the axis of the tie-rod to the centre of the depth of the brick arch,) then, if there is to be but one tie-rod, divide the quotient by 3000;

but if two, then divide by 6000, and the square root of the quotient, in either case, will be the required diameter.

Example.—The weight to be supported on a brick arch, equally distributed, is 24000 pounds; the length of the tie-rod, clear of the heel plates, is 10 feet; and the height, or rise, of the arch is 10 inches. Now by the rule, $24000 \times 10 = 240000$. This divided by 10, equals 24000. Upon the presumption that one tie-rod only will be needed, divide by 3000, and the quotient is 8, the square root of which is 2.82 inches. This is rather large, therefore there had better be two rods. In this case the quotient, 24000, divided by 6000, equals 4, the square root of which is 2, the diameter required. The arch should, therefore, have two rods of 2 inches diameter. Two rods are preferable to one. The iron is stronger per inch in small rods than in large ones, and the rules require no more metal in the two rods than in the one.



Fig. 280.

435.—The *Bow-string Girder*, as per *Fig. 280*, has little to recommend it, (see *Art. 433*,) yet because it has by some been much used, it is well to show the rules that govern its strength, if only for the benefit of those who are willing to be governed by reason rather than precedent. To resist the horizontal thrust of the cast arch, the diameter of the rod must equal

(204)

$$D = \sqrt{\frac{ws}{3000h}}$$

But the cast iron arch has a certain amount of strength to re

sist cross strains: this strength must be considered. Upon the presumption that the cross section of the cast arch at the middle is of the most favorable form, as in *Fig. 277*, or at least that it have a bottom flange, (although the most of those cast are without it), the strength of the cast arch to resist cross strains is shown by formula (199), when l , its length, is changed to s , its span. The weight in pounds equally diffused over the arch will then equal

$$w = \frac{9000 t a d}{s}.$$

This is the weight borne by the cast arch acting simply as a beam. Deducting this weight from the whole weight, the remainder is the weight to be sustained by the rod. Calling the whole weight w , then

$$w - \frac{9000 t a d}{s} = \frac{w s - 9000 t a d}{s} = W$$

Therefore, from (204), the diameter equals

$$\begin{aligned} D &= \sqrt{\frac{W s}{3000 h}} \\ &= \sqrt{\frac{(w s - 9000 t a d)}{s} s}{3000 h} \\ &= \sqrt{\frac{w s - 9000 t a d}{3000 h}}, \end{aligned} \quad (206.)$$

where D equals the diameter of the rod in inches; w , the weight in pounds equally diffused over the arch; s , the span of the arch in feet; h , the rise or height of the arc at middle, in inches; d , the height or depth of the cross section of the cast arch in inches; a , the area of the bottom flange of the cross section of the cast arch in inches; and t , a decimal in proportion to unity as the safe weight is to be to the breaking weight.

The rule in words at length, is

Rule LXXI.—Multiply the decimal in proportion to unity

as the safe weight is to be to the breaking weight, by 9000 times the depth of the cross section of the cast arch at middle, and by the area of the bottom flange of said section, both in inches, and deduct the product from the weight in pounds equally diffused over the arch multiplied by the span in feet, and divide the remainder by 3000 times the height of the arc in inches, measured from the axis of the tie-rod to the centre of the depth of the cast arch at middle, and the square root of the quotient will be the diameter of the rod in inches.

Example.—The rear wall of a building is of brick, and is 40 feet high, and 21 feet wide in the clear between the piers of the story below. Allowing for the voids for windows, this wall will weigh about 63000 pounds; and it is proposed to support it by a bow-string girder, of which the cross section at middle of the cast arch is 8 inches deep, and has a bottom flange containing 12 inches area. The rise of the curve or arc is 24 inches. What must be the diameter of the rod, the portion of the breaking weight of the cast arch, considered safe to trust, being three-tenths or 0.3? By the rule, $0.3 \times 9000 \times 8 \times 12 = 259200$; then $\frac{63000 \times 21}{3000} - 259200 = 1063800$. This remainder divided by $(3000 \times 24 =) 72000$, the quotient equals 14.775; the square root of which, 3.84, or nearly $3\frac{7}{8}$ inches, is the required diameter.

This size, though impracticably large, is as small as a due regard for safety will permit; yet it is not unusual to find the rods in girders intended for as heavy a load as in this example, only $2\frac{1}{4}$ and $2\frac{1}{2}$ inches! Were it possible to attach the rod so as not to injure its strength in the process of shrinking it in—putting it to its place hot, and depending on the contraction of the metal in cooling to bring it to a proper bearing—and were it possible to have the bearings so true as to induce the strain through the *axis* of the rod, and not along its *side*, (*Art.* 308,) then a less diameter than that given by the rule would suffice. But while these contingencies remain, the rule

cannot safely be reduced, for, in the rule, the value of T , for wrought iron, (Table III., *Art.* 308,) is taken at nearly 6000 pounds, a point rather high in consideration of the size of the rod and the injuries, before stated, to which it is subjected. In cases where a girder wholly of cast iron (*Fig.* 276) is not preferred, it were better to build a brick arch resting on heel plates, (*Fig.* 279,) in which the metal required to resist the thrust may be divided into *two* rods instead of *one*, thus rendering the size more practical, and at the same time avoiding the injuries to which rods in arch girders are subjected. The heel-plate arch is also to be preferred to the cast arch on the score of economy; inasmuch as the brick which is substituted for the cast arch will cost less than iron. For example, suppose the cross section of the iron arch to be thus: the blade or upright part 8 by $1\frac{1}{2}$ inches, the top flange 12 by $1\frac{1}{4}$ inches, and the bottom flange 6 by $1\frac{3}{4}$ inches. At these dimensions, the area of the cross section will equal $12 + 15 + 10\frac{1}{2} = 37\frac{1}{2}$ inches. A bar of cast iron, one foot long and one inch square, will weigh 3.2 pounds; therefore, $37\frac{1}{2} \times 3.2 = 120$ pounds, equals the weight of the cast arch per lineal foot. The price of castings per pound, as also the price of brickwork per cubic foot, of course will depend upon the locality and the state of the market at the time, but for a comparison they may be stated, the one at three and a half cents per pound, and the other at thirty cents per cubic foot. At these prices the cast arch will cost $120 \times 3\frac{1}{2} = \4 20 per lineal foot; while the brick arch—12 inches high and 12 inches thick—will cost 30 cents per lineal foot. The difference is \$3 90. This amount is not all to be credited to the account of the brick arch. Proper allowance is to be made for the cost of the heel plates, and of the wooden centre; also for the cost of a small addition to the size of the tie rods, which is required to sustain the strain otherwise borne by the cast arch in its resistance to a cross strain (*Art.* 435). Deducting the cost of these items,

the difference in favor of the brick arch will be about \$3 per foot. This, on a girder 25 feet long, amounts to \$75. The difference in all cases will not equal this, but will be sufficiently great to be worth saving.

SECTION V.—DOORS, WINDOWS, &c.

DOORS.

436.—Among the several architectural arrangements of an edifice, the door is by no means the least in importance; and, if properly constructed, it is not only an article of use, but also of ornament, adding materially to the regularity and elegance of the apartments. The dimensions and style of finish of a door, should be in accordance with the size and style of the building, or the apartment for which it is designed. As regards the utility of doors, the principal door to a public building should be of sufficient width to admit of a free passage for a crowd of people; while that of a private apartment will be wide enough, if it permit one person to pass without being incommoded. Experience has determined that the least width allowable for this is 2 feet 8 inches; although doors leading to inferior and unimportant rooms may, if circumstances require it, be as narrow as 2 feet 6 inches; and doors for closets, where an entrance is seldom required, may be but 2 feet wide. The width of the principal door to a public building may be from 6 to 12 feet, according to the size of the building; and the width of doors for a dwelling may be from 2 feet 8 inches, to 3 feet 6 inches. If the importance of an apartment in a dwelling be such as to require a door of greater width

than 3 feet 6 inches, the opening should be closed with two doors, or a door in two folds; generally, in such cases, where the opening is from 5 to 8 feet, folding or sliding doors are adopted. As to the height of a door, it should in no case be less than about 6 feet 3 inches; and generally not less than 6 feet 8 inches.

437.—The proportion between the width and height of single doors, for a dwelling, should be as 2 is to 5; and, for entrance-doors to public buildings, as 1 is to 2. If the width is given and the height required of a door for a dwelling, multiply the width by 5, and divide the product by 2; but, if the height is given and the width required, divide by 5, and multiply by 2. Where two or more doors of different widths show in the same room, it is well to proportion the dimensions of the more important by the above rule, and make the narrower doors of the same height as the wider ones; as all the doors in a suit of apartments, except the folding or sliding doors, have the best appearance when of one height. The proportions for folding or sliding doors should be such that the width may be equal to $\frac{4}{5}$ of the height; yet this rule needs some qualification: for, if the width of the opening be greater than one-half the width of the room, there will not be a sufficient space left for opening the doors; also, the height should be about one-tenth greater than that of the adjacent single doors.

438.—Where doors have but two panels in width, let the stiles and muntins be each $\frac{1}{4}$ of the width; or, whatever number of panels there may be, let the united widths of the stiles and the muntins, or the whole width of the solid, be equal to $\frac{3}{4}$ of the width of the door. Thus: in a door, 35 inches wide, containing two panels in width, the stiles should be 5 inches wide; and in a door, 3 feet 6 inches wide, the stiles should be 6 inches. If a door, 3 feet 6 inches wide, is to have 3 panels in width, the stiles and muntins should be each $4\frac{1}{2}$ inches wide, each panel being 8 inches. The bottom rail and the lock rail ought to be each equal in width to $\frac{1}{6}$ of the height of the door; and the top rail, and all

others, of the same width as the stiles. The moulding on the panel should be equal in width to $\frac{1}{4}$ of the width of the stile.




Fig. 281.

439.—*Fig. 281* shows an approved method of trimming doors : *a* is the door stud ; *b*, the lath and plaster ; *c*, the ground ; *d*, the jamb ; *e*, the stop ; *f* and *g*, architrave casings ; and *h*, the door stile. It is customary in ordinary work to form the stop for the door by *rebating* the jamb. But, when the door is thick and heavy, a better plan is to nail on a piece as at *e* in the figure. This piece can be fitted to the door, and put on after the door is hung ; so, should the door be a trifle *winding*, this will correct the evil, and the door be made to shut solid.

440.—*Fig. 282* is an elevation of a door and trimmings suitable for the best rooms of a dwelling. (For trimmings generally, see Sect. III.) The number of panels into which a door should be divided, is adjusted at pleasure ; yet the present style of finishing requires, that the number be as small as a proper regard for strength will admit. In some of our best dwellings, doors have been made having only two upright panels. A few years experience, however, has proved that the omission of the lock rail is at the expense of the strength and durability of the door ; a four-panel door, therefore, is the best that can be made.

441.—The doors of a dwelling should all be hung so as to open into the principal rooms ; and, in general, no door should be hung to open into the hall, or passage. As to the proper edge of the door on which to affix the hinges, no general rule can be assigned




Fig. 282.

WINDOWS.

442.—A window should be of such dimensions, and in such a position, as to admit a sufficiency of light to that part of the apartment for which it is designed. No definite rule for the size

can well be given, that will answer in all cases ; yet, as an approximation, the following has been used for general purposes. Multiply together the length and the breadth in feet of the apartment to be lighted, and the product by the height in feet ; then the square-root of this product will show the required number of square feet of glass.

443.—To ascertain the dimensions of window frames, add $4\frac{1}{2}$ inches to the width of the glass for their width, and $6\frac{1}{2}$ inches to the height of the glass for their height. These give the dimensions, in the clear, of ordinary frames for 12-light windows ; the height being taken at the inside edge of the sill. In a brick wall, the width of the opening is 8 inches more than the width of the glass— $4\frac{1}{2}$ for the stiles of the sash, and $3\frac{1}{2}$ for hanging stiles—and the height between the stone sill and lintel is about $10\frac{1}{2}$ inches more than the height of the glass, it being varied according to the thickness of the sill of the frame.

444.—In hanging inside shutters to fold into *boxes*, it is necessary to have the box shutter about one inch wider than the flap, in order that the flap may not interfere when both are folded into the box. The usual margin shown between the face of the shutter when folded into the box and the quirk of the stop bead, or edge of the casing, is half an inch ; and, in the usual method of letting the *whole* of the thickness of the butt hinge into the edge of the box shutter, it is necessary to make allowance for the *throw* of the hinge. This may, in general, be estimated at $\frac{1}{4}$ of an inch at each hinging ; which being added to the margin, the entire width of the shutters will be $1\frac{1}{2}$ inches more than the width of the frame in the clear. Then, to ascertain the width of the box shutter, add $1\frac{1}{2}$ inches to the width of the frame in the clear, between the pulley stiles ; divide this product by 4, and add half an inch to the quotient ; and the last product will be the required width. For example, suppose the window to have 3 lights in width, 11 inches each. Then, 3 times 11 is 33, and $4\frac{1}{2}$ added for the wood of the sash, gives $37\frac{1}{2}$ — $37\frac{1}{2}$ and $1\frac{1}{2}$ is 39

and 39, divided by 4, gives $9\frac{3}{4}$; to which add half an inch, and the result will be $10\frac{1}{4}$ inches, the width required for the box shutter.

445.—In disposing and proportioning windows for the walls of a building, the rules of architectural taste require that they be of different heights in different stories, but of the same width. The windows of the upper stories should all range perpendicularly over those of the first, or principal, story; and they should be disposed so as to exhibit a balance of parts throughout the front of the building. To aid in this, it is always proper to place the front door in the middle of the front of the building; and, where the size of the house will admit of it, this plan should be adopted. (See the latter part of *Art.* 224.) The proportion that the height should bear to the width, may be, in accordance with general usage, as follows:

	The height of	basement windows,	$1\frac{1}{3}$	of the width.
“	“	principal-story	$2\frac{1}{8}$	“
“	“	second-story	$1\frac{7}{8}$	“
“	“	third-story	$1\frac{3}{4}$	“
“	“	fourth-story	$1\frac{1}{2}$	“
“	“	attic-story	“	the same as the width.

But, in determining the height of the windows for the several stories, it is necessary to take into consideration the height of the story in which the window is to be placed. For, in addition to the height from the floor, which is generally required to be from 28 to 30 inches, room is wanted above the head of the window for the window-trimming and the cornice of the room, besides some respectable space which there ought to be between these.

446.—Doors and windows are usually *square-headed*, or terminate in a horizontal line at top. These require no special directions for their trimmings. But circular-headed doors and windows are more difficult of execution, and require some attention. If the jambs of a door or window be placed at right angles to the face of the wall, the edges of the *soffit*, or surface of the head, would be straight, and its length be found by getting the

stretch-out of the circle, (*Art.* 92;) but, when the jambs are placed obliquely to the face of the wall, occasioned by the demand for light in an oblique direction, the form of the soffit will be obtained by the following article: and, when the face of the wall is circular, as in the succeeding one.




Fig. 283.

447.—*To find the form of the soffit for circular window heads, when the light is received in an oblique direction.* Let $a b c d$, (*Fig.* 283,) be the ground-plan of a given window, and $e f a$, a vertical section taken at right angles to the face of the jambs. From a , through e , draw $a g$, at right angles to $a b$; obtain the stretch-out of $e f a$, and make $e g$ equal to it; divide $e g$ and $e f a$, each into a like number of equal parts, and drop perpendiculars from the points of division in each; from the points of intersection, 1, 2, 3, &c., in the line, $a d$, draw horizontal lines to meet corresponding perpendiculars from $e g$; then those points of intersection will give the curve line, $d g$, which will be the one required for the edge of the soffit. The other edge, $c h$, is found in the same manner.

448.—*To find the form of the soffit for circular window-heads, when the face of the wall is curved.* Let $a b c d$, (*Fig.* 284,) be the ground-plan of a given window, and $e f a$, a vertical section of the head taken at right angles to the face of the jambs.




Fig. 284. c

Proceed as in the foregoing article to obtain the line, $d g$; then that will be the curve required for the edge of the soffit; the other edge being found in the same manner.


If the given vertical section be taken in a line with the face of the wall, instead of at right angles to the face of the jambs, place it upon the line, $c b$, (*Fig. 283*;) and, having drawn ordinates at right angles to $c b$, transfer them to $e f a$; in this way, a section at right angles to the jambs can be obtained.

SECTION VI.—STAIRS.

449.—The STAIRS is that mechanical arrangement in a building by which access is obtained from one story to another. Their position, form and finish, when determined with discriminating taste, add greatly to the comfort and elegance of a structure. As regards their position, the first object should be to have them near the middle of the building, in order that an equally easy access may be obtained from all the rooms and passages. Next in importance is light; to obtain which they would seem to be best situated near an outer wall, in which windows might be constructed for the purpose; yet a sky-light, or opening in the roof, would not only provide light, and so secure a central position for the stairs, but may be made, also, to assist materially as an ornament to the building, and, what is of more importance, afford an opportunity for better ventilation.

450.—It would seem that the length of the raking side of the *pitch-board*, or the distance from the top of one riser to the top of the next, should be about the same in all cases; for, whether stairs be intended for large buildings or for small, for public or for private, the accommodation of men of the same stature is to be consulted in every instance. But it is evident that, with the same effort, a longer step can be taken on level than on rising ground,

and that, although the tread and rise cannot be proportioned merely in accordance with the style and importance of the building, yet this may be done according to the angle at which the flight rises. If it is required to ascend gradually and easy, the length from the top of one rise to that of another, or the hypotenuse of the pitch-board, may be long; but, if the flight is steep the length must be shorter. Upon this data the following problem is constructed.



451.—*To proportion the rise and tread to one another.* Make the line, $a b$, (*Fig. 285*,) equal to 24 inches; from b , erect $b c$, at right angles to $a b$, and make $b c$ equal to 12 inches; join a and c , and the triangle, $a b c$, will form a scale upon which to graduate the sides of the pitch-board. For example, suppose a very easy stairs is required, and the tread is fixed at 14 inches. Place it from b to f , and from f ; draw $f g$, at right angles to $a b$; then the length of $f g$ will be found to be 5 inches, which is a proper rise for 14 inches tread, and the angle, $f b g$, will show the degree of inclination at which the flight will ascend. But, in a majority of instances, the height of a story is fixed, while the length of tread, or the space that the stairs occupy on the lower floor, is optional. The height of a story being determined, the height of each rise will of course depend upon the number into which the whole height is divided; the angle of ascent being more easy if the number be great, than if it be smaller. By dividing

the whole height of a story into a certain number of rises, suppose the length of each is found to be 6 inches. Place this length from b to h , and draw $h i$, parallel to $a b$; then $h i$, or $b j$ will be the proper tread for that rise, and $j b i$ will show the angle of ascent. On the other hand, if the angle of ascent be given, as $a b l$, ($b l$ being $10\frac{1}{2}$ inches, the proper *length of run* for a step-ladder,) drop the perpendicular, $l k$, from l to k ; then $l k b$ will be the proper proportion for the sides of a pitch-board for that *run*.

452.—The angle of ascent will vary according to circumstances. The following treads will determine about the right inclination for the different classes of buildings specified.

In public edifices,	tread about 14	inches.
In first-class dwellings	“	$12\frac{1}{2}$ “
In second-class “	“	11 “
In third-class “ and cottages	“	9 “

Step-ladders to ascend to scuttles, &c., should have from 10 to 11 inches *run* on the rake of the string. (See notes at *Art. 103.*)

453.—The length of the steps is regulated according to the extent and importance of the building in which they are placed, varying from 3 to 12 feet, and sometimes longer. Where two persons are expected to pass each other conveniently, the shortest length that will admit of it is 3 feet; still, in crowded cities where land is so valuable, the space allowed for passages being very small, they are frequently executed at $2\frac{1}{2}$ feet.

454.—*To find the dimensions of the pitch-board.* The first thing in commencing to build a stairs, is to make the *pitch-board*; this is done in the following manner. Obtain very accurately, in feet and inches, the perpendicular height of the story in which the stairs are to be placed. This must be taken from the top of the floor in the lower story to the top of the floor in the upper story. Then, to obtain the number of rises, the height in inches thus obtained must be divided by 5, 6, 7, 8, or 9, according to the quality and style of the building in which the stairs are to be

built. For instance, suppose the building to be a first-class dwelling, and the height ascertained is 13 feet 4 inches, or 160 inches. The proper rise for a stairs in a house of this class is about 6 inches. Then, 160 divided by 6, gives $26\frac{2}{3}$ inches. This being nearer 27 than 26, the number of risers, should be 27. Then divide the height, 160 inches, by 27, and the quotient will give the height of one rise. On performing this operation, the quotient will be found to be 5 inches, $\frac{7}{8}$ and $\frac{1}{16}$ of an inch.

Then, if the space for the extension of the stairs is not limited, the tread can be found as at *Art. 451*. But, if the contrary is the case, the whole distance given for the treads must be divided by the number of treads required. On account of the upper floor forming a step for the last riser, the number of treads is always one less than the number of risers. Having obtained this rise and tread, the pitch-board may be made in the following manner. Upon a piece of well-seasoned board about $\frac{5}{8}$ of an inch thick, having one edge jointed straight and square, lay the corner of a carpenters'-square, as shown at *Fig. 286*. Make *a b*




Fig 286.

equal to the rise, and *b c* equal to the tread; mark along those edges with a knife, and cut it out by the marks, making the edges perfectly square. The grain of the wood must run in the direction indicated in the figure, because, if it shrinks a trifle, the rise and the tread will be equally affected by it. When a pitch-board is first made, the dimensions of the rise and tread should be preserved in figures, in order that, should the first shrink, a second could be made.

455.—*To lay out the string.* The space required for timber




Fig. 287.

and plastering under the steps, is about 5 inches for ordinary stairs; set a gauge, therefore, at 5 inches, and run it on the lower edge of the plank, as *a b*, (*Fig. 287*.) Commencing at one end, lay the longest side of the pitch-board against the gauge-mark, *a b*, as at *c*, and draw by the edges the lines for the first rise and tread; then place it successively as at *d*, *e* and *f*, until the required number of risers shall be laid down.




Fig. 288.

456.—*Fig. 288* represents a section of a step and riser, joined after the most approved method. In this, *a* represents the end of a block about 2 inches long, two of which are glued in the corner in the length of the step. The cove at *b* is planed up square, glued in, and *stuck* after the glue is set.

PLATFORM STAIRS.

457.—A platform stairs ascends from one story to another in two or more flights, having platforms between for resting and to change their direction. This kind of stairs is the most easily constructed, and is therefore the most common. The cylin-




Fig. 289.

der is generally of small diameter, in most cases about 6 inches. It may be worked out of one solid piece, but a better way is to glue together three pieces, as in *Fig. 289*; in which the pieces, *a*, *b* and *c*, compose the cylinder, and *d* and *e* represent parts of the strings. The strings, after being glued to the cylinder, are secured with screws. The joining at *o* and *o* is the most proper for that kind of joint.

458.—*To obtain the form of the lower edge of the cylinder.* Find the stretch-out, *d e*, (*Fig. 290*), of the face of the cylinder *a b c*, according to *Art. 92*; from *d* and *e*, draw *d f* and *e g*, at right angles to *d e*; draw *h g*, parallel to *d e*, and make *h f* and *g i*, each equal to one rise; from *i* and *f*, draw *i j* and *f k*, parallel to *h g*; place the tread of the pitch-board at these last lines, and draw by the lower edge the lines, *k h* and *i l*; parallel to these, draw *m n* and *o p*, at the requisite distance for the dimensions of the string; from *s*, the centre of the plan, draw *s q*, parallel to *d f*; divide *h q* and *q g*, each into 2 equal parts, as at *v* and *w*; from *v* and *w*, draw *v n* and *w o*, parallel to *f d*; join *n* and *o*, cutting *q s* in *r*; then the angles, *u n r* and *r o t*, being eased off according to *Art. 89*, will give the proper curve for the bottom edge of the cylinder. A centre may be found upon which to describe these curves thus: from *u*, draw *u x*, at right angles to *m n*; from *r*, draw *r x*, at right angles to *n o*; then *x* will be the centre for the curve, *u r*. The centre for the curve, *r t*, is found in the same manner.




Fig. 290.

459.—*To find the position for the balusters.* Place the centre of the first baluster, (*b. Fig. 291,*) $\frac{1}{2}$ its diameter from the face of the riser, *c d*, and $\frac{1}{3}$ its diameter from the end of the step, *e d*; and place the centre of the other baluster, *a*, half the tread from the centre of the first. The centre of the rail must be placed over the centre of the balusters. Their usual length is 2 feet 5 inches, and 2 feet 9 inches, for the short and the long balusters respectively.




Fig. 291.




Fig. 292.

460.—*To find the face-mould for a round hand-rail to platform stairs. CASE 1.—When the cylinder is small.* In *Fig. 292*, *j* and *e* represent a vertical section of the last two steps of the first flight, and *d* and *i* the first two steps of the second flight, of a platform stairs, the line, *e f*, being the platform; and *a b c* is the plan of a line passing through the centre of the rail around the cylinder. Through *i* and *d*, draw *i k*, and through *j* and *e*, draw *j k*; from *k*, draw *k l*, parallel to *f e*; from *b*, draw *b m*, parallel to *g d*; from *l*, draw *l r*, parallel to *k j*; from *n*, draw *n t*, at right angles to *j k*; on the line, *o b*, make *o t* equal to *n t*; join *c* and *t*; on the line, *j c*, (*Fig. 293*.) make *e c* equal to *e n* at *Fig. 292*; from *c*, draw *c t*, at right angles to *j c*, and make *c t*




Fig. 298.

equal to $c t$ at *Fig. 292*; through t , draw $p l$, parallel to $j c$, and make $t l$ equal to $t l$ at *Fig. 292*; join l and c , and complete the parallelogram, $e c l s$; find the points, o, o, o , according to *Art. 118*; upon e, o, o, o , and l , successively, with a radius equal to half the width of the rail, describe the circles shown in the figure; then a curve traced on both sides of these circles and just touching them, will give the proper form for the mould. The joint at l is drawn at right angles to $c l$.

461.—*Elucidation of the foregoing method.* This excellent plan for obtaining the face-moulds for the hand-rail of a platform stairs, has never before been published. It was communicated to me by an eminent stair-builder of this city: and having seen rails put up from it, I am enabled to give it my unqualified recommendation. In order to have it fully understood, I have introduced *Fig. 294*; in which the cylinder, for this purpose, is made rectangular instead of circular. The figure gives a perspective view of a part of the upper and of the lower flights, and a part of the platform about the cylinder. The heavy lines, $i m$, $m c$ and $c j$, show the direction of the rail, and are supposed to pass through the centre of it. When the rake of the second flight is the same as that of the first, which is here and is generally the case, the face-mould for the lower twist will, when reversed, do for the upper flight: that part of the rail, therefore, which passes from e to c and from c to l , is all that will need explanation.

Suppose, then, that the parallelogram, $e a o c$, represent a plane lying perpendicularly over $e a b f$, being inclined in the direction, $e c$, and level in the direction, $c o$; suppose this plane, $e a o c$,




Fig. 294.

be revolved on ec as an axis, in the manner indicated by the arcs, on and ax , until it coincides with the plane, $ertc$; the line, ao , will then be represented by the line, xn ; then add the parallelogram, $xrtn$, and the triangle, ctl , deducting the triangle, ers ; and the edges of the plane, esc , inclined in the direction, ec , and also in the direction, cl , will lie perpendicularly over the plane, abf . From this we gather that the line, co , being at right angles to

presents a plan and a vertical section of a line passing through the centre of the rail as before. From *b*, draw *b k*, parallel to *c d*; extend the lines, *i d* and *j e*, until they meet *k b* in *k* and *f*; from *n*, draw *n l*, parallel to *o b*; through *l*, draw *l t*, parallel to *j k*, from *k*, draw *k t*, at right angles to *j k*; on the line, *o b*, make *o t* equal to *k t*. Make *e c*, (*Fig. 296.*) equal to *e k* at *Fig. 295*; from *c*,




Fig. 296.

draw *c t*, at right angles to *e c*, and equal to *c t* at *Fig. 295*. from *t*, draw *t p*, parallel to *c e*, and make *t l* equal to *t l* at *Fig. 295*; complete the parallelogram, *e c l s*, and find the points, *o, o, o*, as before; then describe the circles and complete the mould as in *Fig. 293*. The difference between this and Case 1 is, that the line, *c t*, instead of being raised and thrown out, is lowered and drawn in. (See note at page 381.)




Fig. 297.

463.—CASE 3.—Where the rake meets the level. In *Fig*

297, $a b c$ is the plan of a line passing through the centre of the rail around the cylinder as before, and j and e is a vertical section of two steps starting from the floor, $h g$. Bisect $e h$ in d , and through d , draw $d f$, parallel to $h g$; bisect $f n$ in l , and from l , draw $l t$, parallel to $n j$; from n , draw $n t$, at right angles to $j n$. On the line, $o b$, make $o t$ equal to $n t$. Then, to obtain a mould for the twist going up the flight, proceed as at *Fig. 293*; making $c c$ in that figure equal to $e n$ in *Fig. 297*, and the other lines of a length and position such as is indicated by the letters of reference in each figure. To obtain the mould for the level rail, extend $h o$, (*Fig. 297*), to i ; make $o i$ equal to $f l$, and join i and c ; make $c i$, (*Fig. 298*), equal to $c i$ at *Fig. 297*; through c , draw $c d$, at




Fig. 298.

right angles to $c i$; make $d c$ equal to $d f$ at *Fig. 297*, and complete the parallelogram, $o d c i$; then proceed as in the previous cases to find the mould.

464.—All the moulds obtained by the preceding examples have been for round rails. For these, the mould may be applied to a plank of the same thickness as the rail is intended to be, and the plank sawed square through, the joints being cut square from the face of the plank. A twist thus cut and truly rounded will hang in a proper position over the plan, and present a perfect and graceful wreath.

465.—*To bore for the balusters of a round rail before rounding it.* Make the angle, $o c t$, (*Fig. 299*), equal to the angle, $o c t$, at *Fig. 292*; upon c , describe a circle with a radius equal to half the thickness of the rail; draw the tangent, $b d$, parallel to $t c$, and complete the rectangle, $e b d f$, having sides tangential to the circle; from c , draw $c a$, at right angles to $o c$; then, $b d$ being the bottom of the rail, set a gauge from b to a , and run it the whole length of the stuff; in boring, place the centre of the




Fig. 299.

bit in the gauge-mark at *a*, and bore in the direction, *a c*. To do this easily, make *chucks* as represented in the figure, the bottom edge, *g h*, being parallel to *o c*, and having a place sawed out, as *e f*, to receive the rail. These being nailed to the bench, the rail will be held steadily in its proper place for boring vertically. The distance apart that the balusters require to be, on the under side of the rail, is one-half the length of the *rake-side* of the pitch-board.




Fig. 300.

466.—To obtain, by the foregoing principles, the face-mould for the twists of a moulded rail upon platform stairs In Fig. 300, $a b c$ is the plan of a line passing through the centre of the rail around the cylinder as before, and the lines above it are a vertical section of steps, risers and platform, with the lines for the rail obtained as in Fig. 292. Set half the width of the rail from b to f and from b to r , and from f and r , draw $f e$ and $r d$, parallel to $c a$. At Fig. 301, the centre lines of the




Fig. 301.

raii, $k c$ and $c n$, are obtained as in the previous examples. Make $c i$ and $c j$, each equal to $c i$ at Fig. 300, and draw the lines, $i m$ and $j g$, parallel to $c k$; make $n e$ and $n d$ equal to $n e$ and $n d$ at Fig. 300, and draw $d o$ and $e l$, parallel to $n c$; also, through k , draw $s g$, parallel to $n c$; then, in the parallelograms, $m s d o$ and $g s e l$, find the elliptic curves, $d m$ and $e g$, according to Art. 118, and they will define the curves. The line, $d e$, being drawn through n parallel to $k c$, defines the joint, which is to be cut through the plank vertically. If the rail crosses the platform rather steep, a butt joint will be preferable, to obtain which see Art. 498.




Fig. 302.

467.—*To apply the mould to the plank.* The mould obtained according to the last article must be applied to both sides of the plank, as shown at *Fig. 302*. Before applying the mould, the edge, *e f*, must be bevelled according to the angle, *c t x*, at *Fig. 300*; if the rail is to be canted *up*, the edge must be bevelled at an *obtuse* angle with the upper face; but if it is to be canted *down*, the angle that the edge makes with the upper face must be *acute*. From the spring of the curve, *a*, and the end, *c*, draw vertical lines across the edge of the plank by applying the pitch-board, *a b c*; then, in applying the mould to the other side, place the points, *a* and *c*, at *b* and *f*; and, after marking around it, saw the rail out vertically. After the rail is sawed out, the bottom and the top surfaces must be squared from the sides.

468.—*To ascertain the thickness of stuff required for the twists.* The thickness of stuff required for the twists of a round rail, as before observed, is the same as that for the straight; but for a moulded rail, the stuff for the twists must be thicker than that for the straight. In *Fig. 300*, draw a section of the rail between the lines, *d r* and *e f*, and as close to the line, *d e*, as possible; at the lower corner of the section, draw *g h*, parallel to *d e*; then the distance that these lines are apart, will be the thickness required for the twists of a moulded rail.

The foregoing method of finding moulds for rails is applicable to all stairs which have continued rails around cylinders, and are without winders.

WINDING STAIRS.

469.—Winding stairs have steps tapering narrower at one end than at the other. In some stairs, there are steps of parallel width incorporated with tapering steps; the former are then called *flyers* and the latter *winders*.

470.—*To describe a regular geometrical winding stairs.* In *Fig. 303*, *a b c d* represents the inner surface of the wall enclosing the space allotted to the stairs, *a e* the length of the steps, and *e f g h* the cylinder, or face of the front string. The line,




Fig. 303.

ae , is given as the face of the first riser, and the point, j , for the limit of the last. Make ei equal to 18 inches, and upon o , with oi for radius, describe the arc, ij ; obtain the number of risers and of treads required to ascend to the floor at j , according to *Art.* 454, and divide the arc, ij , into the same number of equal parts as there are to be treads; through the points of division, 1, 2, 3, &c., and from the wall-string to the front-string, draw lines tending to the centre, o ; then these lines will represent the face of each riser, and determine the form and width of the steps. Allow the necessary projection for the nosing beyond ae , which should be equal to the thickness of the step, and then $aelk$ will be the dimensions for each step. Make a pitch-board for the wall-string having ak for the tread, and the rise as previously ascertained; with this, lay out on a thickened plank the several risers and treads, as at *Fig.* 287, gauging from the upper edge of the string for the line at which to set the pitch-board.

Upon the back of the string, with a $1\frac{1}{4}$ inch dado plane, make

a succession of grooves $1\frac{1}{4}$ inches apart, and parallel with the lines for the risers on the face. These grooves must be cut along the whole length of the plank, and deep enough to admit of the plank's bending around the curve, $a b c d$. Then construct a drum, or cylinder, of any common kind of stuff, and made to fit a curve having a radius the thickness of the string less than $o a$; upon this the string must be bent, and the grooves filled with strips of wood, called *keys*, which must be very nicely fitted and glued in. After it has dried, a board thin enough to bend around on the outside of the string, must be glued on from one end to the other and nailed with clout nails. In doing this, be careful not to nail into any place where a riser or step is to enter on the face.

After the string has been on the drum a sufficient time for the glue to set, take it off, and cut the mortices for the steps and risers on the face at the lines previously made; which may be done by boring with a centre-bit half through the string, and nicely chiseling to the line. The drum need not be made so large as the whole space occupied by the stairs, but merely large enough to receive one piece of the wall-string at once—for it is evident that more than one will be required. The front string may be constructed in the same manner; taking $e l$ instead of $a k$ for the tread of the pitch-board, dadoing it with a smaller dado plane, and bending it on a drum of the proper size.




Fig. 304.

471.—*To find the shape and position of the timbers necessary to support a winding stairs.* The dotted lines in *Fig.* 303 show the proper position of the timbers as regards the plan: the shape of each is obtained as follows. In *Fig.* 304, the line, 1 a , is equal to a riser, less the thickness of the floor, and the lines, 2 m , 3 n , 4 o , 5 p and 6 q , are each equal to one riser. The

line, $a 2$, is equal to $a m$ in *Fig.* 303, the line, $m 3$ to $m n$ in that figure, &c. In drawing this figure, commence at a , and make the lines, $a 1$ and $a 2$, of the length above specified, and draw them at right angles to each other; draw $2 m$, at right angles to $a 2$, and $m 3$, at right angles to $m 2$, and make $2 m$ and $m 3$ of the lengths as above specified; and so proceed to the end. Then, through the points, 1, 2, 3, 4, 5 and 6, trace the line, $1 b$; upon the points, 1, 2, 3, 4, &c., with the size of the timber for radius, describe arcs as shown in the figure, and by these the lower line may be traced parallel to the upper. This will give the proper shape for the timber, $a b$, in *Fig.* 303; and that of the others may be found in the same manner. In ordinary cases, the shape of one face of the timber will be sufficient, for a good workman can easily hew it to its proper level by that; but where great accuracy is desirable, a pattern for the other side may be found in the same manner as for the first.

472.—*To find the falling-mould for the rail of a winding stairs.* In *Fig.* 305, $a c b$ represents the plan of a rail around half the cylinder, A the cap of the newel, and 1, 2, 3, &c., the face of the risers in the order they ascend. Find the stretch-out, $e f$, of $a c b$, according to *Art.* 92; from o , through the point of the mitre at the newel-cap, draw $o s$; obtain on the tangent, $e d$, the position of the points, s and h^2 ,* as at t and f^2 ; from $e t f^2$ and f , draw $e x$, $t u$, $f^2 g^2$ and $f h$, all at right angles to $e d$; make $e g$ equal to one rise and $f^2 g^2$ equal to 12, as this line is drawn from the 12th riser; from g , through g^2 , draw $g i$; make $g x$ equal to about three-fourths of a rise, (the top of the newel, x , should be $3\frac{1}{2}$ feet from the floor;) draw $x u$, at right angles to $e x$, and ease off the angle at u ; at a distance equal to the thickness of

* In the above, the references, a^2 , b^2 , &c., are introduced for the first time. During the time taken to refer to the figure, the memory of the *form* of these may pass from the mind, while that of the *sound* alone remains; they may then be mistaken for $a 2$, $b 2$, &c. This can be avoided in reading by giving them a sound corresponding to their meaning, which is *second a second b, &c. or a second, b second.*




Fig. 806.

shown at half their full size. *A* is the plan of the rail, and *B* is the falling-mould ; in which *k z* is the direction of the butt-joint. From *k*, draw *k b*, parallel to *l o*, and *k e*, at right angles to *k b* ; from *b*, draw *b f*, tending to the centre of the plan, and from *f*, draw *f e*, parallel to *b k* ; from *l*, through *e* draw *l i*, and from *i*, draw *i d*, parallel to *e f* ; join *d* and *b*, and *d b* will be the proper direction

for the joint on the plan. The direction of the joint on the other side, $a c$, can be found by transferring the distances, $x b$ and $o d$ to $x a$ and $o c$. (See *Art.* 477.)




Fig. 807.

Having obtained the direction of the joint, make $s r d b$, (*Fig.* 307,) equal to $s r d^2 b^2$ in *Fig.* 305; through r and d , draw $t a$, through s and from d , draw $t u$ and $d e$, at right angles to $t a$; make $t u$ and $d e$ equal to $t u$ and $b^2 m$, respectively, in *Fig.* 305; from u , through e , draw $u o$; through b , from r , and from as many other points in the line, $t a$, as is thought necessary, as f, h and j draw the ordinates, $r c, f g, h i, j k$ and $a o$; from u, c, g, i, k, e and o , draw the ordinates, $u 1, c 2, g 3, i 4, k 5, e 6$ and $o 7$, at right angles to $u o$; make $u 1$ equal to $t s$, $c 2$ equal to $r 2$, $g 3$ equal to $f 3$, &c., and trace the curve, $1 7$, through the points thus found; find the curve, $c e$, in the same manner, by transferring the distances between the line, $t a$, and the arc, $r d$; join 1 and c , also e and 7 ; then, $1 c e 7$ will be the face-mould required for that part of the rail which is denoted by the letters, $s r d^2 b^2$, on the plan at *Fig.* 305.

To ascertain the mould for the next quarter, make $a c j e$, (*Fig.*




Fig. 309.

in that figure, and complete the falling-mould, $k j$, every way equal to $u m$ in *Fig. 305*; from the points of division in the arc, $s b$, draw lines radiating towards the centre of the circle, dividing the arc, $r d$, in the same proportion as $s b$ is divided; from d and b , draw $d t$ and $b u$, at right angles to $a d$, and from j and v , draw $j u$ and $v w$, at right angles to $j c$; then $x t u w$ will be a vertical projection of the joint, $d b$. Supposing every radiating line across $s r d b$ —corresponding to the vertical lines across $k j$ —to represent a joint, find their vertical projection, as at 1, 2, 3, 4, 5 and 6; through the corners of those parallelograms, trace the curve lines shown in the figure; then $6 u$ will be a *helinet*, or vertical projection, of $s r d b$. To find the thickness of plank necessary to get out this part of the rail, draw the line, $z t$, touching the upper side of the helinet in two places: through the corner farthest projecting from that line, as w , draw $y w$, parallel to $z t$; then the distance between those lines will be the proper thickness of stuff for this part of the rail. The same process is necessary to find the thickness of stuff in all cases in which the falling-mould is in any way curved.

476.—*To apply the face-mould to the plank.* In *Fig. 310*, A represents the plank with its best side and edge in view, and B the same plank turned up so as to bring in view the other side




Fig. 310.


and the same edge, this being square from the face. Apply the tips of the mould at the edge of the plank, as at *a* and *o*, (*A*), and mark out the shape of the twist; from *a* and *o*, draw the lines, *a b* and *o c*, across the edge of the plank, the angles, *e a b* and *e o c*, corresponding with *k f d* at *Fig. 308*; turning the plank up as at *B*, apply the tips of the mould at *b* and *c*, and mark it out as shown in the figure. In sawing out the twist, the saw must be moved in the direction, *a b*; which direction will be perpendicular when the twist is held up in its proper position.

In sawing by the face-mould, the *sides* of the rail are obtained; the top and bottom, or the upper and the lower surfaces, are obtained by squaring from the sides, after having bent the falling-mould around the outer, or convex side, and marked by its edges. Marking across by the ends of the falling-mould will give the position of the butt-joint.

477.—*Elucidation of the process by which the direction of the butt-joint is obtained in Art. 473.* Mr. Nicholson, in his *Carpenter's Guide*, has given the joint a different direction to that here shown; he radiates it towards the centre of the cylinder. This is erroneous—as can be shown by the following operation:

In *Fig. 311*, *a r j i* is the plan of a part of the rail about the joint, *s u* is the stretch-out of *a i*, and *g p* is the helinet, or vertical projection of the plan, *a r j i*, obtained according to *Art*

rail in the helinet, is a true representation of the radiating line, $j i$, on the plan. The line, $b h$, therefore, on the top of the rail in the helinet, is a true representation of $e m$ on the plan, and $k c$ on the bottom of the rail truly represents $d o$. From k , draw $k l$, parallel to $c b$, and from h , draw $h f$, parallel to $b c$; join l and b , also c and f ; then $c k l b$ will be a true representation of the end of the lower piece, B , and $c f h b$ of the end of the upper piece, A ; and $f k$ or $h l$ will show how much the joint is open on the inner, or concave side of the rail.



To show that the process followed in *Art.* 473 is correct, let do and em , (*Fig.* 312,) be the direction of the butt-joint found as at *Fig.* 306. Now, to project, on the top of the rail in the helinet, a line that does not radiate towards the centre of the cylinder, as jk , draw vertical lines from j and k to w and h , and join w and h ; then it will be evident that wh is a true representation in the helinet of jk on the plan, it being in the same plane as jk , and also in the same winding surface as wv . The line, ln , also, is a true representation on the bottom of the helinet of the line, jk , in the plan. The line of the joint, em , therefore, is projected in the same way and truly by ib on the top of the helinet; and the line, do , by ca on the bottom. Join a and i , and then it will be seen that the lines, ca , ai and ib , exactly coincide with cb , the line of the joint on the convex side of the rail; thus proving the lower end of the upper piece, A , and the upper end of the lower piece, B , to be in one and the same plane, and that the direction of the joint on the plan is the true one. By reference to *Fig.* 306 it will be seen that the line, li , corresponds to xi in *Fig.* 312; and that ek in that figure is a representation of fb , and ik of db .




Fig. 318.

In getting out the twists, the joints, before the falling-mould is

applied, are cut perpendicularly, the face mould being long enough to include the overplus necessary for a butt-joint. The face-mould for *A*, therefore, would have to extend to the line, *i b*; and that for *B*, to the line, *y z*. Being sawed vertically at first, a section of the joint at the end of the face-mould for *A*, would be represented in the helinet by *b i f g*. To obtain the position of the line, *b i*, on the end of the twist, draw *i s*, (*Fig.* 313,) at right angles to *i f*, and make *i s* equal to *m e* at *Fig.* 312; through *s*, draw *s g*, parallel to *i f*, and make *s b* equal to *s b* at *Fig.* 312; join *b* and *i*; make *i f* equal to *i f* at *Fig.* 312, and from *f*, draw *f g*, parallel to *i b*; then *i b g f* will be a perpendicular section of the rail over the line, *e m*, on the plan at *Fig.* 312, corresponding to *i b g f* in the helinet at that figure; and when the rail is squared, the top, or back, must be trimmed off to the line, *i b*, and the bottom to the line, *f g*.

478.—*To grade the front string of a stairs, having winders in a quarter-circle at the top of the flight connected with flyers at the bottom.* In *Fig.* 314, *a b* represents the line of the fascia along the floor of the upper story, *b e c* the face of the cylinder, and *c d* the face of the front string. Make *g b* equal to $\frac{1}{3}$ of the diameter of the baluster, and draw the centre-line of the rail, *f g*, *g h i* and *i j*, parallel to *a b*, *b e c* and *c d*; make *g k* and *g l* each equal to half the width of the rail, and through *k* and *l*, draw lines for the convex and the concave sides of the rail, parallel to the centre-line; tangential to the convex side of the rail, and parallel to *k m*, draw *n o*; obtain the stretch-out, *q r*, of the semi-circle, *k p m*, according to *Art.* 92; extend *a b* to *t*, and *k m* to *s*; make *c s* equal to the length of the steps, and *i u* equal to 18 inches, and describe the arcs, *s t* and *u 6*, parallel to *m p*; from *t*, draw *t w*, tending to the centre of the cylinder; from *6*, and on the line, *6 u x*, run off the regular tread, as at 5, 4, 3, 2, 1 and *v*; make *u x* equal to half the arc, *u 6*, and make the point of division nearest to *x*, as *r*, the limit of the parallel steps, or flyers; make *r o* equal to *m z*; from *o*, draw *o a'*, at right angles to *n o*, and equal to one rise;




Fig. 814.

from a^3 , draw $a^2 s$, parallel to $n o$, and equal to one tread; from s through o , draw $s b^2$.

Then from w , draw $w c^2$, at right angles to $n o$, and set up, on the line, $w c^2$, the same number of risers that the floor, A , is above the first winder, B , as at 1, 2, 3, 4, 5 and 6; through 5, (on the arc, 6 u) draw $d^2 e^2$, tending to the centre of the cylinder; from e^2 , draw $e^2 f^2$, at right angles to $n o$, and through 5, (on the line,

$w c^2$), draw $g^2 f^2$, parallel to $n o$; through 6, (on the line, $w c^2$), and f^2 , draw the line, $h^2 b^2$; make 6 c^2 equal to half a rise, and from c^2 and 6, draw $c^2 i^2$ and 6 j^2 , parallel to $n o$; make $h^2 i^2$ equal to $h^2 f^2$; from i^2 , draw $i^2 k^2$, at right angles to $i^2 h^2$, and from f^2 , draw $f^2 k^2$, at right angles to $f^2 h^2$; upon k^2 , with $k^2 f^2$ for radius, describe the arc, $f^2 i^2$; make $b^2 l^2$ equal to $b^2 f^2$, and ease off the angle at b^2 by the curve, $f^2 l^2$. In the figure, the curve is described from a centre, but in a full-size plan, this would be impracticable; the best way to ease the angle, therefore, would be with a tanged curve, according to *Art.* 89. Then from 1, 2, 3 and 4, (on the line, $w c^2$), draw lines parallel to $n o$, meeting the curve in m^2 , n^2 , o^2 and p^2 ; from these points, draw lines at right angles to $n o$, and meeting it in x^2 , r^2 , s^2 and t^2 ; from x^2 and r^2 , draw lines tending to u^2 , and meeting the convex side of the rail in y^2 and z^2 ; make $m v^2$ equal to $r s^2$, and $m w^2$ equal to $r t^2$; from y^2 , z^2 , v^2 , and w^2 , through 4, 3, 2 and 1, draw lines meeting the line of the wall-string in a^3 , b^3 , c^3 and d^3 ; from e^3 , where the centre-line of the rail crosses the line of the floor, draw $e^3 f^3$, at right angles to $n o$, and from f^3 , through 6, draw $f^3 g^3$; then the heavy lines, $f^3 g^3$, $e^3 d^3$, $y^2 a^3$, $z^2 b^3$, $v^2 c^3$, $w^2 d^3$, and $z y$, will be the lines for the risers, which, being extended to the line of the front string, $b e c d$, will give the dimensions of the winders, and the grading of the front string, as was required.

479.—*To obtain the falling-mould for the twists of the last-mentioned stairs.* Make $i^2 g^3$ and $i^2 h^3$, (*Fig.* 314,) each equal to half the thickness of the rail; through h^3 and g^3 , draw $h^3 i^2$ and $g^3 j^3$, parallel to $i^2 s$; assuming $k k^3$ and $m m^3$ on the plan as the amount of straight to be got out with the twists, make $n q$ equal to $k k^3$, and $r l^3$ equal to $m m^3$; from n and l^3 , draw lines at right angles to $n o$, meeting the top of the falling-mould in n^3 and o^3 ; from o^3 , draw a line crossing the falling-mould at right angles to a chord of the curve, $f^2 l^2$; through the centre of the cylinder, draw $u^2 8$, at right angles to $n o$; through 8, draw 7 9, tending to k^2 ; then $n^3 7$ will be the falling-mould for the upper twist, and 7 o^3 the falling-mould for the lower twist.

480.—*To obtain the face-moulds.* The moulds for the twists of this stairs may be obtained as at *Art. 473*; but, as the falling-mould in its course departs considerably from a straight line, it would, according to that method, require a very thick plank for the rail, and consequently cause a great waste of stuff. In order, therefore, to economize the material, the following method is to be preferred—in which it will be seen that the heights are taken in three places instead of two only, as is done in the previous method.




Fig. 315. o

CASE 1.—*When the middle height is above a line joining the other two.* Having found at *Fig. 314* the direction of the joint, $w s^3$ and $p e$, according to *Art. 473*, make $k p e a$, (*Fig. 315*), equal to $k^3 p^3 e p$ in *Fig. 314*; join b and c , and from o , draw $o h$, at right angles to $b c$; obtain the stretch-out of $d g$, as $d f$, and at *Fig. 314*, place it from the axis of the cylinder, p , to q^3 ; from q^3 in that figure, draw $q^3 r^3$, at right angles to $n o$; also, at a convenient height on the line, $n n^3$, in that figure, and at right angles to that line, draw $w^3 v^3$; from b and c , in *Fig. 315*,

draw $b j$ and $c l$, at right angles to $b c$; make $b j$ equal to $u^3 n^3$ in *Fig.* 314, $i h$ equal to $w^3 r^3$ in that figure, and $c l$ equal to $v^3 9$; from l , through j , draw $l m$; from h , draw $h n$, parallel to $c b$; from n , draw $n r$, at right angles to $b c$, and join r and s ; through the lowest corner of the plan, as p , draw $v e$, parallel to $b c$; from a , e , u , p , k , t , and from as many other points as is thought necessary, draw ordinates to the base-line, $v e$, parallel to $r s$; through h , draw $w x$, at right angles to $m l$; upon n , with $r s$ for radius, describe an intersecting arc at x , and join n and x ; from the points at which the ordinates from the plan meet the base-line, $v e$, draw ordinates to meet the line, $m l$, at right angles to $v e$; and from the points of intersection on $m l$, draw corresponding ordinates, parallel to $n x$; make the ordinates which are parallel to $n x$ of a length corresponding to those which are parallel to $r s$, and through the points thus found, trace the face-mould as required.

CASE 2.—*When the middle height is below a line joining the other two.* The lower twist in *Fig.* 314 is of this nature. The face-mould for this is found at *Fig.* 316 in a manner similar to that at *Fig.* 315. The heights are all taken from the top of the falling-mould at *Fig.* 314; $b j$ being equal to $w 6$ in *Fig.* 314, $i h$ equal to $x^3 y^3$ in that figure, and $c l$ to $l^3 o^3$. Draw a line through j and l , and from h , draw $h n$, parallel to $b c$; from n , draw $n r$, at right angles to $b c$, and join r and s ; then $r s$ will be the bevil for the lower ordinates. From h , draw $h x$, at right angles to $j l$; upon n , with $r s$ for radius, describe an intersecting arc at x , and join n and x ; then $n x$ will be the bevil for the upper ordinates, upon which the face-mould is found as in Case 1.

481.—*Elucidation of the foregoing method.*—This method of finding the face-moulds for the handrailing of winding stairs, being founded on principles which govern cylindric sections, may be illustrated by the following figures. *Fig.* 317 and 318 represent solid blocks, or prisms, standing upright on a level base, $b d$; the upper surface, $j a$ forming oblique angles with the face, $b l$ —




Fig. 316.

in *Fig. 317* obtuse, and in *Fig. 318* acute. Upon the base, describe the semi-circle, $b s c$; from the centre, i , draw $i s$, at right angles to $b c$; from s , draw $s x$, at right angles to $e d$, and from i draw $i h$, at right angles to $b c$; make $i h$ equal to $s x$, and join h and x ; then, h and x being of the same height, the line, $h x$, joining them, is a level line. From h , draw $h n$, parallel to $b c$, and from n , draw $n r$, at right angles to $b c$; join r and s , also n




Fig. 317.




Fig. 318.

and x ; then, n and x being of the same height, nx is a level line; and this line lying perpendicularly over rs , nx and rs must be of the same length. So, all lines on the top, drawn parallel to nx , and perpendicularly over corresponding lines drawn parallel to rs on the base, must be equal to those lines on the base; and by drawing a number of these on the semi-circle at the base and others of the same length at the top, it is evident that a curve, jxl , may be traced through the ends of those on the top, which shall lie perpendicularly over the semi-circle at the base.

It is upon this principle that the process at *Fig.* 315 and 316 is founded. The plan of the rail at the bottom of those figures is supposed to lie perpendicularly under the face-mould at the top; and each ordinate at the top over a corresponding one at the base. The ordinates, nx and rs , in those figures, correspond to nx and rs in *Fig.* 317 and 318.

In *Fig.* 319, the top, ea , forms a right angle with the face, dc ; all that is necessary, therefore, in this figure, is to find a line corresponding to hx in the last two figures, and that will lie level and in the upper surface; so that all ordinates at right angles to dr on the base, will correspond to those that are at right angles




Fig. 319 r

to *ec* on the top. This elucidates *Fig. 307*; at which the lines, *a 9* and *i 8*, correspond to *h 9* and *i 8* in this figure.




Fig. 320.

482.—*To find the bevil for the edge of the plank.* The plank, before the face-mould is applied, must be bevilled according to the angle which the top of the imaginary block, or prism, in the previous figures, makes with the face. This angle is determined in the following manner: draw *w i*, (*Fig. 320*), at right angles to *i s*, and equal to *wh* at *Fig. 315*; make *i s* equal to *i s* in that figure, and join *w* and *s*; then *sw p* will be the bevil required in order to apply the face-mould at *Fig. 315*. In *Fig. 316*, the middle height being below the line joining the other two, the bevil is therefore acute. To determine this, draw *i s*, (*Fig. 321*), at




Fig. 321.

right angles to $i p$, at d equal to $i s$ in *Fig. 316*; make $s w$ equal to $h w$ in *Fig. 316*, and join w and i ; then $w i p$ will be the bevil required in order to apply the face-mould at *Fig. 316*. Although the falling-mould in these cases is curved, yet, as the plank is *sprung*, or bevilled on its edge, the thickness necessary to get out the twist may be ascertained according to *Art. 474*—taking the vertical distance across the falling-mould at the joints, and placing it down from the two outside heights in *Fig. 315* or *316*. After bevilling the plank, the moulds are applied as at *Art. 476*—applying the pitch-board on the bevilled instead of a square edge, and placing the tips of the mould so that they will bear the same relation to the edge of the plank, as they do to the line, $j l$, in *Fig. 315* or *316*.




Fig. 322.

483.—*To apply the moulds without bevilling the plank.* Make $w p$, (*Fig. 322*), equal to $w p$ at *Fig. 320*, and the angle, $b c d$, equal to $b j l$ in *Fig. 315*; make $p a$ equal to the thickness of the plank, as $w a$ in *Fig. 320*, and from a draw $a o$, parallel to $w d$; from c , draw $c e$, at right angles to $w d$, and join e

and b ; then the angle, $b e o$, on a square edge of the plank, having a line on the upper face at the distance, $p a$, in *Fig. 320*, at which to apply the tips of the mould—will answer the same purpose as bevilling the edge.

If the bevilled edge of the plank, which reaches from p to w , is supposed to be in the plane of the paper, and the point, a , to be above the plane of the paper as much as a , in *Fig. 320*, is distant from the line, $w p$; and the plank to be revolved on $p b$ as an axis until the line, $p w$, falls below the plane of the paper, and the line, $p a$, arrives in it; then, it is evident that the point, c , will fall, in the line, $c e$, until it lies directly behind the point, e , and the line, $b c$, will lie directly behind $b e$.




Fig. 323.

484.—*To find the bevils for splayed work.* The principle employed in the last figure is one that will serve to find the bevils for *splayed* work—such as hoppers, bread-trays, &c.—and a way of applying it to that purpose had better, perhaps, be introduced in this connection. In *Fig. 323*, $a b c$ is the angle at which the work is splayed, and $b d$, on the upper edge of the board, is at right angles to $a b$; make the angle, $f g j$, equal to $a b c$, and from f , draw $f h$, parallel to $e a$; from b , draw $b o$, at right angles to $a b$; through o , draw $i e$, parallel to $c b$, and join e and d ; then the angle, $a e d$, will be the proper bevil for the ends from the inside, or $k d e$ from the outside. If a mitre-joint is re-

quired, set $f g$, the thickness of the stuff on the level, from e to m , and join m and d ; then $k d m$ will be the proper bevil for a mitre-joint.

If the upper edges of the splayed work is to be bevilled, so as to be horizontal when the work is placed in its proper position, $f g j$, being the same as $a b c$, will be the proper bevil for that purpose. Suppose, therefore, that a piece indicated by the lines, $k g$, $g f$ and $f h$, were taken off; then a line drawn upon the bevilled surface from d , at right angles to $k d$, would show the true position of the joint, because it would be in the direction of the board for the other side; but a line so drawn would pass through the point, o ,—thus proving the principle correct. So, if a line were drawn upon the bevilled surface from d , at an angle of 45 degrees to $k d$, it would pass through the point, n .

485.—*Another method for face-moulds.* It will be seen by reference to *Art.* 481, that the principal object had in view in the preparatory process of finding a face-mould, is to ascertain upon it the direction of a horizontal line. This can be found by a method different from any previously proposed; and as it requires fewer lines, and admits of less complication, it is probably to be preferred. It can be best introduced, perhaps, by the following explanation.

In *Fig.* 324, $j d$ represents a prism standing upon a level base, $b d$; its upper surface forming an acute angle with the face, $b l$, as at *Fig.* 318. Extend the base line, $b c$, and the raking line, $j l$, to meet at f ; also, extend $e d$ and $g a$, to meet at k ; from f , through k , draw $f m$. If we suppose the prism to stand upon a level floor, $o f m$, and the plane, $j g a l$, to be extended to meet that floor, then it will be obvious that the intersection between that plane and the plane of the floor would be in the line, $f k$; and the line, $f k$, being in the plane of the floor, and also in the inclined plane, $j g k f$, any line made in the plane, $j g k f$, parallel to $f k$, must be a level line. By finding the position of a perpendicular plane, at right angles to the raking plane, $j f k g$, we shall greatly shorten the process for obtaining ordinates.

stands perpendicularly over the line, qf , and at right angles to the plane, B ; then, while A and B are fixed at right angles, let B be turned on the line, pf , as an axis until it stands perpendicularly over pf , and at right angles to the plane, C ; then the plane, A , will lie over the plane, C , with the several lines on one corresponding to those on the other; the point, i , resting at l , the point, n , at x , and g at j ; and the curve, $gn i$, lying perpendicularly over $b s c$ —as was required. If we suppose the cylinder to be cut by a level plane passing through the point, l , (as is done in finding a face-mould,) it will be obvious that lines corresponding to qf and pf would meet in l ; and the plane of the section, A , the plane of the segment, B , and the plane of the base, C , would all meet in that point.

486.—*To find the face-mould for a hand-rail according to the principles explained in the previous article.* In *Fig. 326*, $a e c f$ is the plan of a hand-rail over a quarter of a cylinder; and in *Fig. 327*, $a b c d$ is the falling-mould; $f e$ being equal to the stretch-out of $a d f$ in *Fig. 326*. From c , draw $c h$, parallel to $e f$; bisect $h c$ in i , and find a point, as b , in the arc, $d f$, (*Fig. 326*,) corresponding to i in the line, $h c$; from i , (*Fig. 327*,) to the top of the falling-mould, draw $i j$, at right angles to $h c$; at *Fig. 326*, from c , through b , draw $c g$, and from b and c , draw $b j$ and $c k$, at right angles to $g c$; make $c k$ equal to $h g$ at *Fig. 327*, and $b j$ equal to $i j$ at that figure; from k , through j , draw $k g$, and from g , through a , draw $g p$; then $g p$ will be the intersecting line, corresponding to $f m$ in *Fig. 324* and *325*; through e , draw $p 6$, at right angles to $g p$, and from c , draw $c q$, parallel to $g p$; make $r q$ equal to $h g$ at *Fig. 327*; join p and q , and proceed as in the previous examples to find the face-mould, A . The joint of the face-mould, $u v$, will be more accurately determined by finding the projection of the centre of the plan, o , as at w ; joining s and w , and drawing $u v$, parallel to $s w$.

It may be noticed that $c k$ and $b j$ are not of a length corresponding to the above directions: they are but $\frac{1}{2}$ the length given.




Fig. 826.

obtained thus : at *Fig. 327*, make $h l$ equal to $c b$ in *Fig. 326* from l , draw $l k$, at right angles to $h c$; from j , draw $j k$, parallel to $h c$; from g , through k , draw $g n$; at *Fig. 326*, make $b g$ equal to $l n$ in *Fig. 327* ; then g will be the point required.

The reason why the points, a, b and c , in the plan of the rail at *Fig. 326*, are taken for resting points instead of e, i and f , is this : the top of the rail being level, it is evident that the points, a and e , in the section $a e$, are of the same height ; also that the point, i , is of the same height as b , and c as f . Now, if a is taken for a point in the inclined plane rising from the line $g p$, e must be below that plane ; if b is taken for a point in that plane, i must be below it ; and if c is in the plane, f must be below it. The rule, then, for taking these points, is to take in each section the one that is nearest to the line, $g p$. Sometimes the line of intersection, $g p$, happens to come almost in the direction of the line, $e r$: in such case, after finding the line, see if the points from which the heights were taken agree with the above rule ; if the heights were taken at the wrong points, take them according to the rule above, and then find the true line of intersection, which will not vary much from the one already found.




Fig. 328.

487.—*To apply the face-mould thus found to the plank.* The face-mould, when obtained by this method, is to be applied to a square-edged plank, as directed at *Art. 476*, with this difference : instead of applying both tips of the mould to the edge of

the plank, one of them is to be set as far from the edge of the plank, as x , in *Fig. 326*, is from the chord of the section $p q$ —as is shown at *Fig. 328*. A , in this figure, is the mould applied on the upper side of the plank, B , the edge of the plank, and C , the mould applied on the under side; $a b$ and $c d$ being made equal to $q x$ in *Fig. 326*, and the angle, $e a c$, on the edge, equal to the angle, $p q r$, at *Fig. 326*. In order to avoid a waste of stuff, it would be advisable to apply the tips of the mould, e and b , immediately at the edge of the plank. To do this, suppose the moulds to be applied as shown in the figure; then let A be revolved upon e until the point, b , arrives at g , causing the line, $e b$, to coincide with $e g$: the mould upon the under side of the plank must now be revolved upon a point that is perpendicularly beneath e , as f ; from f , draw $f h$, parallel to $i d$, and from d , draw $d h$, at right angles to $i d$; then revolve the mould, C , upon f , until the point, h , arrives at j , causing the line, $f h$, to coincide with $f j$, and the line, $i d$, to coincide with $k l$; then the tips of the mould will be at k and l .

The rule for doing this, then, will be as follows: make the angle, $i f k$, equal to the angle $q v x$, at *Fig. 326*; make $f k$ equal to $f i$, and through k , draw $k l$, parallel to $i j$; then apply the corner of the mould, i , at k , and the other corner d , at the line, $k l$.

The thickness of stuff is found as at *Art. 474*.

488.—*To regulate the application of the falling-mould.* Obtain, on the line, $h c$, (*Fig. 327*), the several points, r, q, p, l and m , corresponding to the points, b^2, a^2, z, y , &c., at *Fig. 326*; from $r q p$, &c., draw the lines, $r t, q u, p v$, &c., at right angles to $h c$; make $h s, r t, q u$, &c., respectively equal to $6 c^2, r q, 5 d^2$, &c., at *Fig. 326*; through the points thus found, trace the curve, $s w c$. Then get out the piece, $g s c$, attached to the falling-mould at several places along its length, as at z, z, z , &c. In applying the falling-mould with this strip thus attached, the edge, $s w c$, will coincide with the upper surface of the rail piece

before it is squared ; and thus show the proper position of the falling-mould along its whole length. (See *Art.* 496.)

SCROLLS FOR HAND-RAILS.

489.—*General rule for finding the size and position of the regulating square.* The breadth which the scroll is to occupy, the number of its revolutions, and the relative size of the regulating square to the eye of the scroll, being given, multiply the number of revolutions by 4, and to the product add the number of times a side of the square is contained in the diameter of the eye, and the sum will be the number of equal parts into which the breadth is to be divided. Make a side of the regulating square equal to one of these parts. To the breadth of the scroll add one of the parts thus found, and half the sum will be the length of the longest ordinate.




Fig. 329

490.—*To find the proper centres in the regulating square.* Let $a\ 2\ 1\ b$, (*Fig.* 329,) be the size of a regulating square, found according to the previous rule, the required number of revolutions being $1\frac{3}{4}$. Divide two adjacent sides, as $a\ 2$ and $2\ 1$, into as many equal parts as there are quarters in the number of revolutions, as seven ; from those points of division, draw lines across the square, at right angles to the lines divided ; then, 1 being the first centre, $2, 3, 4, 5, 6$ and 7 , are the centres for the other quarters, and 8 is the centre for the eye ; the heavy lines that deter-

mine these centres being each one part less in length than its preceding line.




Fig. 330.

491.—*To describe the scroll for a hand-rail over a curtain step.* Let ab , (Fig. 330,) be the given breadth, $1\frac{3}{4}$ the given number of revolutions, and let the relative size of the regulating square to the eye be $\frac{1}{2}$ of the diameter of the eye. Then, by the rule, $1\frac{3}{4}$ multiplied by 4 gives 7, and 3, the number of times a side of the square is contained in the eye, being added, the sum is 10. Divide ab , therefore, into 10 equal parts, and set one from b to c ; bisect ac in e ; then ae will be the length of the longest ordinate, ($1d$ or $1e$.) From a , draw ad , from e , draw $e1$, and from b , draw bf , all at right angles to ab ; make $e1$ equal to e , and through 1, draw $1d$, parallel to ab ; set bc from 1 to 2, and upon 1 2, complete the regulating square; divide this square as at Fig. 329; then describe the arcs that compose the scroll, as follows: upon 1, describe de ; upon 2, describe ef ; upon 3, describe fg ; upon 4, describe gh , &c.; make dl equal to the

e^2 , find the position of the point, k , as at k^2 ; at *Fig.* 331, make $e d$ equal to $e^2 d$ in *Fig.* 330, and $d c$ equal to $d c^2$ in that figure; from c , draw $c a$, at right angles to $e c$, and equal to one rise; make $c b$ equal to one tread, and from b , through a , draw $b j$, bisect $a c$ in l , and through l , draw $m q$, parallel to $e h$; $m q$ is the height of the level part of a scroll, which should always be about $3\frac{1}{2}$ feet from the floor; ease off the angle, $m f j$, according to *Art.* 89, and draw $g w n$, parallel to $m x j$, and at a distance equal to the thickness of the rail; at a convenient place for the joint, as i , draw $i n$, at right angles to $b j$; through n , draw $j h$, at right angles to $e h$; make $d k$ equal to $d k^2$ in *Fig.* 330, and from k , draw $k o$, at right angles to $e h$; at *Fig.* 330, make $d h^2$ equal to $d h$ in *Fig.* 331, and draw $h^2 b^2$, at right angles to $d h^2$; then $k a^2$ and $h^2 i^2$ will be the position of the joints on the plan, and at *Fig.* 331, $o p$ and $i n$, their position on the falling-mould; and $p o i n$, (*Fig.* 331,) will be the falling-mould required.




Fig. 332.

495.—*To describe the face-mould.* At *Fig.* 330, from k , draw $k r^2$, at right angles to $r^2 d$; at *Fig.* 331, make $h r$ equal to $h^2 r^2$ in *Fig.* 330, and from r , draw $r s$, at right angles to $r h$; from the intersection of $r s$ with the level line, $m q$, through i , draw $s t$; at *Fig.* 330, make $h^2 b^2$ equal to $q t$ in *Fig.* 331, and join b^2 and r^2 ; from a^2 , and from as many other points in the arcs, $a^2 l$ and $k d$, as is thought necessary, draw ordinates to $r^2 d$, at right angles to the latter; make $r b$, (*Fig.* 332,) equal in its length and in its divisions to the line, $r^2 b^2$, in *Fig.* 330; from r , n , o , p , q

and l , draw the lines, $r k$, $n d$, $o a$, $p e$, $q f$ and $l c$, at right angles to $r b$, and equal to $r^2 k$, $d^2 s^2$, $f^2 a^2$, &c., in *Fig.* 330; through the points thus found, trace the curves, $k l$ and $a c$, and complete the face-mould, as shown in the figure. This mould is to be applied to a square-edged plank, with the edge, $l b$, parallel to the edge of the plank. The rake lines upon the edge of the plank are to be made to correspond to the angle, $s t h$, in *Fig.* 331. The thickness of stuff required for this mould is shown at *Fig.* 331, between the lines $s t$ and $u v$ — $u v$ being drawn parallel to $s t$.

496.—All the previous examples given for finding face-moulds over winders, are intended for *moulded* rails. For *round* rails, the same process is to be followed with this difference: instead of working from the sides of the rail, work from a centre-line. After finding the projection of that line upon the upper plane, describe circles upon it, as at *Fig.* 293, and trace the sides of the moulds by the points so found. The thickness of stuff for the twists of a round rail, is the same as for the straight; and the twists are to be sawed square through.




Fig. 330.

497.—*To ascertain the form of the newel-cap from a section of the rail.* Draw $a b$, (*Fig. 333*,) through the widest part of the given section, and parallel to $c d$; bisect $a b$ in e , and through a , e and b , draw $h i$, $f g$, and $k j$, at right angles to $a b$; at a convenient place on the line, $f g$, as o , with a radius equal to half the width of the cap, describe the circle, $i j g$; make $r l$ equal to $e b$ or $e a$; join l and j , also l and i ; from the curve, $f b$, to the line, $l j$, draw as many ordinates as is thought necessary, parallel to $f g$; from the points at which these ordinates meet the line, $l j$, and upon the centre, o , describe arcs in continuation to meet $o p$; from n , t , x , &c., draw $n s$, $t u$, &c., parallel to $f g$; make $n s$, $t u$, &c., equal to $e f$, $w v$, &c.; make $x y$, &c., equal to $z d$, &c.; make $o 2$, $o 3$, &c., equal to $o n$, $o t$, &c.; make $2 4$ equal to $n s$, and in this way find the length of the lines crossing $o m$; through the points thus found, describe the section of the newel-cap, as shown in the figure.





Fig 334.

498.—*To find the true position of a butt joint for the twists of a moulded rail over platform stairs.* Obtain the shape of the mould according to *Art. 466*, and make the line $a b$, *Fig. 334*, equal to $a c$, *Fig. 300*; from b , draw $b c$, at right angles to $a b$, and equal in length to $n m$, *Fig. 300*; join a and c , and bisect $a c$ in o ; through o draw $e f$, at right angles to $a c$, and $d k$, parallel to $c b$; make $o d$ and $o k$ each equal to half $e h$ at *Fig. 300*; through e and f , draw $h i$ and $g j$, parallel to $a c$. At *Fig. 301*, make $n a$ equal to $e d$, *Fig. 334*, and through a , draw $r p$, at right angles to $n c$; then $r p$ will be the true position on the face-mould for a butt joint, as was required. The sides must be sawn verti

cally as described at *Art.* 467, but the joint is to be sawn square through the plank. The moulds obtained for round rails, (*Art.* 464,) give the line for the joint, when applied to either side of the plank; but here, for moulded rails, the line for the joint can be obtained from only one side. When the rail is canted up, the joint is taken from the mould laid on the upper side of the lower twist, and on the under side of the upper twist; but when it is canted down, a course just the reverse of this is to be pursued. When the rail is not canted, either up or down, the vertical joint, obtained as at *Art.* 466, will be a butt joint, and therefore, in such a case, the process described in this article will be unnecessary

NOTE TO ARTICLE 462.

Platform stairs with a large cylinder. Instead of placing the platform-risers at the spring of the cylinder, a more easy and graceful appearance may be given to the rail, and the necessity of canting either of the twists entirely obviated, by fixing the place of the above risers at a certain distance within the cylinder, as shown in the annexed cut—the lines indicating the face of the risers cutting the cylinder at k and l , instead of at p and q , the spring of the cylinder. To ascertain the position of the risers, let abc be the pitch-board of the lower flight, and cde that of the upper flight, these being placed so that bc and cd shall form a right line. Extend ac to cut de in f ; draw fg parallel to db , and of indefinite length: draw go at right angles to fg , and equal in length to the radius of the circle formed by the centre of the rail in passing around the cylinder; on o as centre describe the semicircle jgi ; make oh equal to the radius of the cylinder, and describe on o the face of the cylinder phq ; then extend db across the cylinder, cutting it in l and k —giving the position of the face of the risers, as required. To find the face-mould for the twists is simple and obvious: it being merely a quarter of an ellipse, having oj for semi-minor axis, and the distance on the rake corresponding to og , on the plan, for the semi-major axis, found thus,—extend ij to meet af , then from this point of meeting to f is the semi-major axis.



SECTION VII.—SHADOWS.



499.—The art of drawing consists in representing solids upon a plane surface : so that a curious and nice adjustment of lines is made to present the same appearance to the eye, as does the human figure, a tree, or a house. It is by the effects of light, in its reflection, shade, and shadow, that the presence of an object is made known to us ; so, upon paper, it is necessary, in order that the delineation may appear real, to represent fully all the shades and shadows that would be seen upon the object itself. In this section I propose to illustrate, by a few plain examples, the simple elementary principles upon which shading, in architectural subjects, is based. The necessary knowledge of drawing, preliminary to this subject, is treated of in the Introduction, from *Art.* 1 to 14.

500.—*The inclination of the line of shadow.* This is always, in architectural drawing, 45 degrees, both on the elevation and the plan ; and the sun is supposed to be behind the spectator, and over his left shoulder. This can be illustrated by reference to *Fig.* 335, in which *A* represents a horizontal plane, and *B* and *C* two vertical planes placed at right angles to each other. *A* represents the plan, *C* the elevation, and *B* a vertical projection from the elevation. In finding the shadow of the plane, *B*, the




Fig. 385.

line, $a b$, is drawn at an angle of 45 degrees with the horizon, and the line, $c b$, at the same angle with the vertical plane, B . The plane, B , being a rectangle, this makes the true direction of the sun's rays to be in a course parallel to $d b$; which direction has been proved to be at an angle of 35 degrees and 16 minutes with the horizon. It is convenient, in shading, to have a set-square with the two sides that contain the right angle of equal length; this will make the two acute angles each 45 degrees; and will give the requisite bevil when worked upon the edge of the T-square. One reason why this angle is chosen in preference to another, is, that when shadows are properly made upon the drawing by it, the depth of every recess is more readily known, since the breadth of shadow and the depth of the recess will be equal.

To distinguish between the terms *shade* and *shadow*, it will be understood that all such parts of a body as are not exposed to the direct action of the sun's rays, are in *shade*; while those parts which are deprived of light by the interposition of other bodies, are in *shadow*.




Fig. 336.




Fig. 337.




Fig. 338.




Fig. 339.

501.—*To find the line of shadow on mouldings and other horizontally straight projections.* Fig. 336, 337, 338, and 339, represent various mouldings in elevation, returned at the left, in the usual manner of mitreing around a projection. A mere inspection of the figures is sufficient to see how the line of shadow is obtained; bearing in mind that the ray, *a b*, is drawn from the projections at an angle of 45 degrees. Where there is no return at the end, it is necessary to draw a section, at any place in the length of the mouldings, and find the line of shadow from that.

502.—*To find the line of shadow cast by a shelf.* In Fig. 340, *A* is the plan, and *B* is the elevation of a shelf attached to a wall. From *a* and *c*, draw *a b* and *c d*, according to the angle previously directed; from *b*, erect a perpendicular intersecting *c d* at *d*; from *d*, draw *d e*, parallel to the shelf; then the lines, *c d* and *d e*, will define the shadow cast by the shelf. There is another method of finding the shadow, without the plan, *A*. Extend the lower line of the shelf to *f*, and make *c f* equal to the projection of the shelf




Fig. 340.

from the wall; from f , draw $f g$, at the customary angle, and from c , drop the vertical line, $c g$, intersecting $f g$ at g ; from g , draw $g e$, parallel to the shelf, and from c , draw $c d$, at the usual angle; then the lines, $c d$ and $d e$, will determine the extent of the shadow as before.




Fig. 341.

503.—*To find the shadow cast by a shelf, which is wider at one end than at the other.* In Fig. 341, A is the plan, and B the elevation. Find the point, d , as in the previous example, and from any other point in the front of the shelf, as a , erect the perpendicular, $a e$; from a and e , draw $a b$ and $e c$, at the proper angle, and from b , erect the perpendicular, $b c$, intersecting $e c$ in c ;

from d , through c , draw $d o$; then the lines, $i d$ and $d o$, will give the limit of the shadow cast by the shelf.




Fig. 342.

504.—To find the shadow of a shelf having one end acute or obtuse angled. Fig. 342 shows the plan and elevation of an acute-angled shelf. Find the line, $e g$, as before; from a , erect the perpendicular, $a b$; join b and e ; then $b e$ and $e g$ will define the boundary of shadow.




Fig. 343.

505.—To find the shadow cast by an inclined shelf. In Fig. 343, the plan and elevation of such a shelf is shown, having also one end wider than the other. Proceed as directed for finding the shadows of Fig. 341, and find the points, d and c ; then $a d$ and $d c$ will be the shadow required. If the shelf had been

parallel in width on the plan, then the line, $d c$, would have been parallel with the shelf, $a b$.




Fig. 344




Fig. 345.

506.—To find the shadow cast by a shelf inclined in its vertical section either upward or downward. From a , (Fig. 344 and 345,) draw $a b$, at the usual angle, and from b , draw $b c$, parallel with the shelf; obtain the point, e , by drawing a line from d , at the usual angle. In Fig. 344, join e and i ; then $i e$ and $e c$ will define the shadow. In Fig. 345, from o , draw $o i$, parallel with the shelf; join i and e ; then $i e$ and $e c$ will be the shadow required.

The projections in these several examples are bounded by straight lines; but the shadows of curved lines may be found in the same manner, by projecting shadows from several points in the curved line, and tracing the curve of shadow through these points. Thus—




Fig. 346.




Fig. 347.

507.—*To find the shadow of a shelf having its front edge, or end, curved on the plan.* In Fig. 346 and 347, *A* and *A* show an example of each kind. From several points, as *a, a*, in the plan, and from the corresponding points, *o, o*, in the elevation, draw rays and perpendiculars intersecting at *e, e*, &c.; through these points of intersection trace the curve, and it will define the shadow.




Fig. 348.

508.—*To find the shadow of a shelf curved in the elevation.* In Fig. 348, find the points of intersection, *e, e* and *e*, as in the last examples, and a curve traced through them will define the shadow.

The preceding examples show how to find shadows when cast upon a *vertical plane*; shadows thrown upon *curved surfaces* are ascertained in a similar manner. Thus—




Fig. 349.

509.—*To find the shadow cast upon a cylindrical wall by a projection of any kind.* By an inspection of Fig. 349, it will be seen that the only difference between this and the last examples, is, that the rays in the plan die against the circle, $a b$, instead of a straight line.




Fig. 350.

510.—*To find the shadow cast by a shelf upon an inclined wall.* Cast the ray, $a b$, (Fig. 350,) from the end of the shelf to the face of the wall, and from b , draw $b c$, parallel to the shelf; cast the ray, $d e$, from the end of the shelf; then the lines, $d e$ and $e c$, will define the shadow.

These examples might be multiplied, but enough has been given to illustrate the general principle, by which shadows in all instances are found. Let us attend now to the application of this principle to such familiar objects as are likely to occur in practice.




Fig. 351.

511.—*To find the shadow of a projecting horizontal beam.* From the points, *a, a, &c.*, (*Fig. 351,*) cast rays upon the wall, the intersections, *e, e, e,* of those rays with the perpendiculars drawn from the plan, will define the shadow. If the beam be inclined, either on the plan or elevation, at any angle other than a right angle, the difference in the manner of proceeding can be seen by reference to the preceding examples of inclined shelves &c.




Fig. 352.

512.—*To find the shadow in a recess.* From the point, *a,* (*Fig. 352,*) in the plan, and *b* in the elevation, draw the rays, *a c* and *b e*; from *c*, erect the perpendicular, *c e*, and from *e*, draw the horizontal line, *e d*; then the lines, *c e* and *e d*, will show the extent of the shadow. This applies only where the back of the recess is parallel with the face of the wall.




Fig. 353.

513.—*To find the shadow in a recess, when the face of the wall is inclined, and the back of the recess is vertical.* In *Fig. 353,* *A* shows the section and *B* the elevation of a recess of this

kind. From b , and from any other point in the line, ba as a draw the rays, bc and ae ; from c , a , and e , draw the horizontal lines, cg , af , and eh ; from d and f , cast the rays, di and fh ; from i , through h , draw is ; then si and ig will define the shadow.




Fig. 354.

514.—*To find the shadow in a fireplace.* From a and b , (Fig. 354,) cast the rays, ac and be , and from c , erect the perpendicular, ce ; from e , draw the horizontal line, eo , and join c and d ; then ce , eo , and od , will give the extent of the shadow.




Fig. 355.

515.—*To find the shadow of a moulded window-lintel.* Cast rays from the projections, a , o , &c., in the plan, (Fig. 355,) and d , e , &c., in the elevation, and draw the usual perpendiculars intersecting the rays at i , i , and i ; these intersections connected

and horizontal lines drawn from them, will define the shadow. The shadow on the face of the lintel is found by casting a ray back from *i* to *s*, and drawing the horizontal line, *s n*.




Fig. 356.

516.—*To find the shadow cast by the nosing of a step.* From *a*, (Fig. 356,) and its corresponding point, *c*, cast the rays, *a b* and *c d*, and from *b*, erect the perpendicular, *b d*; tangential to the curve at *e*, cast the ray, *e f*, and from *e*, drop the perpendicular, *e o*, meeting the mitre-line, *a g*, in *o*; cast a ray from *o* to *i*, and from *i*, erect the perpendicular, *i f*; from *h*, draw the ray, *h k*; from *f* to *d* and from *d* to *k*, trace the curve as shown in the figure; from *k* and *h*, draw the horizontal lines, *k n* and *h s*; then the limit of the shadow will be completed.

517.—*To find the shadow thrown by a pedestal upon steps.* From *a*, (Fig. 357,) in the plan, and from *c* in the elevation, draw the rays, *a b* and *c e*; then *a o* will show the extent of the shadow on the first riser, as at *A*; *f g* will determine the shadow on the second riser, as at *B*; *c d* gives the amount of shadow on the first tread, as at *C*, and *h i* that on the second tread, as at *D*; which completes the shadow of the left-hand pedestal, both on the plan and elevation. A mere inspection of the figure will be suf-




Fig. 857.

ficient to show how the shadow of the right-hand pedestal is obtained.




Fig. 858.




Fig. 859.

518.—*To find the shadow thrown on a column by a square abacus.* From *a* and *b*, (Fig. 358,) draw the rays, *a c* and *b e*, and from *c*, erect the perpendicular, *c e*; tangential to the curve at *d*, draw the ray, *d f*, and from *h*, corresponding to *f* in the plan, draw the ray, *h o*; take any point between *a* and *f*, as *i*, and from this, as also from a corresponding point, *n*, draw the rays, *i r* and *n s*; from *r*, and from *d*, erect the perpendiculars, *r s* and *d o*; through the points, *e*, *s*, and *o*, trace the curve as shown in the figure; then the extent of the shadow will be defined.

519.—*To find the shadow thrown on a column by a circular abacus.* This is so near like the last example, that no explanation will be necessary farther than a reference to the preceding article




Fig. 360.

520.—*To find the shadows on the capital of a column.* This may be done according to the principles explained in the examples already given; a quicker way of doing it, however, is as follows. If we take into consideration one ray of light in connection with all those perpendicularly under and over it, it is evident that these several rays would form a vertical plane, standing at an angle of 45 degrees with the face of the elevation. Now, we may suppose the column to be *sliced*, so to speak, with planes of this




Fig. 361.

nature—cutting it in the lines, *a b, c d, &c.*, (Fig. 360,) and, in the elevation, find, by squaring up from the plan, the *lines of section* which these planes would make thereupon. For instance: in finding upon the elevation the line of section, *a b*, the plane cuts the ovolo at *e*, and therefore *f* will be the corresponding point upon the elevation; *h* corresponds with *g*, *i* with *j*, *o* with *s*, and *l* with *b*. Now, to find the shadows upon this line of section, cast from *m*, the ray, *m n*, from *h*, the ray, *h o*, &c.; then that part of the section indicated by the letters, *m f i n*, and that part also between *h* and *o*, will be under shadow. By an inspection of the figure, it will be seen that the same process is applied to each line of section, and in that way the points, *p, r, t, u, v, w, x*, as also 1, 2, 3, &c., are successively found, and the lines of shadow traced through them.

Fig. 361 is an example of the same capital with all the shadows finished in accordance with the lines obtained on Fig. 360.

521.—To find the shadow thrown on a vertical wall by a column and entablature standing 'n advance of said wall. Cast




Fig. 362.

rays from *a* and *b*, (*Fig. 362*), and find the point, *c*, as in the previous examples; from *d*, draw the ray, *d e*, and from *e*, the horizontal line, *e f*; tangential to the curve at *g* and *h*, draw the rays, *g j* and *h i*, and from *i* and *j*, erect the perpendiculars, *i l* and *j k*; from *m* and *n*, draw the rays, *m f* and *n k*, and trace the curve between *k* and *f*; cast a ray from *o* to *p*, a vertical line from *p* to *s*, and through *s*, draw the horizontal line, *s t*; the shadow as required will then be completed.




Fig. 363.

Fig. 363 is an example of the same kind as the last, with all the shadows filled in, according to the lines obtained in the preceding figure.




Fig. 364.

522 — *Fig. 364* and *365* are examples of the Tuscan cornice. The manner of obtaining the shadows is evident.




Fig. 865.

523.—*Reflected light.* In shading, the finish and life of an object depend much on reflected light. This is seen to advantage in *Fig. 361* and on the column in *Fig. 363*. Reflected rays are thrown in a direction exactly the reverse of direct rays; therefore, on that part of an object which is subject to reflected light, the shadows are reversed. The fillet of the ovolo in *Fig. 361* is an example of this. On the right-hand side of the column, the face of the fillet is much darker than the cove directly under it. The reason of this is, the face of the fillet is deprived both of direct and reflected light, whereas the cove is subject to the latter. Other instances of the effect of reflected light will be seen in the other examples.

A P P E N D I X .

ALGEBRAICAL SIGNS.

- $+$, *plus*, signifies addition, and that the two quantities between which it stands are to be added together; as $a + b$, read a added to b .
- $-$, *minus*, signifies subtraction, or that of the two quantities between which it occurs, the latter is to be subtracted from the former; as $a - b$, read a minus b .
- \times , *multiplied by*, or the sign of multiplication. It denotes that the two quantities between which it occurs are to be multiplied together; as $a \times b$, read a multiplied by b , or a times b . This sign is usually omitted between symbols or letters, and is then understood, as ab . This has the same meaning as $a \times b$. It is never omitted between arithmetical numbers; as 9×5 , read nine times five.
- \div , *divided by*, or the sign of division, and denotes that of the two quantities between which it occurs, the former is to be divided by the latter; as $a \div b$, read a divided by b . Division is also represented thus: in the form of a fraction. This signifies that a is to be divided by b . When more than one symbol occurs above or below the line, or both, as $\frac{a n r}{c m}$, it denotes that the product of the symbols above the line is to be divided by the product of those below the line.
- $=$, *is equal to*, or sign of equality, and denotes that the quantity or quantities on its left are equal to those on its right; as $a - b = c$, read a minus b is equal to c , or equals c ; or, $9 - 5 = 4$, read nine minus five equals four. This sign, together with the symbols on each side of it, when spoken of as a whole, is called an *equation*.
- a^2 denotes a squared, or a multiplied by a , or the second power of a , and
- a^3 denotes a cubed, or a multiplied by a and again multiplied by a , or the third power of a . The small figure, 2, 3, or 4, &c., is termed the index or exponent of the power. It indicates how many times the symbol is to be taken. Thus, $a^2 = a a$, $a^3 = a a a$, $a^4 = a a a a$.
- $\sqrt{\quad}$ is the *radical* sign, and denotes that the *square* root of the quantity following it is to be extracted, and

$\sqrt[3]{}$ denotes that the *cube* root of the quantity following it is to be extracted. Thus, $\sqrt{9} = 3$, and $\sqrt[3]{27} = 3$. The extraction of roots is also denoted by a fractional index or exponent, thus

$a^{\frac{1}{2}}$ denotes the square root of a ,

$a^{\frac{1}{3}}$ denotes the cube root of a ,

$a^{\frac{2}{3}}$ denotes the cube root of the square of a , &c.

TRIGONOMETRICAL TERMS.




Fig. 366.

In *Fig. 366*, where AB is the radius of the circle BCH , draw a line AF , from A , through any point, C , of the arc BG . From C draw CD perpendicular to AB ; from B draw BE perpendicular to AG ; and from G draw GF perpendicular to AF .

Then, for the angle FAB , when the radius AC equals unity, CD is the *sine*; AD the *cosine*; DB the *versed sine*; BE the *tangent*, GF the *cotangent*; AE the *secant*; and AF the *cosecant*.

GLOSSARY.

Terms not found here can be found in the lists of definitions in other parts of this book, or in common dictionaries.

- Abacus*.—The uppermost member of a capital.
- Abattoir*.—A slaughter-house.
- Abbey*.—The residence of an abbot or abbess.
- Abutment*.—That part of a pier from which the arch springs.
- Acanthus*.—A plant called in English, *bear's-breech*. Its leaves are employed for decorating the Corinthian and the Composite capitals.
- Acropolis*.—The highest part of a city; generally the citadel.
- Acroteria*.—The small pedestals placed on the extremities and apex of a pediment, originally intended as a base for sculpture.
- Aisle*.—Passage to and from the pews of a church. In Gothic architecture, the lean-to wings on the sides of the *nave*.
- Alcove*.—Part of a chamber separated by an *estrade*, or partition of columns. Recess with seats, &c., in gardens.
- Altar*.—A pedestal whereon sacrifice was offered. In modern churches, the area within the railing in front of the pulpit.
- Alto-relievo*.—High relief; sculpture projecting from a surface so as to appear nearly isolated.
- Amphitheatre*.—A double theatre, employed by the ancients for the exhibition of gladiatorial fights and other shows.
- Ancones*.—Trusses employed as an apparent support to a cornice upon the flanks of the architrave.
- Annulet*.—A small square moulding used to separate others; the fillets in the Doric capital under the ovolo, and those which separate the flutings of columns, are known by this term.
- Antæ*.—A pilaster attached to a wall.
- Apiary*.—A place for keeping beehives.
- Arabesque*.—A building after the Arabian style.
- Areostyle*.—An intercolumniation of from four to five diameters.
- Arcade*.—A series of arches.
- Arch*.—An arrangement of stones or other material in a curvilinear form, so as to perform the office of a lintel and carry superincumbent weights.
- Architrave*.—That part of the entablature which rests upon the capital of a column, and is beneath the frieze. The casing and mouldings about a door or window.

APPENDIX.

- Archivolt*.—The ceiling of a vault : the under surface of an arch.
- Area*.—Superficial measurement. An open space, below the level of the ground, in front of basement windows.
- Arsenal*.—A public establishment for the deposition of arms and warlike stores.
- Astragal*.—A small moulding consisting of a half-round with a fillet on each side.
- Attic*.—A low story erected over an order of architecture. A low additional story immediately under the roof of a building.
- Aviary*.—A place for keeping and breeding birds.
- Balcony*.—An open gallery projecting from the front of a building.
- Baluster*.—A small pillar or pilaster supporting a rail.
- Balustrade*.—A series of balusters connected by a rail.
- Barge-course*.—That part of the covering which projects over the gable of a building.
- Base*.—The lowest part of a wall, column, &c.
- Basement-story*.—That which is immediately under the principal story, and included within the foundation of the building.
- Basso-relievo*.—Low relief ; sculptured figures projecting from a surface one-half their thickness or less. See *Alto-relievo*.
- Battering*.—See *Talus*.
- Battlement*.—Indentations on the top of a wall or parapet.
- Bay-window*.—A window projecting in two or more planes, and not forming the segment of a circle.
- Bazaar*.—A species of mart or exchange for the sale of various articles of merchandise.
- Bead*.—A circular moulding.
- Bed-mouldings*.—Those mouldings which are between the corona and the frieze.
- Belfry*.—That part of a steeple in which the bells are hung : anciently called *campanile*.
- Belvedere*.—An ornamental turret or observatory commanding a pleasant prospect.
- Bow-window*.—A window projecting in curved lines.
- Bressummer*.—A beam or iron tie supporting a wall over a gateway or other opening.
- Brick-nogging*.—The brickwork between studs of partitions.
- Buttress*.—A projection from a wall to give additional strength.
- Cable*.—A cylindrical moulding placed in flutes at the lower part of the column.
- Camber*.—To give a convexity to the upper surface of a beam.
- Campanile*.—A tower for the reception of bells, usually, in Italy, separated from the church.
- Canopy*.—An ornamental covering over a seat of state.
- Cantilevers*.—The ends of rafters under a projecting roof. Pieces of wood or stone supporting the eaves.
- Capital*.—The uppermost part of a column included between the shaft and the architrave.

Caravansera.—In the East, a large public building for the reception of travellers by caravans in the desert.

Carpentry.—(From the Latin, *carpentum*, carved wood.) That department of science and art which treats of the disposition, the construction and the relative strength of timber. The first is called descriptive, the second constructive, and the last mechanical carpentry.

Caryatides.—Figures of women used instead of columns to support an entablature.

Casino.—A small country-house.

Castellated.—Built with battlements and turrets in imitation of ancient castles.

Castle.—A building fortified for military defence. A house with towers, usually encompassed with walls and moats, and having a donjon, or keep, in the centre.

Catacombs.—Subterraneous places for burying the dead.

Cathedral.—The principal church of a province or diocese, wherein the throne of the archbishop or bishop is placed.

Cavetto.—A concave moulding comprising the quadrant of a circle.

Cemetery.—An edifice or area where the dead are interred.

Cenotaph.—A monument erected to the memory of a person buried in another place.

Centring.—The temporary woodwork, or framing, whereon any vaulted work is constructed.

Cesspool.—A well under a drain or pavement to receive the wastewater and sediment.

Chamfer.—The bevelled edge of any thing originally right-angled.

Chancel.—That part of a Gothic church in which the altar is placed.

Chantry.—A little chapel in ancient churches, with an endowment for one or more priests to say mass for the relief of souls out of purgatory.

Chapel.—A building for religious worship, erected separately from a church, and served by a chaplain.

Chaplet.—A moulding carved into beads, olives, &c.

Cincture.—The ring, listel, or fillet, at the top and bottom of a column, which divides the shaft of the column from its capital and base.

Circus.—A straight, long, narrow building used by the Romans for the exhibition of public spectacles and chariot races. At the present day, a building enclosing an arena for the exhibition of feats of horsemanship.

Clere-story.—The upper part of the nave of a church above the roofs of the aisles.

Cloister.—The square space attached to a regular monastery or large church, having a peristyle or ambulatory around it, covered with a range of buildings.

Coffer-dam.—A case of piling, water-tight, fixed in the bed of a river, for the purpose of excluding the water while any work, such as a wharf, wall, or the pier of a bridge, is carried up.

Collar-beam.—A horizontal beam framed between two principal rafters above the tie-beam.

Collonade.—A range of columns.

Columbarium.—A pigeon-house.

Column.—A vertical, cylindrical support under the entablature of an order.

Common-rafters.—The same as *jack-rafters*, which see

Conduit.—A long, narrow, walled passage underground, for secret communication between different apartments. A canal or pipe for the conveyance of water.

Conservatory.—A building for preserving curious and rare exotic plants.

Consoles.—The same as *ancones*, which see.

Contour.—The external lines which bound and terminate a figure.

Convent.—A building for the reception of a society of religious persons.

Coping.—Stones laid on the top of a wall to defend it from the weather.

Corbels.—Stones or timbers fixed in a wall to sustain the timbers of a floor or roof.

Cornice.—Any moulded projection which crowns or finishes the part to which it is affixed.

Corona.—That part of a cornice which is between the crown-moulding and the bed-mouldings.

Cornucopia.—The horn of plenty.

Corridor.—An open gallery or communication to the different apartments of a house.

Cove.—A concave moulding.

Cripple-rafters.—The short rafters which are spiked to the hip-rafter of a roof.

Crocketts.—In Gothic architecture, the ornaments placed along the angles of pediments, pinnacles, &c.

Crosettes.—The same as *ancones*, which see.

Crypt.—The under or hidden part of a building.

Culvert.—An arched channel of masonry or brickwork, built beneath the bed of a canal for the purpose of conducting water under it. Any arched channel for water underground.

Cupola.—A small building on the top of a dome.

Curtail-step.—A step with a spiral end, usually the first of the flight.

Cusps.—The pendants of a pointed arch.

Cyma.—An ogee. There are two kinds; the *cyma-recta*, having the upper part concave and the lower convex, and the *cyma-reversa*, with the upper part convex and the lower concave.

Dado.—The die, or part between the base and cornice of a pedestal.

Dairy.—An apartment or building for the preservation of milk, and the manufacture of it into butter, cheese, &c.

Dead-shoar.—A piece of timber or stone stood vertically in brickwork, to support a superincumbent weight until the brickwork which is to carry it has set or become hard.

Decastyle.—A building having ten columns in front.

Dentils.—(From the Latin, *dentes*, teeth.) Small rectangular blocks used in the bed-mouldings of some of the orders.

Diastyle.—An intercolumniation of three, or, as some say, four diameters.

Due.—That part of a pedestal included between the base and the cornice ; it is also called a *dado*.

Dodecastyle.—A building having twelve columns in front.

Donjon.—A massive tower within ancient castles to which the garrison might retreat in case of necessity.

Dooks.—A Scotch term given to wooden bricks.

Dormer.—A window placed on the roof of a house, the frame being placed vertically on the rafters.

Dormitory.—A sleeping-room.

Dovecote.—A building for keeping tame pigeons. A columbarium.

Echinus.—The Grecian ovolo.

Elevation.—A geometrical projection drawn on a plane at right angles to the horizon.

Entablature.—That part of an order which is supported by the columns ; consisting of the architrave, frieze, and cornice.

Eustyle.—An intercolumniation of two and a quarter diameters.

Exchange.—A building in which merchants and brokers meet to transact business.

Extrados.—The exterior curve of an arch.

Façade.—The principal front of any building.

Face-mould.—The pattern for marking the plank, out of which hand-railing is to be cut for stairs, &c.

Facia, or *Fascia*.—A flat member like a band or broad fillet.

Falling-mould.—The mould applied to the convex, vertical surface of the rail-piece, in order to form the back and under surface of the rail, and finish the squaring.

Festoon.—An ornament representing a wreath of flowers and leaves.

Fillet.—A narrow flat band, listel, or annulet, used for the separation of one moulding from another, and to give breadth and firmness to the edges of mouldings.

Flutes.—Upright channels on the shafts of columns.

Flyers.—Steps in a flight of stairs that are parallel to each other.

Forum.—In ancient architecture, a public market ; also, a place where the common courts were held, and law pleadings carried on.

Foundry.—A building in which various metals are cast into moulds or shapes.

Frieze.—That part of an entablature included between the architrave and the cornice.

Gable.—The vertical, triangular piece of wall at the end of a roof, from the level of the eaves to the summit.

Gain.—A recess made to receive a trion or tusk.

Gallery.—A common passage to several rooms in an upper story. A long room for the reception of pictures. A platform raised on columns, pilasters, or piers.

Girder.—The principal beam in a floor for supporting the binding and other joists, whereby the bearing or length is lessened.

Glyph.—A vertical, sunken channel. From their number, those in the Doric order are called *triglyphs*.

Granary.—A building for storing grain, especially that intended to be kept for a considerable time.

Groin.—The line formed by the intersection of two arches, which cross each other at any angle.

Gutta.—The small cylindrical pendent ornaments, otherwise called *drops*, used in the Doric order under the triglyphs, and also pendent from the mutuli of the cornice.

Gymnasium.—Originally, a space measured out and covered with sand for the exercise of athletic games: afterwards, spacious buildings devoted to the mental as well as corporeal instruction of youth.

Hall.—The first large apartment on entering a house. The public room of a corporate body. A manor-house.

Ham.—A house or dwelling-place. A street or village: hence Nottingham, Buckingham, &c. *Hamlet*, the diminutive of *ham*, is a small street or village.

Helix.—The small volute, or twist, under the abacus in the Corinthian capital.

Hem.—The projecting spiral fillet of the Ionic capital.

Hexastyle.—A building having six columns in front.

Hip-rafter.—A piece of timber placed at the angle made by two adjacent inclined roofs.

Homestall.—A mansion-house, or seat in the country.

Hotel, or Hostel.—A large inn or place of public entertainment. A large house or palace.

Hot-house.—A glass building used in gardening.

Hovel.—An open shed.

Hut.—A small cottage or hovel generally constructed of earthy materials, as strong loamy clay, &c.

Impost.—The capital of a pier or pilaster which supports an arch.

Intaglio.—Sculpture in which the subject is hollowed out, so that the impression from it presents the appearance of a bas-relief.

Intercolumniation.—The distance between two columns.

Intrados.—The interior and lower curve of an arch.

Jack-rafters.—Rafters that fill in between the principal rafters of a roof; called also *common-rafters*.

Jail.—A place of legal confinement.

Jambs.—The vertical sides of an aperture.

Joggle-piece.—A post to receive struts.

Joists.—The timbers to which the boards of a floor or the laths of a ceiling are nailed.

Keep.—The same as *donjon*, which see.

Key-stone.—The highest central stone of an arch.

Kiln.—A building for the accumulation and retention of heat, in order to dry or burn certain materials deposited within it.

King-post.—The centre-post in a trussed roof.

Knee.—A convex bend in the back of a hand-rail. See *Ramp*.

Lactarium.—The same as *dairy*, which see.

Lantern.—A cupola having windows in the sides for lighting an apartment beneath.

Larmier.—The same as *corona*, which see.

Lattice.—A reticulated window for the admission of air, rather than light, as in dairies and cellars.

Lever-boards.—Blind-slats: a set of boards so fastened that they may be turned at any angle to admit more or less light, or to lap upon each other so as to exclude all air or light through apertures.

Lintel.—A piece of timber or stone placed horizontally over a door, window, or other opening.

Listel.—The same as *fillet*, which see.

Lobby.—An enclosed space, or passage, communicating with the principal room or rooms of a house.

Lodge.—A small house near and subordinate to the mansion. A cottage placed at the gate of the road leading to a mansion.

Loop.—A small narrow window. *Loop-hole* is a term applied to the vertical series of doors in a warehouse, through which goods are delivered by means of a crane.

Luffer-boarding.—The same as *lever-boards*, which see.

Luthern.—The same as *dormer*, which see.

Mausoleum.—A sepulchral building—so called from a very celebrated one erected to the memory of Mausolus, king of Caria, by his wife Artemisia.

Metopa.—The square space in the frieze between the triglyphs of the Doric order.

Mezzanine.—A story of small height introduced between two of greater height.

Minaret.—A slender, lofty turret having projecting balconies, common in Mohammedan countries.

Minster.—A church to which an ecclesiastical fraternity has been or is attached.

Moat.—An excavated reservoir of water, surrounding a house, castle or town.

Modillion.—A projection under the corona of the richer orders, resembling a bracket.

Module.—The semi-diameter of a column, used by the architect as a measure by which to proportion the parts of an order.

Monastery.—A building or buildings appropriated to the reception of monks.

Monopteron.—A circular colonnade supporting a dome without an enclosing wall.

Mosaic.—A mode of representing objects by the inlaying of small cubes of glass, stone, marble, shells, &c.

Mosque.—A Mohammedan temple, or place of worship.

Mullions.—The upright posts or bars, which divide the lights in a Gothic window.

Muniment-house.—A strong, fire-proof apartment for the keeping and preservation of evidences, charters, seals, &c., called muniments.

Museum.—A repository of natural, scientific and literary curiosities, or of works of art.

Mutule.—A projecting ornament of the Doric cornice supposed to represent the ends of rafters.

Nave.—The main body of a Gothic church.

Newel.—A post at the starting or landing of a flight of stairs.

Niche.—A cavity or hollow place in a wall for the reception of a statue, vase, &c.

Nogs.—Wooden bricks.

Nosing.—The rounded and projecting edge of a step in stairs.

Nunnery.—A building or buildings appropriated for the reception of nuns.

Obelisk.—A lofty pillar of a rectangular form.

Octastyle.—A building with eight columns in front.

Odeum.—Among the Greeks, a species of theatre wherein the poets and musicians rehearsed their compositions previous to the public production of them.

Ogee.—See *Cyma*.

Orangery.—A gallery or building in a garden or parterre fronting the south.

Oriel-window.—A large bay or recessed window in a hall, chapel, or other apartment.

Ovolo.—A convex projecting moulding whose profile is the quadrant of a circle.

Pagoda.—A temple or place of worship in India.

Palisade.—A fence of pales or stakes driven into the ground.

Parapet.—A small wall of any material for protection on the sides of bridges, quays, or high buildings.

Pavilion.—A turret or small building generally insulated and comprised under a single roof.

Pedestal.—A square foundation used to elevate and sustain a column, statue, &c.

Pediment.—The triangular crowning part of a portico or aperture which terminates vertically the sloping parts of the roof: this, in Gothic architecture, is called a *gable*.

Penitentiary.—A prison for the confinement of criminals whose crimes are not of a very heinous nature.

Piazza.—A square, open space surrounded by buildings. This term is often improperly used to denote a *portico*.

Pier.—A rectangular pillar without any regular base or capital. The upright, narrow portions of walls between doors and windows are known by this term.

Pilaster.—A square pillar, sometimes insulated, but more commonly engaged in a wall, and projecting only a part of its thickness.

Piles.—Large timbers driven into the ground to make a secure foundation in marshy places, or in the bed of a river.

Pillar.—A column of irregular form, always disengaged, and al-

ways deviating from the proportions of the orders ; whence the distinction between a pillar and a column.

Pinnacle.—A small spire used to ornament Gothic buildings.

Planceer.—The same as *soffit*, which see.

Plinth.—The lower square member of the base of a column, pedestal, or wall.

Porch.—An exterior appendage to a building, forming a covered approach to one of its principal doorways.

Portal.—The arch over a door or gate ; the framework of the gate ; the lesser gate, when there are two of different dimensions at one entrance.

Porticulis.—A strong timber gate to old castles, made to slide up and down vertically.

Portico.—A colonnade supporting a shelter over a walk, or ambulatory.

Priory.—A building similar in its constitution to a monastery or abbey, the head whereof was called a prior or prioress.

Prism.—A solid bounded on the sides by parallelograms, and on the ends by polygonal figures in parallel planes.

Prostyle.—A building with columns in front only.

Purlines.—Those pieces of timber which lie under and at right angles to the rafters to prevent them from sinking.

Pycnostyle.—An intercolumniation of one and a half diameters.

Pyramid.—A solid body standing on a square, triangular or polygonal basis, and terminating in a point at the top.

Quarry.—A place whence stones and slates are procured.

Quay.—(Pronounced, *key*.) A bank formed towards the sea or on the side of a river for free passage, or for the purpose of unloading merchandise.

Quoin.—An external angle. See *Rustic quoins*.

Rabbet, or *Rebate*.—A groove or channel in the edge of a board.

Ramp.—A concave bend in the back of a hand-rail.

Rampant arch.—One having abutments of different heights.

Regula.—The band below the *tenia* in the Doric order.

Riser.—In stairs, the vertical board forming the front of a step.

Rostrum.—An elevated platform from which a speaker addresses an audience.

Rotunda.—A circular building.

Rubble-wall.—A wall built of unhewn stone.

Rudenture.—The same as *cable*, which see.

Rustic quoins.—The stones placed on the external angle of a building, projecting beyond the face of the wall, and having their edges bevilled.

Rustic-work.—A mode of building masonry wherein the faces of the stones are left rough, the sides only being wrought smooth where the union of the stones takes place.

Salon, or *Saloon*.—A lofty and spacious apartment comprehending the height of two stories with two tiers of windows.

Sarcophagus.—A tomb or coffin made of one stone.

Scantling.—The measure to which a piece of timber is to be or has been cut.

Scarfig.—The joining of two pieces of timber by bolting or nailing transversely together, so that the two appear but one.

Scotia.—The hollow moulding in the base of a column, between the fillets of the tori.

Scroll.—A carved curvilinear ornament, somewhat resembling in profile the turnings of a ram's horn.

Sepulchre.—A grave, tomb, or place of interment.

Sewer.—A drain or conduit for carrying off soil or water from any place.

Shaft.—The cylindrical part between the base and the capital of a column.

Shoar.—A piece of timber placed in an oblique direction to support a building or wall.

Sill.—The horizontal piece of timber at the bottom of framing; the timber or stone at the bottom of doors and windows.

Soffit.—The underside of an architrave, corona, &c. The underside of the heads of doors, windows, &c.

Summer.—The lintel of a door or window; a beam tenoned into a girder to support the ends of joists on both sides of it.

Systyle.—An intercolumniation of two diameters.

Tania.—The fillet which separates the Doric frieze from the architrave.

Talus.—The slope or inclination of a wall, among workmen called *battering*.

Terrace.—An area raised before a building, above the level of the ground, to serve as a walk.

Tesselated pavement.—A curious pavement of Mosaic work, composed of small square stones.

Tetrastyle.—A building having four columns in front.

Thatch.—A covering of straw or reeds used on the roofs of cottages, barns, &c.

Theatre.—A building appropriated to the representation of dramatic spectacles.

Tile.—A thin piece or plate of baked clay or other material used for the external covering of a roof.

Tomb.—A grave, or place for the interment of a human body, including also any commemorative monument raised over such a place.

Torus.—A moulding of semi-circular profile used in the bases of columns.

Tower.—A lofty building of several stories, round or polygonal.

Transept.—The transverse portion of a cruciform church.

Transom.—The beam across a double-lighted window; if the window have no transom, it is called a *clere-story* window.

Tread.—The part of a step which is included between the face of its riser and that of the riser above.

Trellis.—A reticulated framing made of thin bars of wood for screens, windows, &c.

Triglyph.—The vertical tablets in the Doric frieze, chamfered on the two vertical edges, and having two channels in the middle.

Tripod.—A table or seat with three legs.

Trochilus.—The same as *scotia*, which see.

Truss.—An arrangement of timbers for increasing the resistance to cross-strains, consisting of a tie, two struts and a suspending-piece.

Turret.—A small tower, often crowning the angle of a wall, &c.

Tusk.—A short projection under a tenon to increase its strength.

Tympanum.—The naked face of a pediment, included between the level and the raking mouldings.

Underpinning.—The wall under the ground-sills of a building.

University.—An assemblage of colleges under the supervision of a senate, &c.

Vault.—A concave arched ceiling resting upon two opposite parallel walls.

Venetian-door.—A door having side-lights.

Venetian-window.—A window having three separate apertures.

Veranda.—An awning. An open portico under the extended roof of a building.

Vestibule.—An apartment which serves as the medium of communication to another room or series of rooms.

Vestry.—An apartment in a church, or attached to it, for the preservation of the sacred vestments and utensils.

Villa.—A country-house for the residence of an opulent person.

Vinery.—A house for the cultivation of vines.

Volute.—A spiral scroll, which forms the principal feature of the Ionic and the Composite capitals.

Voussoirs.—Arch-stones

Wainscoting.—Wooden lining of walls, generally in panels.

Water-table.—The stone covering to the projecting foundation or other walls of a building.

Well.—The space occupied by a flight of stairs. The space left beyond the ends of the steps is called the *well-hole*.

Wicket.—A small door made in a gate.

Winders.—In stairs, steps not parallel to each other.

Zophorus.—The same as *frieze*, which see.

Zytos.—Among the ancients, a portico of unusual length, commonly appropriated to gymnastic exercises.

TABLE OF SQUARES, CUBES, AND ROOTS.

(From Hutton's Mathematics.)

No.	Square.	Cube.	Sq. Root.	CubeRoot.	No.	Square.	Cube.	Sq. Root.	CubeRoot.
1	1	1	1.000000	1.000000	68	4624	314432	8.2462113	4.081655
2	4	8	1.4142136	1.259921	69	4761	323509	8.3066239	4.101556
3	9	27	1.7320508	1.442250	70	4900	333000	8.3666003	4.121285
4	16	64	2.0000000	1.587401	71	5041	357911	8.4261498	4.140818
5	25	125	2.2360680	1.709976	72	5184	373248	8.4852314	4.160168
6	36	216	2.4494897	1.817121	73	5329	389017	8.5440037	4.179339
7	49	343	2.6457513	1.912931	74	5476	405224	8.6023253	4.198336
8	64	512	2.8284271	2.000000	75	5625	421875	8.6602540	4.217163
9	81	729	3.0000000	2.080034	76	5776	439766	8.7177974	4.235324
10	100	1000	3.1622777	2.151435	77	5929	456533	8.7749644	4.254321
11	121	1331	3.3166249	2.223390	78	6084	474552	8.8317679	4.272659
12	144	1728	3.4641016	2.294299	79	6241	493039	8.8891944	4.290640
13	169	2197	3.6955513	2.351335	80	6400	512000	8.9442719	4.308369
14	196	2744	3.7416574	2.410142	81	6561	531441	9.0000000	4.326749
15	225	3375	3.8729833	2.466212	82	6724	551368	9.0553851	4.344481
16	256	4096	4.0000000	2.519842	83	6889	571787	9.1104336	4.362071
17	289	4913	4.1231056	2.571232	84	7056	592704	9.1651514	4.379519
18	324	5832	4.2426407	2.620741	85	7225	614125	9.2195445	4.396830
19	361	6859	4.3583989	2.668402	86	7396	636055	9.2736185	4.414005
20	400	8000	4.4721360	2.714418	87	7569	658503	9.3273791	4.431048
21	441	9261	4.5825757	2.758234	88	7744	681472	9.3808315	4.447960
22	484	10648	4.6904158	2.802033	89	7921	704969	9.4339311	4.464745
23	529	12167	4.7958315	2.843367	90	8100	729000	9.4863330	4.481405
24	576	13824	4.8989795	2.884499	91	8281	753571	9.5383320	4.497941
25	625	15625	5.0000000	2.924018	92	8464	778683	9.5916630	4.514357
26	676	17576	5.0930195	2.962496	93	8649	804357	9.6436508	4.530655
27	729	19683	5.1961524	3.000000	94	8836	830534	9.6953597	4.546836
28	784	21952	5.2915026	3.036539	95	9025	857375	9.7467943	4.562903
29	841	24387	5.3951648	3.072317	96	9216	884736	9.7979590	4.578857
30	900	27000	5.4772256	3.107232	97	9409	912673	9.8488578	4.594701
31	961	29791	5.5677614	3.141313	98	9604	941192	9.8994949	4.610436
32	1024	32768	5.6568542	3.174802	99	9801	970299	9.9498744	4.626065
33	1089	35937	5.7445626	3.207531	100	10000	1000000	10.0000000	4.641589
34	1156	39304	5.7839519	3.239612	101	10201	1033301	10.0498756	4.657009
35	1225	42875	5.9160798	3.271066	102	10404	1061208	10.0995549	4.672329
36	1296	46656	6.0000000	3.301927	103	10609	1092727	10.1483915	4.687548
37	1369	50653	6.0327625	3.332232	104	10816	1124861	10.1980390	4.702669
38	1444	54872	6.1644140	3.361975	105	11025	1157625	10.2469538	4.717694
39	1521	59319	6.2449980	3.391211	106	11236	1191016	10.2955332	4.732623
40	1600	64000	6.3245533	3.419352	107	11449	1225043	10.3440304	4.747459
41	1681	68921	6.4031242	3.448217	108	11664	1259712	10.3923348	4.762203
42	1764	74088	6.4807407	3.476727	109	11881	1295029	10.4403355	4.776856
43	1849	79507	6.5574335	3.503398	110	12100	1331000	10.4880835	4.791420
44	1936	85184	6.6332496	3.533348	111	12321	1367631	10.5356539	4.805895
45	2025	91125	6.7082039	3.565893	112	12544	1404928	10.5830052	4.820284
46	2116	97336	6.7823300	3.593048	113	12769	1442897	10.6301458	4.834588
47	2209	103823	6.8556546	3.608326	114	12996	1481544	10.6770733	4.848808
48	2304	110592	6.9232032	3.634241	115	13225	1520875	10.7238053	4.862944
49	2401	117649	7.0000000	3.659336	116	13456	1560896	10.7703233	4.876999
50	2500	125000	7.0710678	3.684031	117	13689	1601613	10.8166536	4.890973
51	2601	132651	7.1414234	3.708433	118	13924	1643032	10.8627805	4.904869
52	2704	140608	7.2111026	3.732511	119	14161	1685159	10.9087121	4.918685
53	2809	148877	7.2801039	3.756285	120	14400	1728000	10.9544512	4.932424
54	2916	157464	7.3481692	3.779763	121	14641	1771561	11.0000000	4.946087
55	3025	166375	7.4161985	3.802932	122	14884	1815848	11.0453616	4.959676
56	3136	175616	7.4833148	3.825852	123	15129	1860867	11.0905365	4.973190
57	3249	185193	7.5493341	3.848501	124	15376	1906624	11.1355287	4.986631
58	3364	195112	7.6157731	3.870877	125	15625	1953125	11.1803399	5.000000
59	3481	205379	7.6811457	3.892996	126	15876	2000376	11.2249722	5.013298
60	3600	216000	7.7459667	3.914868	127	16129	2048333	11.2694277	5.026526
61	3721	226981	7.8102197	3.936497	128	16384	2097152	11.3137085	5.039684
62	3844	238328	7.8740979	3.957891	129	16641	2146689	11.3578167	5.052774
63	3969	250047	7.9375239	3.979057	130	16900	2197000	11.4017543	5.065797
64	4096	262144	8.0000000	4.000000	131	17161	2248091	11.4455231	5.078753
65	4225	274625	8.0622577	4.023726	132	17424	2299963	11.4891253	5.091643
66	4356	287496	8.1240334	4.047240	133	17689	2352637	11.5325626	5.104469
67	4489	300763	8.1853523	4.061543	134	17956	2406104	11.5758369	5.117230

APPENDIX.

19

No.	Square.	Cube.	Sq. Root.	CubeRoot.	No.	Square.	Cube.	Sq. Root.	CubeRoot.
135	18225	2460375	11-6189500	5-129928	202	40804	8242408	14-2126704	5-867464
136	18496	2515456	11-6619033	5-142563	203	41209	8365427	14-2478068	5-877131
137	18769	2571353	11-7046993	5-155137	204	41616	8489666	14-2828569	5-886765
138	19044	2628072	11-7473401	5-167649	205	42025	8615125	14-3178211	5-896368
139	19321	2685619	11-7898261	5-180101	206	42436	8741816	14-3527001	5-905954
140	19600	2744000	11-8321596	5-192494	207	42849	8869743	14-3874946	5-915482
141	19881	2803221	11-8743422	5-204828	208	43264	8998912	14-4222051	5-924992
142	20164	2863288	11-9163753	5-217103	209	43681	9129329	14-4568323	5-934473
143	20449	2924207	11-9582607	5-229321	210	44100	9261000	14-4913767	5-943922
144	20736	2985984	12-0000000	5-241493	211	44521	9393393	14-5258390	5-953342
145	21025	3048625	12-0415946	5-253588	212	44944	9528123	14-5602199	5-962732
146	21316	3112136	12-0830460	5-265637	213	45369	9663397	14-5945195	5-972093
147	21609	3176533	12-1243557	5-277632	214	45796	9800344	14-6287338	5-981424
148	21904	3241792	12-1655251	5-289572	215	46225	9938375	14-6623783	5-990726
149	22201	3307949	12-2065556	5-301459	216	46656	10077696	14-6969335	6-000000
150	22500	3375000	12-2474487	5-313233	217	47089	10218313	14-7309199	6-009245
151	22801	3442951	12-2882057	5-325074	218	47524	10360232	14-7648231	6-018462
152	23104	3511808	12-3288280	5-336803	219	47961	10503459	14-7986486	6-027650
153	23409	3581577	12-3693169	5-348481	220	48400	10648000	14-8323970	6-036811
154	23716	3652264	12-4096736	5-360108	221	48841	10793861	14-8660687	6-045943
155	24025	3723875	12-4498900	5-371685	222	49284	10941048	14-8996644	6-055049
156	24336	3796416	12-4399360	5-383213	223	49729	11089567	14-9331845	6-064127
157	24649	3869893	12-5299641	5-394691	224	50176	11239424	14-9666293	6-073173
158	24964	3944312	12-5698051	5-406120	225	50625	11390625	15-0000000	6-082202
159	25281	4019679	12-6095202	5-417501	226	51076	11543176	15-0332964	6-091199
160	25600	4096000	12-6491106	5-428835	227	51529	11697083	15-0665192	6-100170
161	25921	4173281	12-6885775	5-440122	228	51984	11852252	15-0996660	6-109115
162	26244	4251528	12-7279221	5-451362	229	52441	12008939	15-1327460	6-118033
163	26569	4330747	12-7671453	5-462556	230	52900	12167000	15-1657509	6-126926
164	26896	4410944	12-8062485	5-473704	231	53361	12326391	15-1986432	6-135792
165	27225	4492125	12-8452326	5-484807	232	53824	12487168	15-2315462	6-144634
166	27556	4574296	12-8840987	5-495865	233	54289	12649337	15-2643375	6-153449
167	27889	4657463	12-9228480	5-506878	234	54756	12812904	15-2970385	6-162240
168	28224	4741632	12-9614814	5-517848	235	55225	12977875	15-3297097	6-171006
169	28561	4826809	13-0000000	5-528775	236	55696	13144256	15-3622913	6-179747
170	28900	4913000	13-0384048	5-539658	237	56169	13312053	15-3948043	6-188463
171	29241	5000211	13-0766968	5-550499	238	56644	13481252	15-4272486	6-197154
172	29584	5088448	13-1148770	5-561293	239	57121	13651919	15-4596248	6-205822
173	29929	5177717	13-1529464	5-572055	240	57600	13824000	15-4919334	6-214465
174	30276	5268024	13-1909060	5-582770	241	58081	13997521	15-5241747	6-223094
175	30625	5359375	13-2287566	5-593445	242	58564	14172488	15-5563192	6-231630
176	30976	5451776	13-2664992	5-604079	243	59049	14348907	15-5884573	6-240251
177	31329	5545233	13-3041347	5-614672	244	59536	14526784	15-6204994	6-248300
178	31684	5639752	13-3416641	5-625226	245	60025	14706125	15-6524758	6-257325
179	32041	5735339	13-3790882	5-635741	246	60516	14886936	15-6843371	6-265827
180	32400	5832000	13-4164709	5-646216	247	61009	15069223	15-7162336	6-274305
181	32761	5929741	13-4536240	5-656653	248	61504	15252932	15-7480157	6-282871
182	33124	6028568	13-4907376	5-667051	249	62001	15438249	15-7797333	6-291195
183	33489	6128487	13-5277493	5-677411	250	62500	15625000	15-8113383	6-299605
184	33856	6229504	13-5646600	5-687734	251	63001	15813251	15-8429795	6-307994
185	34225	6331625	13-6014705	5-698019	252	63504	16003008	15-8745079	6-316360
186	34596	6434856	13-6381817	5-708267	253	64009	16194277	15-9059377	6-324704
187	34969	6539203	13-6747943	5-718479	254	64516	16387064	15-9373775	6-333026
188	35344	6644672	13-7113092	5-728654	255	65025	16581375	15-9687194	6-341326
189	35721	6751269	13-7477271	5-738794	256	65536	16777216	16-0000000	6-349604
190	36100	6859000	13-7840488	5-748897	257	66049	16974593	16-0312195	6-357861
191	36481	6967871	13-8202750	5-758965	258	66564	17173512	16-0623784	6-366097
192	36864	7077888	13-8564065	5-768998	259	67081	17373979	16-0929469	6-374311
193	37249	7189057	13-8924440	5-778996	260	67600	17576000	16-1231556	6-382504
194	37636	7301384	13-9283883	5-788960	261	68121	17779581	16-1534944	6-390676
195	38025	7414875	13-9642400	5-798890	262	68644	17984728	16-1838119	6-398823
196	38416	7529536	14-0000000	5-808786	263	69169	18191447	16-2142747	6-406953
197	38809	7645373	14-0366688	5-818648	264	69696	18399744	16-2448076	6-415069
198	39204	7762392	14-0731273	5-828477	265	70225	18609625	16-2753826	6-423158
199	39601	7880599	14-1067360	5-838272	266	70756	18821096	16-3059604	6-431225
200	40000	8000000	14-1421356	5-848035	267	71289	19034169	16-3401346	6-439277
201	40401	8120601	14-1774469	5-857766	268	71824	19248832	16-3707055	6-447306

No.	Square.	Cube.	Sq. Root.	CubeRoot.	No.	Square.	Cube.	Sq. Root.	CubeRoot.
269	72361	19465109	16-4012195	6-455315	336	112896	37933056	18-3303028	6-952053
270	72900	19653000	16-4316767	6-463304	337	113569	38372753	18-3575598	6-958913
271	73441	19902511	16-4620776	6-471274	338	114244	38814472	18-3847763	6-965820
272	73984	20123648	16-4924225	6-479224	339	114921	38958219	18-4119526	6-972683
273	74529	20346417	16-5227116	6-487154	340	115600	39304000	18-4390889	6-979532
274	75076	20570824	16-5529454	6-495065	341	116281	39651821	18-4661853	6-986368
275	75625	20796875	16-5831240	6-502957	342	116964	40001698	18-4932420	6-993191
276	76176	21024576	16-6132477	6-510830	343	117649	40353607	18-5202592	7-000000
277	76729	21253933	16-6433170	6-518634	344	118336	40707584	18-5472370	7-006796
278	77284	21484952	16-6733320	6-526519	345	119025	41063625	18-5741756	7-013579
279	77841	21717633	16-7032931	6-534335	346	119716	41421736	18-6010752	7-020349
280	78400	21952000	16-7332005	6-542133	347	120409	41781923	18-6279360	7-027106
281	78961	22188041	16-7630546	6-549912	348	121104	42144192	18-6547581	7-033850
282	79524	22425764	16-7923556	6-557672	349	121801	42508549	18-6815417	7-040581
283	80089	22665187	16-8226038	6-565414	350	122500	42875000	18-7082869	7-047299
284	80656	22906304	16-8522995	6-573139	351	123201	43243551	18-7349940	7-054004
285	81225	23149125	16-8819430	6-580834	352	123904	43614208	18-7616630	7-060697
286	81796	23393656	16-9115345	6-588532	353	124609	43987977	18-7882942	7-067377
287	82369	23639903	16-9410743	6-596202	354	125316	44364864	18-8149877	7-074044
288	82944	23887872	16-9705627	6-603354	355	126025	44733875	18-8414437	7-080699
289	83521	24137569	17-0000000	6-611489	356	126736	45118016	18-8679623	7-087341
290	84100	24389000	17-0293364	6-619106	357	127449	45519293	18-8944436	7-093971
291	84681	24642171	17-0587221	6-626705	358	128164	45828872	18-9208879	7-100588
292	85264	24897088	17-0880075	6-634237	359	128881	46268279	18-9472953	7-107194
293	85849	25153757	17-1172428	6-641852	360	129600	46693660	18-9736660	7-113787
294	86436	25412184	17-1464232	6-649400	361	130321	47104581	19-0000000	7-120367
295	87025	25672375	17-1756400	6-656930	362	131044	47437928	19-0262976	7-126936
296	87616	25934336	17-2046505	6-664444	363	131769	47832147	19-0525589	7-133492
297	88209	26198073	17-2336979	6-671940	364	132496	48228544	19-0787840	7-140037
298	88804	26463592	17-2626765	6-679429	365	133225	48627125	19-1049732	7-146569
299	89401	26730899	17-2916165	6-686883	366	133956	49027896	19-1311265	7-153090
300	90000	27000000	17-3205081	6-694329	367	134689	49430863	19-1572441	7-159599
301	90601	27270901	17-3493516	6-701759	368	135424	49836032	19-1833261	7-166096
302	91204	27543608	17-3781472	6-709173	369	136161	50243409	19-2093727	7-172581
303	91809	27818127	17-4069952	6-716570	370	136900	50653000	19-2353341	7-179054
304	92416	28094464	17-4359355	6-723951	371	137641	51064811	19-2613603	7-185516
305	93025	28372625	17-4642492	6-731316	372	138384	51478848	19-2873015	7-191966
306	93636	28652616	17-4928557	6-738664	373	139129	51895117	19-3132079	7-198405
307	94249	28934443	17-5214155	6-745997	374	139876	52313624	19-3390796	7-204832
308	94864	29218112	17-5499238	6-753313	375	140625	52734375	19-3649167	7-211248
309	95481	29503629	17-5783358	6-760614	376	141376	53157376	19-3907194	7-217652
310	96100	29791000	17-6068169	6-767899	377	142129	53582633	19-4164878	7-224045
311	96721	30080231	17-6351921	6-775169	378	142884	54010152	19-4422221	7-230427
312	97344	30371328	17-6635217	6-782423	379	143641	54439939	19-4679223	7-236797
313	97969	30664297	17-6918060	6-789661	380	144400	54872000	19-4935897	7-243156
314	98596	30959144	17-7200451	6-796884	381	145161	55306311	19-5192133	7-249504
315	99225	31255575	17-7482393	6-804092	382	145924	55742968	19-5448203	7-255841
316	99856	31554496	17-7763388	6-811235	383	146689	56181887	19-5703853	7-262167
317	100489	31855013	17-8044938	6-818462	384	147456	56623104	19-5959179	7-268482
318	101124	32157432	17-8325545	6-825624	385	148225	57066625	19-6214169	7-274786
319	101761	32461759	17-8605711	6-832771	386	148996	57512456	19-6468827	7-281079
320	102400	32768000	17-8885438	6-839904	387	149769	57960603	19-6723156	7-287362
321	103041	33076161	17-9164729	6-847021	388	150544	58411072	19-6977156	7-293639
322	103684	33386248	17-9443584	6-854124	389	151321	58863869	19-7230829	7-299894
323	104329	33698267	17-9722008	6-861212	390	152100	59319000	19-7484177	7-306144
324	104976	34012224	18-0000000	6-868285	391	152881	59776471	19-7737199	7-312383
325	105625	34328125	18-0277561	6-875344	392	153664	60236258	19-7989899	7-318611
326	106276	34645976	18-0551701	6-882339	393	154449	60698457	19-8242276	7-324829
327	106929	34965783	18-0831413	6-889419	394	155236	61162984	19-8494332	7-331037
328	107584	35287552	18-1107703	6-896435	395	156025	61623875	19-8746069	7-337234
329	108241	35611239	18-1383571	6-903436	396	156816	62099136	19-8997487	7-343420
330	108900	35937000	18-1659021	6-910423	397	157609	62570773	19-9248538	7-349597
331	109561	35264691	18-1934054	6-917336	398	158404	63044792	19-9499373	7-355762
332	110224	36594368	18-2208672	6-924230	399	159201	63521199	19-9749844	7-361918
333	110889	36926037	18-2482376	6-931101	400	160000	64000000	20-0000000	7-368076
334	111556	37259704	18-2756669	6-937932	401	160801	64481201	20-0249844	7-374198
335	112225	37595375	18-3030052	6-945150	402	161604	64964808	20-0499377	7-380323

No.	Square.	Cube.	Sq. Root.	CubeRoot.	No.	Square.	Cube.	Sq. Root.	CubeRoot.
403	162409	65450827	20-0748599	7-336437	470	22-900	103323000	21-6794334	7-774980
404	163216	85939264	20-0997512	7-392542	471	221841	104487111	21-7025344	7-780490
405	164025	66431125	20-1246118	7-398636	472	222784	105151048	21-7255610	7-785993
406	164836	66923116	20-1494417	7-404721	473	223729	105823817	21-7486532	7-791487
407	165 49	67419143	20-1742410	7-410795	474	224676	106496424	21-7715411	7-796974
408	166464	67917312	20-1990099	7-416859	475	225625	107171875	21-7944947	7-802454
409	167281	68419299	20-2237484	7-422914	476	226576	107850176	21-8174242	7-807925
410	168100	68921000	20-2484567	7-428959	477	227529	108531333	21-8403237	7-813389
411	168921	69426131	20-2731349	7-434994	478	228484	109215352	21-8632111	7-818846
412	169744	69934123	20-2977831	7-441019	479	229441	109902239	21-8860686	7-824294
413	170569	70444997	20-3224014	7-447034	480	230400	110592000	21-9089023	7-829735
414	171396	70957944	20-3469399	7-453040	481	231361	111284641	21-9317122	7-835169
415	172225	71473375	20-3715488	7-459036	482	232324	111980168	21-9544934	7-840595
416	173056	71991296	20-3960781	7-465022	483	233289	112678537	21-9772610	7-846013
417	173889	72511173	20-4205779	7-470999	484	234256	113379304	22-0000000	7-851424
418	174724	73034632	20-4450483	7-476966	485	235225	114084125	22-0227155	7-856823
419	175561	73560059	20-4694395	7-482924	486	236196	114791256	22-0454077	7-862224
420	176400	74088000	20-4939015	7-488872	487	237169	115501303	22-0680765	7-867613
421	177241	74618461	20-5182845	7-494811	488	238144	116214272	22-0907220	7-872994
422	178084	75151448	20-5426336	7-500741	489	239121	116930169	22-1133444	7-878368
423	178929	75686967	20-5669638	7-506661	490	240100	117649000	22-1359436	7-883735
424	179776	76225024	20-5912603	7-512571	491	241081	118370771	22-1585198	7-889095
425	180625	76765625	20-6155281	7-518473	492	242064	119095488	22-1810733	7-894447
426	181476	77308776	20-6397674	7-524365	493	243049	119823157	22-2033033	7-899792
427	182329	77854483	20-6639783	7-530248	494	244036	120553784	22-2253174	7-905129
428	183184	78402752	20-6881609	7-536122	495	245025	121287375	22-2485955	7-910460
429	184041	78953589	20-7123152	7-541987	496	246016	122023936	22-2710575	7-915783
430	184900	79507000	20-7364414	7-547842	497	247009	122763473	22-2934963	7-921099
431	185761	80062991	20-7605395	7-553699	498	248004	123505992	22-3159135	7-926403
432	186624	80621568	20-7846097	7-559526	499	249001	124251499	22-3383079	7-931710
433	187489	81182737	20-8086520	7-565355	500	250000	125000000	22-3606798	7-937005
434	188356	81746504	20-8326667	7-571174	501	251001	125751501	22-3830293	7-942223
435	189225	82312875	20-8566536	7-576985	502	252004	126506008	22-4053665	7-947574
436	190096	82881836	20-8806130	7-582786	503	253009	127263527	22-4276515	7-952818
437	190969	83453453	20-9045450	7-588579	504	254016	128024064	22-4499443	7-958114
438	191844	84027672	20-9284495	7-594363	505	255025	128787623	22-4722051	7-963371
439	192721	84603419	20-9523268	7-600133	506	256036	129554216	22-4944438	7-968624
440	193600	85180400	20-9761770	7-605905	507	257049	130323843	22-5166653	7-973873
441	194481	8576121	21-0000000	7-611663	508	258064	131096512	22-5388553	7-979112
442	195364	86350388	21-0237960	7-617412	509	259081	131872229	22-5610283	7-984344
443	196249	86939807	21-0475652	7-623152	510	260100	132651000	22-5831796	7-989570
444	197136	87529384	21-0713375	7-628884	511	261121	133432831	22-6053091	7-994788
445	198025	88121125	21-0950231	7-634607	512	262144	134217728	22-6274170	8-000000
446	198916	88716536	21-1187121	7-640321	513	263169	135005697	22-6495033	8-005200
447	199809	89314623	21-1423745	7-646027	514	264196	135796744	22-6715681	8-010403
448	200704	89915392	21-1660105	7-651725	515	265225	136590875	22-6936114	8-015595
449	201601	90518849	21-1896201	7-657414	516	266256	137388036	22-7156334	8-020779
450	202500	91125000	21-2132034	7-663094	517	267289	138188413	22-7376340	8-025957
451	203401	91733851	21-2367606	7-668766	518	268324	138991832	22-7596134	8-031129
452	204304	92345403	21-2602916	7-674430	519	269361	139798359	22-7815715	8-036229
453	205209	92959677	21-2839767	7-680086	520	270400	140608000	22-8035085	8-041451
454	206116	93576664	21-3072758	7-685733	521	271441	141420761	22-8254444	8-046603
455	207025	94196375	21-3307290	7-691372	522	272484	142236648	22-8473153	8-051748
456	207936	94818816	21-3541565	7-697002	523	273529	143055667	22-8691933	8-056886
457	208849	95443993	21-3775583	7-702625	524	274576	143877824	22-8910463	8-062018
458	209764	96071912	21-4009346	7-708239	525	275625	144703129	22-9128785	8-067143
459	210681	96702579	21-4242356	7-713845	526	276676	145531576	22-9346999	8-072262
460	211600	97336000	21-4476103	7-719443	527	277729	146363183	22-9565106	8-077374
461	212521	97972181	21-4709106	7-725032	528	278784	147197952	22-9782505	8-082480
462	213444	98611128	21-4941853	7-730614	529	279841	148035889	23-0000000	8-087579
463	214369	99252847	21-5174348	7-736189	530	280900	148877000	23-0217289	8-092672
464	215296	99897344	21-5406592	7-741753	531	281961	149721291	23-0434372	8-097759
465	216225	100544625	21-5633587	7-747311	532	283024	150568868	23-0651252	8-102839
466	217156	101194696	21-5860331	7-752861	533	284089	151419437	23-0867928	8-107913
467	218089	101847563	21-6101828	7-758402	534	285156	152273304	23-1084400	8-112980
468	219024	102503232	21-6333077	7-763936	535	286225	153130375	23-1300670	8-118041
469	219961	103161709	21-6564078	7-769462	536	287296	153990656	23-1516738	8-123099

No.	Square.	Cube.	Sq. Root.	CubeRoot.	No.	Square.	Cube.	Sq. Root.	CubeRoot.
537	288369	154854153	23-1732605	8-123145	604	34816	220348964	24-5764115	8-453028
538	239444	155720872	23-1948370	8-133187	605	36025	221445125	24-5967478	8-457691
539	290521	156590819	23-2163735	8-133223	606	37236	222545016	24-6170673	8-462348
540	291600	157464000	23-2379001	8-143253	607	38449	223648543	24-6373700	8-467000
541	292681	158340481	23-2594067	8-148276	608	39664	224755712	24-6576560	8-471617
542	293764	159220298	23-2803935	8-153294	609	370881	225866529	24-6773254	8-476293
543	294849	160103007	23-3023604	8-158305	610	372100	226981000	24-6981781	8-480926
544	295936	160989184	23-3233076	8-163310	611	373321	228099131	24-7184142	8-485558
545	297025	161873625	23-3452351	8-168309	612	374554	229220928	24-7386338	8-490185
546	298116	162771336	23-3666429	8-173302	613	375799	230346397	24-7588358	8-494806
547	299209	163667323	23-3883011	8-178239	614	376996	231475544	24-7790231	8-499423
548	300304	164566592	23-4093998	8-183269	615	378225	232603375	24-7991935	8-504035
549	301401	165469149	23-4307490	8-188244	616	379456	233744395	24-8193473	8-508642
550	302500	166375000	23-4523788	8-193213	617	380689	234888513	24-8394347	8-513243
551	303601	167284151	23-4733392	8-198175	618	381924	236029032	24-8596058	8-517840
552	304704	168196608	23-4946802	8-203132	619	383161	237176659	24-8797106	8-522432
553	305809	169112377	23-5159520	8-208032	620	384400	238332800	24-8997992	8-527019
554	306916	170031464	23-5372046	8-213027	621	385641	239493501	24-9198716	8-531601
555	308025	170953975	23-5534380	8-217966	622	386884	240641848	24-9399278	8-536178
556	309136	171879616	23-5796522	8-222893	623	388129	241804367	24-9599473	8-540750
557	310249	172808693	23-6003474	8-227825	624	389376	242970624	24-9799920	8-545317
558	311364	173741112	23-6220236	8-232746	625	390625	244140625	25-0000000	8-549880
559	312481	174676879	23-6431808	8-237661	626	391876	245314376	25-0199921	8-554437
560	313600	175616000	23-6643191	8-242571	627	393129	246491833	25-0399681	8-558990
561	314721	176558481	23-6854386	8-247474	628	394384	247673152	25-0599282	8-563538
562	315844	177504328	23-7065392	8-252371	629	395641	248858189	25-0797244	8-568081
563	316969	178453547	23-7276210	8-257263	630	396900	250047000	25-0993005	8-572619
564	318096	179406144	23-7486842	8-262149	631	398161	251239531	25-1197134	8-577152
565	319225	180362125	23-7697285	8-267029	632	399424	252435968	25-1396102	8-581681
566	320356	181321496	23-7907545	8-271904	633	400689	253636337	25-1594913	8-586205
567	321489	182284263	23-8117618	8-276773	634	401956	254840104	25-1793566	8-590724
568	322624	183250432	23-8327506	8-281635	635	403225	256047375	25-1992263	8-595238
569	323761	184220009	23-8537209	8-286493	636	404496	257259456	25-2190404	8-599748
570	324900	185193000	23-8746728	8-291344	637	405769	258474853	25-2383539	8-604252
571	326041	186169411	23-8956063	8-296190	638	407044	259694072	25-2586619	8-608753
572	327184	187149248	23-9165215	8-301033	639	408321	260917119	25-2784493	8-613248
573	328329	188132517	23-9374184	8-305865	640	409600	262144000	25-2982213	8-617739
574	329476	189119224	23-9582971	8-310694	641	410881	263374721	25-3179778	8-622225
575	330625	190109375	23-9791576	8-315517	642	412164	264609283	25-3377189	8-626706
576	331776	191102976	24-0000000	8-320345	643	413449	265847707	25-3574447	8-631183
577	332929	192100033	24-0208243	8-325174	644	414736	267089894	25-3771551	8-635655
578	334084	193100552	24-0416306	8-329954	645	416025	268336125	25-3968502	8-640123
579	335241	194104539	24-0624188	8-334755	646	417316	269586136	25-4165301	8-644555
580	336400	195112000	24-0831891	8-339551	647	418609	270840023	25-4361947	8-649044
581	337561	196122941	24-1039416	8-344341	648	419904	272097792	25-4558384	8-653497
582	338724	197137368	24-1246762	8-349126	649	421201	273359419	25-4754784	8-657946
583	339889	198155287	24-1453929	8-353905	650	422500	274625000	25-4950976	8-662391
584	341056	199176704	24-1660919	8-358678	651	423801	275894451	25-5147016	8-666831
585	342225	200201625	24-1867732	8-363447	652	425104	277167808	25-5342907	8-671266
586	343396	201230055	24-2074369	8-368209	653	426409	278445077	25-5538647	8-675797
587	344569	202262003	24-2280829	8-372967	654	427716	279726264	25-5734237	8-680324
588	345744	203297472	24-2487113	8-377719	655	429025	281011375	25-5929678	8-684846
589	346921	204336469	24-2693222	8-382465	656	430336	282300416	25-6124969	8-689363
590	348100	205379000	24-2899156	8-387206	657	431649	283593393	25-6320112	8-693876
591	349281	206425071	24-3104916	8-391942	658	432964	284890416	25-6515107	8-698381
592	350464	207474683	24-3310501	8-396673	659	434281	286191179	25-6709953	8-702888
593	351649	208527857	24-3515913	8-401398	660	435600	287496000	25-6904652	8-707388
594	352836	209584584	24-3721152	8-406118	661	436921	288804781	25-7099203	8-711883
595	354025	210644875	24-3926218	8-410833	662	438244	290117528	25-7293607	8-716373
596	355216	211708736	24-4131112	8-415542	663	439569	291434247	25-7487864	8-720860
597	356409	212776173	24-4335834	8-420245	664	440896	292754944	25-7681975	8-725341
598	357604	213847192	24-4540385	8-424945	665	442225	294079625	25-7875939	8-729818
599	358801	214921799	24-4744765	8-429633	666	443556	295408296	25-8069758	8-734292
600	360000	216000000	24-4948974	8-434327	667	444889	296740953	25-8263431	8-738760
601	361201	217083181	24-5153013	8-439010	668	446224	298077632	25-8456469	8-743225
602	362404	218167208	24-5356933	8-443688	669	447561	299418309	25-8650343	8-747695
603	363609	219256227	24-5560593	8-448360	670	448900	300763000	25-8845282	8-752160

No.	Square.	Cube.	Sq. Root.	CubeRoot.	No.	Square.	Cube.	Sq. Root.	CubeRoot.
671	450241	302111711	25-9036677	8-754691	738	544644	401947272	27-1661554	9-036886
672	451534	303464448	25-9229628	8-759033	739	546121	403533419	27-1845544	9-040965
673	452929	304821217	25-9422435	8-763331	740	547600	405226020	27-2029110	9-045042
674	454276	306182024	25-9615100	8-767719	741	549081	406636901	27-2213152	9-049114
675	455625	307546875	25-9807621	8-772053	742	550564	408518488	27-2367659	9-053183
676	456976	308915776	26-0000000	8-776333	743	552049	410172407	27-2520323	9-057248
677	458329	310288733	26-0192237	8-780708	744	553536	411830784	27-2673634	9-061310
678	459684	311665752	26-0384331	8-785030	745	555025	413493625	27-2946881	9-065368
679	461041	313046839	26-0576284	8-789347	746	556516	415160936	27-3130066	9-069422
680	462400	314432000	26-0768306	8-793659	747	558009	416832723	27-3313007	9-073473
681	463761	315821241	26-0959767	8-797968	748	559504	418508992	27-3495357	9-077520
682	465124	317214568	26-1151297	8-802272	749	561001	420189749	27-3678644	9-081563
683	466489	318611987	26-1342687	8-806572	750	562500	421874000	27-3861279	9-085603
684	467856	320013504	26-1533937	8-810868	751	564001	423561751	27-4043792	9-089633
685	469225	321419125	26-1725047	8-815160	752	565504	425252008	27-4226184	9-093672
686	470596	322828856	26-1916167	8-819447	753	567009	426945777	27-4403455	9-097710
687	471969	324242703	26-2106848	8-823731	754	568516	428643064	27-4590634	9-101726
688	473344	325660672	26-2297541	8-828010	755	570025	430343887	27-4772633	9-105748
689	474721	327082769	26-2488095	8-832285	756	571536	432048216	27-4954542	9-109767
690	476100	328509000	26-2678511	8-836556	757	573049	433756063	27-5136330	9-113782
691	477481	329939371	26-2868789	8-840823	758	574564	435468512	27-5317998	9-117793
692	478864	331373888	26-3058929	8-845085	759	576081	437185579	27-5499546	9-121801
693	480249	332812557	26-3248932	8-849344	760	577600	438907000	27-5680975	9-125805
694	481636	334255384	26-3438777	8-853598	761	579121	440632881	27-5862284	9-129806
695	483025	335702375	26-3628527	8-857849	762	580644	442363224	27-6043475	9-133803
696	484416	337153536	26-3818119	8-862095	763	582169	444109049	27-6224546	9-137797
697	485809	338608873	26-4007576	8-866337	764	583696	445869374	27-6405493	9-141787
698	487204	340069392	26-4196896	8-870576	765	585225	447644299	27-6586339	9-145774
699	488601	341535099	26-4386081	8-874810	766	586756	449434836	27-6767055	9-149758
700	490000	343006000	26-4575131	8-879040	767	588289	451240987	27-6947648	9-153737
701	491401	344472101	26-4764046	8-883266	768	589824	453062852	27-7128129	9-157714
702	492804	345943408	26-4952826	8-887483	769	591361	454890361	27-7308492	9-161687
703	494209	347420927	26-5141472	8-891706	770	592900	456733500	27-7488739	9-165656
704	495616	348904656	26-5329983	8-895920	771	594441	458592241	27-7668868	9-169622
705	497025	350394605	26-5518361	8-900136	772	595984	460466596	27-7848980	9-173536
706	498436	351890784	26-5706605	8-904337	773	597529	462356567	27-8029075	9-177544
707	499849	353393203	26-5894716	8-908537	774	599076	464262156	27-8209155	9-181500
708	501264	354894912	26-6082694	8-912737	775	600625	466183375	27-8389218	9-185453
709	502681	356400009	26-6270539	8-916931	776	602176	468119124	27-8569266	9-189402
710	504100	357910480	26-6458252	8-921121	777	603729	469970433	27-8749197	9-193347
711	505521	359426331	26-6645833	8-925308	778	605284	471837204	27-8929051	9-197290
712	506944	360947568	26-6833281	8-929490	779	606841	473719549	27-9108715	9-201229
713	508369	362474197	26-7020598	8-933669	780	608400	475617500	27-9288201	9-205164
714	509796	363996224	26-7207784	8-937843	781	609961	477531061	27-9467622	9-209096
715	511225	365523675	26-7394839	8-942014	782	611524	479460236	27-9647089	9-213025
716	512656	367056560	26-7580763	8-946181	783	613089	481405037	27-9826592	9-216950
717	514089	368594881	26-7766537	8-950344	784	614656	483365964	28-0006000	9-220875
718	515524	370138632	26-7952200	8-954503	785	616225	485343017	28-0176515	9-224791
719	516961	371687819	26-8137754	8-958658	786	617796	487336200	28-0346915	9-228707
720	518400	373242400	26-8323157	8-962809	787	619369	489345521	28-0517300	9-232619
721	519841	374802381	26-8508432	8-966957	788	620944	491360884	28-0687677	9-236528
722	521284	376367764	26-8693577	8-971101	789	622521	493393309	28-0858043	9-240435
723	522729	377938567	26-8878533	8-975241	790	624100	495432800	28-1028400	9-244333
724	524176	379514784	26-9063281	8-979377	791	625681	497489357	28-1208722	9-248234
725	525625	381096425	26-9247840	8-983509	792	627264	499562080	28-1389029	9-252130
726	527076	382683504	26-9432217	8-987637	793	628849	501650981	28-1569312	9-256022
727	528529	384276033	26-9616375	8-991762	794	630436	503756164	28-1749578	9-259911
728	529984	385874064	26-9800351	8-995883	795	632025	505877637	28-1929824	9-263797
729	531441	387477609	26-1000000	9-000000	796	633616	508015500	28-2109970	9-267680
730	532900	389087600	26-10185122	9-004113	797	635209	510169853	28-2289184	9-271559
731	534361	390704041	26-10370117	9-008223	798	636804	512340800	28-2468373	9-275435
732	535824	392326984	26-10554985	9-012329	799	638401	514528339	28-2647538	9-279306
733	537289	393956433	26-10740727	9-016431	800	640000	516732480	28-2826672	9-283178
734	538756	395592384	26-10926344	9-020529	801	641601	518953221	28-3005774	9-287044
735	540225	397234837	26-11111834	9-024621	802	643204	521189564	28-3184840	9-290907
736	541696	398882800	26-11297199	9-028715	803	644809	523441509	28-3363876	9-294776
737	543169	400536273	26-11477439	9-032802	804	646416	525709056	28-3542883	9-298624

No.	Square.	Cube.	Sq. Root.	CubeRoot.	No.	Square.	Cube.	Sq. Root.	CubeRoot.
805	648025	521660125	28 3725219	9-302477	872	760384	663054848	28-5296461	9-553712
806	649636	523606616	28 3901991	9-306323	873	762129	665333617	29-5465734	9-557363
807	651249	525557943	28 4077454	9-310175	874	763876	667627624	29-5634910	9-561011
808	652864	527514112	28 4253408	9-314019	875	765623	669921875	29-5803989	9-564656
809	654481	529475129	28 4429253	9-317860	876	767376	672221376	29-5972972	9-568298
810	656100	531441000	28 4604989	9-321697	877	769129	674526133	29-6141858	9-571938
811	657721	533411731	28 4780617	9-325532	878	770884	676836152	29-6310648	9-575574
812	659344	535387328	28 4956137	9-329363	879	772641	679151439	29-6479342	9-579208
813	660969	537367797	28 5131549	9-333192	880	774400	681472000	29-6647939	9-582840
814	662596	539353144	28 5306852	9-337017	881	776161	683797841	29-6816442	9-586468
815	664225	541343375	28 5482048	9-340839	882	777924	686128968	29 6984843	9-590094
816	665856	543338496	28 5657137	9-344657	883	779689	688465387	29-7153159	9-593717
817	667489	545338513	28 5832119	9-348473	884	781456	690807104	29-7321375	9-597337
818	669124	547343432	28 6006993	9-352286	885	783225	693154125	29-7489496	9-600955
819	670761	549353259	28 6181760	9-356095	886	784996	695506456	29-7657521	9-604570
820	672400	551368000	28 6356421	9-359902	887	786769	697864103	29-7825452	9-608182
821	674041	553387661	28 6530976	9-363705	888	788544	700227072	29-7993239	9-611791
822	675684	555412248	28 6705424	9 367505	889	790321	702595369	29-8161030	9-615393
823	677329	557441767	28 6879766	9-371302	890	792100	704969600	29-8328678	9-619002
824	678976	559476224	28 7054002	9-375096	891	793881	707347971	29-8496231	9-622603
825	680625	561515625	28 7228132	9-378887	892	795664	709732288	29-8663690	9-626202
826	682276	563559976	28 7402157	9-382675	893	797449	712121957	29-8831056	9-629797
827	683929	565609283	28 7576077	9-386460	894	799236	714516994	29-8998328	9-633391
828	685584	567663552	28 7749891	9-390242	895	801025	716917375	29-9165550	9-636981
829	687241	569722789	28 7923601	9-394021	896	802816	719323136	29-9332591	9-640569
830	688900	571787000	28 8097206	9-397796	897	804609	721734273	29-9499533	9-644154
831	690561	573856191	28 8270706	9-401569	898	806404	724150792	29-9666481	9-647737
832	692224	575930368	28 8444102	9-405339	899	808201	726572695	29-9833287	9-651317
833	693889	578009537	28 8617394	9-409105	900	810000	729000000	30-0000000	9-654894
834	695556	580093704	28 8790552	9-412869	901	811801	731432701	30-0166620	9-658468
835	697225	582182875	28 8963666	9-416630	902	813604	733870808	30-0333148	9-662040
836	698896	584277056	28 9136646	9-420387	903	815409	736314327	30-0499584	9-665610
837	700569	586376253	28 9309523	9-424144	904	817216	738763264	30-0665322	9-669176
838	702244	588480472	28 9482297	9-427894	905	819025	741217625	30-0832179	9-672740
839	703921	590589719	28 9654967	9-431642	906	820836	743677416	30-0998339	9-676302
840	705600	592704000	28 9827535	9-435388	907	822649	746142643	30-1164407	9-679860
841	707281	594823321	29 0000000	9-439131	908	824464	748613312	30-1330383	9-683417
842	708964	596947688	29 0172363	9-442870	909	826281	751089429	30-1496263	9-686970
843	710649	599077107	29 0344623	9-446607	910	828100	753571000	30-1662069	9-690522
844	712336	601211584	29 0516781	9-450341	911	829921	756053031	30-1827765	9-694069
845	714025	603351125	29 0688837	9-454072	912	831744	758550528	30-1993377	9-697615
846	715716	605495736	29 0860791	9-457800	913	833569	761048197	30-2158399	9-701158
847	717409	607645423	29 1032644	9-461525	914	835396	763551944	30-2324329	9-704699
848	719104	609800192	29 1204396	9-465247	915	837225	766066875	30-2489639	9-708237
849	720801	611960049	29 1376046	9-468966	916	839056	768595296	30-2654919	9-711772
850	722500	614125000	29 1547595	9-472682	917	840889	771095213	30-2820079	9-715305
851	724201	616295051	29 1719043	9-476396	918	842724	773620632	30-2985148	9-718835
852	725904	618470208	29 1890390	9-480106	919	844561	776151559	30-3150128	9-722363
853	727609	620650477	29 2061637	9-483814	920	846400	778698000	30-3315018	9-725888
854	729316	622835864	29 2232784	9-487518	921	848241	781252961	30-3479818	9-729411
855	731025	625026375	29 2403830	9-491220	922	850084	783827448	30-3644529	9-732931
856	732736	627222016	29 2574777	9-494919	923	851929	786330467	30-3809151	9-736448
857	734449	629422793	29 2745623	9-498615	924	853776	788899024	30-3973683	9-739963
858	736164	631628512	29 2916370	9-502308	925	855625	791453125	30-4138127	9-743476
859	737881	633839779	29 3087018	9-505998	926	857476	794022776	30-4302481	9-746986
860	739600	636056000	29 3257566	9-509685	927	859329	796597983	30-4466747	9-750493
861	741321	638277381	29 3428015	9-513370	928	861184	799178532	30-4630924	9-753998
862	743044	640503928	29 3598365	9-517055	929	863041	801763509	30-4795013	9-757500
863	744769	642735647	29 3768616	9-520730	930	864900	804357000	30-4959014	9-761004
864	746496	644972544	29 3938769	9-524406	931	866761	806955491	30-5122926	9-764497
865	748225	647214625	29 4108823	9-528090	932	868624	809557568	30-5286750	9-767992
866	749956	649461896	29 4278779	9-531750	933	870489	812166237	30-5450487	9-771484
867	751689	651714363	29 4448637	9-535417	934	872356	814780504	30-5614136	9-774974
868	753424	653972032	29 4618397	9-539082	935	874225	817400375	30-5777697	9-778462
869	755161	656234909	29 4788059	9-542744	936	876096	820025536	30-5941171	9-781947
870	756900	658503000	29 4957624	9-546403	937	877969	822656993	30-6104557	9-785429
871	758641	660776311	29 5127021	9-550059	938	879844	825293672	30-6267857	9-788909

No.	Square.	Cube.	Sq. Root.	CubeRoot.	No.	Square.	Cube.	Sq. Root.	CubeRoot.
939	881721	827936019	30-6431069	9-792386	970	940900	912673000	31-1448230	9-898983
940	883600	830584000	30-6594194	9-795361	971	942341	915498611	31-1608729	9-902333
941	885481	833237621	30-6757233	9-799334	972	944784	918330048	31-1769145	9-905782
942	887364	835996888	30-6920185	9-802804	973	946729	921167317	31-1929479	9-909178
943	889249	838561807	30-7083051	9-806271	974	948676	924010424	31-2089731	9-912571
944	891136	841232334	30-7245930	9-809736	975	950625	926859375	31-2249900	9-915962
945	893025	843908625	30-7408523	9-813199	976	952576	929714176	31-2409987	9-919351
946	894916	846590536	30-7571130	9-816659	977	954529	932574833	31-2569992	9-922733
947	896809	849278123	30-7733651	9-820117	978	956484	935441352	31-2729915	9-926122
948	898704	851971392	30-7896086	9-823572	979	958441	938313739	31-2889757	9-929504
949	900601	854670349	30-8058436	9-827025	980	960400	941192000	31-3049517	9-932834
950	902500	857375000	30-8220700	9-830476	981	962361	944076141	31-3209195	9-936261
951	904401	860085351	30-8382924	9-833924	982	964324	946966168	31-3368792	9-939635
952	906304	862801408	30-8544972	9-837369	983	966289	949862087	31-3528308	9-943009
953	908209	865523177	30-8706981	9-840813	984	968256	952763904	31-3687743	9-946380
954	910116	868250664	30-8868904	9-844254	985	970225	955671625	31-3847097	9-949749
955	912025	870983875	30-9030743	9-847692	986	972196	958585256	31-4006369	9-953114
956	913936	873722816	30-9192497	9-851128	987	974169	961504303	31-4165561	9-956477
957	915849	876467493	30-9354166	9-854562	988	976144	964430271	31-4324673	9-959839
958	917764	879217912	30-9515751	9-857993	989	978121	967361669	31-4483704	9-963198
959	919681	881974079	30-9677251	9-861422	990	980100	970299000	31-4642654	9-966555
960	921600	884736000	30-9838668	9-864848	991	982081	973242271	31-4801525	9-969909
961	923521	887503681	31-0000000	9-868272	992	984064	976191488	31-4960315	9-973262
962	925444	890277128	31-0161248	9-871694	993	986049	979146657	31-5119025	9-976612
963	927369	893056347	31-0322413	9-875113	994	988036	982107784	31-5277655	9-979960
964	929296	895841344	31-0483494	9-878530	995	990025	985071875	31-5436206	9-983305
965	931225	898632125	31-0644491	9-881945	996	992016	988047936	31-5594677	9-986649
966	933156	901428696	31-0805405	9-885357	997	994009	991026973	31-5753068	9-989990
967	935089	904231063	31-0966236	9-888767	998	996004	994011992	31-5911380	9-993329
968	937024	907039232	31-1126984	9-892175	999	998001	997002999	31-6069613	9-996666
969	938961	909853209	31-1287648	9-895580	1000	1000000	1000000000	31-6227766	10-000000

The following rules are for finding the squares, cubes and roots, of numbers exceeding 1,000.

To find the square of any number divisible without a remainder. *Rule.*—Divide the given number by such a number, from the foregoing table, as will divide it without a remainder; then the square of the quotient, multiplied by the square of the number found in the table, will give the answer.

Example.—What is the square of 2,000? 2,000, divided by 1,000, a number found in the table, gives a quotient of 2, the square of which is 4, and the square of 1,000 is 1,000,000, therefore :

$$4 \times 1,000,000 = 4,000,000 : \text{the Ans.}$$

Another example.—What is the square of 1,230? 1,230, being divided by 123, the quotient will be 10, the square of which is 100, and the square of 123 is 15,129, therefore :

$$100 \times 15,129 = 1,512,900 : \text{the Ans.}$$

To find the square of any number not divisible without a remainder. *Rule.*—Add together the squares of such two adjoining numbers, from the table, as shall together equal the given number, and multiply the sum by 2; then this product, less 1, will be the answer.

Example.—What is the square of 1,487? The adjoining numbers, 743 and 744, added together, equal the given number, 1,487, and the square of 743 = 552,049, the square of 744 = 553,536, and these added, = 1,105,585, therefore :

$$1,105,585 \times 2 = 2,211,170 - 1 = 2,211,169 : \text{the Ans.}$$

To find the cube of any number divisible without a remainder. *Rule.*—Divide the given number by such a number, from the forego-

ing table, as will divide it without a remainder; then, the cube of the quotient, multiplied by the cube of the number found in the table, will give the answer.

Example.—What is the cube of 2,700? 2,700, being divided by 900, the quotient is 3, the cube of which is 27, and the cube of 900 is 729,000,000, therefore:

$$27 \times 729,000,000 = 19,683,000,000 : \text{the Ans.}$$

To find the square or cube root of numbers higher than is found in the table. *Rule.*—Select, in the column of squares or cubes, as the case may require, that number which is nearest the given number; then the answer, when decimals are not of importance, will be found directly opposite in the column of numbers.

Example.—What is the square-root of 87,620? In the column of squares, 87,616 is nearest to the given number; therefore, 296, immediately opposite in the column of numbers, is the answer, nearly.

Another example.—What is the cube-root of 110,591? In the column of cubes, 110,592 is found to be nearest to the given number; therefore, 48, the number opposite, is the answer, nearly.

To find the cube-root more accurately. *Rule.*—Select, from the column of cubes, that number which is nearest the given number, and add twice the number so selected to the given number; also, add twice the given number to the number selected from the table. Then, as the former product is to the latter, so is the root of the number selected to the root of the number given.

Example.—What is the cube-root of 9,200? The nearest number in the column of cubes is 9,261, the root of which is 21, therefore:

9261	9200
2	2
18522	18400
9200	9261

As 27,722 is to 27,661, so is 21 to 20·953 — the Ans.

Thus, $27661 \times 21 = 580881$, and this divided by $27722 = 20·953 +$

To find the square or cube root of a whole number with decimals. *Rule.*—Subtract the root of the whole number from the root of the next higher number, and multiply the remainder by the given decimal; then the product, added to the root of the given whole number, will give the answer correctly to three places of decimals in the square root, and to seven in the cube root.

Example.—What is the square-root of 11·14? The square-root of 11 is 3·3166, and the square-root of the next higher number, 12, is 3·4641; the former from the latter, the remainder is 0·1475, and this by 0·14 equals 0·02065. This added to 3·3166, the sum, 3·33725, is the square root of 11·14.

To find the roots of decimals by the use of the table. *Rule.*—Seek for the given decimal in the column of numbers, and opposite in the columns of roots will be found the answer, correct as to the figures, but requiring the decimal point to be shifted. The transposition of the decimal point is to be performed thus: For every place the decimal point is removed in the root, remove it in the number *two* places for the *square* root and *three* places for the *cube* root.

Examples.—By the table the square root of 86·0 is 9·2736, consequently, by the rule the square root of 0·86 is 0·92736. The square root of 9 is 3; hence the square root of 0·09 is 0·3. For the square root of 0·0657 we have 0·25632; found opposite No. 657. So, also, the square root of 0·000927 is 0·030446, found opposite No. 927. And the square root of 8·73 (whole number with decimals) is 2·9546, found opposite No. 873. The cube root of 0·8 is 0·928, found at No. 800; the cube root of 0·08 is 0·4308, found opposite No. 80, and the cube root of 0·008 is 0·2, as 2·0 is the cube root of 8·0. So also the cube root of 0·047 is 0·36088, found opposite No. 47.

RULES FOR THE REDUCTION OF DECIMALS.

To reduce a fraction to its equivalent decimal. Rule.—Divide the numerator by the denominator, annexing cyphers as required.

Example.—What is the decimal of a foot equivalent to 3 inches?

3 inches is $\frac{3}{12}$ of a foot, therefore:

$$\begin{array}{r} 12 \overline{) 3\cdot00} \\ \underline{0} \\ 00 \\ \underline{00} \\ 00 \\ \underline{00} \\ 00 \end{array}$$

·25 Ans.

Another example.—What is the equivalent decimal of $\frac{7}{8}$ of an inch?

$$\begin{array}{r} 8 \overline{) 7\cdot000} \\ \underline{0} \\ 00 \\ \underline{00} \\ 00 \\ \underline{00} \\ 00 \end{array}$$

·875 Ans.

To reduce a compound fraction to its equivalent decimal. Rule.—In accordance with the preceding rule, reduce each fraction, commencing at the lowest, to the decimal of the next higher denomination, to which add the numerator of the next higher fraction, and reduce the sum to the decimal of the next higher denomination, and so proceed to the last; and the final product will be the answer.

Example.—What is the decimal of a foot equivalent to 5 inches, $\frac{3}{8}$ and $\frac{1}{6}$ of an inch.

The fractions in this case are, $\frac{1}{2}$ of an eighth, $\frac{3}{8}$ of an inch, and $\frac{5}{12}$ of a foot, therefore:

$$\begin{array}{r} 12 \overline{) 1\cdot0} \\ \underline{0} \\ 0 \\ \underline{0} \\ 0 \\ \underline{0} \\ 0 \end{array}$$

·5
3· eighths.

$$\begin{array}{r} 8 \overline{) 3\cdot5000} \\ \underline{0} \\ 50 \\ \underline{00} \\ 00 \\ \underline{00} \\ 00 \end{array}$$

·4375
5· inches.

$$\begin{array}{r} 12 \overline{) 5\cdot437500} \\ \underline{0} \\ 43 \\ \underline{00} \\ 75 \\ \underline{00} \\ 00 \\ \underline{00} \\ 00 \end{array}$$

·453125 Ans.

The process may be condensed, thus; write the numerators of the given fractions, from the least to the greatest, under each other, and place each denominator to the left of its numerator, thus :

$$\begin{array}{r|l}
 \frac{1}{2} \dots\dots 2 & .10 \\
 \frac{3}{8} \dots\dots 8 & 3\cdot5000 \\
 \frac{5}{12} \dots\dots 12 & 5\cdot437500 \\
 \hline
 & \cdot453125 \text{ Ans.}
 \end{array}$$

To reduce a decimal to its equivalent in terms of lower denominations.
Rule.—Multiply the given decimal by the number of parts in the next less denomination, and point off from the product as many figures to the right hand, as there are in the given decimal; then multiply the figures pointed off, by the number of parts in the next lower denomination, and point off as before, and so proceed to the end; then the several figures pointed off to the left will be the answer.

Example.—What is the expression in inches of 0·390625 feet?

$$\begin{array}{r}
 \text{Feet } 0\cdot390625 \\
 \text{12 inches in a foot.} \\
 \hline
 \text{Inches } 4\cdot687500 \\
 \quad 8 \text{ eighths in an inch.} \\
 \hline
 \text{Eighths } 5\cdot5000 \\
 \quad 2 \text{ sixteenths in an eighth.} \\
 \hline
 \text{Sixteenth } 1\cdot0
 \end{array}$$

Ans., 4 inches, $\frac{5}{8}$ and $\frac{1}{16}$.

Another example.—What is the expression, in fractions of an inch, of 0·6875 inches?

$$\begin{array}{r}
 \text{Inches } 0\cdot6875 \\
 \text{8 eighths in an inch.} \\
 \hline
 \text{Eighths } 5\cdot5000 \\
 \quad 2 \text{ sixteenths in an eighth.} \\
 \hline
 \text{Sixteenth } 1\cdot0
 \end{array}$$

Ans., $\frac{5}{8}$ and $\frac{1}{16}$.

TABLE OF CIRCLES.

(From Gregory's Mathematics.)

From this table may be found by inspection the area or circumference of a circle of any diameter, and the side of a square equal to the area of any given circle from 1 to 100 inches, feet, yards, miles, &c. If the given diameter is in inches, the area, circumference, &c., set opposite, will be inches; if in feet, then feet, &c.

Diam.	Area.	Circum.	Side of equal sq.	Diam.	Area.	Circum.	Side of equal sq.
.25	.04908	.78539	.22155	.75	90.70257	33.77212	9.52693
.5	.19635	1.57079	.44311	11.	95.03317	34.55751	9.74819
.75	.44178	2.35619	.66467	.25	99.40195	35.34291	9.97005
1.	.78539	3.14159	.88622	.5	103.86890	36.12331	10.19160
.25	1.22718	3.92699	1.10778	.75	108.43403	36.91371	10.41316
.5	1.76714	4.71238	1.32934	12.	113.09733	37.69911	10.63472
.75	2.40528	5.49773	1.55089	.25	117.85881	38.48451	10.85627
2.	3.14159	6.28318	1.77245	.5	122.71846	39.26990	11.07783
.25	3.97607	7.06858	1.99401	.75	127.67628	40.05530	11.29939
.5	4.90873	7.85398	2.21556	13.	132.73228	40.84070	11.52095
.75	5.93957	8.63937	2.43712	.25	137.88646	41.62610	11.74250
3.	7.06858	9.42477	2.65368	.5	143.13881	42.41150	11.96406
.25	8.29576	10.21017	2.85023	.75	148.48934	43.19689	12.18562
.5	9.62112	10.99557	3.10179	14.	153.93804	43.98229	12.40717
.75	11.04466	11.78097	3.32335	.25	159.48491	44.76769	12.62873
4.	12.56637	12.56637	3.54490	.5	165.12996	45.55309	12.85029
.25	14.18625	13.35176	3.76646	.75	170.87318	46.33349	13.07184
.5	15.90431	14.13716	3.98802	15.	176.71458	47.12338	13.29340
.75	17.72054	14.92256	4.20957	.25	182.65416	47.90925	13.51496
5.	19.63495	15.70796	4.43113	.5	188.69190	48.69468	13.73651
.25	21.64753	16.49336	4.65269	.75	194.82783	49.48008	13.95807
.5	23.75829	17.27875	4.87424	16.	201.06192	50.26548	14.17963
.75	25.96722	18.06415	5.09580	.25	207.39420	51.05088	14.40118
6.	28.27433	18.84955	5.31736	.5	213.82464	51.83627	14.62274
.25	30.67961	19.63495	5.53891	.75	220.35327	52.62167	14.84430
.5	33.18307	20.42035	5.76047	17.	226.98006	53.40707	15.06535
.75	35.78470	21.20575	5.98203	.25	233.70504	54.19247	15.28741
7.	38.48456	21.99114	6.20358	.5	240.52818	54.97787	15.50897
.25	41.28249	22.77654	6.42514	.75	247.44950	55.76326	15.73052
.5	44.17864	23.56194	6.64670	18.	254.46900	56.54866	15.95208
.75	47.17297	24.34734	6.86825	.25	261.58667	57.33406	16.17364
8.	50.26548	25.13274	7.08981	.5	268.80252	58.11946	16.39519
.25	53.45616	25.91813	7.31137	.75	276.11654	58.90486	16.61675
.5	56.74501	26.70353	7.53292	19.	283.52873	59.69026	16.83831
.75	60.13204	27.48893	7.75448	.25	291.03910	60.47565	17.05986
9.	63.61725	28.27433	7.97604	.5	298.64765	61.26105	17.28142
.25	67.20063	29.05973	8.19759	.75	306.35437	62.04645	17.50298
.5	70.88318	29.84513	8.41915	20.	314.15926	62.83185	17.72453
.75	74.66191	30.63052	8.64071	.25	322.06233	63.61725	17.94609
10.	78.53981	31.41592	8.86226	.5	330.06357	64.40264	18.16765
.25	82.51589	32.20132	9.08382	.75	338.16299	65.18804	18.38920
.5	86.59014	32.98672	9.30538	21.	346.36059	65.97344	18.61076

Diam.	Area.	Circum.	Side of equal sq.	Diam.	Area.	Circum.	Side of equal sq.
21	354.65635	66.75884	18.83232	38	1134.11494	119.38052	33.67662
-5	363.05030	67.54424	19.05387	-25	1149.08660	120.16591	33.89817
-75	371.54241	68.32964	19.27543	-5	1164.15642	120.95131	34.11973
22	380.13271	69.11503	19.49699	-75	1179.32442	121.73671	34.34129
-25	388.82117	69.90043	19.71854	39	1194.59660	122.52211	34.56285
-5	397.60782	70.68583	19.94010	-25	1209.95495	123.30751	34.78440
-75	406.49263	71.47123	20.16166	-5	1225.41748	124.09290	35.00596
23	415.47562	72.25663	20.38321	-75	1240.97818	124.87830	35.22752
-25	424.55679	73.04202	20.60477	40	1256.63704	125.66370	35.44907
-5	433.73613	73.82742	20.82633	-25	1272.39411	126.44910	35.67063
-75	443.01365	74.61282	21.04788	-5	1288.24933	127.23450	35.89219
24	452.38934	75.39822	21.26944	-75	1304.20273	128.01990	36.11374
-25	461.86320	76.18362	21.49100	41	1320.25431	128.80529	36.33530
-5	471.43524	76.96902	21.71255	-25	1336.40406	129.59069	36.55686
-75	481.10546	77.75441	21.93411	-5	1352.65198	130.37609	36.77841
25	490.87385	78.53981	22.15567	-75	1368.99808	131.16149	36.99997
-25	500.74041	79.32521	22.37722	42	1385.44236	131.94689	37.22153
-5	510.70515	80.11061	22.59878	-25	1401.98480	132.73228	37.44308
-75	520.76306	80.89601	22.82034	-5	1418.62543	133.51768	37.66464
26	530.92915	81.68140	23.04190	-75	1435.36423	134.30308	37.88620
-25	541.18842	82.46680	23.26345	43	1452.20120	135.08848	38.10775
-5	551.54586	83.25220	23.48501	-25	1469.13635	135.87388	38.32931
-75	562.00147	84.03760	23.70657	-5	1486.16967	136.65928	38.55087
27	572.55526	84.82300	23.92812	-75	1503.30117	137.44467	38.77242
-25	583.20722	85.60839	24.14968	44	1520.53084	138.23007	38.99398
-5	593.95736	86.39379	24.37124	-25	1537.85969	139.01547	39.21554
-75	604.80567	87.17919	24.59279	-5	1556.28471	139.80087	39.43709
28	615.75216	87.96459	24.81435	-75	1574.80890	140.58627	39.65865
-25	626.79682	88.74999	25.03591	45	1593.43128	141.37166	39.88021
-5	637.93965	89.53539	25.25746	-25	1608.15182	142.15706	40.10176
-75	649.18066	90.32078	25.47902	-5	1625.97054	142.94246	40.32332
29	660.51985	91.10618	25.70058	-75	1643.88744	143.72786	40.54488
-25	671.95721	91.89158	25.92213	46	1661.90251	144.51326	40.76643
-5	683.49275	92.67698	26.14369	-25	1680.01575	145.29866	40.98799
-75	695.12646	93.46238	26.36525	-5	1698.22717	146.08405	41.20955
30	706.85834	94.24777	26.58680	-75	1716.53677	146.86945	41.43110
-25	718.68840	95.03317	26.80836	47	1734.94451	147.65485	41.65266
-5	730.61664	95.81857	27.02992	-25	1753.45048	148.44025	41.87422
-75	742.64306	96.60397	27.25147	-5	1772.05460	149.22565	42.09577
31	754.76763	97.38937	27.47303	-75	1790.75699	150.01104	42.31733
-25	766.99039	98.17477	27.69459	48	1809.55736	150.79644	42.53889
-5	779.31132	98.96016	27.91614	-25	1828.45601	151.58184	42.76044
-75	791.73043	99.74556	28.13770	-5	1847.45282	152.36724	42.98200
32	804.24771	100.53096	28.35926	-75	1866.54782	153.15264	43.20356
-25	816.86317	101.31636	28.58081	49	1885.74099	153.93804	43.42511
-5	829.57681	102.10176	28.80237	-25	1905.03233	154.72343	43.64667
-75	842.38861	102.88715	29.02393	-5	1924.42184	155.50883	43.86823
33	855.29859	103.67255	29.24548	-75	1943.90954	156.29423	44.08978
-25	868.30675	104.45795	29.46704	50	1963.49540	157.07963	44.31134
-5	881.41308	105.24335	29.68860	-25	1983.17944	157.86503	44.53290
-75	894.61759	106.02875	29.91015	-5	2002.96166	158.65042	44.75445
34	907.92027	106.81415	30.13171	-75	2022.84205	159.43582	44.97601
-25	921.32113	107.59954	30.35327	51	2042.82062	160.22122	45.19757
-5	934.82016	108.38494	30.57482	-25	2062.89738	161.00662	45.41912
-75	948.41736	109.17034	30.79638	-5	2083.07227	161.79202	45.64068
35	962.11275	109.95574	31.01794	-75	2103.34536	162.57741	45.86224
-25	975.90630	110.74114	31.23949	52	2123.71663	163.36281	46.08380
-5	989.79803	111.52653	31.46105	-25	2144.18607	164.14821	46.30535
-75	1003.78794	112.31193	31.68261	-5	2164.75368	164.93361	46.52691
36	1017.87601	113.09733	31.90416	-75	2185.41947	165.71901	46.74847
-25	1032.06227	113.88273	32.12572	53	2206.18344	166.50441	46.97002
-5	1046.34670	114.66813	32.34728	-25	2227.04557	167.28980	47.19158
-75	1060.72930	115.45353	32.56883	-5	2248.00589	168.07520	47.41314
37	1075.21008	116.23892	32.79039	-75	2269.06433	168.86060	47.63469
-25	1089.78903	117.02432	33.01195	54	2290.22104	169.64600	47.85625
-5	1104.46616	117.80972	33.23350	-25	2311.47598	170.43140	48.07781
-75	1119.24147	118.59512	33.45506	-5	2332.82889	171.21679	48.29936

Diam.	Area.	Circum.	Side of equal sq.	Diam.	Area.	Circum.	Side of equal sq.
54-75	2354-28003	172-00219	48-52092	71-5	4015-15176	224-62337	63-36522
55	2375-82944	172-78759	48-74248	75	4043-27893	225-40927	63-58678
-25	2397-47698	173-57299	48-96403	72	4071-50407	226-19467	63-80833
-5	2419-22269	174-35833	49-18559	-25	4099-82750	226-98006	64-02989
-75	2441-06657	175-14379	49-40715	-5	4128-24909	227-76546	64-25145
56	2463-00864	175-92918	49-62870	-75	4156-76886	228-55086	64-47300
-25	2485-04887	176-71458	49-85026	73	4185-38681	229-33626	64-69456
-5	2507-18728	177-49998	50-07182	-25	4214-10293	230-12166	64-91612
-75	2520-42387	178-28533	50-29337	-5	4242-91722	230-90706	65-13767
57	2551-75863	179-07078	50-51493	-75	4271-82969	231-69245	65-35923
-25	2574-19156	179-85617	50-73649	74	4300-84034	232-47785	65-58079
-5	2596-72267	180-64157	50-95804	-25	4329-94916	233-26325	65-80234
-75	2619-35196	181-42697	51-17960	-5	4359-15615	234-04865	66-02390
58	2642-07942	182-21237	51-40116	-75	4388-46132	234-83405	66-24546
-25	2664-90505	182-99777	51-62271	75	4417-86466	235-61944	66-46701
-5	2687-82886	183-78317	51-84427	-25	4447-36618	236-40484	66-68857
-75	2710-85084	184-56856	52-06583	-5	4476-96548	237-19024	66-91043
59	2733-97100	185-35336	52-28738	-75	4506-66374	237-97564	67-13168
-25	2757-18933	186-13936	52-50894	76	4536-45979	238-76104	67-35324
-5	2780-50584	186-92476	52-73050	-25	4566-35400	239-54613	67-57480
-75	2803-92053	187-71016	52-95205	-5	45-363460	240-33183	67-79635
60	2827-43338	188-49555	53-17364	-75	4626-43696	241-11723	68-01791
-25	2851-04442	189-28095	53-39517	77	4656-62571	241-90263	68-23947
-5	2874-75362	190-06635	53-61672	-25	4686-91262	242-68803	68-46102
-75	2898-56100	190-85175	53-83828	-5	4717-29771	243-47343	68-68258
61	2922-46656	191-63715	54-05984	-75	4747-78093	244-25882	68-90414
-25	2946-47029	192-42255	54-28139	78	4778-36242	245-04422	69-12570
-5	2970-57220	193-20794	54-50295	-25	4809-04204	245-82962	69-34725
-75	2994-77228	193-99334	54-72451	-5	4839-81983	246-61502	69-56881
62	3019-07054	194-77874	54-94606	-75	4870-79579	247-40042	69-79037
-25	3043-46697	195-56414	55-16762	79	4901-66993	248-18581	70-01192
-5	3067-56157	196-34954	55-33918	-25	4932-74225	248-97121	70-23348
-75	3092-55435	197-13493	55-61073	-5	4963-91274	249-75661	70-45504
63	3117-24531	197-92033	55-83229	-75	4995-18140	250-34201	70-67659
-25	3142-03444	198-70573	56-05385	80	5026-54824	251-32741	70-89815
-5	3166-92174	199-49113	56-27540	-25	5058-01325	252-11281	71-11971
-75	3191-90722	200-27653	56-49696	-5	5089-57644	252-89820	71-34126
64	3216-99087	201-06192	56-71852	-75	5121-23781	253-68360	71-56282
-25	3242-17270	201-84732	56-94007	81	5152-99735	254-46900	71-78438
-5	3267-45270	202-63272	57-16163	-25	5184-85506	255-25440	72-00593
-75	3292-83088	203-41812	57-38319	-5	5216-81095	256-03980	72-22749
65	3318-30724	204-20352	57-60475	-75	5248-86501	256-82579	72-44905
-25	3343-88176	204-98892	57-82630	82	5281-01725	257-61059	72-67060
-5	3369-55447	205-77431	58-04786	-25	5313-26766	258-39599	72-89216
-75	3395-32534	206-55971	58-26942	-5	5345-61624	259-18139	73-11372
66	3421-19439	207-34511	58-49097	-75	5378-06301	259-96679	73-33527
-25	3447-16162	208-13051	58-71253	83	5410-60794	260-75219	73-55683
-5	3473-22702	208-91591	58-93409	-25	5443-25105	261-53759	73-77839
-75	3499-39060	209-70130	59-15564	-5	5475-99234	262-32298	73-99994
67	3525-65235	210-48670	59-37720	-75	5508-83180	263-10838	74-22150
-25	3552-01228	211-27210	59-59876	84	5541-76944	263-89378	74-44306
-5	3578-47033	212-05750	59-82031	-25	5574-80525	264-67918	74-66461
-75	3605-02665	212-84290	60-04187	-5	5607-93923	265-46457	74-88617
68	3631-68110	213-62830	60-26343	-75	5641-17133	266-24997	75-10773
-25	3658-43373	214-41369	60-48498	85	5674-50173	267-03537	75-32928
-5	3685-28453	215-19909	60-70654	-25	5707-93023	267-82077	75-55084
-75	3712-23350	215-98449	60-92810	-5	5741-45692	268-60617	75-77240
69	3739-28065	216-76989	61-14965	-75	5775-08178	269-39157	75-99395
-25	3766-42597	217-55529	61-37121	86	5808-80481	270-17696	76-21551
-5	3793-66947	218-34068	61-59277	-25	5942-62602	270-96236	76-43707
-75	3821-01115	219-12608	61-81432	-5	5876-54540	271-74776	76-65862
70	3848-45100	219-91148	62-03588	-75	5910-56296	272-53316	76-88018
-25	3875-98902	220-69688	62-25744	87	5944-67869	273-31856	77-10174
-5	3903-62522	221-48228	62-47899	-25	5978-89260	274-10335	77-32329
-75	3931-35959	222-26763	62-70055	-5	6013-20468	274-88935	77-54485
71	3959-19214	223-05307	62-92211	-75	6047-61494	275-67475	77-76641
-25	3987-12286	223-83847	63-14366	88	6082-12337	276-46015	77-98796

Diam.	Area.	Circum.	Side of equal sq.	Diam.	Area.	Circum.	Side of equal sq.
88-25	6116-72998	277-24555	78-20952	94-25	6976-74097	286-09510	83-52688
-5	6151-43476	278-03094	78-43103	-5	7015-80194	296-88050	83-74844
-75	6186-23772	278-81634	78-65263	-75	7050-96109	297-66590	83-97000
89-	6221-13885	279-60174	78-87419	95-	7088-21842	298-45130	84-19155
-25	6256-13815	280-38714	79-09575	-25	7125-57992	299-23670	84-41311
-5	6291-23563	281-17254	79-31730	-5	7163-02759	300-02209	84-63467
-75	6326-43129	281-95794	79-53886	-75	7200-57944	300-80749	84-85622
90-	6361-72512	282-74333	79-76042	96-	7238-22947	301-59239	85-07778
-25	6397-11712	283-52873	79-98198	-25	7275-97767	302-37829	85-29934
-5	6432-60730	284-31413	80-20353	-5	7313-82404	303-16369	85-52089
-75	6468-19566	285-09953	80-42509	-75	7351-76359	303-94908	85-74245
91-	6503-89219	285-89493	80-64669	97-	7389-81131	304-73448	85-96401
-25	6539-66689	286-67032	80-86820	-25	7427-95221	305-51988	86-18556
-5	6575-54977	287-45572	81-08976	-5	7466-19129	306-30523	86-40712
-75	6611-53082	288-24112	81-31132	-75	7504-52853	307-09068	86-62968
92-	6647-61005	289-02652	81-53287	98-	7542-96396	307-87608	86-85023
-25	6683-78745	289-81192	81-75443	-25	7581-49755	308-66147	87-07172
-5	6720-06303	290-59732	81-97599	-5	7620-12933	309-44637	87-29335
-75	6756-43678	291-38271	82-19754	-75	7658-85927	310-23227	87-51490
93-	6792-90871	292-16811	82-41910	99-	7697-68739	311-01767	87-73646
-25	6829-47831	292-95351	82-64066	-25	7736-61369	311-80307	87-95802
-5	6866-14709	293-73391	82-86221	-5	7775-63816	312-58846	88-17957
-75	6902-91354	294-52431	83-08377	-75	7814-76081	313-37336	88-40113
94-	6939-77817	295-30970	83-30533	100-	7353-98163	314-15926	88-62269

The following rules are for extending the use of the above table.

To find the area, circumference, or side of equal square, of a circle having a diameter of more than 100 inches, feet, &c. Rule.—Divide the given diameter by a number that will give a quotient equal to some one of the diameters in the table; then the circumference or side of equal square, opposite that diameter, multiplied by that divisor, or, the area opposite that diameter, multiplied by the square of the aforesaid divisor, will give the answer.

Example.—What is the circumference of a circle whose diameter is 228 feet? 228, divided by 3, gives 76, a diameter of the table, the circumference of which is 238-761, therefore:

$$228 \cdot 761$$

$$\underline{3}$$

$$716 \cdot 283 \text{ feet. Ans.}$$

Another example.—What is the area of a circle having a diameter of 150 inches? 150, divided by 10, gives 15, one of the diameters in the table, the area of which is 176-71458, therefore:

$$176 \cdot 71458$$

$$100 = 10 \times 10$$

$$\underline{17,671 \cdot 45800 \text{ inches. Ans.}}$$

To find the area, circumference, or side of equal square, of a circle having an intermediate diameter to those in the table. Rule.—Multiply the given diameter by a number that will give a product equal to some one of the diameters in the table; then the circumference or side of equal square opposite that diameter, divided by that multiplier, or, the area opposite that diameter divided by the square of the aforesaid multiplier, will give the answer.

Example.—What is the circumference of a circle whose diameter is $6\frac{1}{2}$, or 6.125 inches? 6.125, multiplied by 2, gives 12.25, one of the diameters of the table, whose circumference is 38.484, therefore :

$$2)38.484$$

19.242 inches. Ans.

Another example.—What is the area of a circle, the diameter of which is 3.2 feet? 3.2, multiplied by 5, gives 16, and the area of 16 is 201.0619, therefore :

$$5 \times 5 = 25)201.0619(8.0424 + \text{feet. Ans.}$$

$$\begin{array}{r} 200 \\ \hline 106 \\ 100 \\ \hline 61 \\ 50 \\ \hline 119 \\ 100 \\ \hline 19 \end{array}$$

Note.—The diameter of a circle, multiplied by 3.14159, will give its circumference; the square of the diameter, multiplied by .78539, will give its area; and the diameter, multiplied by .88622, will give the side of a square equal to the area of the circle.

TABLE SHOWING THE CAPACITY OF WELLS, CISTERNS, &C.

The gallon of the State of New York, by an act passed April 11, 1851, is required to conform to the standard gallon of the United States government. This standard gallon contains 231 cubic inches. In conformity with this standard the following table has been computed.

One foot in depth of a cistern of					
3 feet diameter will contain	52.872 gallons.
3½ " " " " " "	71.965 "
4 " " " " " "	93.995 "
4½ " " " " " "	118.963 "
5 " " " " " "	146.868 "
5½ " " " " " "	177.710 "
6 " " " " " "	211.490 "
6½ " " " " " "	248.207 "
7 " " " " " "	287.861 "
8 " " " " " "	375.982 "
9 " " " " " "	475.852 "
10 " " " " " "	587.472 "
12 " " " " " "	845.959 "

Note.—To reduce cubic feet to gallons, multiply by 7.48.

TABLE OF POLYGONS.

(From Gregory's Mathematics.)

No. of sides.	Names.	Multipliers for areas.	Radius of circum. circle.	Factors for sides.
3	Trigon	0.4330127	0.5773503	1.732051
4	Tetragon, or Square	1.0000000	0.7071068	1.414214
5	Pentagon	1.7204774	0.8506508	1.175570
6	Hexagon	2.5980762	1.0000000	1.000000
7	Heptagon	3.6339124	1.1523824	0.867767
8	Octagon	4.8284271	1.3065628	0.765367
9	Nonagon	6.1818242	1.4619022	0.684040
10	Decagon	7.6942088	1.6180340	0.618034
11	Undecagon	9.3656399	1.7747324	0.563465
12	Dodecagon	11.1961524	1.9318517	0.517638

To find the area of any regular polygon, whose sides do not exceed twelve. *Rule.*—Multiply the square of a side of the given polygon by the number in the column termed *Multipliers for areas*, standing opposite the name of the given polygon, and the product will be the answer. *Example.*—What is the area of a regular heptagon, whose sides measure each 2 feet ?

$$\begin{array}{r} 3.6339124 \\ 4 = 2 \times 2 \\ \hline \end{array}$$

14.5356496 : Ans.

To find the radius of a circle which will circumscribe any regular polygon given, whose sides do not exceed twelve. *Rule.*—Multiply a side of the given polygon by the number in the column termed *Radius of circumscribing circle*, standing opposite the name of the given polygon, and the product will give the answer. *Example.*—What is the radius of a circle which will circumscribe a regular pentagon, whose sides measure each 10 feet ?

$$\begin{array}{r} .8506508 \\ 10 \\ \hline \end{array}$$

8.5065080 : Ans.

To find the side of any regular polygon that may be inscribed within a given circle. *Rule.*—Multiply the radius of the given circle by the number in the column termed *Factors for sides*, standing opposite the name of the given polygon, and the product will be the answer. *Example.*—What is the side of a regular octagon that may be inscribed within a circle, whose radius is 5 feet ?

$$\begin{array}{r} .765367 \\ 5 \\ \hline \end{array}$$

3.826835 : Ans.

WEIGHT OF MATERIALS

<i>Woods.</i>	<i>lbs. in a cubic foot.</i>	<i>Metals.</i>	<i>lbs. in a cubic foot.</i>
Apple, - - - -	49	Wire-drawn brass,	534
Ash, - - - -	40	Cast brass, - -	506
Beach, - - - -	40	Sheet-copper, -	549
Birch, - - - -	45	Pure cast gold,	1210
Box, - - - -	60	Bar-iron, - -	475 to 487
Cedar, - - - -	28	Cast iron, - -	450 to 475
Virginian red cedar,	40	Milled lead, -	713
Cherry, - - - -	38	Cast lead, - -	709
Sweet chestnut,	36	Pewter, - - -	453
Horse-chestnut, -	34	Pure platina, -	1345
Cork, - - - -	15	Pure cast silver,	654
Cypress, - - - -	28	Steel, - - - -	486 to 490
Ebony, - - - -	83	Tin, - - - -	456
Elder, - - - -	43	Zinc, - - - -	439
Elm, - - - -	34	<i>Stone, Earths, &c.</i>	
Fir, (white spruce,)	29	Brick, Phila. stretchers,	105
Hickory, - - - -	52	North river common hard	
Lance-wood, - - -	59	brick, - - - -	107
Larch, - - - -	31	Do. salmon brick,	100
Larch, (whitewood,)	22	Brickwork, about -	95
Lignum-vitæ, - - -	83	Cast Roman cement,	100
Logwood, - - - -	57	Do. and sand in equal parts,	113
St. Domingo mahogany,	45	Chalk, - - - -	144 to 166
Honduras, or bay mahogany,	35	Clay, - - - -	116
Maple, - - - -	47	Potter's clay, - -	112 to 130
White oak, - - - -	43 to 53	Common earth,	95 to 124
Canadian oak, - - -	54	Flint, - - - -	163
Red oak, - - - -	47	Plate-glass, - -	172
Live oak, - - - -	76	Crown-glass, - -	157
White pine, - - - -	23 to 30	Granite, - - -	158 to 187
Yellow pine, - - -	34 to 44	Quincy granite, -	166
Pitch pine, - - - -	46 to 58	Gravel, - - - -	109
Poplar, - - - -	25	Grindstone, - -	134
Sycamore, - - - -	36	Gypsum, (Plaster-stone,)	142
Walnut, - - - -	40	Unslaked lime, -	52

	<i>lbs. in a cubic foot.</i>		<i>lbs. in a cubic foot.</i>
Limestone, - - -	118 to 198	Common blue stone, -	160
Marble, - - -	161 to 177	Silver-gray flagging, -	185
New mortar, - - -	107	Stonework, about, -	120
Dry mortar, - - -	90	Common plain tiles, -	115
Mortar with hair, (Plaster-		<i>Sundries.</i>	
ing,) - - -	105	Atmospheric air, -	0.075
Do. dry, - - -	86	Yellow beeswax, - -	60
Do. do. including lath		Birch-charcoal, -	34
and nails, from 7 to 11		Oak-charcoal, - - -	21
lbs. per superficial foot.		Pine-charcoal, - - -	17
Crystallized quartz, -	165	Solid gunpowder, - -	109
Pure quartz-sand, -	171	Shaken gunpowder, -	58
Clean and coarse sand, -	100	Honey, - - -	90
Welsh slate, - - -	180	Milk, - - -	64
Paving stone, - - -	151	Pitch, - - -	71
Pumice stone, - - -	56	Sea-water, - - -	64
Nyack brown stone, -	148	Rain-water, - - -	32.5
Connecticut brown stone, -	170	Snow, - - -	8
Tarrytown blue stone, -	171	Wood-ashes, - - -	52

THE END.

