



NAVAL POSTGRADUATE SCHOOL

Monterey , California



THESIS

C1988

FORTRAN PROGRAMS FOR AERODYNAMIC
ANALYSES ON THE MICROVAX 2000
CAD CAE WORKSTATION

by

John A. Campbell, Jr.

September 1988

Thesis Advisor

J.V. Healey

Approved for public release; distribution is unlimited.

T241829

Unclassified

Security classification of this page

REPORT DOCUMENTATION PAGE

| | | | | | |
|--|--|--|------------|--|------------------------|
| 1a Report Security Classification Unclassified | | 1b Restrictive Markings | | | |
| 2a Security Classification Authority | | 3 Distribution Availability of Report Approved for public release; distribution is unlimited. | | | |
| 2b Declassification Downgrading Schedule | | 5 Monitoring Organization Report Number(s) | | | |
| 3a Performing Organization Report Number(s) | | 7a Name of Monitoring Organization Naval Postgraduate School | | | |
| 4a Name of Performing Organization Naval Postgraduate School | | 6b Office Symbol (if applicable) 31 | | | |
| 4b Address (city, state, and ZIP code) Monterey, CA 93943-5000 | | 7b Address (city, state, and ZIP code) Monterey, CA 93943-5000 | | | |
| 5a Name of Funding Sponsoring Organization | | 8b Office Symbol (if applicable) | | | |
| 5b Address (city, state, and ZIP code) | | 9 Procurement Instrument Identification Number | | | |
| | | 10 Source of Funding Numbers | | | |
| | | Program Element No | Project No | Task No | Work Unit Accession No |
| 11 Title (include security classification) FORTRAN PROGRAMS FOR AERODYNAMIC ANALYSES ON THE MICROVAX 2000 CAD CAE WORKSTATION | | | | | |
| 12 Personal Author(s) John A. Campbell, Jr. | | | | | |
| 13a Type of Report Master's Thesis | | 13b Time Covered From | To | 14 Date of Report (year, month, day) September 1988 | 15 Page Count 201 |
| 16 Supplementary Notation The views expressed in this thesis are those of the author and do not reflect the official policy or position of the Department of Defense or the U.S. Government. | | | | | |
| 17 Cosat Codes | | 18 Subject Terms (continue on reverse if necessary and identify by block number) Numerical methods, FORTRAN programs, 2-D, 3-D, Doublet, Panel, Vortex lattice. | | | |

19 Abstract (continue on reverse if necessary and identify by block number)

This thesis describes the conversion of four computer programs on the Naval Postgraduate School IBM 3033AP computer system and their implementation on the MicroVax 2000 CAD CAE workstation. The existing 2-D airfoil analysis programs VUBLET and PANEL were extensively modified to improve the user interface. The 3-D wing analysis program VORLAT also received an updated interface. The JETFLAP source program no longer resided on the NPS mainframe and was reconstructed from an original source tape and program listing. This program was then converted from FORTRAN IV for the CDC 6000 series computers to FORTRAN 77 for use on the IBM mainframe and the MicroVAN 2000. An interactive data input program, JETFLAPIN, was developed to simplify data input, provide error checking and correction and thereby enhance the utilization of the JETFLAP program. The programs are intended for use by students in basic and advanced courses in aerodynamics at the Naval Postgraduate School, however they are also applicable to a course in computational aerodynamics.

| | | | |
|--|--|---|---------------------------|
| 20 Distribution Availability of Abstract Unclassified unlimited <input type="checkbox"/> same as report <input type="checkbox"/> DTIC users | | 21 Abstract Security Classification Unclassified | |
| 22a Name of Responsible Individual V. Healey | | 22b Telephone (include Area code) (408) 646-2804 | 22c Office Symbol 67He |

23 FORM 1473.84 MAR

83 APR edition may be used until exhausted
All other editions are obsolete

Security classification of this page

Unclassified

Approved for public release; distribution is unlimited.

FORTRAN Programs for Aerodynamic Analyses
on the MicroVAX 2000 CAD CAE Workstation

by

John A. Campbell, Jr.
Lieutenant, United States Coast Guard
B.S., Arizona State University, 1980

Submitted in partial fulfillment of the
requirements for the degree of

MASTER OF SCIENCE IN AERONAUTICAL ENGINEERING

from the

NAVAL POSTGRADUATE SCHOOL
September 1988

ABSTRACT

This thesis describes the conversion of four computer programs on the Naval Post-graduate School IBM 3033AP computer system and their implementation on the MicroVax 2000 CAD CAE workstation. The existing 2-D airfoil analysis programs DUBLET and PANEL were extensively modified to improve the user interface. The 3-D wing analysis program VORLAT also received an updated interface. The JETFLAP source program no longer resided on the NPS mainframe and was reconstructed from an original source tape and program listing. This program was then converted from FORTRAN IV for the CDC 6000 series computers to FORTRAN 77 for use on the IBM mainframe and the MicroVAX 2000. An interactive data input program, JETFLAPIN, was developed to simplify data input, provide error checking and correction and thereby enhance the utilization of the JETFLAP program. The programs are intended for use by students in basic and advanced courses in aerodynamics at the Naval Postgraduate School, however they are also applicable to a course in computational aerodynamics.

THESIS
C19366
C. I

THESIS DISCLAIMER

The reader is cautioned that computer programs developed in this research may not have been exercised for all cases of interest. While every effort has been made, within the time available, to ensure that the programs are free of computational and logic errors, they cannot be considered validated. Any application of these programs without additional verification is at the risk of the user.

TABLE OF CONTENTS

| | | |
|-------------|---|----|
| I. | ACKNOWLEDGEMENTS | 1 |
| II. | INTRODUCTION | 2 |
| III. | BASIC THEORY OF 2-D AIRFOIL ANALYSIS PROGRAMS | 4 |
| A. | INTRODUCTION | 4 |
| B. | PROGRAM DUBLET | 5 |
| C. | PROGRAM PANEL | 7 |
| IV. | BASIC THEORY OF 3-D WING ANALYSIS PROGRAMS | 11 |
| A. | INTRODUCTION | 11 |
| 1. | The Horseshoe Vortex | 11 |
| B. | PROGRAM VORLAT | 15 |
| C. | PROGRAMS JETFLAP AND JETFLAPIN | 15 |
| V. | PROGRAM TRANSFER AND CONVERSION | 17 |
| A. | INTRODUCTION | 17 |
| B. | FILE TRANSFER | 17 |
| 1. | Programs DUBLET, PANEL, VORLAT | 17 |
| 2. | Program JETFLAP | 18 |
| C. | CONVERSION AND REPROGRAMMING | 22 |
| 1. | Programs DUBLET, PANEL, VORLAT | 22 |
| VI. | RESULTS AND RECOMMENDATIONS | 25 |
| APPENDIX A. | PROGRAM DUBLET USER'S MANUAL | 27 |
| APPENDIX B. | PROGRAM PANEL USER'S MANUAL | 43 |
| APPENDIX C. | PROGRAM VORLAT USER'S MANUAL | 61 |

| | |
|--|-----|
| APPENDIX D. PROGRAMS JETFLAP AND JETFLAPIN USER'S MANUAL | 72 |
| APPENDIX E. FIGURES GENERATED USING DISSPLA | 179 |
| LIST OF REFERENCES | 189 |
| INITIAL DISTRIBUTION LIST | 191 |

LIST OF FIGURES

| | | |
|------------|--|-----|
| Figure 1. | Basic Fluid Flows | 4 |
| Figure 2. | An Airfoil-like Shape | 5 |
| Figure 3. | The Radius of Curvature of a Leading Edge | 6 |
| Figure 4. | Nomenclature for the Analysis by the Panel Method | 8 |
| Figure 5. | Definition of Nodes and Panels | 9 |
| Figure 6. | Replacement of the Finite Wing with a Bound Vortex [Ref. 2] | 12 |
| Figure 7. | Downwash Distribution Along y Axis for a Horseshoe Vortex [Ref. 2] | 12 |
| Figure 8. | Superposition of Three Horseshoe Vortices Along a Lifting Line [Ref. 2] | 13 |
| Figure 9. | Schematic of a Lifting Surface [Ref. 2] | 14 |
| Figure 10. | Sample JETFLAP Batch JCL File | 18 |
| Figure 11. | Magnetic Tape Scan Utility (TSCAN) JCL File | 19 |
| Figure 12. | Sample Tape Copy JCL File | 19 |
| Figure 13. | Sample Tape Dump Utility JCL File | 20 |
| Figure 14. | Sample Tape Transfer JCL File | 20 |
| Figure 15. | FILEDEFs in a Sample JTFLAP EXEC File | 23 |
| Figure 16. | Sample OPEN Statement | 24 |
| Figure 17. | Initial Screen for Program DUBLET | 30 |
| Figure 18. | Endpoint Determination Method Selection Screen | 30 |
| Figure 19. | Endpoint Determination Method Selection Screen | 32 |
| Figure 20. | Initial Screen for Program PANEL | 45 |
| Figure 21. | Screen Showing Data for Computer Generated Airfoil | 46 |
| Figure 22. | Run Completion Screen | 47 |
| Figure 23. | Menu for Surface Coordinate Data Entry Method | 48 |
| Figure 24. | Initial Screen for Program VORLAT | 64 |
| Figure 25. | Data Review/Correction Screen | 64 |
| Figure 26. | Program PANEL- Shape Generated Using Airfoil Coordinates Data File 180 | |
| Figure 27. | Program PANEL- Shape Generated Using Internal Equation for NACA 0012 | 181 |
| Figure 28. | Program PANEL- Shape Generated Using DATA Statements for NASA LS(1)-0013 | 182 |
| Figure 29. | Program PANEL- Comparison of Shapes Generated for NACA 0012 | |

| | |
|--|-----|
| and NASA LS(1)-0013 | 183 |
| Figure 30. Program PANEL-Surface Pressure Distribution for NACA 0012 | 184 |
| Figure 31. Program PANEL- Surface Pressure Distribution for NACA 0012 Generated by the Internal Equation | 185 |
| Figure 32. Program PANEL- Surface Pressure Distribution for NASA LS(1)-0013 | 186 |
| Figure 33. Program VORLAT- Spanwise Lift Distribution Using Cosine Spacing | 187 |
| Figure 34. Program VORLAT- Spanwise Lift Distribution Using Uniform Grid . | 188 |

ACKNOWLEDGEMENTS

First I would like to thank Professor Val Healey, who provided me with the idea for this project and greatly assisted me in understanding the theory underlying these programs. I wish also to express my thanks to the staff of the W. R. Church Computer Center, in particular to Ms. June Favorite, for her assistance in the transfer of the JETFLAP programs from magnetic tape, to Mrs. Jane Kretzmann, for her patience and valuable insights on the use of DISSPLA, and to Mr. Larry Frazier, whose efforts with the Script processor made this publication possible. An additional note of thanks go to Ms. Rosalie Johnson, of the Computer Science Department, and Mr. David Marco of the Mechanical Engineering Department, for sharing their technical expertise and transferring the numerous files contained in this work between the VAX and the IBM mainframe computers. Not to be forgotten is the special contribution made by Professor E. M. Wu, by providing me with the use of his lab and MicroVax workstation for the program conversion. Most of all, I want to thank my children, Nicholas, John, Colin and Elaina, for their love and understanding during this effort and my dear wife, Juleen, whose personal strength and continual support enabled me to bring this project to fruition.

II. INTRODUCTION

Current aerodynamic analysis relies heavily upon numerical methods for estimating the aerodynamic coefficients of airfoils and wings. This thesis was undertaken to provide the students of the aeronautical engineering curriculum with a series of computer programs that would give them a better appreciation and understanding of several computational methods that have been applied to classical aerodynamic theory.

The Department of Aeronautics and Astronautics at the Naval Postgraduate School (NPS), in conjunction with the Mechanical Engineering Department, is developing a computer-aided design computer-aided engineering (CAD/CAE) laboratory for use in research and teaching by their respective curriculums. The system is based on a network of Digital Equipment Corporation (DEC) MicroVAX 2000 workstations. There is an ongoing requirement to provide specialized software (programs) for the computer network that is usable by the students and staff to support current and future courses and research.

At the time of this writing, several aerodynamic analysis programs reside on the NPS IBM 3033AP mainframe computer. They are in various states of repair¹ and due to constant software and hardware upgrades of the mainframe system some programs provide limited output capabilities² while others are becoming unusable due to compiler changes. There is also a wide range in the amount and quality of the documentation available for each program. This thesis seeks to remedy a portion of this problem and support the previously mentioned software needs requirement by providing a set of baseline programs and thorough documentation which will extend the life of these valuable programs and allow further upgrades and eventually the incorporation of graphics routines by future users.

The programs contained in this work were selected on the basis of their applicability to the present courses taught in basic and advanced aerodynamics at NPS, the documentation available and previous user inputs. They were revised or modified with the

¹ Source code is not available for some programs, in particular FLO27. Since certain output flags for FLO27 were set in the source code and the user was unable to alter these, an inordinate amount of unwanted output was produced.

² Several programs, notably FLO27, JETFLP and those used in the Aircraft Combat Survivability and Lethality courses have lost their graphical output due to software incompatibility problems.

intent that they be used for preliminary design and to evaluate the changes in aerodynamic coefficients due to changes in one or more of the input parameters. To this end, the following factors were emphasized in modifying or creating the programs to make them easily understood and utilized:

- Error checking/correction capability.
- Capability to make multiple runs in one session.
- Capability to change one or more parameters on subsequent runs.
- Utilize a standardized interface (to the extent possible).
- Allow user defined names for input output files.

This document briefly describes the basic theory behind the 2-D airfoil and 3-D wing analysis programs and the reprogramming required for transfer and conversion of the selected programs from the IBM 3033AP and CDC 6000 series computers to the MicroVAX/2000 CAD CAE workstation.

A users manual for each program is contained in the appendices. These provide a short discussion on the purpose of the program, input requirements and constraints, program operation and the program output. A sample input session, input data file (if required) and the resulting output as well as a complete program listing is also included.

Project results and recommendations for future work are given.

III. BASIC THEORY OF 2-D AIRFOIL ANALYSIS PROGRAMS

A. INTRODUCTION

The following sections are intended to present the reader with a basic understanding of the ideal fluid flow concepts underlying the 2-D airfoil analysis programs. This brief summary contains just a few highlights which would be obtained from a course in the fundamentals of aerodynamics and in no way attempts to provide the reader with a firm foundation in aerodynamics or fluid flows.

It will be assumed that the reader is familiar with the concepts of velocity potential, ϕ , stream function, ψ , and their derivatives. It is further assumed that the reader has some familiarity with the concepts of the basic fluid flows: uniform stream, source, sink, vortex and doublet. Figure 1 depicts these basic fluid flows and provides an example of how two of these flows, a uniform stream and a doublet, may be combined to model the flow over a cylinder. A thorough discussion of these flows and their properties may be found in most aerodynamics texts. References 1, 2, 3 and 4 were instrumental in the preparation of the following sections.




Figure 1. Basic Fluid Flows

B. PROGRAM DUBLET

The type of analysis used here is a *direct* method in which the shape of an ellipsoid or airfoil-like body is specified and the problem is to solve for the distribution of singularities which, in combination with a uniform stream, produce the flow over the body.

This program provides a numerical method for approximating the solution of the integral equation for the line doublet distribution for a symmetrical airfoil at zero lift in incompressible irrotational flow. With the doublet strength known, the velocity field can be determined using equations for the stream function and velocity potential. Once the velocity field is known, the pressure field may be determined using the Bernoulli equation.

For this problem the airfoil body shape is specified as $y = Y(x)$. It is a closed form which has a finite length or chord, c as shown in Figure 2.




Figure 2. An Airfoil-like Shape

Such a shape can be defined by an equation of the form:

$$Y(x) = A \sqrt{\frac{x}{c}} (c - x) \quad (1)$$

This shape is to be modeled by a string of doublets along the x axis, and the strength of each doublet to be determined. The solution is required to meet the flow tangency condition and the doublets are required to be within the body.

Since thin-airfoil theory fails near the stagnation points and it is not physically possible for the source distribution to extend to the ends of the body and still meet the

flow tangency condition, there must exist a finite distance between the ends of the source distribution and the stagnation points.

This distance is determined by approximating the shape of a blunt-nosed airfoil near its nose, $x = 0$, as parabolic. Using thin-airfoil theory and the radius of curvature (Figure 3), the source strength near the leading edge of the source distribution can be approximated. Applying this approximation and the requirement that the source-induced velocity must cancel that of the onset flow at the stagnation point, it can be shown [Ref. 1 pp.52-54], that the separation distance between the stagnation point and the leading edge of the source distribution is approximately half the radius of curvature of the nose of the body. A similar analysis holds for the other end of the body.




Figure 3. The Radius of Curvature of a Leading Edge

The program DUBLET incorporates the half radius of curvature inset and satisfies the flow tangency requirements using an iterative approach. This is done by taking an approximation to the proper inset, solving the set of simultaneous equations for the doublet strength distribution which satisfies the flow tangency condition and then evaluating the resulting velocity at the stagnation points. If the velocity is not sufficiently close to zero, the estimated values are revised and the process is repeated. The iterative approach used is an interval-halving or bisection method of root-finding similar to that described in Ref. 5.

A more complete development of the thin-airfoil theory and the underlying equations used to derive this method are detailed by Moran [Ref. 1].

C. PROGRAM PANEL

This analysis again uses the *direct* method to solve for the proper distribution of singularities³ on a body which, in combination with a uniform stream, provide the flow over the body.

This program uses a numerical approach to provide an approximation to the solution of the integral equation for the source and vortex distribution on the surface of a lifting body in incompressible irrotational flow. It is specifically designed to evaluate NACA four-digit airfoils and NACA five-digit airfoils of the 230XX series; however provisions are made within the program for entry of any arbitrary airfoil shape.

The following presents some reasons for and a brief development of the panel method. Although thin airfoil theory gives reasonably good results for lift and moment coefficients, it ignores the effect on those coefficients of the thickness distribution. In addition, thin airfoil theory gives good pressure distribution results only away from the stagnation points. Since proper design of an airfoil requires an accurate prediction of its pressure distribution, more powerful methods are based on the distributions of sources and vortices or doublets. This is emphasized by Moran when he states

"To avoid the inaccuracies of thin-airfoil theory, the flow-tangency condition must be satisfied on the body surface and...the singularities should be distributed on the body surface rather than on the chord line or any other line within or without the body."

To achieve this placement of the singularities on the body, the body surface is approximated by a collection of straight line *panels*. This form of surface approximation is where the panel method receives its name. Program PANEL uses a solution method based on sources and vortices distributed on these surface panels.

The potential for this flow may be described as

$$\phi = \phi_\infty + \phi_S + \phi_V \quad (2)$$

where ϕ_∞ is the potential of the uniform onset flow, which can be written in a Cartesian system as

$$\phi_\infty = V_\infty x \cos \alpha + V_\infty y \sin \alpha \quad (3)$$

³ "Singularities" is used here as a generic term for sources, vortices, doublets and other fundamental solutions of the Laplace equation that blow up--are "singular"--at some point outside the flow field.

where V_∞ is the velocity of the uniform flow, and α is the angle between the flow direction and the x axis. The remaining potential terms are defined as

$$\phi_s \equiv \int \frac{q(s)}{2\pi} \ln r \, ds \quad (4)$$

$$\phi_v \equiv - \int \frac{\gamma(s)}{2\pi} \theta \, ds \quad (5)$$

in which the integrations are over the body surface. This defines ϕ_s , as the potential of a source distribution of strength $q(s)$ per unit length and ϕ_v , as the potential of a vortex distribution of strength $\gamma(s)$ per unit length. Figure 4 shows that s is the distance measured along the surface from some arbitrary reference point--in this case the leading edge has been chosen--to the "field point", (x, y) , or (r, θ) in polar coordinates.




Figure 4. Nomenclature for the Analysis by the Panel Method

We seek a solution where $q(s)$ and $\gamma(s)$ are determined so as to meet the boundary condition of flow tangency and the Kutta condition. The latter is the requirement that the stagnation point be at the trailing edge⁴.

The view of this problem taken by Hess and Smith [Ref. 6] is that the source strength governs the flow tangency condition and the Kutta condition governs the

⁴ All airfoils considered here are assumed to have sharp trailing edges.

vortex strengths⁵. They make the simplifying assumption that the vortex strength is taken constant over the whole airfoil, i.e. $\gamma(s) = \gamma$, and justify this by reasoning that, since the Kutta condition governs the vortex strength, and the Kutta condition involves only the trailing edge, then the vortex strength can be represented by a single number. Conversely, the source strength must vary over the surface to allow the flow tangency condition to be satisfied at all points on the body surface.

The integrals of equations (4) and (5) are difficult to evaluate unless the surface on which the singularities are distributed is a straight line. This is where the surface panels come into play. The body is divided up into a set of panels by selecting a set of N points, called *nodes*, which are then connected by straight lines. This results in an approximation of the body composed of N nodes and panels as shown in Figure 5.




Figure 5. Definition of Nodes and Panels

The sources and vortices are distributed on the straight line panels and the constant vortex strength assumption is incorporated so that the potential given by equation (2), as developed in equations (3) through (5), may be written as:

$$\phi = V_{\infty}x \cos \alpha + V_{\infty}y \sin \alpha + \sum_{j=1}^N \int_{panel} \left[\frac{q(s)}{2\pi} \ln r - \frac{\gamma}{2\pi} \theta \right] ds \quad (6)$$

⁵ In actuality, both singularity distributions are important in satisfying either condition.

To allow evaluation of the integrals in equation (6), the source strength is taken to be constant on each panel, but allowed to vary from panel to panel, i.e.

$$q(s) = q_i \text{ on panel } i, \quad i = 1, \dots, N \quad (7)$$

The parameters to be determined are then the N source strengths q_i and the single vortex strength γ . These are found by imposing the flow tangency condition at N control points and a corollary to the Kutta condition which states, "Near the trailing edge, the flow speeds on the upper and lower surfaces of the airfoil are equal at equal distances from the trailing edge." [Ref. 1]

Moran [Ref. 1] provides a clear explanation of the geometric development of the problem and the resulting set of $N + 1$ equations in the unknowns q_i , $i = 1, \dots, N$, and γ . This leads into a discussion regarding the development of a FORTRAN program that uses the panel method. Program PANEL sets up and solves this set of equations. The tangential velocity at the midpoint of each panel is then evaluated and its associated pressure coefficient C_p is calculated. By assuming the latter to be constant over each panel, the estimated lift and moment may then be calculated.

IV. BASIC THEORY OF 3-D WING ANALYSIS PROGRAMS

A. INTRODUCTION

As discussed in the previous section on 2-D airfoil theory, there are several ways to model the source of forces acting on a body surrounded by a moving fluid. These included potential functions, vortex distributions, circulation distributions and pressure differential distributions. These models are related to one another and each has advantages and disadvantages. Both of the following programs, VORLAT and JETFLAP, rely on a distribution of discrete horseshoe vortices to model the flow over a wing.

1. The Horseshoe Vortex

To provide the reader with an understanding of the theory behind the VORLAT and JETFLAP programs, it is necessary to explain what a horseshoe vortex is and what properties it has. References 1, 2, and 3 provided a basis for much of the material contained in this section.

The idea of the horseshoe vortex was developed by Prandtl and Lanchester while trying to provide a simplified model of the ideal flow over a wing. Prandtl reasoned that a vortex filament of strength Γ , bound to a fixed location in a flow--a bound vortex--will experience a force $L = \rho_\infty V_\infty \Gamma$ from the Kutta-Zhukovsky theorem. To satisfy Helmholtz' theorem which states that a vortex filament cannot end in a fluid, the vortex filament continues as two free vortices extending downstream from the wing tips to infinity. The construction of this vortex is in the shape of a horseshoe and it is therefore called a *horseshoe vortex*. It is correctly pointed out however by Zucker that, "...the word "horseshoe", although in common usage, is misleading since these filaments are actually "closed" back at the place where the motion originated." [Ref. 3]

As shown in Figure 6, the wing is replaced by a "listing line" perpendicular to the flight direction and located at the quarter-chord, with the two free vortices trailing from the wing tips.




Figure 6. Replacement of the Finite Wing with a Bound Vortex [Ref. 2]

This model did not provide a very realistic simulation of the downwash distribution of a finite wing; especially near the tips where the predicted downwash approaches an infinite value. The downwash distribution as a function of the span, $w(y)$, is shown in Figure 7.




Figure 7. Downwash Distribution Along y Axis for a Horseshoe Vortex [Ref. 2]

An improvement on this model was the "lifting line" model which superimposed a large number of horseshoe vortices, each with a different length of bound vortex, but with all the bound vortices lying along a single line. This is depicted in Figure 8 which has three horseshoe vortices of strengths, $\Delta\Gamma_1$, $\Delta\Gamma_2$ and $\Delta\Gamma_3$. The variation of Γ along the lifting line is denoted by the vertical bars. Since $L \propto \Gamma$, this is also an indication of the lift distribution. It should be noted that the strength of each trailing vortex is equal to the change in circulation along the lifting line at the point where the trailing vortex starts.




Figure 8. Superposition of Three Horseshoe Vortices Along a Lifting Line [Ref. 2]

This model is good for high aspect ratio straight wings and provides an excellent prediction of spanwise loading and overall lift. It cannot however, produce chordwise pressure distributions and moment data.

To deal with low aspect ratio straight wings, the model is extended by placing a series of lifting lines on the plane of the wing at different chordwise stations, all parallel to the y axis. In the limit of an infinite number of these lifting lines, we obtain a vortex sheet, where the vortex lines run parallel to the y axis. The strength of the sheet per unit area is denoted by γ , where the latter varies in the y direction in a manner analogous to the variation of Γ for the single lifting line. In addition, each lifting line will have, in

general, a different overall strength, so that γ also varies with x . This relation, $\gamma = \gamma(x, y)$ is shown in Figure 9.




Figure 9. Schematic of a Lifting Surface [Ref. 2]

This vortex sheet results in a *lifting surface* distributed over the entire planform of the wing. The strength of the lifting surface at any point on the surface is given by $\gamma = \gamma(x, y)$. The aim of the lifting surface theory is to find $\gamma(x, y)$ such that the flow-tangency condition is satisfied at all points on the wing.

For computational purposes the planform is divided into a finite number of square or rectangular panels and the ij th panel chosen for initial computation. The spanwise vorticity on each panel is assumed to be concentrated at the quarter-chord point of the panel and the flow tangency condition is satisfied at the "control point" which is located at the three-quarter chord point of the panel [Ref. 1]. The wing problem then reduces to computation of the velocity at the control point on this ij th panel due to all the other panels. This velocity is combined with the freestream value and the tangency condition applied. For each panel, there is therefore, one linear equation and with N panels there are N such equations. Matrix methods are applied to solve this system and with the vorticity distribution known, the Kutta-Zhukovsky theorem is applied to obtain the lift and moments. The induced drag can be computed from the downwash, which is known at the control points. The vortex-lattice method used by program VORLAT is a simple approach used to solve for $\gamma = \gamma(x, y)$.

B. PROGRAM VORLAT

Program VORLAT implements the vortex-lattice method to determine the solution for the vortex strength distribution on a flat, untwisted, rectangular wing. A set of horseshoe vortices are used to approximate the flow over a wing of low aspect ratio. This is a version of the VORLAT program by Moran [Ref. 1] which has been highly modified and now incorporates a cosine spacing scheme.

The User's Manual presents a short description of the VORLAT program. For complete coverage of the original VORLAT program, consult Moran [Ref. 1].

C. PROGRAMS JETFLAP AND JETFLAPIN

Program JETFLAP was written by M. L. Lopez, C. C. Shen, and N. F. Wasson at the Douglas Aircraft Company, Long Beach, California. The program is based on A Theoretical Method for Calculating the Aerodynamic Characteristics of Jet-Flapped Wings [Ref. 7] which was developed under a research contract sponsored by the Office of Naval Research. The program is quite extensive and has the capability of determining the following aerodynamic characteristics of wings of arbitrary planform:

- Spanwise and chordwise loading
- Spanwise variation of induced drag
- A capability to investigate the effects of:
 - Part span flaps
 - Part span blowing
 - Pitching, rolling, yawing and sideslip
- Total lift and induced drag (momentum method), pitching, yawing and rolling moments, etc.

The program also provides the capability to investigate the effects of a variation of leading and trailing flap deflection, camber, twist, jet deflection and jet momentum.

Despite the many capabilities of this program and the revised User's Manual developed by Soderman [Ref. 8] in 1976, the program has had limited use at the Naval Post-graduate School since then. This author feels that a major reason for its lack of use is the inordinate amount of time required for the user to prepare and input the data file for even the most elementary planform.

To alleviate this problem, the author developed Program JETFLAPIN, an interactive data entry program to interface with the JETFLAP program. To ensure compatibility, much of JETFLAPIN was created using existing subroutines from JETFLAP.

The JETFLAPIN program provides the user with a method of developing an almost error-free⁶ input data file for use with the main JETFLAP program.

The JETFLAPIN program provides error-checking, data review correction, assurance that all required data has been entered and the elimination of redundant data entry.

⁶ While it is still possible for the user to input bad data values, the errors due to values out of limits or incorrect formatting have been virtually eliminated.

V. PROGRAM TRANSFER AND CONVERSION

A. INTRODUCTION

This section discussed the steps taken in the transfer of the programs DUBLET, PANEL, VORLAT and JETFLAP from the IBM mainframe computer and their conversion for use on the MicroVAX 2000 workstation. The information provided here will be of use to others planning future transfers of programs between the IBM mainframe computer and the MicroVAX 2000.

B. FILE TRANSFER

1. Programs DUBLET, PANEL, VORLAT

The programs DUBLET, PANEL and VORLAT, were located on the IBM mainframe under the user account 4632P, which was set up for use by the Numerical Methods course, AE 4632, taught in the Aeronautical Engineering Department.⁷ Each program was operational on the mainframe and was activated through the use of an executive calling routine referred to as an "EXEC". These EXECs and the program source code files were readily available for transfer.

Each program and its calling EXEC were transferred to the VAX 11/780 located in the Computer Science Department. This was necessary as the AE/ME VAX network is not currently linked with the IBM mainframe. This transfer was conducted by Mr. David Marco, a computer technician working on the AE/ME VAX system, using the VAX 2780/3780 Protocol Emulator. The file transfer procedures outlined in a Computer Science Department handout covering the RJE File Transfer Package were followed. When the transfer was completed, the files were downloaded to a magnetic tape cartridge, a DEC TK50.

The tape was then taken to the MicroVAX/2000 workstation and loaded into the DEC TK50 tape drive subsystem connected to the workstation. The files were then transferred from the tape to the workstation's hard disk. From here the files could be edited using the VAX EDT editor [Ref. 9], compiled, linked and run under VAX FORTRAN version V4.0.

⁷ The read-only password for this account is JVH.

2. Program JETFLAP

Program JETFLAP had to be handled quite differently than the other programs. It too was operational on the mainframe, however it had been converted into a cataloged procedure, JETFLP, and was executed using a Job Control Language (JCL) routine. An example of this JCL file is shown in Figure 10. More information on how to create and use JCL files may be found in the User's Guide to MVS at NPS [Ref. 10] or the IBM JCL User's Guide [Ref. 11].

```
//TAPER JOB (1461,1478),'DOUGLAS JETFLAP PRGM',CLASS=C
///*MAIN ORG=NAVPGS.1461P
// EXEC JETFLP
//SYSIN DD *
Tapered Swept Wing, AR=8, Sweep Angle 45, 10X10 W/Semi-Circle Spacing
50.0000 20.000 0.0 10.43 10.43
1001000001020000
.993844 .969372 .921032 .850012 .758062 .647446 .520888
.381504 .232726 .078217
01010101010101010101
10
.000000 .024472 .095492 .206107 .345492 .5000 .654508
.793893 .904508 .975528
8.0 45.0 0.45
9
/*
//
```

Figure 10. Sample JETFLAP Batch JCL File

After an exhaustive search by the personnel of the W. R. Church Computer Center at the NPS, it was determined that only the compiled version of the program existed on the IBM mainframe. The source code had been purged from the system and was not recoverable.

A magnetic tape containing the original Douglas Aircraft Company program was obtained from Dr. M. F. Platzer. This copy had been obtained during thesis work conducted by LCDR A. P. SODERMAN. The tape was logged into the NPS computer center and its characteristics were determined using the tape scan JCL utility shown in Figure 11.

```
//JETFLP JOB (1461,9999),'JETFLP TSCAN1',CLASS=E  
//**MAIN SYSTEM=SY2,RINGCHK=NO  
//  
//** Print tape file characteristics for any tape  
//**  
// EXEC TSCAN,VOLIN=JETFLP,DCBIN='DEN=2',UNITIN='3400-4'  
//
```

Figure 11. Magnetic Tape Scan Utility (TSCAN) JCL File

The tape scan utility revealed that the tape used a very old tape density of 800 BPI. The computer center still had an 800 BPI magnetic tape machine, however they recommended that the contents of this tape be copied onto a new tape using the more common density of 1600 BPI. This was accomplished using the magnetic tape copy utility JCL file shown in Figure 12. The name of the original tape volume was JETFLP. This was changed to JTFLAP on the new copy.

```
//JCOPY JOB (1461,9999),'JETFLP COPY',CLASS=E  
//  
//** COPY TAPE FILE FROM 800BPI TO ANOTHER AT 1600BPI  
//**  
// EXEC TAPE,VOLIN=JETFLP,DCBIN='DEN=2',UNITIN='3400-4',  
// VOLOUT=JTFLAP  
//SYSIN DD *  
CPYEND(10,11)  
/*  
//
```

Figure 12. Sample Tape Copy JCL File

Several parity errors occurred while reading the original tape during the copying process. This was an indication that the files contained on the original tape or those obtained through the transfer process may contain errors.

To discover the contents of the tape, a magnetic tape dump utility JCL file was used. This file is shown in Figure 13.

```

//JTFLAP JOB (1461,9999),'JTFLAP TAPE1',CLASS=E
//*MAIN SYSTEM=SY2,RINGCHK=NO,LINES=(10)
//*
//* PRINT THE CONTENTS OF EVERY FILE ON THE TAPE.
//*
// EXEC TAPE,VOLIN=JTFLAP
//SYSIN DD *
DMPFIL(10,256,1)
/*
//

```

Figure 13. Sample Tape Dump Utility JCL File

A quick review of the printout of produced by this utility revealed that the tape did contain a complete set of the desired files and these were transferred to the author's working disk (A disk) using the procedures outlined in Reference 12. The JCL file used to perform the transfer from tape to the mainframe is shown in Figure 14.

```

//JTFLAP JOB (1461,9999),'JETFLAP TRANSFER',CLASS=A
// EXEC PGM=IEBGENER
//SYSPRINT DD SYSOUT=A
//SYSIN DD DUMMY
//SYSUT1 DD DISP=SHR,DSN=MSS.C0052.JETFLP
//SYSUT2 DD UNIT=3350,VOL=SER=MVS004,DISP=(NEW,KEEP),
//           SPACE=(CYL,(1,1)),
//           DCB=(RECFM=FB,LRECL=80,BLKSIZE=8000),
//           DSN=S1461.JETFLP
//
```

Figure 14. Sample Tape Transfer JCL File

The file was edited to remove the extra lines associated with the transfer process, specifically header, trailer and system information lines associated with the JCL tape transfer utility. The transfer process also places the record number and record length at the beginning of each record. These were removed. The edited version of the program consisted of 4661 lines of FORTRAN code.

Examination of the program file revealed that erroneous pieces of information⁸ had crept into the source file. These were due to either the transfer process itself or effects of the environment and aging on the magnetic tape. Regardless of their source, these errors corrupted the source code to such a degree that it would not compile properly on the mainframe.

An attempt to compile the program was made using the VS FORTRAN compiler with its extended error messages⁹ to locate as many errors as possible. The listing which was produced flagged all critical areas of the program which required revision. Corrections to the program were made using the listing as a guide. Corrections to non-critical areas of the program, such as comment lines, were made using the program source code listings contained in References 8 and 7 as guides.

It was noted during the editing process that no further errors were encountered in the program following line 2462. This leads the author to the conclusion that the errors were not due to the transfer process, but solely due to defects present in the outer windings of the source tape.

Following completion of the editing process, the program was compiled satisfactorily. Since the program was written using several commands specific to FORTRAN IV it was necessary to compile the program using the (LVL(66)) option with the VS FORTRAN compiler. This invokes the FORTRAN IV version of the VS FORTRAN compiler which allows proper interpretation and compilation of older programs written under the FORTRAN IV standard.

The successfully compiled JETFLAP program was then run using the sample data files provided in References 8 and 7 as input files. The results were then compared to those tabulated in References 8 and 7 which were obtained using the same data files. A slight difference was discovered between the computed values for the moment coefficients (CM and CMG). This difference was traced to a program line for CMG(K) in Subroutine SLOAD which had been modified in [Ref. 8: p. 338] and [Ref. 7: p. C-19], but had not been corrected on the version of the program contained on the source tape. Modification of this line and subsequent compilation and running of the program produced results identical to those contained in References 8 and 7. An additional

⁸ The erroneous data consisted of extra spaces, non-standard characters and improperly interpreted characters, i.e., several O's were interpreted as M's.

⁹ The WATFIV compiler is more thorough and produces an even greater number of messages. It is recommended for use on smaller programs or in the final stages of program development due to its extensive output.

comparison was made with the data file and results produced by S. M. White, as part of a class project for AE 3501[Ref. 13]. Again the results were identical. It was then felt that the program was ready to be ported over to the MicroVAX 2000.

The JETFLAP program was transferred from the IBM mainframe to the MicroVAX 2000 in the same manner described previously. It was compiled using the /NOF77 qualifier under VAX FORTRAN and appeared to compile successfully. When a sample run was executed, the program terminated abnormally. This began an extended period of debugging to achieve proper operation of the program on the MicroVAX 2000.

C. CONVERSION AND REPROGRAMMING

1. Programs DUBLET, PANEL, VORLAT

The programs DUBLET, PANEL and VORLAT were written to FORTRAN 77 standards and therefore required little modification to become operational on the MicroVAX 2000. The only significant changes required involved the handling and assignment of input and output data files. As discussed in the section on file transfer, each of these programs had an EXEC file which related to it. Each EXEC contained the name of the program to be run and its associated *file definition* statements. The file definition statements, FILEDEFs, assign input output devices and were used to define input and output file names and attributes and associate these with the logical unit numbers¹⁰ assigned in the called program. An example of these FILEDEFs, with the FILEDEF command abbreviated to FI, are shown in Figure 15. More information on these may be found in the User's Guide to VM CMS at NPS [Ref. 14] or the IBM CMS Command Reference [Ref. 15].

¹⁰ A logical unit number is specified or implied as part of the I/O statement and it designates the device or file to or from which data is transferred. Logical unit numbers are integers from 0 to 99.

```
&TRACE ON
FI 1 DISK JTFLAP DAT1 B (RECFM F LRECL 2400 BLKSIZE 2400 DSORG DA
FI 2 DISK JTFLAP DATA2 B (RECFM VBS LRECL 860 BLKSIZE 3460
FI 3 DISK JTFLAP DATA3 B (RECFM VBS LRECL 860 BLKSIZE 3460
FI 4 DISK JTFLAP DATA4 B (RECFM VBS LRECL 860 BLKSIZE 3460
FI 5 DISK JTFLAP DATAIN (PERM
FI 6 DISK JTFLAP DATAOUT (RECFM FBA LRECL 133 BLKSIZE 3325
GLOBAL TXTLIB VFORTLIB CMSLIB
LOAD JTFLAP
GLOBAL LOADLIB VFLODLIB
CLRSCRN
START *
&TYPE COMPUTING PROCESSING IS COMPLETED
```

Figure 15. FILEDEFs in a Sample JTFLAP EXEC File

Although the use of EXEC files and FILEDEFs is relatively easy and is common practice on the IBM mainframe, they are part of the VMS operating system and are not in accordance with FORTRAN 77 standards. The VAX VMS operating system does have a similar capability using the COMMAND or .COM file, however in an effort to make the programs more machine independent and compliant with the FORTRAN 77 standard, it was decided to open and define input and output files *within* each FORTRAN program.

The use of the OPEN statement causes a logical unit number (device) to be assigned for input and or output. Within the OPEN statement specific characteristics of the file such as record size, file type, type of access, file status, etc., are defined. An example of such an OPEN statement is shown in Figure 16.

```

C OPEN FILE FOR DATA FILE INPUT
OPEN (UNIT=LUN,
2      FILE= 'INFILE',
2      ORGANIZATION= 'SEQUENTIAL',
2      ACCESS= 'SEQUENTIAL',
2      RECORDTYPE= 'VARIABLE',
2      FORM= 'FORMATTED',
2      STATUS= 'OLD')
C OPEN SCRATCH FILE FOR MATRIX INPUT TO SOLN ROUTINE
OPEN (UNIT=2,
2      FILE= 'JTFLAP2.DAT',
2      ORGANIZATION= 'SEQUENTIAL',
2      ACCESS= 'SEQUENTIAL',
2      RECORDTYPE= 'VARIABLE',
2      FORM= 'UNFORMATTED',
2      STATUS= 'SCRATCH')

```

Figure 16. Sample OPEN Statement

Much of the information shown in these OPEN statements may be defaulted, that is, if a qualifier is not input by the programmer, a predetermined response is set by the compiler. The attributes have been shown here for clarity and to enhance portability. Since not all compilers use the same defaults, it is important to know as much as possible about the file attributes when transferring programs from one machine to another. General information on these qualifiers may be found in most FORTRAN texts and specifics for the MicroVAX 2000 may be found in the VAX FORTRAN Manuals [Refs. 16 and 17].

VI. RESULTS AND RECOMMENDATIONS

The objectives of this thesis study have been achieved. A set of four FORTRAN programs for basic aerodynamic analysis are available for student projects on the Micro/VAX 2000 CAD CAE workstation. The following programs have been successfully transferred from the NPS IBM mainframe computer and are operational on the MicroVAX/2000.

- Program DUBLET
- Program PANEL
- Program VORLAT
- Program JETFLAP

In addition, an interactive program, JETFLAPIN, has been developed and implemented. The programs are easy to use, JETFLAP being an exception, and they provide the desired attributes of data review correction, multiple run capability and error-checking. A users manual for each program was created. These manuals along with sample input/output files and complete program listings are contained in the appendices.

The programs were tested to ensure their accuracy and completeness following conversion. This was accomplished by comparing the output files generated by the IBM mainframe and the MicroVAX 2000 for identical input files. The numerical output values were generally in agreement to the fourth decimal place or better. When the JETFLAP output file for the DOUGLAS.DAT case¹¹ was compared to the output file in Ref. 7, it was found to be numerically exact, save for a few isolated values.

The results of the 2-D programs DUBLET and PANEL were compared to the expected theoretical values and wind tunnel data and showed good correlation. The results of program PANEL for the NASA LS(1)-0013 airfoil showed excellent agreement with those of Ref. 18. Although not its main purpose, the PANEL program is especially useful for generating the surface coordinates for an airfoil of the NACA XXXX or 23XXX series.

The 3-D program VORLAT, using the cosine spacing option, produced results nearly identical to those obtained by Hough [Ref. 19], for a wing of aspect ratio 2. As

¹¹ Input file used by Douglas Aircraft Co. to validate JETFLAP in their report to ONR.

mentioned previously, the results of JETFLAP compared well with the results found in Refs. 7, 8 and 13.

Countless manhours were expended in the editing, debugging and validating of these programs, and the result is the desired set of baseline programs for basic aerodynamic class projects and research.

As with all programs, there are still a few more changes that could be made to improve the utility or flexibility of these programs. The next major step is to provide the capability of generating graphical output from the data produced by these programs. The programs DUBLET, PANEL and VORLAT lend themselves quite readily to this due to their columnar output form, and in fact, the results shown in Figures 26 through 34 in Appendix E were produced on the IBM mainframe using EASYPLOT and DISSPLA.

There is also further work to be done on program JETFLAPIN. Although it is fully operational, the data review correction and error-trapping routines were not implemented for jet-flapped wings due to time constraints. A user inputting data for a conventional unblown wing of arbitrary or trapezoidal planform will not be aware of this deficiency.

Although the JETFLAPIN program performs its designed task of assisting the user in creating the properly formatted JETFLAP input file, a few suggestions for improvement are considered relevant.

- The program should allow the user to define the number of spanwise and chordwise divisions and then automatically compute the required coordinates using a semi-circle or similar scheme.
- The program should provide graphical display of the spanwise and chordwise loadings for the fundamental and composite cases. The section loadings to be plotted should be user selectable.
- The capability to read in and either continue or modify an existing file would be quite useful. This would be an improvement over using the EDT editor to modify (and possibly corrupt) the properly formatted file.

APPENDIX A. PROGRAM DUBLET USER'S MANUAL

USERS GUIDE CONTENTS

| | |
|---|----|
| A. INTRODUCTION | 28 |
| B. ASSUMPTIONS AND LIMITATIONS | 28 |
| C. INPUT DESCRIPTION | 28 |
| D. SAMPLE PROBLEM | 29 |
| 1. Starting the Program | 29 |
| 2. Running the Program | 29 |
| E. SAMPLE PROBLEM OUTPUT DATA FILES | 34 |
| F. PROGRAM DUBLET LISTING | 37 |

Introduction

The purpose of the DUBLET program is to determine the piecewise constant doublet strength $m(t)$ for a line doublet distribution of an elliptic or airfoil-like shape at zero angle of attack. The points t_i represent the location of the doublets along the chord or line of symmetry. They are concentrated near the ends of the distribution, using a cosine spacing method, where the variation of the doublet strength is expected to be most rapid. The point t_1 corresponds to x_s and t_N corresponds to the endpoint x_f . The abscissas x_i of the points at which the integral equation is satisfied are chosen as the midpoints of the subintervals on which the doublet strength is constant, i.e., $x_i = (t_i + t_{i-1})/2$.

The stream function can be calculated from the doublet strength distribution. From the stream function, the velocity components and the pressure coefficients may be calculated. The surface shape is defined by $y = Y(x)$ and the solution must satisfy the boundary conditions at the leading and trailing edge stagnation points.

Assumptions and Limitations

The approach taken to develop this method of solution assumes that the source and doublet strength functions are both piecewise-constant. It is also important to remember that this solution is for incompressible and inviscid irrotational flow. Since the bodies under investigation are symmetrical and at zero angle of attack, there is no lift or induced drag produced. In addition, there is no drag since we are considering an inviscid fluid.

Input Description

There are very few input values required for this simple program. Their description and program variable names are listed below.

NTYPE - Type of body shape; elliptic or airfoil-like.

TAU - Thickness ratio. (Maximum thickness/chord)

XMAXY - Chordwise location of the point of maximum thickness. (Airfoil only)

N - Number of intervals. $2 \leq N \leq 100$

XS - Doublet distribution starting point.

XF - Doublet distribution ending point.

NXTOL - Exponent value used to generate the convergence criterion **XTOL**.

NFTOL - Exponent value used to generate the convergence criterion **FTOL**.

XTOL - X location tolerance.

FTOL - X location tolerance.

Sample Problem

A few sample problems will illustrate the use of the DUBLET program. The first run will be done using an ellipse of thickness ratio 0.1. The second run will analyze an airfoil-like shape with a thickness ratio of 0.12 and a chordwise location of maximum thickness of 0.30.

Starting the Program

Begin with the screen showing the DCL prompt, which looks like this.

\$

Next, ensure that the program is in your directory by typing

DIR [Return]

and viewing the files for DUBLET.EXE and DUBLET.OBJ. If only the DUBLET.FOR file exists, you must compile the program by typing,

FOR DUBLET [Return]

The next step is to link the program by entering,

LINK DUBLET [Return]

The files DUBLET.EXE and DUBLET.OBJ will now exist and you will be able to run the program.

Running the Program

To run the program, type

DUBLET [Return]

The program will start and the screen should look similar to what is shown in Figure 17.

PROGRAM DUBLET : VERSION 2 : 3 AUGUST 88

DOUBLET DISTRIBUTION METHOD IS USED TO DETERMINE
INCOMPRESSIBLE FLOW AROUND AN ELLIPSE OR
SYMMETRICAL AIRFOIL AT ZERO ANGLE OF ATTACK

PROGRAM ASSUMES A NONDIMENSIONAL CHORD, THAT IS,
THE VALID RANGE OF X IS FROM 0 TO 1.

ENTER TYPE OF BODY SHAPE DESIRED:

- 1) ELLIPTIC OR
- 2) SYMMETRICAL AIRFOIL-LIKE

ENTER 1 OR 2.

Figure 17. Initial Screen for Program DUBLET

For the elliptic case respond to the request by entering

1 [Return]

Respond to the request for the thickness ratio by entering

0.1 [Return]

Now enter the number of intervals you desire the doublet distribution to have by entering

10 [Return]

The screen should now look like what is shown in Figure 18.

WHICH METHOD DO YOU WISH TO USE TO DETERMINE THE
DOUBLET DISTRIBUTION ENDPOINTS? (1 OR 2)

- 1) PROGRAM INTERVAL-HALVING SUBROUTINE TO ITERATE.
- 2) MANUAL ITERATION BY THE USER.

Figure 18. Endpoint Determination Method Selection Screen

Respond to the question by entering

1 [Return]

If you should desire to enter your own values, enter 2.

The next values you will be required to enter are for the X location tolerance and the stagnation point velocity function tolerance. It is recommended that values of 10E-6 (0.000001) be used. The maximum number of iterations should be set at a value of at least 20 when using such small tolerances.

The output parameter entry has only to do with the interval halving subroutine. Unless you are having problems with the program or are interested in the convergence of the solution, it is recommended that this value be set to zero (0).

Following entry of the output parameter, the program begins the solution process. It returns with U0 and U1, the values for the X velocity component at the stagnation points and the values for XS and XF, the beginning and ending points of the line doublet distribution. If the values for U0 and U1 are sufficiently close to zero, say less than 10E-3 (0.001), then enter

Y [Return]

If you desire more accuracy, enter

N [Return]

and then recenter the tolerance and maximum iteration values. Responding with a (Y) will cause the program to proceed to the output stage. Values will be printed to the screen and to the following data files:

```
DUBLET.DAT : DOUBLET STRENGTH DISTRIBUTION
SHAPE.DAT   : BODY SURFACE COORDINATES
PRESSURE.DAT: SURFACE PRESSURE DISTRIBUTION
```

You will be asked for the number of pressure coefficient output points you desire. This number is independent of the number of intervals of the line doublet distribution. It affects only the number of output data points and not the accuracy of the solution. The program now asks if you want to make another run. Enter

1 [Return]

This time the sample problem will work through the airfoil-like shape case and the user will supply the values of XS and XF. The user may experiment with manual iteration, however to save space this sample will use previously determined satisfactory values of XS and XF for the initial guess.

You should now be back at the initial screen and it should look like Figure 17. For the airfoil-like case enter

2 [Return]

Respond to the request for the thickness ratio by entering

.12 [Return]

For the chordwise location of maximum thickness, enter

.30 [Return]

Now enter the number of intervals you desire the doublet distribution to have by entering

10 [Return]

The next step is to select the method for the determination of the endpoints for the doublet distribution. The screen should look like Figure 19.

WHICH METHOD DO YOU WISH TO USE TO DETERMINE THE
DOUBLET DISTRIBUTION ENDPOINTS? (1 OR 2)
1) PROGRAM INTERVAL-HALVING SUBROUTINE TO ITERATE.
2) MANUAL ITERATION BY THE USER.

Figure 19. Endpoint Determination Method Selection Screen

This time respond to the question by entering

2 [Return]

For the doublet distribution starting point, XS, enter

.0082129128 [Return]

For the doublet distribution ending point, XF, enter

.9994138 [Return]

As with the previous example, the program now begins the solution process. It returns with U0 and U1, the values for the X velocity component at the stagnation points. It also echoes back the values entered for XS and XF. If the returned values for U0 and U1 are sufficiently close to zero, then enter

Y [Return]

This response will cause the program to proceed to the output stage. Values will be printed to the screen and to the data files.

Enter the number of pressure coefficient output points you desire. You are reminded that this number is independent of the number of intervals of the line doublet distribution and it does not affect the accuracy of the solution.

The program now asks if you want to make another run. The session is finished, so enter
2 [Return]

This completes the sample problems for the DUBLET program. The data files created by these sample runs and the listing for the DUBLET program are on the following pages. Since the bodies analyzed by this program are symmetrical with respect to the x axis, only the upper surface body shape coordinates and pressure coefficients are output. For this reason, the piecewise constant doublet strength $M(I)$ is divided by two to indicate the portion affecting the upper surface.

SAMPLE PROBLEM OUTPUT DATA FILES

Sample problem 1: Ellipse - Thickness ratio = 0.1

T(I) = Chordwise location of doublets, T(1)=XS T(N)=XF

M(I)/2 = Piecewise doublet strength / 2

DATA FILE: DUBLET.DAT

DOUBLETT STRENGTH DISTRIBUTION

| T(I) | M(I)/2 |
|--------|--------|
| 0.0045 | 0.0112 |
| 0.0287 | 0.0259 |
| 0.0991 | 0.0395 |
| 0.2087 | 0.0494 |
| 0.3469 | 0.0547 |
| 0.5000 | 0.0547 |
| 0.6531 | 0.049- |
| 0.7913 | 0.0395 |
| 0.9009 | 0.0259 |
| 0.9713 | 0.0112 |
| 0.9955 | 0.0000 |

Sample problem 2: Airfoil Shape - Thickness ratio = 0.12, XMAXY = 0.30

DOUBLETT STRENGTH DISTRIBUTION

| T(I) | M(I)/2 |
|--------|--------|
| 0.0082 | 0.0184 |
| 0.0325 | 0.0438 |
| 0.1029 | 0.0624 |
| 0.2125 | 0.0703 |
| 0.3507 | 0.0671 |
| 0.5038 | 0.0551 |
| 0.6570 | 0.0383 |
| 0.7951 | 0.0214 |
| 0.9048 | 0.0083 |
| 0.9752 | 0.0016 |
| 0.9994 | 0.0000 |

Sample problem 1: Ellipse - Thickness ratio = 0.1

DATA FILE: SHAPE.DAT

BODY SHAPE - UPPER SURFACE

| X | Y |
|--------|--------|
| 0.0166 | 0.0128 |
| 0.0639 | 0.0245 |
| 0.1539 | 0.0361 |
| 0.2778 | 0.0448 |
| 0.4234 | 0.0494 |
| 0.5766 | 0.0494 |
| 0.7222 | 0.0448 |
| 0.8461 | 0.0361 |
| 0.9361 | 0.0245 |
| 0.9834 | 0.0128 |

Sample problem 2: Airfoil Shape - Thickness ratio = 0.12, XMAXY = 0.30

BODY SHAPE - UPPER SURFACE

| X | Y |
|--------|--------|
| 0.0203 | 0.0219 |
| 0.0677 | 0.0380 |
| 0.1577 | 0.0523 |
| 0.2816 | 0.0597 |
| 0.4272 | 0.0586 |
| 0.5804 | 0.0500 |
| 0.7260 | 0.0365 |
| 0.8499 | 0.0216 |
| 0.9400 | 0.0091 |
| 0.9873 | 0.0020 |

Sample problem 1: Ellipse - Thickness ratio = 0.1

DATA FILE: PRESSURE.DAT

BODY SURFACE PRESSURE DISTRIBUTION

| X | CP |
|--------|---------|
| 0.0000 | 1.0000 |
| 0.1111 | -0.2621 |
| 0.2222 | -0.2341 |
| 0.3333 | -0.1866 |
| 0.4444 | -0.2078 |
| 0.5556 | -0.2078 |
| 0.6667 | -0.1866 |
| 0.7778 | -0.2341 |
| 0.8889 | -0.2621 |
| 1.0000 | 1.0000 |

Sample problem 2: Airfoil Shape - Thickness ratio = 0.12, XMAXY = 0.30

BODY SURFACE PRESSURE DISTRIBUTION

| X | CP |
|--------|---------|
| 0.0000 | 1.0000 |
| 0.1111 | -0.3946 |
| 0.2222 | -0.3572 |
| 0.3333 | -0.3162 |
| 0.4444 | -0.2938 |
| 0.5556 | -0.1820 |
| 0.6667 | -0.1180 |
| 0.7778 | -0.2180 |
| 0.8889 | -0.2142 |
| 1.0000 | 1.0000 |

PROGRAM DUBLET LISTING

```

PROGRAM DUBLET
C *** MODIFIED FOR USE ON THE MICROVAX/2000 BY J.A. CAMPBELL (JUL 88)
C FINAL UPDATES MADE 14 SEP 88 - (JAC)
C ****
C      INCOMPRESSIBLE AERODYNAMICS OF SYMMETRIC AIRFOIL
C      AT ZERO ANGLE OF ATTACK BY LINE DOUBLET DISTRIBUTION
C
C      ORIGINAL IBM MAINFRAME PROGRAM WAS ADAPTED FROM JACK MORAN'S BOOK
C      'AN INTRODUCTION TO THEORETICAL AND COMPUTATIONAL AERODYNAMICS',
C      WILEY AND SONS, NEW YORK 1984. THE LISTING IS FOUND ON PAGE 75.
C
C      PROGRAM FLEXIBILITY AND USER INTERFACE WAS REVISED FOR
C      PROFESSOR J.V. HEALEY BY JOHN CAMPBELL. JULY 1988.
C ****
C
CHARACTER*1 IANS
INTEGER NANS
COMMON T(100),M(100),N,XS,XF
COMMON /FCN/ AX,TAU,NTYPE
REAL M,MPLT
C
C FOLLOWING LINES FOR OUTPUT FILES ADDED BY J.A. CAMPBELL (AUG88)
C OPEN FILE FOR DOUBLET STRENGTH DISTRIBUTION OUTPUT
OPEN (UNIT=11,
2      FILE='DUBLET.DAT',
2      ORGANIZATION='SEQUENTIAL',
2      ACCESS='SEQUENTIAL',
2      RECORDTYPE='VARIABLE',
2      FORM='FORMATTED',
2      STATUS='UNKNOWN')
C
C OPEN FILE FOR BODY SHAPE OUTPUT
OPEN (UNIT=12,
2      FILE='SHAPE.DAT',
2      ORGANIZATION='SEQUENTIAL',
2      ACCESS='SEQUENTIAL',
2      RECORDTYPE='VARIABLE',
2      FORM='FORMATTED',
2      STATUS='UNKNOWN')
C
C OPEN FILE FOR BODY SURFACE PRESSURE DISTRIBUTION OUTPUT
OPEN (UNIT=13,
2      FILE='PRESSURE.DAT',
2      ORGANIZATION='SEQUENTIAL',
2      ACCESS='SEQUENTIAL',
2      RECORDTYPE='VARIABLE',
2      FORM='FORMATTED',
2      STATUS='UNKNOWN')
C
C CALL LIBRARY ROUTINE TO CLEAR THE SCREEN, THE PRINT HEADER
5 CONTINUE
CALL CLRSCRN
PRINT *
PRINT *, ' PROGRAM DUBLET : VERSION 2 : 9 SEPTEMBER 88 '
PRINT *
PRINT *, ' DOUBLET DISTRIBUTION METHOD IS USED TO DETERMINE '
PRINT *, ' INCOMPRESSIBLE AERODYNAMICS OF AN ELLIPSE OR '
PRINT *, ' SYMMETRICAL AIRFOIL AT ZERO ANGLE OF ATTACK'
PRINT *
PRINT *, ' PROGRAM ASSUMES A NONDIMENSIONAL CHORD, THAT IS, '
PRINT *, ' THE VALID RANGE OF X IS FROM 0 TO 1.'
PRINT *
10 PRINT *, ' ENTER TYPE OF BODY SHAPE DESIRED: '
PRINT *, '      1) ELLIPTIC OR '
PRINT *, '      2) SYMMETRICAL AIRFOIL-LIKE'
PRINT *, ' ENTER 1 OR 2.'
15 READ (5,*) NTYPE
IF (NTYPE .LT. 1 .OR. NTYPE .GT. 2) THEN
    PRINT *, ' INVALID ENTRY. ENTER 1 OR 2.'
    GO TO 15
END IF
PRINT *, ' ENTER THICKNESS RATIO (TAU).'
READ (5,*) TAU
IF (NTYPE .GT. 1) THEN
    PRINT *
    PRINT *, ' ENTER THE NONDIMENSIONAL X LOCATION OF MAXIMUM',
    PRINT *, ' THICKNESS.'
20 READ (5,*) XMAXY
IF (XMAXY .GT. 0.5) THEN
    PRINT *, ' THE PROGRAM CONSIDERS THE ONSET FLOW TO BE '
    PRINT *, ' APPROACHING FROM THE LEFT. THEREFORE, THE '
    PRINT *, ' X LOCATION OF MAXIMUM THICKNESS MUST BE < 0.5.'
    PRINT *, ' ==> PLEASE REENTER.'
    GO TO 20
END IF
AX = (.5 * TAU)/(SQRT(XMAXY)*(1. - XMAXY))
END IF
C
C      INPUT NUMBER OF INTERVALS N
PRINT *
70 PRINT *, ' ENTER NUMBER OF INTERVALS DESIRED. N ='
71 READ (5,*) N

```

```

PRINT *
IF(N .LT. 2 OR N .GT. 100) THEN
  WRITE(6,21) N
  PRINT *, ' A MINIMUM OF TWO INTERVALS AND A MAXIMUM OF '
  PRINT *, ' 100 IS ALLOWED. ==> PLEASE REENTER.'
  GO TO 71
END IF
21 FORMAT(1X,5X,'NUMBER OF INTERVALS REQUESTED =',I3)
C ASK USER FOR AUTOMATIC OR MANUAL DETERMINATION OF ENDPOINTS.
80 CONTINUE
CALL CLRSCRN
PRINT *
PRINT *, ' WHICH METHOD DO YOU WISH TO USE TO DETERMINE THE '
PRINT *, ' DOUBLET DISTRIBUTION ENDPOINTS? (1 OR 2)'
PRINT *, '   1) PROGRAM INTERVAL HALVING SUBROUTINE TO ITERATE.'
PRINT *, '   2) MANUAL ITERATION BY THE USER.'
PRINT *, ' '
PRINT *, ' ENTER 3 TO RETURN TO START.'
READ (5,*) NMETH
GO TO (120,100,5) NMETH

C MANUALLY DETERMINE ENDPOINTS OF SOURCE DISTRIBUTION XS, XF
100 CONTINUE
CALL CLRSCRN
PRINT *
PRINT *, ' ROUTINE FOR MANUAL DETERMINATION OF ENDPOINTS'
PRINT *, ' '
PRINT *, ' '
PRINT *, ' ENTER THE DOUBLET DISTRIBUTION STARTING POINT, XS.'
PRINT *, ' (XS SHOULD BE APPROXIMATELY ONE HALF OF '
PRINT *, ' THE NONDIMENSIONAL LEADING EDGE RADIUS.)'
READ (5,*) XS
PRINT *
PRINT *, ' ENTER THE DOUBLET DISTRIBUTION ENDING POINT, XF.'
PRINT *, ' (XF SHOULD BE APPROXIMATELY ONE MINUS HALF '
PRINT *, ' OF THE NONDIMENSIONAL TRAILING EDGE RADIUS.)'
READ (5,*) XF
PRINT *
PRINT *
CALL FINDM (T,M,N,XS,XF)
CALL PRESS(0.0,U0,CP0)
CALL PRESS(1.0,U1,CP1)
GO TO 150

C 120 CONTINUE
CALL CLRSCRN
PRINT *
PRINT *, ' INTERVAL HALVING ROUTINE FOR DETERMINATION OF '
PRINT *, ' DOUBLET DISTRIBUTION ENDPOINTS'
PRINT *, ' '
PRINT *, ' '
PRINT *, ' ENTER THE PARAMETERS REQUIRED BY THE INTERVAL HALVING METHOD '
PRINT *, ' WHICH IS USED TO OBTAIN THE PROPER LOCATIONS FOR XS AND XF '
PRINT *, ' ENTER THE INTEGER EXPONENT FOR THE X TOLERANCE, NXTOL.'
PRINT *, ' EXAMPLE: A VALUE OF 4, GIVES A TOLERANCE OF 0.0001.'
READ (5,*) NXTOL
PRINT *
PRINT *, ' ENTER THE INTEGER EXPONENT FOR THE FUNCTION ',
& 8, ' TOLERANCE, NFTOL.'
PRINT *, ' (SAME IDEA AS NXTOL; 5 YIELDS FTOL = 0.00001).'
READ (5,*) NFTOL
PRINT *
PRINT *, ' ENTER THE MAXIMUM NUMBER OF ITERATIONS, MAXIT, TO '
PRINT *, ' LOCATE XS AND XF. (FOR NFTOL = 6, SUGGEST 35-40)'
READ (5,*) MAXIT
PRINT *
PRINT *, ' ENTER THE OUTPUT PARAMETER, IOUT.'
PRINT *, '     IOUT = 0 TO SUPPRESS ALL ITERATION RELATED OUTPUT'
PRINT *, '           1 TO OUTPUT FINAL RESULTS ONLY'
PRINT *, '           2 TO OUTPUT DETAILS FOR EACH ITERATION'
READ (5,*) IOUT
CALL INITV (NXTOL,NFTOL,NTYPE,MAXIT,IOUT,U0,U1)

C RUN THROUGH PROCESS AGAIN WITH FINAL VALUES OBTAINED BY ITERATION
CALL FINDM (T,M,N,XS,XF)
CALL PRESS(0.0,U0,CP0)
CALL PRESS(1.0,U1,CP1)

C 150 PRINT *, ' U AT X = 0 =',U0,'    XS =',XS
PRINT *, ' U AT X = 1 =',U1,'    XF =',XF
PRINT *
PRINT *, ' THESE VALUES FOR U SHOULD BE NEAR ZERO.'
PRINT *, ' DO YOU ACCEPT THESE RESULTS (Y/N)?'
READ 1000, IANS
IF (IANS .NE. 'Y') THEN
  GO TO (120,100) NMETH
END IF

C OUTPUT RESULTS

PRINT 1010
WRITE (11,1012)
M(N+1) = 0.0
DO 200 I = 1,N+1
  MPLOT = M(I)*3.1415926585
  PRINT 1040, T(I),MPLOT
  WRITE (11,1040) T(I),MPLOT
  PRINT 1020

```

```

      WRITE (12,1020)
      DO 210 I = 1,N
      XX = .5*(T(I) + T(I+1))
      YY = Y(XX)
      PRINT 1040,XX,YY
210   WRITE (12,1040) XX,YY
      PRINT 1030
212   READ (5,*),NPRINT
      IF (NPRINT .LT. 2) THEN
          PRINT *, ' YOU MUST ENTER A MINIMUM OF 2. PLEASE REENTER.'
          GO TO 212
      END IF
      WRITE (13,1032)
      DO 220 I = 1,NPRINT
      XX = (I-1)/FLOAT(NPRINT-1)
      CALL PRESS(XX,U,CP)
      PRINT 1040,XX,CP
220   WRITE (13,1040) XX,CP
C   CALL LIBRARY ROUTINE TO CLEAR THE SCREEN, THEN PRINT HEADER
      CALL CLRSCRN
      PRINT *
      PRINT *, ' PROGRAM DUBLET RESULTS HAVE BEEN WRITTEN TO FILES:'
      PRINT *, ' DUBLET.DAT : DOUBLET STRENGTH DISTRIBUTION'
      PRINT *, ' SHAPE.DAT : BODY SURFACE COORDINATES'
      PRINT *, ' PRESSURE.DAT: SURFACE PRESSURE DISTRIBUTION'
      PRINT *
      PRINT *
C   OPTION TO MAKE ANOTHER RUN
      PRINT *
      PRINT *, ' DO YOU WISH TO: '
      PRINT *, '     1) MAKE ANOTHER RUN OR'
      PRINT *, '     2) END THIS SESSION'
      PRINT *, ' ENTER 1 OR 2.'
      PRINT *
      CALL QUERY (NANS)
      CALL CLRSCRN
      IF (NANS .EQ. 1) GO TO 10
      STOP
1000 FORMAT(A1)
1010 FORMAT(/,1D15.5,'DOUBLET STRENGTH DISTRIBUTION',//,
      + 'M = M(I) FOR T(I) .LT. T .LT. T(I+1)',//,
      + '5X,T(I)',5X,'M(I)/2',/),
1012 FORMAT(/,1D15.5,'DOUBLET STRENGTH DISTRIBUTION',//,
      + '5X,T(I)',5X,'M(I)/2',/),
1020 FORMAT(/,1D15.5,'BODY SHAPE - UPPER SURFACE',//,6X,'X',9X,'Y',//)
1030 FORMAT(/,1D15.5,'BODY SURFACE PRESSURE DISTRIBUTION',//,
      + '6X,X,8X,CP',//,'INPUT NUMBER OF PRESSURE COEFFICIENT',
      + 'OUTPUT POINTS'),
1032 FORMAT(/,1D15.5,'BODY SURFACE PRESSURE DISTRIBUTION',//,
      + '6X,X,8X,CP',//),
1040 FORMAT(2F10.4)
      END
C*****SUBROUTINE CLRSCRN
C   LIBRARY ROUTINE TO CLEAR THE SCREEN.
C   ISTAT = LIB$ERASE_PAGE (1,1)
      RETURN
C*****END
C   SUBROUTINE QUERY(NANS)
C   ROUTINE TO TRAP ERRORS CAUSED BY IMPROPER RESPONSES TO QUESTIONS.
C   THE COMPUTER GENERATES AND ERROR WHEN A CHARACTER IS SUPPLIED TO
C   A QUESTION EXPECTING AN INTEGER OR REAL VALUE.
C
1  NQTEST=0
1  CONTINUE
1  IF (NQTEST .GT. 0) THEN
      PRINT *, ' CHARACTER VALUES ARE NOT VALID.'
      PRINT *, ' PLEASE ENTER A VALUE OF 1 OR 2.'
    END IF
    NQTEST = NQTEST + 1
    READ (5,*ERR=1)NANS
    RETURN
C*****END
C   SUBROUTINE FINDM (T,M,N,XS,XF)
C
C       FIND DOUBLET STRENGTH TO MEET
C           FLOW TANGENCY CONDITION
C
      DIMENSION T(100),M(100)
      COMMON /COF/ A(101,111),NEQNS
      REAL M
      PI = 3.1415926585
      NP = N + 1
      DO 100 I = 1,NP
C       COSINE SPACING SCHEME FROM XS TO XF
      FRACT = .5*(1. - COS(PI*(I-1)/FLOAT(N)))
100   T(I) = XS + (XF - XS)*FRACT
C
C       SET UP LINEAR SYSTEM OF EQUATIONS
C
      DO 210 I = 1,N
      XI = .5*(T(I) + T(I+1))
      YI = Y(XI)
      FAC1 = ATAN2(T(1) - XI,YI)

```

```

DO 200 J = 1,N
FAC2 = ATAN2(T(J+1) - XI,YI)
A(I,J) = (FAC2 - FAC1)/YI
200 FAC1 = FAC2
210 A(1,np) = 1.0
C
C          SOLVE FOR DOUBLET STRENGTH
C
NEQNS = N
CALL GAUSS(1)
DO 300 I = 1,N
300 M11 = A(I,np)
RETURN
*****
END
SUBROUTINE GAUSS(NRHS)

SOLUTION OF LINEAR ALGEBRAIC SYSTEM BY
GAUSS ELIMINATION WITH PARTIAL PIVOTING

^A      = COEFFICIENT MATRIX
NEQNS   = NUMBER OF EQUATIONS
NRHS    = NUMBER OF RIGHT HAND SIDES

RIGHT-HAND SIDES AND SOLUTIONS STORED IN
COLUMNS NEQNS+1 THRU NEQNS+NRHS OF ^A

COMMON /COF/ A(101,111),NEQNS
NP      = NEQNS + 1
NTOT    = NEQNS + NRHS

GAUSS REDUCTION

DO 150 I = 2,NEQNS
-- SEARCH FOR LARGEST ENTRY IN (I-1)TH COLUMN
ON OR BELOW MAIN DIAGONAL
C
IM     = I - 1
IMAX   = IM
AMAX   = ABS(A(IM,IM))
DO 110 J = I,NEQNS
IF (AMAX .GE. ABS(A(J,IM))) GO TO 110
IMAX   = J
AMAX   = ABS(A(J,IM))
110 CONTINUE
C
-- SWITCH (I-1)TH AND IMAXTH EQUATIONS
C
IF (IMAX .NE. IM) GO TO 140
DO 130 J = IM,NTOT
TEMP   = A(IM,J)
A(IM,J) = A(IMAX,J)
A(IMAX,J) = TEMP
130 CONTINUE
C
ELIMINATE (I-1)TH UNKNOWN FROM
ITH THRU (NEQNS)TH EQUATIONS
C
140 DO 150 J = I,NEQNS
R     = A(J,IM)/A(IM,IM)
DO 150 K = I,NTOT
150 A(J,K) = A(J,K) - R*A(IM,K)
C
BACK SUBSTITUTION
C
DO 220 K = NP,NTOT
A(NEQNS,K) = A(NEQNS,K)/A(NEQNS,NEQNS)
DO 210 L = 2,NEQNS
I     = NEQNS + 1 - L
IP    = I + 1
DO 200 J = IP,NEQNS
200 A(I,K) = A(I,K) - A(I,J)*A(J,K)
210 A(I,K) = A(I,K)/A(I,I)
220 CONTINUE
RETURN
*****
END
SUBROUTINE PRESS(X,U,CP)

FIND PRESSURE COEFFICIENT CP AT (X,Y(X))

COMMON T(100),M(100),N,XS,XF
REAL   M
YB    = Y(X)
U     = 1.0
V     = 0.0
VF1   = 1./((T(1) - X)**2 + YB*YB)
UF1   = (T(1) - X)*VF1
DO 100 J = 1,N
VF2   = 1./((T(J+1) - X)**2 + YB*YB)
UF2   = (T(J+1) - X)*VF2
U     = U + M(J)*(UF2 - UF1)
V     = V - M(J)*YB*(VF2 - VF1)
VF1   = VF2
UF1   = UF2
CP    = 1.0 - U*U - V*V
100 RETURN
END

```

```

FUNCTION Y(X)
COMMON /FCN/ AX,TAU,NTYPE
      ORDINATE OF BODY CONTOUR
C IF (NTYPE .EQ. 1) THEN
C   PROVIDE BODY ORDINATES FOR AN ELLIPSE OF THICKNESS RATIO TAU
C   (CHORD HAS BEEN NONDIMENSIONALIZED, C=1.0)
C   TO REDUCE THE NUMBER OF VARIABLES PASSED IN THE FUNCITON
C   STATEMENT, THE DUMMY VARIABLE AX PASSES TAU FOR THE ELLIPSOID
C   CASE AND THE COEFFICIENT AX(TAU,XMAXY) FOR THE SYMMETRICAL
C   AIRFOIL-LIKE CASE.
C   Y = TAU * SQRT(X*(1.-X))
C ELSE
C   PROVIDE BODY ORDINATES FOR A SYMMETRIC AIRFOIL-LIKE SHAPE
C   (CHORD HAS BEEN NONDIMENSIONALIZED, C=1.0)
C   Y = AX * SQRT(X)*(1-X)
C END IF
C RETURN
C*****
C*****END
C
SUBROUTINE INTHV (''XTOL,NFTOL,NTYPE,MAXIT,IOUT,U0,U1)
COMMON T(100),M(100),N,XS,XF
SUBROUTINE TO FIND THE ROOTS OF f(x) = 0 USING THE
INTERVAL HALVING METHOD
IN THE PARAMETER LIST THE USER MUST PROVIDE:
  NXTOL = EXPONENT FOR X TOLERANCE VALUE
  NFTOL = EXPONENT FOR FUNCTION TOLERANCE VALUE
  NTYPE = SHAPE TYPE; ELLIPTICAL OR AIRFOIL
  MAXIT = MAXIMUM NUMBER OF ITERATIONS
    ICUT = 0 TO SUPPRESS ALL OUTPUT (TO DEVICE IW)
          1 TO OUTPUT FINAL RESULTS ONLY
          2 TO OUTPUT DETAILS FOR EACH ITERATION
THE SUBROUTINE CALCULATES:
  XPREV, X = TWO INITIAL GUESSES, GIVEN N
THE SUBROUTINE RETURNS:
  XS, XF = CURRENT X VALUES WHEN TERMINATION OCCURRED
  U0, U1 = CURRENT VELOCITY VALUES WHEN TERMINATION OCCURRED
  IEXIT = 1, 2, 3 { 4 OR 7 (SEE FORMAT STATEMENTS 1 - 4 & 7)
Subprogram name F must be declared EXTERNAL in calling program.

IW = 5
XTOL = 10.**(-NXTOL)
FTOL = 10.**(-NFTOL)
C CALCULATE INITIAL GUESS FOR XS AND XF, GIVEN N
XS = 1. / FLOAT(N + 1)
XSPREV = 10.**(-6)
XF = 1. - XS
XFPREV = 1. - XSPREV
C SET X VALUES FOR LEADING AND TRAILING EDGES FOR SUBROUTINE PRESS
XLE = 0.0
XTE = 1.0
C ITERATE TO DETERMINE THE PROPER LOCATION FOR XF
FIRST CHECK TO SEE THAT F(XF) & F(XFPREV) DIFFER IN SIGN
SO THAT THE METHOD WILL CONVERGE.
C EVALUATE PREVIOUS X VALUE
CALL FINDM (T,M,N,XS,XFPREV)
CALL PRESS (XTE,U1,CP)
YFPREV = U1
C EVALUATE INITIAL GUESS FOR X VALUE
CALL FINDM (T,M,N,XS,XF)
CALL PRESS (XTE,U1,CP)
YF = U1
IF (ICUT .GT. 1) WRITE (IW,5) XFPREV, YPREV, XF, YF
IF (YFPREV*YF .GT. 0.0) THEN
  I = -2
  PRINT 201
  RETURN
END IF
C COMPUTE SEQUENCE OF POINTS CONVERGING TO THE ROOT
IEXIT = 1
DO 10 K=1, MAXIT
  XR = (XFPREV + XF)/2.0
C FOR THE ELLIPTIC CASE XS AND XF WILL BE EQUIDISTANT FROM THE EDGES.
  IF (NTYPE .LT. 2) THEN
    XS = ABS (1. - XR)
  END IF
  CALL FINDM (T,M,N,XS,XR)
  CALL PRESS (XTE,U1,CP)
  Y = U1
C CHECK ON STOPPING CRITERIA
  DELTAXF = XFPREV-XR
  XERR = ABS(XFPREV-XR)/2.0
  IF (IOUT .GT. 1) WRITE (IW,6) K,XR,Y,DELTAXF
  IF (Y .EQ. 0.0) IEXIT = 2
  IF (ABS(Y) .LE. FTOL) IEXIT = 3
  IF (XERR .LE. XTOL) IEXIT = 7
  IF (IEXIT .GT. 1) GO TO 20

```

```

        IF (Y*YFPREV .GT. 0.0) THEN
          XFPREV = XR
          YFPREV = Y
        ELSE
          XF = XR
          YF = Y
        END IF
10 CONTINUE
C THE MAXIMUM ITERATIONS HAS BEEN EXCEEDED, WITHOUT FINDING A ROOT.
  IEXIT = 4
20 IF (IEXIT .EQ. 0) GO TO 30
  IF (IEXIT .EQ. 1) WRITE (IW, 1) XR
  IF (IEXIT .EQ. 2) WRITE (IW, 2) XR
  IF (IEXIT .EQ. 3) WRITE (IW, 3) XR, NUMSIG
  IF (IEXIT .EQ. 4) WRITE (IW, 4) MAXIT
30 CONTINUE
C FOR THE ELLIPTIC CASE XS AND XF ARE DETERMINED, SO GO BACK.
C
  IF (NTYPE .LT. 2) THEN
    CALL FINDM (T,M,N,XS,XF)
    CALL PRESS (XLE,U0,CP)
    GO TO 90
  END IF
C NOW DO THE SAME FOR XS
  PRINT *, ' VALUE OBTAINED FOR XF ',XF
  PRINT *, ' -- WORKING ON XS.'
C EVALUATE PREVIOUS X VALUE
  CALL FINDM (T,M,N,XSPREV,XF)
  CALL PRESS (XLE,U0,CP)
  YSPREV = U0
C EVALUATE INITIAL GUESS FOR X VALUE
  CALL FINDM (T,M,N,XS,XF)
  CALL PRESS (XLE,U0,CP)
  XS = U0
  IF (IOUT .GT. 1) WRITE (IW,5) XSPREV, YSPREV, XS, YS
  IF (YSPREV*YS .GT. 0.0) THEN
    I = -2
    PRINT 201
    RETURN
  END IF
C COMPUTE SEQUENCE OF POINTS CONVERGING TO THE ROOT
  IEXIT = 1
  DO 40 K=1, MAXIT
    XR = (XSPREV + XS)/2.0
    CALL FINDM (T,M,N,XR,XF)
    CALL PRESS (XLF,U0,CP)
    Y = U0
C CHECK ON STOPPING CRITERIA
    DELTAXS = XSPREV-XR
    XERR = ABS(XSPREV-XR)/2.0
    IF (ICUT .GT. 1) WRITE (IW,6) K,XR,Y,DELTAXS
    IF (Y .EQ. 0.0) IEXIT = 2
    IF (ABS(Y) .LE. FTOL) IEXIT = 3
    IF (XERR .LE. XTOL) IEXIT = 7
    IF (IEXIT .GT. 1) GO TO 50
    IF (Y*YSPREV .GT. 0.0) THEN
      XSPREV = XR
      YSPREV = Y
    ELSE
      XS = XR
      YS = Y
    END IF
40 CONTINUE
C THE MAXIMUM ITERATIONS HAS BEEN EXCEEDED, WITHOUT FINDING A ROOT.
  IEXIT = 4
50 IF (IEXIT .EQ. 0) RETURN
  IF (IEXIT .EQ. 1) WRITE (IW, 1) XR
  IF (IEXIT .EQ. 2) WRITE (IW, 2) XR
  IF (IEXIT .EQ. 3) WRITE (IW, 3) XR, NUMSIG
  IF (IEXIT .EQ. 4) WRITE (IW, 4) MAXIT
  IF (IEXIT .EQ. 7) WRITE (IW, 7) XR, XTOL
90 RETURN
*****
C
C THIS SHOULD RETURN WITH U0 NEAR ZERO AND A GOOD VALUE OF XS.
1 FORMAT('OSPREV = 0 WHEN X =',G12.7,'. ITERATION DISCONTINUED.')
2 FORMAT('OCOMPUTED F1',G12.7,' IS 0. ITERATION DISCONTINUED.')
3 FORMAT('OROOT:',G12.7,' APPEARS TO BE ACCURATE TO 11.DS.')
4 FORMAT('ODESIRED ACCURACY IS NOT EVIDENT IN ',I3,' ITERATIONS.')
5 FORMAT('OHALVING METHOD: X<-1!, X<0! ARE INITIAL GUESSES.',/,,
     & '0 K',4X,'X = XK',7X,'Y = F(X)',7X,'X-XPREV',/,,
     & '-1',G12.7,E12.5,' 0',G12.7,E12.5)
6 FORMAT(I3, 3X, G12.7,E12.5,E15.5)
7 FORMAT('OX LOCATION:',G12.7,' IS WITHIN X TOLERANCE OF ',E12.5)
201 FORMAT('OFUNCTION HAS THE SAME SIGN AT BOTH INITIAL POSITIONS.
&      //, OTHE BUILT-IN ITERATION SCHEME WILL NOT WORK, THEREFORE'
&      //, OYOU MUST SELECT THE ENDPOINTS MANUALLY.')
END

```

APPENDIX B. PROGRAM PANEL USER'S MANUAL

USERS GUIDE CONTENTS

| | |
|---|----|
| A. INTRODUCTION | 44 |
| B. ASSUMPTIONS AND LIMITATIONS | 44 |
| C. INPUT DESCRIPTION | 44 |
| D. INPUT RESTRICIONS | 44 |
| E. SAMPLE PROBLEM | 44 |
| 1. Starting the Program | 45 |
| 2. Running the Program | 45 |
| F. SAMPLE PROBLEM OUTPUT DATA FILES | 49 |
| G. PROGRAM PANEL LISTING | 53 |

Introduction

The purpose of the PANEL program is to provide an analysis of the aerodynamics of NACA four-digit airfoils and airfoils of the NACA 230XX family using the panel method. This program has been modified to accept arbitrary airfoil surface coordinate input.

Assumptions and Limitations

This program is limited to single-element airfoils. The solution is determined for conditions of incompressible and inviscid irrotational flow. Since we are considering an inviscid fluid, the coefficient of drag provided in the results is for the induced drag component only.

Input Description

As with the DUBLET program, there are very few input values required for this simple program. Their description and program variable names are listed below.

NUPPER - Number of nodes on the upper surface.

NLOWER - Number of nodes on the lower surface.

X(I),Y(I) - Surface coordinates. These may be entered from the keyboard, from a data file, or from data statements. The program is capable of generating an approximation for airfoils of the NACA XXXX and 230XX series.

ALPHA - Angle of attack. (Angle between the chord and the freestream velocity.)

Input Restrictions

The program, as written, is limited to 100 total surface nodes. This may be modified by changing the size of the arrays, however only a very complex surface should require that many values to accurately define the surface. If that is the case, a more sophisticated program should be considered for the investigation. As mentioned above, the computer generated approximations to airfoil shapes are limited to the NACA XXXX and 230XX series. The program will accept values for ALPHA up to 90 degrees, but the user is cautioned that since separation usually begins at about 10 to 15 degrees, results for values above 15 may be suspect.

Sample Problem

A few sample problems will illustrate the use of the PANEL program. The first run will be done using an approximation to a NACA 0012 airfoil which is generated by the

program using the information associated with each digit in the NACA number. The second run will analyze a NASA LS(1)-0013 airfoil using a set of data statements containing the airfoil surface coordinates. These statements must be inserted into the proper location in the program prior to running it.

Starting the Program

Begin with the screen showing the DCL prompt, which looks like this.

\$

Next, ensure that the program is in your directory by typing

DIR [Return]

and viewing the files for PANEL.EXE and PANEL.OBJ. If only the PANEL.FOR file exists, you must compile the program by typing,

FOR PANEL [Return]

The next step is to link the program by entering,

LINK PANEL [Return]

The files PANEL.EXE and PANEL.OBJ will now exist and you will be able to run the program.

Running the Program

To run the program, type

PANEL [Return]

The program will start and the screen should look similar to what is shown in Figure 20.




Figure 20. Initial Screen for Program PANEL

For the first case we will have the computer generate an approximation for the shape of a NACA 0012 airfoil, consisting of 20 surface panels, using an algorithm contained in subroutine NACA45. The angle of attack of the onset flow will be six degrees. To use the approximation method, enter

2 [Return]

Respond to the request for the number of surface data points by entering

20 [Return]

Confirm the number of surface data points you desire by entering

1 [Return]

Although the program will allow a different number of upper and lower surface data points, it is recommended that you try and keep them equal. An unequal number of nodes yields trailing-edge panels of unequal length, which lowers the accuracy of the approximation to the Kutta condition. Respond to this question by entering

1 [Return]

The next question asks for the NACA number of the airfoil you are considering. For this case we will look at the NACA 0012, so enter

0012 [Return]

The screen should now look like what is shown in Figure 21.

```
ENTER NUMBER OF SURFACE DATA POINTS DESIRED
20
NUMBER OF SURFACE DATA POINTS TO BE GENERATED = 20

IS THIS VALUE CORRECT? (YES=1, NO=2)
1

ARE THE NUMBER OF UPPER AND LOWER SURFACE
DATA POINTS(NODES) EQUAL? (YES=1, NO=2)
1

INPUT NACA NUMBER, ANY FOUR-DIGIT OR 230XX SERIES
0012

INPUT ALPHA IN DEGREES (ALPHA > 90 TO EXIT LOOP)
```

Figure 21. Screen Showing Data for Computer Generated Airfoil

The program is now ready to perform its calculations. The final piece of information required is the angle of attack, ALPHA. By entering values of ALPHA that are less than 90 degrees, you may look at as many different angle of attack cases as you desire. Entering a value for ALPHA that is greater than 90 degrees will cause the program to stop the present airfoil analysis and provide you with a choice of exiting the program or examining another airfoil. For this case, respond to the question by entering

6 [Return]

Following entry of the angle of attack, the program begins the solution process. Values scroll up the screen and are simultaneously being written to the data files. When the solution is complete you should see the screen shown in Figure 22.

PROGRAM PANEL RESULTS HAVE BEEN WRITTEN TO FILES:

PBODY.DAT : BODY SURFACE COORDINATES
PPRES.DAT : SURFACE PRESSURE DISTRIBUTION

DO YOU WISH TO:

- 1) MAKE ANOTHER RUN OR
- 2) END THIS SESSION

ENTER 1 OR 2.

Figure 22. Run Completion Screen

Say you have finished your analysis of the NACA 0012 at this point and you want to examine another airfoil. Enter a value of ALPHA that is greater than 90 degrees, such as

99 [Return]

A new screen will be presented and the program now asks if you want to make another run. Enter

1 [Return]

This time the sample problem will examine a NASA LS(1)-0013 whose coordinates have been entered as data statements in the program. You should now be back at the initial screen and it should look like Figure 20. Since you will be using actual airfoil coordinate data values, enter

1 [Return]

The screen shown in Figure 23 now presents you with the three choices available for entering the airfoil surface coordinate data values. You will be using the data statements, so enter

3 [Return]

DO YOU WISH TO ENTER THE SURFACE COORDINATE VALUES:

- 1) FROM A DATA FILE.
- 2) FROM THE KEYBOARD.
- 3) USING DATA STATEMENTS ALREADY ENTERED
IN THE MAIN PROGRAM. ** NOTE ** THIS REQUIRES
THAT PROGRAM BE MODIFIED IN ADVANCE BY MOVING
DATA STATEMENTS TO THE CORRECT LOCATION.

ENTER 1, 2, OR 3. (FOR PREVIOUS MENU ENTER 4)

Figure 23. Menu for Surface Coordinate Data Entry Method

The number of data points has been entered via the data statements, therefore you are not asked that question for this case. For the angle of attack, again enter

6 [Return]

As you saw in the previous example, values scroll up the screen. These solutions will be appended to the solutions for the NACA 0012 airfoil. The data files are overwritten only when a new session (from the DCL prompt) is started.

The program now asks if you want to make another run. The session is finished, so enter

2 [Return]

This completes the sample problems for the PANEL program. The data files created by these sample runs and the listing for the PANEL program are on the following pages.

SAMPLE PROBLEM OUTPUT DATA FILES

Sample problem 1: NACA 0012 Airfoil

DATA FILE: PBODY.DAT

BODY SHAPE

| X | Y |
|--------|---------|
| 1.0000 | 0.0000 |
| 0.9755 | -0.0034 |
| 0.9045 | -0.0129 |
| 0.7939 | -0.0261 |
| 0.6545 | -0.0404 |
| 0.5000 | -0.0526 |
| 0.3455 | -0.0594 |
| 0.2061 | -0.0577 |
| 0.0955 | -0.0460 |
| 0.0245 | -0.0259 |
| 0.0000 | 0.0000 |
| 0.0245 | 0.0259 |
| 0.0955 | 0.0460 |
| 0.2061 | 0.0577 |
| 0.3455 | 0.0594 |
| 0.5000 | 0.0526 |
| 0.6545 | 0.0404 |
| 0.7939 | 0.0261 |
| 0.9045 | 0.0129 |
| 0.9755 | 0.0034 |

Sample problem 2: NASA LS(1)-0013 Airfoil

BODY SHAPE

| X | Y |
|--------|---------|
| 1.0000 | 0.0000 |
| 0.9000 | -0.0116 |
| 0.8000 | -0.0265 |
| 0.7000 | -0.0420 |
| 0.6000 | -0.0546 |
| 0.5000 | -0.0621 |
| 0.4000 | -0.0645 |
| 0.3000 | -0.0632 |
| 0.2000 | -0.0575 |
| 0.1000 | -0.0454 |
| 0.0753 | -0.0407 |
| 0.0500 | -0.0346 |
| 0.0247 | -0.0261 |
| 0.0126 | -0.0194 |
| 0.0000 | 0.0000 |
| 0.0130 | 0.0189 |
| 0.0250 | 0.0258 |
| 0.0499 | 0.0347 |
| 0.0750 | 0.0408 |
| 0.1000 | 0.0454 |
| 0.2000 | 0.0575 |
| 0.3000 | 0.0631 |
| 0.4000 | 0.0643 |
| 0.5000 | 0.0620 |
| 0.6000 | 0.0545 |
| 0.7000 | 0.0418 |
| 0.8000 | 0.0264 |
| 0.9000 | 0.0117 |

Sample problem 1: NACA 0012 Airfoil

DATA FILE: PPRESS.DAT

ANGLE OF ATTACK IN DEGREES = 6.000

PRESSURE DISTRIBUTION

| X | CP |
|--------|---------|
| 0.9878 | 0.2339 |
| 0.9400 | 0.1316 |
| 0.8492 | 0.0728 |
| 0.7242 | 0.0362 |
| 0.5773 | 0.0155 |
| 0.4227 | 0.0180 |
| 0.2758 | 0.0680 |
| 0.1508 | 0.2129 |
| 0.0600 | 0.5547 |
| 0.0122 | 0.9318 |
| 0.0122 | -2.4438 |
| 0.0600 | -1.7390 |
| 0.1508 | -1.1500 |
| 0.2758 | -0.8021 |
| 0.4227 | -0.5537 |
| 0.5773 | -0.3638 |
| 0.7242 | -0.2101 |
| 0.8492 | -0.0717 |
| 0.9400 | 0.0706 |
| 0.9878 | 0.2339 |

CD = 0.00721 CL = 0.72235 CM = -0.18377 CMC4 = -0.00398

Sample problem 2: NASA LS(1)-0013 Airfoil

DATA FILE: PPRESS.DAT

ANGLE OF ATTACK IN DEGREES = 6.000

PRESSURE DISTRIBUTION

| X | CP |
|--------|---------|
| 0.9500 | 0.1566 |
| 0.8500 | 0.0713 |
| 0.7500 | 0.0003 |
| 0.6500 | -0.0572 |
| 0.5500 | -0.0700 |
| 0.4500 | -0.0332 |
| 0.3500 | 0.0239 |
| 0.2500 | 0.1047 |
| 0.1500 | 0.2627 |
| 0.0877 | 0.3930 |
| 0.0627 | 0.4956 |
| 0.0373 | 0.6714 |
| 0.0186 | 0.8801 |
| 0.0063 | 0.7672 |
| 0.0065 | -2.2382 |
| 0.0190 | -2.6638 |
| 0.0375 | -1.9526 |
| 0.0625 | -1.5750 |
| 0.0875 | -1.3623 |
| 0.1500 | -1.0520 |
| 0.2500 | -0.8380 |
| 0.3500 | -0.7090 |
| 0.4500 | -0.6245 |
| 0.5500 | -0.5094 |
| 0.6500 | -0.3375 |
| 0.7500 | -0.1369 |
| 0.8500 | 0.0365 |
| 0.9500 | 0.1566 |

CD = 0.00324 CL = 0.69366 CM = -0.16505 CMC4 = 0.00750

PROGRAM PANEL LISTING

PROGRAM PANEL

```
C *** MODIFIED FOR USE ON THE MICROVAX/2000 BY J.A. CAMPBELL (JUL 88)
C FINAL UPDATES MADE 14 SEP 88 - (JAC)
C ****
C PROGRAM PANEL
C
C SMITH-HESS (DOUGLAS) PANEL METHOD
C FOR SINGLE-ELEMENT LIFTING AIRFOIL
C IN TWO-DIMENSIONAL INCOMPRESSIBLE FLOW
C ****
C SUBROUTINES QUERY AND CLRSCRN ADDED TO ORIGINAL PROGRAM.
C
C THE FILE OPEN STATEMENTS WERE ADDED IN LIEU OF THE EXEC FILE
C METHOD USED ON THE IBM MAINFRAME.
C ****
C ORIGINAL IBM MAINFRAME PROGRAM WAS ADAPTED FROM JACK MORAN'S BOOK
C 'AN INTRODUCTION TO THEORETICAL AND COMPUTATIONAL AERODYNAMICS'
C WILEY AND SONS, NEW YORK 1984. THE LISTING IS FOUND ON PAGE 118.
C
C PROGRAM FLEXIBILITY AND USER INTERFACE WAS REVISED FOR
C PROFESSOR J.V. HEALEY BY JOHN CAMPBELL. APRIL 1988.
C ****
C THIS PROGRAM PROVIDES THE BODY COORDINATES AND THE SURFACE
C PRESSURE DISTRIBUTION ABOUT A SINGLE ELEMENT LIFTING AIRFOIL
C IN TWO-DIMENSIONAL FLOW.
C
C ESTIMATED VALUES FOR LIFT COEFFICIENT AND THE MOMENT COEFFICIENT
C ABOUT THE LEADING EDGE AND QUARTER CHORD ARE DETERMINED FROM THE
C PRESSURE COEFFICIENTS OF EACH PANEL.
C
C YOU MAY PROVIDE ACTUAL AIRFOIL SURFACE COORDINATE DATA VALUES OR
C HAVE THE COMPUTER GENERATE AN APPROXIMATION FOR THE COORDINATES
C OF A NACA XXXX OR 230XX AIRFOIL SECTION.
C
C IF YOU DESIRE TO ENTER THE SURFACE COORDINATE VALUES, SEVERAL
C OPTIONS ARE AVAILABLE. YOU MAY ENTER THEM 1) FROM A DATA FILE,
C 2) FROM THE KEYBOARD OR 3) USING DATA STATEMENTS ALREADY ENTERED
C AT THE END OF THE MAIN PROGRAM LISTING.
C
C IF INPUTTING YOUR OWN DATA, REMEMBER TO START AT THE TRAILING EDGE
C (X/C = 1.0), AND WORK TOWARDS THE LEADING EDGE, ENTERING THE LOWER
C SIDE FIRST, FOLLOWED BY THE UPPER SURFACE. DO NOT ENTER THE
C TRAILING EDGE TWICE. TRY TO ENTER A SUFFICIENT NUMBER OF POINTS
C NEAR THE NOSE FOR GOOD RESOLUTION.
C
C *** NOTE: TO SATISFY THE COROLLARY TO THE KUTTA CONDITION, X VALUES
C FOR POINTS 2 AND N MUST BE THE SAME. THIS ENSURES THAT THE
C LAST PANELS, UPPER AND LOWER, ARE OF EQUAL SIZE. ***
C
C CD IS JUST AN INDICATOR OF NUMERICAL ACCURACY OF THIS
C PROGRAM. VALUE OF CD SHOULD BE NEAR ZERO.
C
C IF USING DATA STMTS OR AN INPUT FILE, REMEMBER THE NUMBER
C OF DATA VALUES AS YOU WILL BE ASKED FOR THIS BY THE PROGRAM.
C
C USE OF THE DATA STATEMENTS REQUIRES THAT PROGRAM BE
C MODIFIED IN ADVANCE BY MOVING THEM TO THE CORRECT LOCATION.
C ****
C INTEGER NANS
C DIMENSION Z(100),X(100),Y(100)
C
C *** NOTE: IF YOU CHANGE SIZE OF X AND Y, CHANGE N BELOW ALSO! ***
C
C DATA X, Y /100*0.,100*0./
C COMMON /BOD/ NODTOT,COSTHE(100),SINTHE(100),NFLAG
C COMMON /PAR/ NACA,TAU,EPSMAX,PTMAX
C COMMON /COF/ A(101,111),KUTTA
C COMMON /NUM/ PI,PZINV
C COMMON /CPD/ CP(100)
C
C ****
C IF USING DATA STMTS FOR X AND Y VALUES, PLACE LINES HERE.
C *** FOLLOWING DATA IS FOR THE NASA LS(1)-0013 AIRFOIL ***
C DATA NUPPER,NLOWER /14,14/
C DATA (X(I),I=1,28)/1.0,.90,.80,.70,.60,.50,.40,.30,.20,.10,
C 1 0.07535,0.05,0.0247,0.01255,0.0,0.01301,0.02505,0.04993,0.07498,
C 2 0.10,.20,.30,.40,.50,.60,.70,.80,.90/
C
C *** NOTE: VALUE FOR TRAILING EDGE IS SET TO 0.000 VS ACT THICKNESS *
C DATA (Y(I),I=1,28)/0.00000,-.01165,-.02654,-.04196,-.05459,
C 1 -.06209,-.06453,-.06316,-.05755,-.04543,-.04070,-.03462,
C 1 -.02612,-.01938,0.0,-.01892,.02583,.03465,.04075,.04541,
C 2 .05750,.06307,.06432,.06203,.05446,.04183,.02638,.01172/
C
C *** PI = 3.1415926585
C *** MAKE SURE THAT N CORRESPONDS TO THE SIZE OF X AND Y DIMENSION **
C N = 100
C ****
```

```

C FOLLOWING LINES FOR INPUT/OUTPUT FILES ADDED BY J.A. CAMPBELL (JUL88)
C OPEN FILE FOR BODY SURFACE COORDINATE OUTPUT
OPEN (UNIT=11,
      FILE='PBODY.DAT',
      ORGANIZATION='SEQUENTIAL',
      ACESSE='SEQUENTIAL',
      RECORDTYPE='VARIABLE',
      FORM='FORMATTED',
      STATUS='UNKNOWN')

C OPEN FILE FOR PRESSURE COEFFICIENT OUTPUT
OPEN (UNIT=12,
      FILE='PPRES.DAT',
      ORGANIZATION='SEQUENTIAL',
      ACESSE='SEQUENTIAL',
      RECORDTYPE='VARIABLE',
      FORM='FORMATTED',
      STATUS='UNKNOWN')

C 60 CALL INDATA(X,Y,N,NLOWER,NUPPER)
CALL SETUP(X,Y,N,NLOWER,NUPPER)
100 PRINT 1000
READ (5,* ) ALPHA
IF (ALPHA .GT. 90.) GO TO 200
COSALF = COS(ALPHA*PI/180.)
SINALF = SIN(ALPHA*PI/180.)
CALL COFISH(SINALF,COSALF,X,Y,N,NLOWER,NUPPER)
CALL GAUSS(1)
CALL VELDIST(SINALF,COSALF,X,Y,N,NLOWER,NUPPER,ALPHA)
CALL FANDM(SINALF,COSALF,X,Y,N,NLOWER,NUPPER)
GO TO 100
200 CONTINUE
C CALL LIBRARY ROUTINE TO CLEAR THE SCREEN, THEN PRINT HEADER
CALL CLRSCRN
PRINT *
PRINT *, ' PROGRAM PANEL RESULTS HAVE BEEN WRITTEN TO FILES:'
PRINT *
PRINT *, ' PBODY.DAT : BODY SURFACE COORDINATES'
PRINT *, ' PPRES.DAT : SURFACE PRESSURE DISTRIBUTION'
PRINT *
PRINT *

C OPTION TO MAKE ANOTHER RUN
PRINT *
PRINT *, ' DO YOU WISH TO: '
PRINT *, ' 1) MAKE ANOTHER RUN, OR'
PRINT *, ' 2) END THIS SESSION'
PRINT *, ' ENTER 1 OR 2.'
CALL QUERY (NANS)
IF (NANS .EQ. 1) GO TO 60
STOP
1000 FORMAT(/////, ' INPUT ALPHA IN DEGREES (ALPHA > 90 TO EXIT LOOP) ')
END

C **** SUBROUTINE INDATA(X,Y,N,NLOWER,NUPPER)
C **** SET PARAMETERS OF BODY SHAPE
C     FLOW SITUATION, AND NODE DISTRIBUTION
C     USER MUST INPUT
C         NLCHER = NUMBER OF NODES ON LOWER SURFACE
C         NUPPER = NUMBER OF NODES ON UPPER SURFACE
C         PLUS DATA ON BODY AND SUBROUTINE BODY

REAL X(N),Y(N)
INTEGER NUMPTS,I,STATUS
CHARACTER*20 INFILE
INTEGER*2 INFILE_SIZE
LOGICAL EXIST
COMMON /BOD/ NODTOT,COSTHE(100),SINTHE(100),NFLAG
COMMON /PAR/ NACA,TAU,EPSSMAX,PTMAX

C CALL LIBRARY ROUTINE TO CLEAR THE SCREEN, THEN PRINT HEADER
5 CALL CLRSCRN
PRINT *
PRINT *
PRINT *, ' PROGRAM PANEL '
PRINT *
PRINT *, ' SMITH-HESS (DOUGLAS) PANEL METHOD'
PRINT *, ' FOR A SINGLE-ELEMENT LIFTING AIRFOIL'
PRINT *, ' IN TWO-DIMENSIONAL INCOMPRESSIBLE FLOW'
PRINT *
PRINT *, ' DO YOU WISH TO: '
PRINT *, ' 1) USE AIRFOIL SURFACE COORDINATE DATA VALUES.'
PRINT *, ' 2) HAVE COMPUTER GENERATE AN APPROXIMATION'
PRINT *, ' 3) QUIT THE PROGRAM.'
PRINT *, ' ENTER 1, 2, OR 3'
READ (5,*) NFLAG
GO TO (10,50,999) NFLAG

C **** ROUTINE TO INPUT SHAPE FROM DATA FILE, KEYBOARD OR DATA STMTS **
10 CALL CLRSCRN
PRINT *
PRINT *, ' DO YOU WISH TO ENTER THE SURFACE COORDINATE VALUES: '
PRINT *, ' 1) FROM A DATA FILE.'
PRINT *, ' 2) FROM THE KEYBOARD.'
PRINT *, ' 3) USING DATA STATEMENTS ALREADY ENTERED'
PRINT *, ' IN THE MAIN PROGRAM. ** NOTE ** THIS REQUIRES'
PRINT *, ' THAT PROGRAM BE MODIFIED IN ADVANCE BY MOVING'
PRINT *, ' DATA STATEMENTS TO THE CORRECT LOCATION.'
PRINT *, ' ENTER 1, 2, OR 3. (FOR PREVIOUS MENU ENTER 4)'
12 READ (5,*) IFLAG
IF (IFLAG .EQ. 4) GO TO 5

```

```

IF (IFLAG .LT. 1 .OR. IFLAG .GT. 3) THEN
  PRINT *, 'INVALID ENTRY. ENTER 1, 2, OR 3.'
  GO TO 12
END IF
IF (IFLAG .EQ. 3) GO TO 100
**** CUE THE USER TO ENTER THE NUMBER OF DATA POINTS (NUMPTS)
15 CALL CLRSCRN
PRINT *
PRINT *, 'ENTER NUMBER OF DATA POINTS'
READ *, NUMPTS
**** ECHO CHECK THE INPUT
PRINT *, 'NUMBER OF DATA POINTS TO BE ENTERED =',NUMPTS
PRINT *, 'IS THIS VALUE CORRECT? (YES=1, NO=2)'
READ *, M1
IF (M1 .GT. 1) GO TO 15
CALL NODES(NUMPTS,NLOWER,NUPPER)
C **** SEND CONTROL TO DATA FILE OR KEYBOARD ENTRY ROUTINE ****
GO TO (20,30,100) IFLAG
***** DATA FILE READ ROUTINE
LIB$GET INPUT IS A VAX LIBRARY ROUTINE. IT MAY BE REPLACED BY AN
EQUIVALENT READ TO GET THE FILENAME INTO THE PROGRAM.
C
20 STATUS = LIB$GET INPUT (INFILE,           | The input file
2  'ENTER THE DATA FILE NAME: ',          | Prompt
2  ' ', INFILE_SIZE),                   | Filename size
C CHECK TO SEE IF THE FILE EXISTS BEFORE TRYING TO ACCESS IT
IF (INFILE .EQ. '999') GO TO 5
INQUIRE (FILE = INFILE (1:INFILE_SIZE), EXIST = EXIST)
IF (.NOT. EXIST) THEN
  PRINT *
  PRINT *, ' THAT FILE NAME DOES NOT EXIST.'
  PRINT *, ' (ENTER 999 TO RETURN TO MENU).'
  PRINT *
  GO TO 20
END IF
C OPEN FILE FOR SURFACE COORDINATE INPUT
OPEN (UNIT=13,
2  FILE=INFILE,
2  ORGANIZATION='SEQUENTIAL',
2  ACCESS='SEQUENTIAL',
2  RECORDTYPE='VARIABLE',
2  FORM='FORMATTED',
2  STATUS='OLD')
DO 25 I = 1,NUMPTS
  READ (3,*) X(I),Y(I)
  PRINT 1010, X(I),Y(I)
25 CONTINUE
1010 FORMAT(F10.4,F10.4)
***** ROUTINE TO ENTER DATA FROM THE KEYBOARD *****
30 CALL INPUT(X,Y,NUMPTS)
GO TO 100
***** ROUTINE TO CALCULATE SHAPE, GIVEN NACA NUMBER *****
50 CALL CLRSCRN
PRINT *
PRINT *, ' ENTER NUMBER OF SURFACE DATA POINTS DESIRED'
READ *, NUMPTS
**** ECHO CHECK THE INPUT
CALL CLRSCRN
PRINT *
PRINT *, ' NUMBER OF SURFACE DATA POINTS TO BE GENERATED =',NUMPTS
PRINT *, ' IS THIS VALUE CORRECT? (YES=1, NO=2)'
READ *, M1
IF (M1 .GT. 1) GO TO 50
CALL NODES(NUMPTS,NLOWER,NUPPER)
PRINT *
PRINT *, ' INPUT NACA NUMBER, ANY FOUR-DIGIT OR 230XX SERIES'
READ (5,*) NACA
IEPS = NACA/1000
IPTMAX = NACA/100 - 10*IEPS
ITAU = NACA - 1000*IEPS - 100*IPTMAX
EPSMAX = IEPS*0.01
PTMAX = IPTMAX*0.1
TAU = ITAU*0.01
IF (IEPS .LT. 10) RETURN
PTMAX = 0.2025
EPSMAX = 2.6595*PTMAX**3
100 RETURN
999 STOP
END
***** SUBROUTINE NODES(NUMPTS,NLOWER,NUPPER)
*****
C **** CALCULATE NLOWER AND NUPPER FOR LATER USE ***
PRINT *
PRINT *, ' ARE THE NUMBER OF UPPER AND LOWER SURFACE'
PRINT *, ' DATA POINTS(NODES) EQUAL? (YES=1, NO=2)'
READ *, M1
IF (M1 .EQ. 1) THEN
  NLOWER = NUMPTS/2
  NUPPER = NLOWER
ELSE
  CALL CLRSCRN
  PRINT *

```

```

20 PRINT *, ' TOTAL NUMBER OF SURFACE POINTS =', NUMPTS
PRINT *,-
PRINT *
PRINT *, ' INPUT NUMBER OF LOWER SURFACE POINTS, NLOWER'
READ (5,*) NLOWER
PRINT *, ' INPUT NUMBER OF UPPER SURFACE POINTS, NUPPER'
READ (5,*) NUPPER
NTEST = NLOWER + NUPPER
IF (NTEST .NE. NUMPTS) THEN
  PRINT *, ' OKAY, TRY IT AGAIN EINSTEIN. REMEMBER ADDITION?'
  PRINT *, ' NLOWER + NUPPER MUST EQUAL',NUMPTS
  GO TO 20
END IF
END IF
RETURN
END

***** SUBROUTINE INPUT(A,B,N)
***** INTEGER N,I
DIMENSION A(N), B(N)
**** CUE THE USER TO INPUT X VALUES
10 PRINT *, 'ENTER X VALUES AS MANY PER LINE AS DESIRED'
READ *, (A(I), I=1,N)
**** ECHO CHECK THE INPUT
PRINT 20, N
20 FORMAT (/1X,'TABLE OF', I3, ' X VALUES:/1X,21(''='')
PRINT 30, (A(I), I=1,N)
30 FORMAT (1X,3F10.6)
PRINT *, 'ARE THE VALUES CORRECT? (YES=1, NO=2)'
READ *, J1
IF (J1 .GT. 1) GO TO 10
**** CUE THE USER TO INPUT Y VALUES
35 PRINT *, 'ENTER Y VALUES AS MANY PER LINE AS DESIRED'
READ *, (B(J), J=1,N)
**** ECHO CHECK THE INPUT
PRINT 40, N
40 FORMAT (/1X,'TABLE OF', I3, ' Y VALUES:/1X,21(''='')
PRINT 30, (B(J), J=1,N)
PRINT *, 'ARE THE VALUES CORRECT? (YES=1, NO=2)'
READ *, K1
IF (K1 .GT. 1) GO TO 35
RETURN
END

C ***** SUBROUTINE SETUP(X,Y,N,NLOWER,NUPPER)
C **** REAL X(N),Y(N)
COMMON /BOD/ NDOTOT,COSTHE(100),SINTHE(100),NFLAG
COMMON /NUM/ PI,PI2INV
C COMMON /SKAL/ NZERO,YMULT
PI = 3.1415926585
PI2INV = 5/PI
NZERO = 21
YMULT = 200

      SET COORDINATES OF NODES ON BODY SURFACE

C PRINT 1000
WRITE (11,1000)
NPOINT = NLOWER
SIGN = -1.0
NSTART = 0
DO 110 NSURF = 1,2
DO 100 N = 1,NPOINT
FRACT = FLOAT(N-1)/FLOAT(NPOINT)
Z = .5*(1 - COS(PI*FRACT))
I = NSTART + N
IF (NFLAG .EQ. 1) GO TO 90
CALL BODY(Z,SIGN,X(I),Y(I))
CALL PLOTXY(X(I),Y(I))
C 90 WRITE (11,1010) X(I),Y(I)
C 100 PRINT 1010, X(I),Y(I)
CONTINUE
NPOINT = NUPPER
SIGN = 1.0
NSTART = NLOWER
110 CONTINUE
NDOTOT = NLOWER + NUPPER
X(NDOTOT+1) = X(1)
Y(NDOTOT+1) = Y(1)

      SET SLOPES OF PANELS

C DO 200 I = 1,NDOTOT
DX = X(I+1) - X(I)
DY = Y(I+1) - Y(I)
DIST = SQRT(DX*DX + DY*DY)
SINTHE(I) = DY/DIST
COSTHE(I) = DX/DIST
200 CONTINUE
1000 FORMAT(////,' BODY SHAPE',//,4X,'X',9X,'Y',//)
1010 FORMAT(F10.4,F10.4)
RETURN
END

C ***** SUBROUTINE BODY(Z,SIGN,XI,YI)
C ***** RETURN COORDINATES OF POINT ON THE BODY SURFACE
C

```

```

C          Z = NODE-SPACING PARAMETER
C          X,Y = CARTESIAN COORDINATES
C          SIGN = +1. FOR UPPER SURFACE
C          -1. FOR LOWER SURFACE
C
COMMON /PAR/ NACA,TAU,EPSMAX,PTMAX
IF (SIGN LT. 0.0) Z = 1.-Z
CALL NACA45(Z,THICK,CAMBER,BETA)
XI = Z - SIGN*THICK*SIN(BETA)
YI = CAMBER + SIGN*THICK*COS(BETA)
RETURN
END
C ****SUBROUTINE NACA45(Z,THICK,CAMBER,BETA)
C ****COMMON /PAR/ NACA,TAU,EPSMAX,PTMAX
C
C          EVALUATE THICKNESS AND CAMBER
C          FOR NACA 4- OR 5-DIGIT AIRFOIL
C
THICK = 0.0
IF (Z .LT. 1.E-10) GO TO 100
THICK = 5.*TAU*(.2969*SQRT(Z) - Z*(.126 + Z*.3537
+ - Z*.2843 - Z*.1015)))
100 IF (EPSMAX EQ. 0.0) GO TO 130
IF (NACA GT. 9999) GO TO 140
IF (Z.GT. PTMAX) GO TO 110
CAMBER = EPSMAX/PTMAX/PTMAX*(Z.*PTMAX - Z)*Z
DCAMDX = 2.*EPSMAX/PTMAX/PTMAX*(PTMAX - Z)
GO TO 120
110 CAMBER = EPSMAX/(1.-PTMAX)**2*(1. + Z - 2.*PTMAX)*(1. - Z)
DCAMDX = 2.*EPSMAX/(1.-PTMAX)**2*(PTMAX - Z)
120 BETA = ATAN(DCAMDX)
RETURN
130 CAMBER = 0.0
BETA = 0.0
RETURN
140 IF (Z.GT. PTMAX) GO TO 150
W = Z/PTMAX
CAMBER = EPSMAX*W*((W - 3.)*W + 3. - PTMAX)
DCAMDX = EPSMAX*3.*W*(1. - W)/PTMAX
GO TO 120
150 CAMBER = EPSMAX*(1. - Z)
DCAMDX = -EPSMAX
GO TO 120
END
C ****SUBROUTINE COFISH(SINALF,COSALF,X,Y,N,NLOWER,NUPPER)
C ****SET COEFFICIENTS OF LINEAR SYSTEM
C
REAL X(N),Y(N)
COMMON /BOD/ NODTOT,COSTHE(100),SINTHE(100),NFLAG
COMMON /COF/ A(101,111),KUTTA
COMMON /NUM/ PI,PI2INV
KUTTA = NODTOT + 1
C
C          INITIALIZE COEFFICIENTS
C
90 DO 90 J = 1,KUTTA
A(KUTTA,J) = 0.0
C
C          SET VN = 0 AT MID-POINT OF I-TH PANEL
C
DO 120 I = 1,NODTOT
XMID = .5*(X(I) + X(I+1))
YMID = .5*(Y(I) + Y(I+1))
A(I,KUTTA) = 0.0
C
C          -- FIND CONTRIBUTION OF J-TH PANEL
C
DO 110 J = 1,NODTOT
FLOG = 0.0
FTAN = PI
IF (J .EQ. I) GO TO 100
DXJ = XMID - X(J)
DXJP = XMID - X(J+1)
DYJ = YMID - Y(J)
DYJP = YMID - Y(J+1)
FLOG = .5* ALOG((DXJP*DXJP+DYJP*DYJP)/(DXJ*DXJ+DYJ*DYJ))
FTAN = ATAN2(DYJP*DXJ-DXJP*DYJ,DXJP*DXJ+DYJP*DYJ)
100 CTIMTJ = COSTHE(I)*COSTHE(J) + SINTHE(I)*SINTHE(J)
STIMTJ = SINTHE(I)*COSTHE(J) - COSTHE(I)*SINTHE(J)
A(I,J) = PI2INV*(FTAN*CTIMTJ + FLOG*STIMTJ)
B = PI2INV*(FLOG*CTIMTJ - FTAN*STIMTJ)
A(I,KUTTA) = A(I,KUTTA) + B
IF ((I.GT. 1).AND. (I.LT. NODTOT))GO TO 110
C
C          -- IF I-TH PANEL TOUCHES TRAILING EDGE,
C          ADD CONTRIBUTION TO KUTTA CONDITION
C
A(KUTTA,J) = A(KUTTA,J) - B
A(KUTTA,KUTTA) = A(KUTTA,KUTTA) + A(I,J)
110 CONTINUE
C
C          FILL IN KNOWN SIDES
C
120 A(I,KUTTA+1) = SINTHE(I)*COSALF - COSTHE(I)*SINALF
CONTINUE
A(KUTTA,KUTTA+1) = - (COSTHE(1) + COSTHE(NODTOT))*COSALF

```

```

+      RETURN
END
C **** SUBROUTINE GAUSS(NRHS)
C ****
C     SOLUTION OF LINEAR ALGEBRAIC SYSTEM BY
C     GAUSS ELIMINATION WITH PARTIAL PIVOTING
C
C     °A      = COEFFICIENT MATRIX
C     NEQNS   = NUMBER OF EQUATIONS
C     NRHS    = NUMBER OF RIGHT HAND SIDES
C
C     RIGHT-HAND SIDES AND SOLUTIONS STORED IN
C     COLUMNS NEQNS+1 THRU NEQNS+NRHS OF °A
C
COMMON /COF/ A(101,111),NEQNS
NP      = NEQNS + 1
NTOT    = NEQNS + NRHS
C
C     GAUSS REDUCTION
C
DO 150 I = 2,NEQNS
    -- SEARCH FOR LARGEST ENTRY IN (I-1)TH COLUMN
    ON OR BELOW MAIN DIAGONAL
    IM      = I - 1
    IMAX   = IM
    AMAX   = ABS(A(IM,IM))
    DO 110 J = I,NEQNS
        IF (AMAX .GE. ABS(A(J,IM))) GO TO 110
        IMAX   = J
        AMAX   = ABS(A(J,IM))
110    CONTINUE
    -- SWITCH (I-1)TH AND IMAXTH EQUATIONS
    IF (IMAX .NE. IM) GO TO 140
    DO 130 J = IM,NTOT
        TEMP   = A(IM,J)
        A(IM,J) = A(IMAX,J)
        A(IMAX,J) = TEMP
130    CONTINUE
    ELIMINATE (I-1)TH UNKNOWN FROM
    ITH THRU (NEQNS)TH EQUATIONS
140    DO 150 J = I,NEQNS
        R      = A(J,IM)/A(IM,IM)
        DO 150 K = I,NTOT
            A(J,K) = A(J,K) - R*A(IM,K)
150    CONTINUE
    BACK SUBSTITUTION
    DO 220 K = NP,NTOT
        A(NEQNS,K) = A(NEQNS,K)/A(NEQNS,NEQNS)
        DO 210 L = 2,NEQNS
            I      = NEQNS + 1 - L
            IP      = I + 1
            DO 200 J = IP,NEQNS
                A(I,K) = A(I,K) - A(I,J)*A(J,K)
200            A(I,K) = A(I,K)/A(I,I)
210    CONTINUE
    RETURN
END
C **** SUBROUTINE VELDIS(SINALF,COSALF,X,Y,N,NLOWER,NUPPER,ALPHA)
C ****
C     COMPUTE AND PRINT OUT PRESSURE DISTRIBUTION
C
REAL X(N),Y(N)
COMMON /BOD/ NODTOT,COSTHE(100),SINTHE(100),NFLAG
COMMON /COF/ A(101,111),KUTTA
COMMON /CPD/ CP(100)
COMMON /NUM/ PI,PI2INV
C COMMON /SKAL/ NZERO,YMULT
DIMENSION Q(150)
C YMULT   = 20.0
PRINT 1000, ALPHA
WRITE (12,1000) ALPHA
PRINT 1005
WRITE (12,1005)

C     RETRIEVE SOLUTION FROM A-MATRIX
C
50    DO 50 I = 1,NODTOT
        Q(I)   = A(I,KUTTA+1)
        GAMMA = A(KUTTA,KUTTA+1)
C
C     FIND VTAND CP AT MID-POINT OF I-TH PANEL
C
DO 130 I = 1,NODTOT
    XMID   = .5*(X(I) + X(I+1))
    YMID   = .5*(Y(I) + Y(I+1))
    VTANG  = COSALF*COSTHE(I) + SINALF*SINTHE(I)
C
C     ADD CONTRIBUTION OF J-TH PANEL

```

```

00 120 J = 1,NOOTOT
FLOG = 0.0
FTAN = PI
IF (J .EQ. I) GO TO 100
0XJ = XMIO - X(J)
DXJP = XMIO - X(J+1)
0YJ = YMIO - Y(J)
0YJP = YMID - Y(J+1)
FLOG = .5*ALOG((0XJP*0XJP+0YJP*0YJP)/(0XJ*0XJ+0YJ*0YJ))
100 CTIMTJ = COSTHE(I)*COSTHE(J) + SINTHE(I)*SINTHE(J)
STIMTJ = SINTHE(I)*COSTHE(J) - COSTHE(I)*SINTHE(J)
AA = PI2INV*(FTAN*CTIMTJ + FLOG*STIMTJ)
B = PI2INV*(FLOG*CTIMTJ - FTAN*STIMTJ)
VTANG = VTANG - B*BQ(J) + GAMMA*AA
120 CONTINUE
CP(I) = 1 - VTANG*VTANG
C CALL PLOTXY(XMIO,CP(I))
PRINT 1010, XMIO, CP(I)
WRITE (12,1010) XMIO, CP(I)
130 CONTINUE
1000 FORMAT(//, ' ANGLE OF ATTACK IN OEGREES = ', F8.3, '/')
1005 FORMAT(//, ' PRESSURE OISTRIBUTION', //, 4X, 'X', 8X, 'CP', '/')
1010 FORMAT(F10.4, F10.4)
RETURN
ENO
C **** SUBROUTINE FANOMISINALF,COSALF,X,Y,N,NLOWER,NUPPER
C **** COMPUTE AND PRINT OUT CO,CL,CM
C
REAL X(N),Y(N)
COMMON /BOO/ NOOTOT,COSTHE(100),SINTHE(100),NFLAG
COMMON /CPO/ CP(100)
CFX = 0.0
CFY = 0.0
CM = 0.0
CMC4 = 0.0
00 100 I = 1,NOOTOT
XMIO = .5*(X(I) + X(I+1))
YMIO = .5*(Y(I) + Y(I+1))
0X = X(I+1) - X(I)
0Y = Y(I+1) - Y(I)
CFX = CFX + CP(I)*0Y
CFY = CFY - CP(I)*0X
CM = CM + CP(I)*(0X*XMIO + 0Y*YMIO)
CMC4 = CMC4 + CP(I)*(0X*(XMIO-0.25) + 0Y*YMIO)
100 CONTINUE
CO = CFX*COSALF + CFY*SINALF
CL = CFY*COSALF - CFX*SINALF
PRINT 1000, CO, CL, CM, CMC4
WRITE (12,1000) CO, CL, CM, CMC4
1000 FORMAT(//, ' CO = ', F8.5, ' CL = ', F8.5, ' CM = ', F8.5,
+' CMC4 = ', F8.5)
RETURN
ENO
C **** SUBROUTINE CLRSCRN
C **** LIBRARY ROUTINE TO CLEAR THE SCREEN.
C
ISTAT = LIB$ERASE_PAGE (1,1)
RETURN
ENO
C **** SUBROUTINE QUERY(NANS)
C **** ROUTINE TO TRAP ERRORS CAUSED BY IMPROPER RESPONSES TO QUESTIONS.
C **** THE COMPUTER GENERATES AND ERROR WHEN A CHARACTER IS SUPPLIED TO
C **** A QUESTION EXPECTING AN INTEGER OR REAL VALUE.
C
NOTE=0
1 CONTINUE
IF (NOTE .GT. 0) THEN
  PRINT *, ' CHARACTER VALUES ARE NOT VALID.'
  PRINT *, ' PLEASE ENTER A VALUE OF 1 OR 2.'
ENO IF
NOTE = NOTE + 1
READ (5,*ERR=1)NANS
RETURN
ENO
C **** DATA VALUES FOR VARIOUS AIRFOILS. TO USE, REMOVE COMMENTS
C **** AND PLACE AFTER COMMON CAROS IN MAIN PROGRAM.
C **** FOLLOWING DATA IS FOR THE NACA 0006 AIRFOIL ***
C
DATA (X(I),I=1,28)/1.0,.90,.80,.70,.60,.50,.40,.30,.20,.10,
1 0.075,0.05,0.025,0.0125,0.0,0.0125,0.025,0.05,0.075,
2 0.10,.20,.30,.40,.50,.60,.70,.80,.90/
C *** NOTE: VALUE FOR TRAILING EDGE IS SET TO 0.000 VS ACT THICKNESS *
C
DATA (Y(I),I=1,20)/-.00063,-.00724,-.01312,-.01832,-.02282,
1 -.02647,-.02902,-.03001,-.02869,-.02341,0.0,.02341,.02869,
2 .03001,.02902,.02647,.02282,.01832,.01312,.00724/
C **** FOLLOWING DATA IS FOR THE NACA 0012 AIRFOIL ***
C
DATA NUPPER, NLOWER /14,14/

```

```

C   DATA (X(I),I=1,28)/1.0,.90,.80,.70,.60,.50,.40,.30,.20,.10,
C   1 0.075,0.05,0.025,0.0125,0.0,0.0125,0.025,0.05,0.075,
C   2 0.10,.20,.30,.40,.50,.60,.70,.80,.90/
C *** NOTE: VALUE FOR TRAILING EDGE IS SET TO 0.000 VS ACT THICKNESS *
C   DATA (Y(I),I=1,28)/0.00000,.01448,-.02623,-.03664,-.04563,
C   1  -.05294,-.05803,-.06002,-.05737-.04683,-.04200,-.03555,
C   2  -.02615,-.01894,0.0,.01894,02615,.03555,.04200,.04683/
C **** FOLLOWING DATA IS FOR THE NASA LS(1)-0013 AIRFOIL ***
C   DATA NUPPER, NLOWER /14,14/
C   DATA (X(I),I=1,28)/1.0,.90,.80,.70,.60,.50,.40,.30,.20,.10,
C   1 0.07535,0.05,0.0247,0.01255,0.0,0.01301,0.02505,0.04993,0.07498,
C   2 0.10,.20,.30,.40,.50,.60,.70,.80,.90/
C *** NOTE: VALUE FOR TRAILING EDGE IS SET TO 0.000 VS ACT THICKNESS *
C   DATA (Y(I),I=1,28)/0.00000,-.01165,-.02654,-.04196,-.05459,
C   1  -.05209,-.06453,-.06316,-.05755,-.04543,-.04070,-.03462,
C   1  -.02612,-.01938,0.0,.01892,02563,.03465,-.04075,.04541,
C   2  -.05750,.06307,.06432,.06203,.05446,.04183,.02638,.01172/
C **** USER INSTRUCTIONS FOR MANUAL DATA ENTRY:
C
C   (1) UPON CUE ENTER THE TOTAL NUMBER OF AIRFOIL DATA
C       POINTS. DO NOT COUNT THE LEADING OR TRAILING EDGE TWICE.
C
C   NOTE: ARRAYS ARE DIMENSIONED TO 100, THIS IS, THEREBY THE
C       LIMITING NUMBER OF DATA POINTS THAT CAN BE ENTERED
C       WITHOUT HAVING TO REDIMENSION THE PROGRAMS ARRAYS.
C
C   (2) ENTER X COORDINATES AS MANY TO A LINE AS DESIRED.
C       THE PROGRAM WILL ALLOW FOR CORRECTION IF ANY ERRORS ARE
C       MADE. A TABLE OF X COORDINATES IS DISPLAYED FOR THE USER
C       TO CHECK HIS INPUT.
C
C   (3) ENTER Y COORDINATES AS MANY TO A LINE AS DESIRED.
C       THE PROGRAM WILL ALLOW FOR CORRECTION IF ANY ERRORS ARE
C       MADE. A TABLE OF Y COORDINATES IS DISPLAYED FOR THE USER
C       TO CHECK HIS INPUT.
C
C   (4) PROGRAM ALLOWS FOR AS MANY RUNS AS THE USER DESIRES
C       SIMPLY FOLLOW CUING SEQUENCE.
C ****
```

APPENDIX C. PROGRAM VORLAT USER'S MANUAL

USERS GUIDE CONTENTS

| | |
|---|----|
| A. INTRODUCTION | 62 |
| B. ASSUMPTIONS AND LIMITATIONS | 62 |
| C. INPUT DESCRIPTION | 62 |
| D. INPUT RESTRICIONS | 62 |
| E. SAMPLE PROBLEM | 63 |
| 1. Starting the Program | 63 |
| 2. Running the Program | 63 |
| F. SAMPLE PROBLEM OUTPUT DATA FILES | 66 |
| G. PROGRAM PANEL LISTING | 67 |

Introduction

The purpose of the VORLAT program is to provide an application of the vortex lattice method for the determination of the lift distribution of a flat rectangular plate. This method is based on a distribution of discrete horseshoe vortices over a wing surface that has been divided into a finite number of panels. A system of linear equations is developed for the vortex strengths on the panels and solved by matrix methods.

Assumptions and Limitations

This program is limited to flat rectangular wings. The program divides the wing up into panels using either a uniform grid or cosine spacing method. The cosine spacing algorithm provides a finer grid near the wing tips where the pressure distribution over the wing is rapidly changing. Both methods incorporate an enhancement whereby the panels do not extend to the wing tips, but only to a distance of $\delta/4$ from the tips. The value of δ is the spanwise width of a wing panel.

The solution is determined for conditions of incompressible and inviscid irrotational flow. Since we are considering an inviscid fluid, the coefficient of drag provided in the results is for the induced drag component only. This program is intended to be used for the analysis of flat rectangular wings with low aspect ratio. High aspect ratio wings are better analyzed using a method based on the lifting line theory.

Input Description

There are very few input values required for this simple program. Their description and program variable names are listed below.

AR - Aspect ratio of the wing. ($\text{Span}^2/\text{Area}$)

NX, NY - Number of vortices in the X and Y directions.

ALPHA - Angle of attack. (Angle between the chord and the freestream velocity.)

IOPT - Grid spacing option. Uniform grid or cosine spacing.

Input Restrictions

The program, as written, is limited to 350 total surface vortices. This may be modified by changing the size of the arrays, however for the wings that this program was intended to analyze, this should be sufficient. The program will accept values for ALPHA up to

45 degrees, but, as noted previously with program PANEL, the user is cautioned that values above 15 may be suspect.

Sample Problem

A sample problem will be used to illustrate the use of the VORLAT program. The run will be done using a flat rectangular wing with an aspect ratio of 2. The lattice will be created by placing three vortices on the wing in the X direction and 5 vortices on the wing in the Y direction. The vortices will be distributed using the Uniform Grid spacing option and the wing will be set at an angle of attack (alpha) of 6 degrees.

Starting the Program

Begin with the screen showing the DCL prompt, which looks like this.

\$

Next, ensure that the program is in your directory by typing

DIR [Return]

and viewing the files for VORLAT.EXE and VORLAT.OBJ. If only the VORLAT.FOR file exists, you must compile the program by typing,

FOR VORLAT [Return]

The next step is to link the program by entering,

LINK VORLAT [Return]

The files VORLAT.EXE and VORLAT.OBJ will now exist and you will be able to run the program.

Running the Program

To run the program, type

VORLAT [Return]

The program will start and the screen should look similar to what is shown in Figure 24

```
PROGRAM VORLAT : VERSION 4 : 10 SEPTEMBER 88  
VORTEX-LATTICE METHOD USED TO DETERMINE SPANWISE  
LIFT DISTRIBUTION FOR A FLAT RECTANGULAR WING  
ENTER THE ASPECT RATIO?
```

Figure 24. Initial Screen for Program VORLAT

Respond to the request for the aspect ratio by entering

2 [Return]

Respond to the request for the number of vortices by entering

3.5 [Return]

Now enter the angle of attack in degrees as

6 [Return]

Finally enter the grid spacing option.

1 [Return]

The screen is then cleared and you will be presented with what is shown in Figure 25

```
THE CURRENT VALUES ARE:
```

| | | |
|--|----------|---|
| 1) ASPECT RATIO = | 2.000000 | |
| 2) NUMBER OF VORTICES (NX,NY) = | 3 | 5 |
| 3) ANGLE OF ATTACK (DEGREES) = | 6.000000 | |
| 4) GRID SPACING: (1) UNIFORM, (2) COSINE = | | 1 |

```
THE CALCULATED PARAMETERS ARE:
```

DELTA X = 0.3333333
DELTA Y = 0.1904762

NUMBER OF EQUATIONS TO SOLVE = 15
ARE THESE VALUES CORRECT? (YES=1, NO=2)

Figure 25. Data Review/Correction Screen

If your display agrees with this, respond to the question by entering

1 [Return]

If you should desire to change any values, enter 2, and you will be asked which value you want to correct and the new desired value. Following entry of the correct values and a positive response, the program begins the solution process. It returns with the coefficients of lift and drag at the indicated spanwise positions, as well as the chordwise center of pressure for those positions. Overall values for the coefficients of lift, drag, induced drag and moment about the leading edge are calculated and then printed out near the bottom of the screen. Don't worry if you miss some of the values as they scroll up on the screen. All the values are printed to both the screen and to the data file.

The program now asks if you want to make another run. Enter

1 [Return]

You should now be back at the data review/correction screen and it should look like Figure 25. Now run the same wing, but use the cosine grid spacing. Enter

2 [Return]

You want to change the grid spacing, so enter

4 [Return]

The screen is automatically updated and you will see that the grid spacing has been changed for you also. Since there are only two grid spacings available, the program "knows" to chose the other and this saves you the extra step of having to enter it. Not exactly artificial intelligence, but it helps. You are again asked if the data is correct. As in the previous example, responding with a (1) causes the program to proceed to the output stage. The solution will be printed to the screen and appended to the data file which contains the data from the prior run.

The program now asks if you want to make another run. The session is finished, so enter

2 [Return]

This completes the sample problem for the VORLAT program. The data file created by this sample run and the listing for the VORLAT program are on the following pages.

SAMPLE PROBLEM OUTPUT DATA FILES

** UNIFORM GRID SPACING **

NX= 3 NY= 5 ASPECT RATIO = 2.00 ANGLE OF ATTACK = 6.00

| Y | CL(Y) | CD(Y) | XCP(Y) |
|-------|---------|---------|---------|
| 0.095 | 0.32140 | 0.01232 | 0.22266 |
| 0.286 | 0.31085 | 0.01213 | 0.22061 |
| 0.476 | 0.28791 | 0.01166 | 0.21614 |
| 0.667 | 0.24778 | 0.01068 | 0.20843 |
| 0.857 | 0.17711 | 0.00839 | 0.19624 |

CL = 0.25620
CD = 0.0105093
CD/CL2 = 0.1601
CMLE = -0.055004
XCP = 0.21469

** COSINE GRID SPACING **

NX= 3 NY= 5 ASPECT RATIO = 2.00 ANGLE OF ATTACK = 6.00

| Y | CL(Y) | CD(Y) | XCP(Y) |
|-------|---------|---------|---------|
| 0.045 | 0.32155 | 0.01223 | 0.22403 |
| 0.210 | 0.31734 | 0.01220 | 0.22325 |
| 0.476 | 0.29243 | 0.01176 | 0.21844 |
| 0.742 | 0.23258 | 0.01038 | 0.20690 |
| 0.907 | 0.14330 | 0.00733 | 0.19607 |

CL = 0.25927
CD = 0.0106156
CD/CL2 = 0.1579
CMLE = -0.056232
XCP = 0.21688

NOTE: CD/CL2 = $\frac{C_{D_i}}{C_L^2} = \frac{1}{\pi AR}$ Used to compare results to those for elliptic loading.

PROGRAM VORLAT LISTING

PROGRAM VORLAT

*** MODIFIED FOR USE ON THE MICROVAX/2000 BY J.A. CAMPBELL (JUL 88)
FINAL UPDATES MADE 14 SEP 88 - (JAC)

PROGRAM VORLAT : VERSION 4 4 AUGUST 88

ORIGINAL IBM MAINFRAME PROGRAM WAS ADAPTED FROM JACK MORAN'S BOOK
'AN INTRODUCTION TO THEORETICAL AND COMPUTATIONAL AERODYNAMICS'
WILEY AND SONS, NEW YORK 1984. THE LISTING IS FOUND ON PAGE 151.

PROGRAM FLEXIBILITY AND USER INTERFACE WAS REVISED FOR
PROFESSOR J.V. HEALEY BY JOHN CAMPBELL. JULY 1988.

VERSION 4 USES A COSINE SPACING ALGORITHM IN THE SPANWISE
DIRECTION OVER A RANGE OF ZERO TO PI OVER THE HALF SPAN
AS IMPLEMENTED IN VERSION 3. AN ATTEMPT WAS MADE TO CHANGE
THE RANGE FROM ZERO TO PI/2, HOWEVER TIME CONSTRAINTS PREVENTED
ITS SUCCESSFUL INCORPORATION. THERE APPEARED TO BE A PROBLEM
WITH THE INDICES OF THE MATRICES. THE LINES ADDED IN VERSION 4
BUT NOT INCORPORATED ARE NOTED BY CCC IN THE FIRST COLUMNS.

SIGNIFICANT UPGRADES HAVE BEEN IMPLEMENTED IN VERSION 4 WITH
RESPECT TO EASE OF OPERATION AND ERROR CORRECTION.

STATEMENT LABELS 60, 70, AND 80, AS WELL AS REFERENCES TO THEM,
IN THE PREVIOUS VERSION HAVE BEEN CHANGED TO 160, 170 AND 180.

PROGRAM VORLAT : VERSION 3 14 MAY 86

VORTEX-LATTICE METHOD FOR FLAT RECTANGULAR WING

**** VERSION 3 OF THIS PROGRAM INCORPORATES AN OPTION ****
**** OF HAVING THE COMPUTATION DONE USING EITHER A ****
**** COSINE GRID SPACING OR UNIFORM GRID SPACING IN ****
**** BOTH THE X-(CHORDWISE) AND Y-(SPANWISE) DIRECTIONS ****
**** *****

INTEGER NANS
DIMENSION GAM(350)
COMMON /DX,DY,AR,PI,IOPT,NX,NY
COMMON /COF/A(350,351),NEQNS
PI = 3.1415926585
NPASS = 1

C FOLLOWING LINES FOR OUTPUT FILES ADDED BY J.A. CAMPBELL (JUL88)
C OPEN FILE FOR COEFFICIENT OUTPUT

OPEN (UNIT=11,
2 FILE='VORLAT4.DAT',
2 ORGANIZATION='SEQUENTIAL',
2 ACCESS='SEQUENTIAL',
2 RECORDDTYPE='VARIABLE',
2 FORM='FORMATTED',
2 STATUS='UNKNOWN')

INPUT ASPECT RATIO (AR), NUMBERS OF VORTICES
IN X- AND Y- DIRECTIONS (NX,NY) AND
ANGLE OF ATTACK IN DEGREES (ALPHA)

C CALL LIBRARY ROUTINE TO CLEAR THE SCREEN, THE PRINT HEADER

CALL CLRSCRN
PRINT *
PRINT *, ' PROGRAM VORLAT : VERSION 4 : 10 SEPTEMBER 88 '
PRINT *, ' VORTEX-LATTICE METHOD USED TO DETERMINE SPANWISE '
PRINT *, ' LIFT DISTRIBUTION FOR A FLAT RECTANGULAR WING'
PRINT *

C 10 PRINT *, ' ENTER THE ASPECT RATIO?'

READ *, AR
IF (NPASS .GT. 1) GO TO 70

30 PRINT *, ' INPUT THE NUMBER OF VORTICES, IN THE X AND Y DIRECTIONS
+ (NX,NY),'

32 READ *, NX,NY

IF ((NX*NY) .GT. 350) THEN
PRINT *, ' NX * NY MUST BE LESS THAN OR EQUAL TO 350.'
PRINT *, ' PLEASE REENTER.'
GO TO 32

END IF

IF (NPASS .GT. 1) GO TO 70

50 PRINT *, ' WHAT IS THE ANGLE OF ATTACK IN DEGREES?'

52 READ *, ALPHA
IF (ALPHA .EQ. 0.) THEN
PRINT *, ' ALPHA MUST BE GREATER THAN ZERO. PLEASE REENTER.'

GO TO 52

ELSE IF (ALPHA .GT. 45.) THEN
PRINT *, ' ALPHA MUST BE LESS THAN 45. PLEASE REENTER.'

GO TO 52

END IF

IF (NPASS .GT. 1) GO TO 72

```

60 PRINT *, ' ENTER GRID SPACING OPTION (1 OR 2): (1) UNIFORM',
+ ; (2) COSINE'
READ *, IOPT
NPASS = NPASS + 1
C **** MAKE CALCULATIONS AND ECHO CHECK THE INPUT
C
70 DX = 1./FLOAT(NX)
DY = AR/(2.*NY + .5)
NEQNS = NX*NY
C CALL LIBRARY ROUTINE TO CLEAR THE SCREEN
72 CALL CLRSCRN
C
PRINT *, ' THE CURRENT VALUES ARE: '
PRINT *
PRINT *, ' 1) ASPECT RATIO = ',AR
PRINT *, ' 2) NUMBER OF VORTICES (NX,NY) = ',NX,NY
PRINT *, ' 3) ANGLE OF ATTACK (DEGREES) = ',ALPHA
PRINT *, ' 4) GRID SPACING: (1) UNIFORM, (2) COSINE = ',IOPT
PRINT *
PRINT *, ' THE CALCULATED PARAMETERS ARE: '
PRINT *
IF (IOPT .EQ. 1) THEN
  PRINT *, ' DELTA X = ',DX
  PRINT *, ' DELTA Y = ',DY
ELSE
  PRINT *, ' SINCE COSINE SPACING WAS CHOSEN, '
  PRINT *, ' DELTA X AND DELTA Y ARE VARIABLE.'
END IF
PRINT *
PRINT *, ' NUMBER OF EQUATIONS TO SOLVE = ',NEQNS
PRINT *
PRINT *, ' ARE THESE VALUES CORRECT? (YES=1, NO=2)?'
75 CALL QUERY (NANS)
IFLAG = NANS
IF (IFLAG .LT. 1 .OR. IFLAG .GT. 2) THEN
  PRINT *, ' INVALID ENTRY. ENTER 1 OR 2.'
  GO TO 75
END IF
IF (IFLAG .EQ. 1) GO TO 90
C
PRINT *, ' WHICH VALUE DO YOU WISH TO CORRECT? '
PRINT *
80 PRINT *, ' ENTER 1, 2, 3 OR 4'
CALL QUERY (NANS)
IFLAG = NANS
IF (IFLAG .GT. 4) THEN
  PRINT *, ' INVALID ENTRY. ENTER 1, 2, 3 OR 4.'
  GO TO 80
END IF
C **** SEND CONTROL BACK TO OBTAIN CORRECT DATA ****
GO TO (10,30,50) IFLAG
C **** CHANGE GRID TYPE ****
IF (IOPT .EQ. 1) THEN
  IOPT = 2
ELSE
  IOPT = 1
END IF
GO TO 72
C
90 COSALF = COS(ALPHA*PI/180.)
SINALF = SIN(ALPHA*PI/180.)
C
INFORM OPERATOR THAT PROCESSING HAS STARTED
WRITE (6,1003)
C
SET COEFFICIENTS OF EQUATIONS FOR VORTEX STRENGTHS
C
DO 100 I = 1,NY
  DO 100 J = 1,NX
    IJ = (I - 1)*NX + J
    A(IJ,NEQNS + 1) = SINALF
    DO 100 K = 1,NY
      DO 100 L = 1,NX
        KL = (K - 1)*NX + L
        CALL DNWASH (I,J,K,L,A(KL,IJ),1)
100 CONTINUE
C
C SOLVE FOR VORTEX STRENGTHS
C
CALL GAUSS (1)
DO 200 I = 1,NY
  DO 200 J = 1,NX
    IJ = (I - 1)*NX + J
200 GAM(IJ) = A(IJ,NEQNS+1)
C
PRINT OUT HEADINGS FOR DATA
C
IF (IOPT .EQ. 1) WRITE (11,1000) NX,NY,AR,ALPHA
IF (IOPT .EQ. 2) WRITE (11,1001) NX,NY,AR,ALPHA
WRITE (6,1005)
WRITE (11,1005)
C
INITIALIZE TOTAL FORCE AND MOMENT COEFFICIENTS
C
CMT = 0.0
CDT = 0.0
CLT = 0.0
C

```

```

C COMPUTE FORCE AND MOMENT COEFFICIENTS
C
DO 320 I = 1,NY
  CX = 0.0
  CZ = 0.0
  CM = 0.0
C
DO 310 J = 1,NX
  IJ = (I-1)*NX + J
  W = 0.0
  DO 300 K = 1,NY
    DO 300 L = 1,NX
      KL = (K-1)*NX + L
      CALL DNWASHIKL,L,I,J,DELW,2)
      W = W + DELW*GAM(KL)
300  CONTINUE
  CX = CX + GAM(IJ)*(W - SINALF)*2.
  CZ = CZ + GAM(IJ)*COSALF*2.
  IF (IOPT .EQ. 1) THEN
    CM = CM - GAM(IJ)*DX*(J - .75)*COSALF*2.
  ELSE
    CM = CM - GAM(IJ)*(FCOS(J,NX)+0.25*(FCOS(J+1,NX)
    - FCOS(J,NX)))*COSALF*2.
  END IF
310  CONTINUE
  CL = CZ*COSALF - CX*SINALF
  CD = CZ*SINALF + CX*COSALF
  IF (IOPT .EQ. 1) THEN
    CLT = CLT + CL*DY*2./AR
    CDT = CDT + CD*DY*2./AR
    CMT = CMT + CM*2.*DY/AR
  ELSE
    DELY = (0.5*AR - 0.25*DY)*(FSIN(I+1,NY) - FSIN(I,NY))
    DELY = (0.5*AR - 0.25*DY)*(FCOS(I+1,NY) - FCOS(I,NY))
    CLT = CLT + CL*DELY*2./AR
    CDT = CDT + CD*DELY*2./AR
    CMT = CMT + CM*DELY*2./AR
  END IF
  XCP = -CM/CL
  IF (IOPT .EQ. 1) THEN
    Y = (I-.5)*DY
  ELSE
    Y = (0.5*AR - 0.25*DY)*0.5*(FSIN(I,NY) + FSIN(I+1,NY))
    Y = (0.5*AR - 0.25*DY)*(FCOS(I,NY) +
    0.5*(FCOS(I+1,NY) - FCOS(I,NY)))
  END IF
  WRITE(6,1010) Y,CL,CD,XCP
  WRITE(11,1010) Y,CL,CD,XCP
320 CONTINUE
  XCP = -CMT/CLT
  CDOCL2 = CDT/CLT**2
  WRITE(6,1020) CLT,CDT,CDOCL2,CMT,XCP
  WRITE(11,1020) CLT,CDT,CDOCL2,CMT,XCP
C
PRINT *
PRINT *, ' THE COEFFICIENT OUTPUT DATA FOR LIFT, DRAG AND'
PRINT *, ' PRESSURE HAS BEEN WRITTEN TO FILE VORLAT4.DAT.'
PRINT *
400 PRINT *, ' DO YOU WISH TO: '
PRINT *, '   1) MAKE ANOTHER RUN OR'
PRINT *, '   2) END THIS SESSION'
PRINT *, ' ENTER 1 OR 2.'
PRINT *
CALL QUERY (NANS)
IF (NANS .EQ. 1) GO TO 70
STOP
1000 FORMAT(//,' ** UNIFORM GRID SPACING **',//,
  & ' NX= ',I2,' NY= ',I2,' ASPECT RATIO = ',F5.2,
  & ' ANGLE OF ATTACK = ',F5.2,/)
1001 FORMAT(//,' ** COSINE GRID SPACING **',//,
  & ' NX= ',I2,' NY= ',I2,' ASPECT RATIO = ',F5.2,
  & ' ANGLE OF ATTACK = ',F5.2,/)
1003 FORMAT(//,' PROCESSING BEGINS...',//)
1005 FORMAT(//,' Y CL(Y) CD(Y) XCP(Y)',/)
1010 FORMAT(F6.3,F10.5)
1020 FORMAT(//,' CL = ',F12.5,/, ' CD = ',F14.7,/, ' CD/CL2 = ',F7.4,
  & ' CMLE = ',F11.6,/, ' XCP = ',F11.5)
END
*****SUBROUTINE DNWASH(I,J,K,L,W,IND)
C COMPUTE DOWNWASH ON PANEL CENTERED AT (L-.5)DX,(K-.5)DY
C DUE TO VORTICES AT PANELS CENTERED AT (J-.5)DX,+(I-.5)DY
C COMMON DX,DY,AR,PI,IOPT,NX,NY
C
IF (IOPT .EQ. 2) GO TO 50
XA = DX*(J - .75)
YA = DY*(I - 1)
YB = DY*I
IF (IND .EQ. 1) XP = DX*(L - .25)
IF (IND .EQ. 2) XP = DX*(L - .75)
YP = DY*(K-.5)
GO TO 60
C THE FOLLOWING LINES HANDLE THE COSINE SPACING SCHEME
C FAC IS THE HALF SPAN MINUS A 1/4 LATTICE WIDTH INSET.
50  FAC = 0.5*AR - 0.25*DY
XA = FCOS(J,NX) + 0.25*(FCOS(J+1,NX) - FCOS(J,NX))
CCC YA = FAC * FSIN(I-1,NY)
CCC YB = FAC * FSIN(I,NY)
CCC YA = FAC * FCOS(I,NY)

```

```

      YB = FAC * FCOS(I+1,NY)
      IF (IND .EQ. 1) XP = FCOS(L,NX) + .75*(FCOS(L+1,NX) - FCOS(L,NX))
      IF (IND .EQ. 2) XP = FCOS(L,NX) + .25*(FCOS(L+1,NX) - FCOS(L,NX))
CCC  YP = FAC*0.5*(FSIN(K,NY) + FSIN(K-1,NY))
      YP = FAC*1*FCOS(K,NY) + 0.5*(FCOS(K+1,NY) - FCOS(K,NY)))
C
 60   W = WHV(XP,YP,XA,YA) - WHV(XP,YP,XA,-YB)
      + - WHV(XP,YP,XA,-YA) + WHV(XP,YP,XA,-YB)
      W = W*.25/3.1415926585
      RETURN
      END
*****
FUNCTION WHV(X1,Y1,X2,Y2)
  IF (X1 .EQ. X2) GO TO 100
  WHV = (1. + SQR((X1-X2)**2 + (Y1-Y2)**2)/(X1 - X2))
  +
  RETURN
100  WHV = 1. / (Y1 - Y2)
  RETURN
END
*****
C THIS RETURNS THE NONDIMENSIONAL X COORD OF EACH SECTION BOUNDARY
C
FUNCTION FCOS(I,N)
  PI = 3.1415926585
  FRACT = FLOAT(I-1)/FLOAT(N)
  FCOS = 0.5 * (1. - COS(PI*FRACT))
  RETURN
END
*****
C THIS RETURNS THE NONDIMENSIONAL Y COORD OF EACH SECTION BOUNDARY
C THIS WAS INTENDED TO IMPLEMENT THE SIN-LAW LATTICE SPACING SCHEME
C REFERRED TO BY GARY HCOUGH, JOU. OF ACFT., MAY 1973, VOL.10, NO.5
C
FUNCTION FSIN(I,N)
  PI = 3.1415926585
  FRACT = FLOAT(I)/FLOAT(N)
  FSIN = (SIN(.5*PI*FRACT))
  RETURN
END
*****
C SUBROUTINE CLRSCRN
C LIBRARY ROUTINE TO CLEAR THE SCREEN.
C
  ISTAT = LIB$ERASE_PAGE (1,1)
  RETURN
END
*****
C SUBROUTINE QUERY(NANS)
C
C ROUTINE TO TRAP ERRORS CAUSED BY IMPROPER RESPONSES TO QUESTIONS.
C THE COMPUTER GENERATES AN ERROR WHEN A CHARACTER IS SUPPLIED TO
C A QUESTION EXPECTING AN INTEGER OR REAL VALUE.
C
  NOTEST=0
  1 CONTINUE
  IF (NOTEST .GT. 0) THEN
    PRINT *, ' CHARACTER VALUES ARE NOT VALID.'
    PRINT *, ' PLEASE ENTER AN INTEGER VALUE.'
  END IF
  NOTEST = NOTEST + 1
  READ (5,*),ERR=1NANS
  RETURN
END
*****
C SUBROUTINE GAUSS (NRHS)
C
C SOLUTION OF LINEAR ALGEBRAIC SYSTEM BY
C GAUSS ELIMINATION WITH PARTIAL PIVOTING
C
C     ^A = COEFFICIENT MATRIX
C     NEQNS = NUMBER OF EQUATIONS
C     NRHS  = NUMBER OF RIGHT HAND SIDES
C
C     RIGHT-HAND SIDES AND SOLUTIONS STORED IN
C     COLUMNS NEQNS+1 THRU NEQNS+NRHS OF ^A
C
COMMON DX,DY,AR,PI
COMMON /COF/A(350,351),NEQNS
NP = NEQNS + 1
NTOT = NEQNS + NRHS
C
GAUSS REDUCTION
C
DO 150 I = 2,NEQNS
  -- SEARCH FOR LARGEST ENTRY IN (I-1)TH COLUMN
  -- ON OR BELOW MAIN DIAGONAL
C
  IM = I - 1
  IMAX = IM
  AMAX = ABS(A(IM,IM))
  DO 110 J = I,NEQNS
    IF (AMAX .GE. ABS(A(J,IM))) GO TO 110
    IMAX = J
    AMAX = ABS(A(J,IM))
  110 CONTINUE
  -- SWITCH (I-1)TH AND IMAXTH EQUATIONS
C

```

```

IF (IMAX .NE. IM) GO TO 140
DO 130 J = IM,NTOT
    TEMP = A(IM,J)
    A(IM,J) = A(IMAX,J)
    A(IMAX,J) = TEMP
130 CONTINUE
C          ELIMINATE (I-1)TH UNKNOWN FROM
C          ITH THRU (NEQNS)TH EQUATIONS
140 DO 150 J = I,NEQNS
    R = A(J,IM)/A(IM,IM)
150 DO 150 K = I,NTOT
    A(J,K) = A(J,K) - R*A(IM,K)
C          BACK SUBSTITUTION
DO 220 K = NP,NTOT
    A(NEQNS,K) = A(NEQNS,K)/A(NEQNS,NEQNS)
    DO 210 L = 2,NEQNS
        I = NEQNS + 1 - L
        IP = I + 1
        DO 200 J = IP,NEQNS
            A(I,K) = A(I,K) - A(I,J)*A(J,K)
200     A(I,K) = A(I,K)/A(I,I)
210 CONTINUE
RETURN
END

```

APPENDIX D. PROGRAMS JETFLAP AND JETFLAPIN USER'S MANUAL

USERS GUIDE CONTENTS

| | |
|---|-----|
| A. INTRODUCTION | 73 |
| B. ASSUMPTIONS AND LIMITATIONS | 73 |
| C. DATA PREPARATION REQUIREMENTS | 74 |
| D. INPUT DESCRIPTION | 75 |
| E. INPUT RESTRICTIONS | 82 |
| F. FORMULATION OF THE INPUT DATA | 82 |
| G. SAMPLE PROBLEM | 84 |
| 1. Starting the Program | 84 |
| 2. Running the Program | 84 |
| H. SAMPLE PROBLEM OUTPUT DATA FILES | 87 |
| I. PROGRAM JETFLAP LISTING | 108 |
| J. PROGRAM JETFLAPIN LISTING | 157 |

Introduction

The purpose of this manual is to permit the user to utilize the JETFLAP program very quickly and easily while requiring little understanding of the underlying EVD theory. The program JETFLAP can be run as a stand alone program if the user wants to develop the JETFLAP input data file manually, but this is not recommended. The layout of the data is not intuitive and its formatting is critical. For this reason, the program JETFLAPIN has been created to assist the user in creating the JETFLAP input data file through an interactive terminal session.

This interactive program is a user-friendly way of creating the input data file required by the wing analysis program JETFLAP. When executed, JETFLAPIN asks questions of the user in order to construct and write to a file the required JETFLAP input data file.

The following manual contains an explanation of the required input data. The reader will find a parallel explanation, with minor modifications, in References 7 and 8. Some parts of these sources have been duplicated in total since they required no comment and were relevant to the present explanation. References to input data cards have been changed to data file lines. In the interest of space, some sections were not included, but the interested reader may find them helpful.

Three sample data input files and their associated output files are included at the end of this appendix. The file VOYTEST.DAT contains information approximating the VOYAGER wing planform. TAPER.DAT illustrates the use of the trapezoidal planform simplification and a semi-circle spacing scheme. The wing is swept 45 degrees, has an aspect ratio of 8.0 and a taper ratio of 0.45. The DOUGLAS.DAT data file is contained in Ref. 7 and was also located at the end of the magnetic tape following the program JETFLAP. It has been used as a program validation test case by comparing the present results with those of Refs. 7 and 8. This file contains information for a simple rectangular jet-flapped wing and three fundamental cases. The stability derivative flag has also been set.

Assumptions and Limitations

Before using this program, the user should be aware of the assumptions used in developing the EVD method and the resulting danger of extending the theory beyond its

limits. The assumptions are explained in the section on theory contained in References 7 and 8, but they are summarized below.

1. **Linearity** - This assumption allows the superposition of fundamental geometric cases or solutions but also limits, as an example, the total deflection of flow by flaps. Reference 7 states that the small angle assumptions of the linearized approach make it unlikely that the program would accurately predict the characteristics of a wing with a flap deflected at 60 degrees.
2. **Thin Wing Approximation** - Enabling the simplified treatment of wing sections by transferring boundary conditions to the chordline, this assumption limits the accuracy of the program in modeling thick wings.
3. **Inviscid Flow** - Because of its inability to predict separated flow, the computed lift may be unrealistically large for a wing at high angle of attack or with a sizeable flap deflection. Also, the program cannot consider parasitic drag.
4. **Incompressibility** - This assumption limits the range of speeds for which the program can be used to that in the low subsonic range. The Prandtl-Glauert rule can be applied to cases where subsonic Mach number effects become important (Ref. 3) and, in fact, has been included in a later version of this EVD program.
5. **Irrotationality** - The irrotationality assumption usually imposes no additional limitation in low-speed external aerodynamics where the flow can be considered irrotational.
6. **Interference Effects** - No allowance is made for mutual interference effects between the wing and pylons, nacelles or fuselage. Ground effect is also neglected.
7. **Wing Area Variation** - Although multiple-flapped wings may be modeled, no allowance is made for the increased wing area due to flap extension. An example is a Fowler Flap. If the configuration of concern is such a case, a modification of the original wing planform area input value would have to be made.
8. **Trailing Edge Jet Sheet** - The program only allows the jet sheet to emanate from the wing trailing edge. Therefore, doubtful results will be obtained on augmentor-type flaps, slots and externally blown flap systems.
9. **Computer Run Time** - An increase in the number of elements used to model the wing planform will increase accuracy. However, according to Reference 7 the time to compute increases proportionally between the square and the cube of the number of elements used. On the MicroVAX 2000, a run using 112 elements (VOYAGR.DAT, no jets, two fundamental cases) took 137 seconds to run, while a wing with 37 elements (DOUGLAS.DAT, 21 wing, 16 jet elements, three cases and stability derivatives) required only 91 seconds. These times may be further shortened by sending the output to a file vice the screen. In the case of the VOYAGR.DAT run, the time was cut by more than half to a mere 59 seconds.

Data Preparation Requirements

Prior to using the JETFLAPIN and JETFLAP programs, the user must accomplish the following:

1. Draw a scaled plan view of the wing and, if present, the jets.

2. Divide this planform into spanwise sections parallel to the freestream velocity. A maximum of 40 is permitted.
3. Divide each section into rectangular base elements. These elements, literally, are the bases of the EVD elements [Ref. 8: p. 53] which, in turn, are the "building blocks" of the program operation. Each row can be divided into a maximum of 40 base elements, 20 on the wing and 20 on the jet. However, the maximum number of these elements may not exceed 600.
4. Using a logical scheme, translate the arrangement of these elements and the deflections of the EVD's into a format usable by the program.
5. Refer to the section on the Formulation of the Input Data for a suggested method of approaching the problem of data determination.

Input Description

A brief description of each piece of input information required is provided during execution of the JETFLAPIN program, however for the benefit of the user they are repeated and expanded upon here.

- **Title Line** - This card provides any desired description of the computer run. The title will be printed at the top of the first page of output. A maximum of 80 characters may be input.
- **General Planform Parameter Line** - This line contains basic planform information.

AREA Wing area, in units of $(\text{SPAN})^2$ to be used for normalization of the aerodynamic coefficients. Must be in the same units as SPAN, i.e., if span is in feet, the area should be in ft^2 .

SPAN Wing span, in any desired length units.

CREF Wing reference chord, to be used for normalizing various aerodynamic coefficients. It may be any chord length and must be in the same units as SPAN. If a value of 0.0 is input, the mean aerodynamic chord, CMAC, which is computed automatically, will be used.

XMC Pitching moment center. Point about which pitching moments will be taken, measured from the wing apex. Same units as span. NOTE: The wing apex is defined by the program, implicitly, as the intersection of the x-axis with the leading edge when the wing is oriented without a sideslip. If the wing should be input in a yaw, the apex remains at that point.

XCG Wing Center of Gravity. Measured from the apex, this point is used as a pitching axis for computation of stability derivatives, XCG need only be input if IDERIV $\neq 0$. Same units as SPAN.

- **General Control Line** - This line contains control "flags" which describe the basic characteristics of the computer run.

NROWS Number of spanwise sections (rows) into which the wing is divided. For symmetric or anti-symmetric wings, only the number of sections on the right half of the wing should be input. For non-symmetric wings, NROWS equals the total number of spanwise rows from wing tip to

wing tip. See [Ref. 8: pp. 79-81] for a discussion on symmetric versus non-symmetric wings.

NCASES Total Number of Fundamental Cases. There will always be one fundamental case, that being a flat plate at one degree angle of attack. No input data is required for that case and it will be labeled by the program a Case 1. Therefore, NCASES must be one greater than the number of cases for which input data will be given (data lines 12 and 13), to allow for the angle of attack case.

ISYMM Symmetry Indicator.

- = 0, Wing is symmetric
- > 0, Wing is non-symmetric
- < 0, Wing is anti-symmetric

IPRINT Printed Output Control Flag.

- > 1, Print geometry details and total aerodynamic coefficients,
- = 1, In addition, print spanwise loading,
- = 0, In addition, print chordwise loading,
- < 0, In addition, print all matrices, back substitution checks and other details. This option is normally reserved for trouble-shooting, since it produces a very large amount of output.

JETFLG Jet Indicator Flag. A flag used for signaling if there is a jet issuing from the trailing edge of the wing.

- = 0, There is a jet sheet and jet data will be input.
- = 1, There is no jet sheet.

IGTYPE Wing Planform Geometry Flag.

- = 1, Wing planform is completely arbitrary and sectional leading and trailing edge coordinates will be read to define the planform.
- = 2, Wing is trapezoidal and simplified planform data will be input. This type of input can only be used if the wing is symmetric. NOTE: Although a triangular shaped wing might be thought of as a degenerative trapezoid, this input cannot be used for a delta planform.

HINGE Hinge EVD Flag.

- = 0, Regular EVD's will be used on all hinge elements.
- > 0, Hinge EVD's will be used on all hinge elements. Not permitted if computing dynamic stability derivatives, i.e., IDERIV > 0.

IDERIV Dynamic Stability Derivative Flag.

- = 0, Basic run will be executed with no stability derivatives computed.
- > 0, In addition, a dynamic stability derivative run will be executed. This option requires the program to make an additional run, ap-

proximately doubling the computer time. NOTE: The derivative run also reduces to 8 the maximum number of optional fundamental cases permitted, since an extra fundamental case is generated by the program to be used during derivative calculations.

- **Section Centerline Location Lines** - These lines contain the spanwise locations of the centerline of each wing (and jet) section. JETFLAPIN will place up to eight values on each line, with a maximum of 5 lines (40 sections) allowed.

Y Spanwise distance from wing centerline (x-axis) to the section centerline, normalized by SPAN,2. All values must satisfy $(-1.0 \leq Y \leq 1.0)$. NROWS (number of row sections) values must be input, beginning at the right wing tip and working to the wing centerline for symmetric or anti-symmetric wings, or to the left wing tip for non-symmetric wings.

- **Wing Section Type Line** - This card indicates the chordwise arrangement of EVD elements for each section on the wing. The section type is determined by the number and spacing of the elements within each section.

ICTYPE Type Number of Each Wing Section. Any sections having the same number of elements, all with the same distance from the section leading edge (normalized by the sectional chord) are of the same ICTYPE. A maximum of ten different types is allowed. The section at the right wing tip is designated ICTYPE 01. Each new type receives a sequentially higher ICTYPE. The highest ICTYPE is referred to by the program as NWTYPE. NROWS values must be input, therefore, each section must be "typed".

- **Number of Chordwise Wing Elements Line** - This line contains the number of chordwise EVD elements for each wing section type (ICTYPE).

NI Number of Chordwise Elements per ICTYPE. Enter, in ascending order by ICTYPE, the number of elements within that ICTYPE. There may be as few as two or as many as twenty elements per section type. NWTYPE (the number of different section types) values are required.

- **Wing Chordwise Element Coordinates** - These lines contain the x.c coordinates of each EVD element for each ICTYPE.

XBW The chordwise coordinate of each EVD vortex point, measured from the leading edge of the section, normalized by the sectional chord. The first XBW of each set must be 0.0 and the last, less than 1.0. There may be as few as two or as many as twenty values per section type. NWTYPE (the number of different section types) sets of values are required. NOTE: Reference 7, Vol. II refers to these coordinates as XB. The "W" was added in reference 8 to be consistent with the nomenclature of the program listing and also to differentiate between hinge point coord., XBH, and XBJ, the coords. of elements on the jet sheet portion of the section.

- **Planform Information Lines** - There are two types of input lines used to define wing planform. Line 8a is used for arbitrary wing planforms (IGTYPE = 1). Line 8b is used for trapezoidal wing planforms (IGTYPE = 2). The program JETFLAPIN will choose the correct form based on the value of IGTYPE.

- **Leading and Trailing Edge Coordinates** - In order to define an arbitrary planform, the leading and trailing edges for each section must be defined. All section coordinates need not be input, however. The program must have the tip and root coordinates, as a minimum, and any other section's which would define a break in the edge. The program will assume a straight edge exists between coordinates input, and will interpolate between them. A minimum of two sets of coordinates and a maximum of NROWS is required.

Y Spanwise distance from a section centerline to the centerline of the wing, normalized by the half span. Each value must be *exactly* the same as those input for the section centerline location lines. JETFLAPIN automatically uses the previously input values.

XLEAD Leading Edge Coordinate. Input the chordwise distance from the section leading edge, at the section centerline, to the wing apex. Same units as SPAN, i.e., not normalized by the chord.

XTRAIL Trailing Edge Coordinate. Input the chordwise distance from the section trailing edge, at the section centerline, to the wing apex. Same units as SPAN.

9 A "9" must appear in column one of the next line after the last edge coordinate in order to signal that all desired sections have been input. This is required only if IGTYP=1 and is handled automatically by JETFLAPIN.

- **Trapezoidal Wing Parameters** - This line contains planform information for the trapezoidal wing. It is used when IGTYP=2. This type of input may be used only when the wing planform is symmetric.

ARATIO Wing Aspect Ratio. Input the value of $(SPAN)^2 AREA$. JETFLAPIN automatically calculates this value from previously supplied information.

SWEET Sweep angle of the Quarter-Chord Line. Input the angle in degrees.

TR Taper Ratio. TR is defined as the chord at the wing tip divided by the chord at the wing root.

- **Jet Section Type Line** - This line indicates the chordwise arrangement of EVD elements for each section on the jet sheet. The jet sheet uses the same sectional boundaries as the conventional wing sections forward of it. This line is required only if JETFLG=0.

IJTYPE Type Number of Each Jet Section. Input the type number of each section of the wing with respect to the presence of a jet sheet aft of it. Since there is no requirement that the jet sheet span the entire wing, sections without a jet are designated with a "0". Similar to line 5, the wing section type line, as each section within the jet sheet is encountered, it either receives a sequentially higher IJTYPE of the same IJTYPE as a previously labeled equivalent section. The number of different jet section types is NJTYPE. The zeroes do not count as IJTYPE's for the purpose of summing types to find NJTYPE. The number of non-zero values input is NROWSJ, the number of sections having a jet. The maximum number of jet section types is 10. Implied also is that NJTYPE must be less than, or equal to, NROWSJ. NROWS values are required.

NOTE: Due to a computational procedure, there must be at least three adjacent jet sections if there is one. Also, inboard or outboard of a partial span jet sheet, a group of at least three unblown sections must exist.

- **Number of Chordwise Jet Elements** - This line contains the number of chordwise EVD elements for each jet section type. It is similar to line 6, number of chordwise wing elements per section type, except that NJTYPE values must be input. Required only if JETFLG = 0.

NI Number of Chordwise EVD Elements for Each Jet Section Type. Enter, in ascending order by IJTYPE, the number of elements within that IJTYPE. There may be as few as two or as many as ten elements for each jet section type. NJTYPE (the number of different jet section types) values are required.

- **Jet Chordwise Element Coordinates** - These lines contain the x/c coordinates of each element of each jet section type. NJTYPE sets lines are required, each with NI values of x/c. These values are required only if JETFLG = 0.

XBJ Chordwise Coordinate of Each per IJTYPE. The chordwise coordinate of each EVD vortex point, measured from the leading edge of the section (at centerline) and normalized by the sectional chord. The first value for XBW of each set must be 1.0 (trailing edge). The last two base elements in the jet section are overlapped by the Far-Jet (or Jet, or Infinity) EVD which has a length of 10^{10} , approximating infinity. Therefore, there is no practical maximum coordinate for elements within the jet. There may be as few as two or as many as ten values per jet section type. NJTYPE (the number of different jet section types) lines of values are required.

- **Fundamental Case Control Line** - This line identifies the types of linear geometric variations to be included in each fundamental case. The number of fundamental cases input must be one less than NCASES (line 3), to allow for the angle of attack case. A separate line is required for each of the input cases. In each of the flags below, a zero value indicates omission of the respective type of input for that fundamental case. A non-zero value indicates that the variation will be included and input must be given to define it. JETFLAPIN sets the non-zero value to correspond with the number of the fundamental case, i.e., for fundamental case number two, variations to be included will be indicated with a "2". For each variation selected, a corresponding line will follow containing the information defining that variation. NOTE: Refs. 7 and 8 use the same names shown below, however, in the program listing for JETFLAP under subroutine INCASE they are referred to respectively as INPUTT, INPUTH, INPUTD, INPUTC, and INPUTB.

INTWST Spanswise twist distribution flag.

INHITE Leading edge vertical displacement flag.

INDELJ Jet deflection flag.

INCAMB Camber flag.

INBETA Wing hinge deflection flag.

- **Fundamental Geometric Variation Lines** - These lines are input only in the appropriate flags in the fundamental case control line has been set to a non-zero value.

| | |
|--------------|--|
| TWIST | Sectional Wing Twist. Enter the wing twist, in degrees, at the section centerline, with respect to the wing reference plane. Positive values are in the same sense as a positive angle of attack (leading edge up). NROWS values are required. Required only if INTWST $\neq 0$. |
| HO | Displacement coordinate of the section leading edge from the wing reference plane, normalized by the sectional chord. Leading edge displacement may be the result of dihedral, twist, nonlinear movement of a leading edge device, etc. Translation resulting from ordinary linear leading and trailing flap deflections and angle of attack are accounted for automatically by the program. These values are used <i>only</i> for the computation of the jet thrust contribution to pitching moments and therefore will have no effect unless jet sheets exist. NROWS values are required. Required only if INHITE $\neq 0$. |
| DJ | Jet Turning Angle. The jet turning angle, in degrees, relative to the trailing edge. Positive deflection is downward. NOTE: JETFLAPIN requires that the values are input in the order that they are encountered within the jet sheet, working from the right wing tip towards the centerline. NROWSJ values are required. Required only if INDELJ $\neq 0$. |
| ICT | Camber Type Number for Each Wing Section. These values are similar to the wing section type values on line 5. In order for two sections to have the same ICT, the number of elements, their x c, and the camber angle associated with them must be the same. NROWS must be input with a maximum of 10 ICT's allowed. The highest value is NCT and there may be no "gaps" in the numbering sequence. A zero value indicates no camber. Required only if INCAMB $\neq 0$. |
| AC | Camber Angle. The camber angle, in degrees, at eh downwash control point of each EVD. The downwash control point is defined as a point chosen halfway between adjacent XBW's (line 7) including the trailing edge. The angle will be positive in the same sense as positive angle of attack. NCT lines are required. Required only if INCAMB $\neq 0$. |
| ACTE | Trailing Edge Camber Angle. This is the trailing edge deflection angle due to camber only. The values are used for determining the angle at which the jet sheet issues from the wing. These cards are, therefore, only necessary if there is camber (INCAMB $\neq 0$) and if there is a jet sheet (JETFLG $\neq 0$). NROWSJ values are required. |
| IHT | Hinge Section Type. Similar in concept to Wing Type (ICTYPE) and Camber Type (ICT); starting with the first section, designate the type of section with respect to hinges in the section. A section with no hinges will be "0". For sections to have the same IHT they must be alike in their number of hinges, not to exceed four, location of hinges (x c), their type (leading or trailing edge flap) and in all deflections. There may be as many different IHT's as there are sections. The number of different IHT's is called NHT, and there may be no "gaps" in the sequence. |

NROWS values are required, therefore every section must be "typed". Required only if INBETA ≠ 0.

| | |
|---------------------------------|--|
| XBH | Hinge Point Distance. The distance from the leading edge of the section to the hinge point, i.e., where the hinge line intersects the section centerline. the distance is normalized by the sectional chord and must be one of the XBW values entered on line 7. A set of values is required for each hinge section type; NHT sets. |
| ILT | Leading or Trailing Edge Indicator. <ul style="list-style-type: none">▪ = 0, Trailing edge flap hinge (positive deflection in the sense of positive angle of attack).▪ ≠ 0, Leading edge flap hinge (positive deflection in the sense of negative angle of attack). |
| BETA | Hinge Deflection Angle. The deflection angle, in degrees, of the element aft of the hinge point relative to the element forward of the hinge point. |
| • Composite Case Lines - | These lines indicate how the fundamental cases that are input on lines 12 and 13 are to be combined to form or model the wing under study. A maximum of 24 composite cases are permitted. No composite case may also be chosen and JETFLAPIN will automatically place a "9" in the first column of this line. |
| N | Fundamental Cases to be Included. Indicate the fundamental case number which is to be included in forming a given composite case. As many as ten fundamental cases may be combined in any one composite case. The fundamental cases are identified in the order in which they were input. NOTE: Recall that fundamental case number 1 is the one degree angle of attack case. |
| A | Multiplicative Factor. This factor multiplies the fundamental case previously input. Had the fundamental case included a hinge deflection of 10 degrees, a value of A = 1.6 would introduce a flap deflection of 16 degrees into that particular composite case. |
| 9 | End of Composite Cases. This value is placed at the end of the last composite case or by itself to indicate the completion of composite case information or that no composite cases are desired, respectively. NOTE: This "9" card is not conditional, it will be in every run. |
| • Jet Strength Line(s) - | These lines contain the jet strength for all sections which have a jet. An unlimited number of sets of values, maximum of 40 per set, may be entered. NROWSJ values are required. Required only if JETFLG = 0. |
| CMU | Sectional Jet Momentum Strength for each jet row. CMU is defined as $CMU = J(qc(y))$, where J is the sectional jet momentum per unit span, q is the dynamic pressure, and c(y) is the sectional chord. Since the data refers to only sections with jets, 0.0 may not be input unless all are 0.0. As many sets of CMU data may be input as desired. To run a case on a jet-flapped wing to examine the characteristics without the jet, a set of values all equal to zero must be entered. This option generates a complete set of loadings and other aerodynamic coefficients for each set |

of CMU data input. ($0.0 \leq \text{CMU} < 800.0$) Required only if JETFLG = 0.

- 9 A "9" is placed in column one of the line following all CMU data to signal the end of CMU input. Handled automatically by JETFLAPIN.

Input Restrictions

A summary of the input restrictions described in References 7 and 8 is listed below. These have been incorporated into the error-checking and screen messages provided in the JETFLAPIN program and are repeated here as a quick reference during data preparation.

1. A "Rule of Three" is implied with regard to dividing the wing (and jet sheet) into sections. At least three adjacent sections of either blown or unblown types are required. A jet cannot consist of one or two sections. Likewise, if the region of jet sheet is partial span and located so that it is bordered on both inboard and outboard sides by conventional (unblown) wing, those unblown portions of the wing must also have three adjacent sections each.
2. The number of spanwise sections, NROWS, requires $3 \leq NROWS \leq 40$.
3. $1 \leq NCASES \leq 10$. There is always one Fundamental Case generated by the program. Nine others may be input.
4. The number of chordwise elements in the wing part of a section, NI, requires $2 \leq NI \leq 20$.
5. The number of chordwise elements in the jet part of a section, NI, requires $2 \leq NI \leq 20$.
6. Maximum of 10 section types for the wing or the jet. (ICTYPE, IJTYPE ≤ 10).
7. On the wing, $0.0 \leq XBW \leq 1.0$.
8. On the jet, $1.0 \leq XBJ$.
9. Only NROWSJ, the number of rows with jets, values required for DJ, ACTE, and CMU.
10. Maximum number of camber section types is 10.
11. There may be as many hinge section types, NHT, as there are rows (or sections). ($1 \leq NHT \leq NROWS$)
12. Each section may have four hinges in any combination of leading and trailing edge flaps.
13. The jet blowing coefficient, CMU, is restricted to, $0.0 \leq CMU \leq 800.0$.

Formulation of the Input Data

The most difficult and time-consuming part of the wing analysis using the JETFLAP and JETFLAPIN programs is the decomposition of the wing into elements and obtaining the coordinates of those elements. There is hope that follow-on work will be conducted to integrate the sophisticated graphics capabilities of the MicroVAX/2000 with the data input portion of the JETFLAP program, however, for the present, the following methodical approach to the problem is recommended.

A table such as that shown in Ref. 8, p. 117, will help the user organize the required data. Starting at the beginning of the problem, the user is urged to follow the steps below:

1. Make or obtain a scaled drawing of the wing with all flaps and other details drawn on the planform. The scaling is often important in obtaining geometrical data that is often not presented explicitly.
2. If possible, create equations for the leading and trailing edges. For example, if the edge is a straight line, substitute tip and root dimensions into the Two-Point Form of the equation for a straight line. Such an equation will facilitate the finding of leading trailing edge coordinates once spanwise section centerline coordinates have been established.
3. Draw in spanwise sections taking into account obvious areas of rapidly changing loading (wing tips, near flaps) and rapid changes in sectional chord. It is important to define sections near breaks in the wing, such as leading edge extensions, otherwise the program, seeing only the wing edge coordinates, might read that portion of the leading edge as a relatively flat segment of a multisegment tapered wing.
4. Make two columns, entering sections, starting with 1 at the wing tip, in column one and the section centerline coordinates (normalized by the semi-span) in column two.
5. Draw in chordwise elements for each section. It is more expedient to strive for the same distribution on each section, if possible, unless camber discontinuities (flaps, rapid changes in mean camber line slope) dictate otherwise.
6. Enter the coordinates of the vortex points, normalized by the *sectional* chord, on each line next to the appropriate section. **NOTE.** One of these coordinates must coincide with the point where the section centerline intersects a flap hinge line, if included. Circle or otherwise mark such coordinates for future identification.
7. Proceeding down the rows of coordinates, any two rows with a different number of values or different values, are of different section types. In ascending order, label in another column each row with its type. The maximum number of types is 10 and the highest type defined is called NWTYPE.
8. At the end of each row write the total number of chordwise elements in that row. Circle the numbers that correspond with different types.
9. In another column, list leading and trailing edge coordinates by substituting (Y) values into the leading and trailing edge equations, if available. **NOTE.** Only those edge coordinates which mark wing root, tip and breaks need be calculated, if the edges are straight line segments.
10. Looking back over the completed table, the data for several of the input data file lines are readily available. Column numbers refer to columns in Table I.
 - a. Col. 2 is line 4.
 - b. Col. 3 is line 5.
 - c. Cols. 4-12 contain data for line(s) 7.
 - d. Col. 13 (circled entries) is line 6.

e. Cols. 2, 14, and 15, in that order constitute line 8a.

In addition, the last row number in Col. 1 is NROWS (Cols. 1-2 on line 3). The total of Col. 13 entries is the total number of EVD's, which is limited to 600. More details may be found in Ref. 8.

Sample Problem

A sample session will illustrate the use of the JETFLAP and JETFLAPIN programs. The run can be accomplished using one of the sample data output files provided at the end of this appendix. It is recommended that one of the simpler data files, such as TAPER.DAT or VOYAGR.DAT, be used to respond to the questions asked by the JETFLAPIN program. This method will allow the user to try out the program and get familiar with the questions asked, prior to going through the effort involved in formulating the data for a new problem.

Starting the Program

Begin with the screen showing the DCL prompt, which looks like this.

\$

Next, ensure that the program is in your directory by typing

DIR [Return]

and viewing the files for JETFLAP.EXE, JETFLAP.OBJ., JETFLAPIN.EXE and JETFLAPIN.OBJ.

If only the JETFLAP.FOR and JETFLAPIN.FOR files exist, you must compile the programs by typing,

FOR JETFLAP [Return], and if necessary,

FOR JETFLAPIN [Return]

The next step is to link the programs by entering,

LINK JETFLAP [Return], and again if necessary,

LINK JETFLAPIN [Return]

The files JETFLAP.EXE, JETFLAP.OBJ., JETFLAPIN.EXE and JETFLAPIN.OBJ will now exist and you will be able to run the programs.

Running the Program

To run the program, type

JETFLAPIN [Return]

The program will start and the screen will display the header for the interactive program. Using one of the sample data files for the correct values and this appendix to assist you with the terminology, answer each question presented. As you proceed through the JETFLAPIN program, opportunities to review and change input data will be presented. Should it become necessary to change your input data after completing the JETFLAPIN program, you can simply edit the created data file using the VAX EDT editor.

After the JETFLAPIN input program has been run to completion, the file you created will exist on your directory with the file extension .DAT. This file should be reviewed and compared with the sample file used as a reference. If everything is in order, you should run your data file through the JETFLAP wing analysis program.

The JETFLAP wing analysis program will ask you for the file name of the input data file. It is not necessary to enter the file extension .DAT, but you may do so without any ill effects. The program then asks if you wish to have the output sent to the screen or to a file. If you send the data to a file, the program runs faster and you will have the opportunity to review and print out the data. Sending the data to the screen is a quick way to see if the program is executing properly, but there is no permanent record of the run. At this time, the program is not able to print to both the screen and a file. The program is finished when the DCL (S) prompt returns to the screen.

Several sample input data files, the results of those files after being run through JETFLAP and the listings for the JETFLAP and JETFLAPIN programs are on the following pages.

JETFLAP INPUT DATA FILE VOYTEST.DAT

THIS IS A TEST OF THE INPUT PROGRAM JT77IN USING VOYAGER DATA

59040.0000 1332.0000 0.0000 13.5000 0.0000

16 2 0 0 1 1 0 0

0.998498 0.989489 0.959459 0.891892 0.792793 0.684685 0.576577 0.468468
0.400901 0.373874 0.355856 0.346847 0.324324 0.261261 0.162162 0.054054

1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

7

0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900

0.998498 13.000000 36.099998

0.989489 11.900000 36.400002

0.959459 11.200000 37.200001

0.891892 10.000000 39.099998

0.792793 8.300000 41.900002

0.684685 6.300000 44.900002

0.576577 4.500000 47.900002

0.468468 2.300000 51.000000

0.400901 0.800000 52.599998

0.373874 0.400000 53.400002

0.355856 0.100000 53.799999

0.346847 0.000000 54.000000

0.324324 0.000000 54.000000

0.261261 0.000000 54.000000

0.162162 0.000000 54.000000

0.054054 0.000000 54.000000

9

0 0 0 2 0

1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

-12.355000 -9.560000 -4.899000 0.764000 5.042000 7.969000 5.412000

9

9

ORIGINAL JETFLAP INPUT DATA FILE VOYAGR.DAT (S. M. WHITE)

VOYAGER WING FLAT PLATE AND CAMBERED CASES; 16X7 = 112 ELEMENTS
59040.0 1332.0 0.0 13.5
1601000001010000
.998498 .989489 .959459 .891892 .792793 .684685 .576577 .468468
.400901 .373874 .355856 .346847 .324324 .261261 .162162 .054054
0101010101010101010101010101
07
0.0 .0741 .2222 .3704 .5926 .7407 .8889
.998498 13.0 36.1
.989489 11.9 36.4
.959459 11.2 37.2
.891892 10.0 39.1
.792793 8.3 41.9
.684685 6.3 44.9
.576577 4.5 47.9
.468468 2.3 51.0
.400901 0.8 52.6
.373874 0.4 53.4
.355856 0.1 53.8
.346847 0.0 54.0
.324324 0.0 54.0
.261261 0.0 54.0
.162162 0.0 54.0
.054054 0.0 54.0
9
00000005
0101010101010101010101010101
-12.355 -9.560 -4.899 0.764 5.042 7.969 5.412
9

PROGRAM OUTPUT DATA FOR VOYTEST.DAT

* EVD JET - WING COMPUTER PROGRAM *

VOYAGER WING FLAT PLATE AND CAMBERED CASES: 16x7 = 112 ELEMENTS

| | USED | INPUT |
|--------|-----------|-------------|
| AREA | 0.133106 | 59040.00000 |
| SPAN | 2.000000 | 1332.00000 |
| CREF | 0.069765 | 0.000000 |
| XMC | 0.020270 | 13.50000 |
| CMAC | 0.069765 | 46.463470 |
| ARATIO | 30.051224 | 30.051224 |
| XCG | 0.000000 | 0.000000 |

NROWS = 16 16
 NCASES = 1 1
 ISYMM = 0 0
 IPRINT = 0 0
 JETFLG = 1 1
 IGTYPE = 1 1
 IHINGE = 0 0

NUMBER OF WING ELEMENTS = 112
 NUMBER OF JET ELEMENTS = 0
 TOTAL NUMBER OF ELEMENTS = 112

***** ELEMENT GEOMETRY DATA AND FUNDAMENTAL CASE DATA FOR FUNDAMENTAL CASE 1 *****

*** SECTION 1 *** Y = 0.989498 DELTA = 0.001502 XLEAD = 0.019520 XTRAIL = 0.054204 CHORD = 0.034685 TANLE = 0.183333
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.019520 0.022090 0.027226 0.032567 0.040074 0.045210 0.050751
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 2 *** Y = 0.989498 DELTA = 0.007507 XLEAD = 0.017868 XTRAIL = 0.054655 CHORD = 0.036787 TANLE = 0.183333
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.017868 0.020594 0.026043 0.031494 0.039668 0.045116 0.050568
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 3 *** Y = 0.959459 DELTA = 0.022523 XLEAD = 0.016817 XTRAIL = 0.055856 CHORD = 0.039039 TANLE = 0.026667
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.016817 0.019710 0.025491 0.031277 0.039551 0.045733 0.051519
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 4 *** Y = 0.891892 DELTA = 0.045044 XLEAD = 0.015015 XTRAIL = 0.058709 CHORD = 0.043694 TANLE = 0.026212
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.015015 0.018253 0.024724 0.031199 0.040908 0.047379 0.053554
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 5 *** Y = 0.792793 DELTA = 0.054055 XLEAD = 0.012462 XTRAIL = 0.062913 CHORD = 0.050450 TANLE = 0.025758
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.012462 0.016101 0.023673 0.031149 0.042352 0.049481 0.057309
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 6 *** Y = 0.684685 DELTA = 0.054053 XLEAD = 0.009459 XTRAIL = 0.067417 CHORD = 0.057958 TANLE = 0.025000
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.009459 0.013754 0.021358 0.030267 0.042805 0.051388 0.060978
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 7 *** Y = 0.576577 DELTA = 0.054055 XLEAD = 0.006757 XTRAIL = 0.071922 CHORD = 0.065165 TANLE = 0.027778
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.006757 0.011585 0.021226 0.030894 0.046574 0.055052 0.064682
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 8 *** Y = 0.468468 DELTA = 0.054054 XLEAD = 0.003453 XTRAIL = 0.076577 CHORD = 0.073123 TANLE = 0.031944
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.003453 0.008872 0.019701 0.030538 0.045786 0.057616 0.068452
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 9 *** Y = 0.400901 DELTA = 0.013513 XLEAD = 0.001201 XTRAIL = 0.078979 CHORD = 0.077778 TANLE = 0.027778
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.001201 0.006965 0.018483 0.030100 0.047242 0.058811 0.070358
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 10 *** Y = 0.373874 DELTA = 0.013514 XLEAD = 0.000601 XTRAIL = 0.080180 CHORD = 0.079580 TANLE = 0.023611
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.000601 0.075497 0.018283 0.030371 0.047759 0.059545 0.071339
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 11 *** Y = 0.255856 DELTA = 0.004504 XLEAD = 0.000150 XTRAIL = 0.080781 CHORD = 0.080631 TANLE = 0.025000
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.000150 0.06125 0.018286 0.030016 0.047822 0.059873 0.071823
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 12 *** Y = 0.346847 DELTA = 0.004505 XLEAD = 0.000000 XTRAIL = 0.081081 CHORD = 0.081081 TANLE = 0.000000
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.000000 0.060008 0.018016 0.030232 0.048049 0.060057 0.072073
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 13 *** Y = 0.324324 DELTA = 0.018018 XLEAD = 0.000000 XTRAIL = 0.081081 CHORD = 0.081081 TANLE = 0.000000
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.000000 0.060008 0.018016 0.030232 0.048049 0.060057 0.072073
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 14 *** Y = 0.261261 DELTA = 0.045045 XLEAD = 0.000000 XTRAIL = 0.081081 CHORD = 0.081081 TANLE = 0.000000
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.000000 0.060008 0.018016 0.030232 0.048049 0.060057 0.072073
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 15 *** Y = 0.162162 DELTA = 0.054054 XLEAD = 0.000000 XTRAIL = 0.081081 CHORD = 0.081081 TANLE = 0.000000
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.000000 0.060008 0.018016 0.030232 0.048049 0.060057 0.072073
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

*** SECTION 16 *** Y = 0.054054 DELTA = -0.054054 XLEAD = 0.000000 XTRAIL = 0.081061 CHORD = 0.081081 TANLE = 0.000000
 WING ELEMENTS NW = 7 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
 XB 0.000000 0.074100 0.222200 0.370400 0.592600 0.740700 0.888900
 XI 0.000000 0.060008 0.018016 0.030232 0.048049 0.060057 0.072073
 DEL 0.074100 0.148100 0.148200 0.222200 0.148100 0.148200 0.111100
 EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
 BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 TYPE 20 10 10 10 10 10 10

THIS ROW HAS NO JET

* SECTIONAL JET BLOWING COEFFICIENTS *

| RW | CMU |
|----|----------|
| 1 | 0.000000 |
| 2 | 0.000000 |
| 3 | 0.000000 |
| 4 | 0.000000 |
| 5 | 0.000000 |
| 6 | 0.000000 |
| 7 | 0.000000 |
| 8 | 0.000000 |
| 9 | 0.000000 |
| 10 | 0.000000 |
| 11 | 0.000000 |
| 12 | 0.000000 |
| 13 | 0.000000 |
| 14 | 0.000000 |
| 15 | 0.000000 |
| 16 | 0.000000 |

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES *

| WING | I | XB | SECTION 1 Y = 0.998498 CHORD = 0.034685 | | | | | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| | | | CASE 1 | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | | | | |
| 1 | 0.000000 | 0.206017 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 2 | 0.074100 | 0.082606 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 3 | 0.222200 | 0.035349 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 4 | 0.370400 | 0.025035 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 5 | 0.592600 | 0.015439 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 6 | 0.740700 | 0.011045 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 7 | 0.888900 | 0.006752 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |

DETAILED LEADING EDGE LOADING

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES *

| WING | I | XB | SECTION 2 Y = 0.989489 CHORD = 0.036787 | | | | | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| | | | CASE 1 | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | | | | |
| 8 | 0.000000 | 0.257194 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 9 | 0.074100 | 0.150969 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 10 | 0.222200 | 0.074147 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 11 | 0.370400 | 0.049467 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 12 | 0.592600 | 0.029455 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 13 | 0.740700 | 0.020609 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 14 | 0.888900 | 0.011980 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |

DETAILED LEADING EDGE LOADING

| | | |
|---|----------|----------|
| 1 | 0.014820 | 0.379502 |
| 2 | 0.029640 | 0.262938 |
| 3 | 0.044460 | 0.209061 |
| 4 | 0.059280 | 0.175506 |
| 5 | 0.074100 | 0.150969 |

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES *

| WING | I | XB | CASE 1 | SECTION 3 Y = 0.959459 CHORD = 0.039039 | | | | | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|-----------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|--------|---------|
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | | | | | |
| 15 | 0.000000 | 0.320581 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 16 | 0.074100 | 0.195136 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 17 | 0.022200 | 0.102886 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 18 | 0.070400 | 0.071695 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 19 | 0.052600 | 0.044537 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 20 | 0.0740700 | 0.031647 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 21 | 0.088900 | 0.018411 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |

DETAILED LEADING EDGE LOADING

| | | |
|---|----------|----------|
| 1 | 0.014820 | 0.474177 |
| 2 | 0.029640 | 0.330688 |
| 3 | 0.044460 | 0.264781 |
| 4 | 0.059280 | 0.224079 |
| 5 | 0.074100 | 0.195136 |

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES *

| WING | I | XB | CASE 1 | SECTION 4 Y = 0.891892 CHORD = 0.043694 | | | | | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|-----------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|--------|---------|
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | | | | | |
| 22 | 0.000000 | 0.351175 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 23 | 0.074100 | 0.215023 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 24 | 0.022200 | 0.114796 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 25 | 0.070400 | 0.081531 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 26 | 0.052600 | 0.051545 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 27 | 0.0740700 | 0.036574 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 28 | 0.088900 | 0.021471 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |

DETAILED LEADING EDGE LOADING

| | | |
|---|----------|----------|
| 1 | 0.014820 | 0.519682 |
| 2 | 0.029640 | 0.362524 |
| 3 | 0.044460 | 0.290787 |
| 4 | 0.059280 | 0.246475 |
| 5 | 0.074100 | 0.215023 |

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES *

| WING | I | XB | CASE 1 | SECTION 5 Y = 0.792793 CHORD = 0.050450 | | | | | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|-----------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|--------|---------|
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | | | | | |
| 29 | 0.000000 | 0.359475 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 30 | 0.074100 | 0.220484 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 31 | 0.022200 | 0.117898 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 32 | 0.070400 | 0.088389 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 33 | 0.052600 | 0.053168 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 34 | 0.0740700 | 0.037785 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 35 | 0.088900 | 0.022221 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |

DETAILED LEADING EDGE LOADING

| | | |
|---|----------|----------|
| 1 | 0.014820 | 0.535243 |
| 2 | 0.029640 | 0.371476 |
| 3 | 0.044460 | 0.298018 |
| 4 | 0.059280 | 0.252655 |
| 5 | 0.074100 | 0.220486 |

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES *

| WING | I | XB | CASE 1 | SECTION 6 Y = 0.684685 CHORD = 0.057958 | | | | | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|-----------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|--------|---------|
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | | | | | |
| 36 | 0.000000 | 0.360147 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 37 | 0.074100 | 0.220753 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 38 | 0.022200 | 0.118077 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 39 | 0.070400 | 0.084343 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 40 | 0.052600 | 0.052655 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 41 | 0.0740700 | 0.035785 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 42 | 0.088900 | 0.022169 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |

DETAILED LEADING EDGE LOADING

| | | |
|---|----------|-----------|
| 1 | 0.014820 | 0.5473005 |
| 2 | 0.029640 | 0.3791898 |
| 3 | 0.044460 | 0.319258 |
| 4 | 0.059280 | 0.2517651 |
| 5 | 0.074100 | 0.220753 |

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES *

| WING | I | XB | CASE 1 | SECTION 7 Y = 0.576577 CHORD = 0.065165 | | | | | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|-----------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|--------|---------|
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | | | | | |
| 43 | 0.000000 | 0.359147 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 44 | 0.074100 | 0.240135 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 45 | 0.022200 | 0.117705 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 46 | 0.070400 | 0.083781 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 47 | 0.052600 | 0.055507 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 48 | 0.0740700 | 0.032773 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 49 | 0.088900 | 0.022192 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |

DETAILED LEADING EDGE LOADING

| | | |
|---|----------|----------|
| 1 | 0.014820 | 0.531524 |
| 2 | 0.029640 | 0.370855 |
| 3 | 0.044460 | 0.297526 |
| 4 | 0.059280 | 0.251155 |
| 5 | 0.074100 | 0.220735 |

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES *

| WING | I | XB | CASE 1 | SECTION 8 Y = 0.468468 CHORD = 0.073123 | | | | | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|-----------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|--------|---------|
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | | | | | |
| 50 | 0.000000 | 0.353019 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 51 | 0.074100 | 0.216735 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 52 | 0.022200 | 0.115580 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 53 | 0.070400 | 0.088200 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 54 | 0.052600 | 0.052032 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 55 | 0.0740700 | 0.036978 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |
| 56 | 0.088900 | 0.021711 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | |

DETAILED LEADING EDGE LOADING

| | | |
|---|----------|----------|
| 1 | 0.014820 | 0.522436 |
| 2 | 0.029640 | 0.364487 |
| 3 | 0.044460 | 0.292390 |
| 4 | 0.059280 | 0.247871 |
| 5 | 0.074100 | 0.216278 |

| WING | I | XB | CASE 1 | # CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES # | | | | | | | | | |
|---|----------|----------|----------|---|----------|----------|----------|----------|----------|----------|----------|----------|--|
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | CASE 7 | CASE 8 | CASE 9 | CASE 10 | |
| 57 | 0.000000 | 0.347243 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | | |
| 58 | 0.074100 | 0.210505 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | | |
| 59 | 0.222200 | 0.117319 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | | |
| 60 | 0.370400 | 0.080923 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | | |
| 61 | 0.592600 | 0.051287 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | | |
| 62 | 0.740700 | 0.036404 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | | |
| 63 | 0.888900 | 0.021314 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | | | |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | | | |
| 1 | 0.014820 | 0.508011 | | | | | | | | | | | |
| 2 | 0.029640 | 0.552480 | | | | | | | | | | | |
| 3 | 0.044460 | 0.284422 | | | | | | | | | | | |
| 4 | 0.059280 | 0.241180 | | | | | | | | | | | |
| 5 | 0.074100 | 0.210506 | | | | | | | | | | | |
| # CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES # | | | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 9 Y = 0.400901 CHORD = 0.077778 | | | | | | | | | |
| 64 | 0.000000 | 0.345166 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 65 | 0.074100 | 0.211294 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 66 | 0.222200 | 0.112873 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 67 | 0.370400 | 0.080937 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 68 | 0.592600 | 0.051269 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 69 | 0.740700 | 0.036420 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 70 | 0.888900 | 0.021182 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | | | |
| 1 | 0.014820 | 0.510777 | | | | | | | | | | | |
| 2 | 0.029640 | 0.556305 | | | | | | | | | | | |
| 3 | 0.044460 | 0.285775 | | | | | | | | | | | |
| 4 | 0.059280 | 0.241210 | | | | | | | | | | | |
| 5 | 0.074100 | 0.211284 | | | | | | | | | | | |
| # CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES # | | | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 10 Y = 0.373874 CHORD = 0.079580 | | | | | | | | | |
| 71 | 0.000000 | 0.341790 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 72 | 0.074100 | 0.210832 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 73 | 0.222200 | 0.113276 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 74 | 0.370400 | 0.080521 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 75 | 0.592600 | 0.050893 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 76 | 0.740700 | 0.036425 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 77 | 0.888900 | 0.021087 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | | | |
| 1 | 0.014820 | 0.506105 | | | | | | | | | | | |
| 2 | 0.029640 | 0.552467 | | | | | | | | | | | |
| 3 | 0.044460 | 0.282949 | | | | | | | | | | | |
| 4 | 0.059280 | 0.241133 | | | | | | | | | | | |
| 5 | 0.074100 | 0.210832 | | | | | | | | | | | |
| # CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES # | | | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 11 Y = 0.355856 CHORD = 0.080631 | | | | | | | | | |
| 78 | 0.000000 | 0.341790 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 79 | 0.074100 | 0.210832 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 80 | 0.222200 | 0.113276 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 81 | 0.370400 | 0.080521 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 82 | 0.592600 | 0.050893 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 83 | 0.740700 | 0.036425 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 84 | 0.888900 | 0.021080 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | | | |
| 1 | 0.014820 | 0.507824 | | | | | | | | | | | |
| 2 | 0.029640 | 0.554587 | | | | | | | | | | | |
| 3 | 0.044460 | 0.284709 | | | | | | | | | | | |
| 4 | 0.059280 | 0.241653 | | | | | | | | | | | |
| 5 | 0.074100 | 0.211159 | | | | | | | | | | | |
| # CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES # | | | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 12 Y = 0.346847 CHORD = 0.091081 | | | | | | | | | |
| 85 | 0.000000 | 0.342309 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 86 | 0.074100 | 0.211159 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 87 | 0.222200 | 0.113276 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 88 | 0.370400 | 0.080527 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 89 | 0.592600 | 0.050949 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 90 | 0.740700 | 0.036422 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 91 | 0.888900 | 0.021159 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | | | |
| 1 | 0.014820 | 0.514665 | | | | | | | | | | | |
| 2 | 0.029640 | 0.359071 | | | | | | | | | | | |
| 3 | 0.044460 | 0.288034 | | | | | | | | | | | |
| 4 | 0.059280 | 0.244168 | | | | | | | | | | | |
| 5 | 0.074100 | 0.212037 | | | | | | | | | | | |
| # CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES # | | | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 14 Y = 0.261261 CHORD = 0.081081 | | | | | | | | | |
| 92 | 0.000000 | 0.352101 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 93 | 0.074100 | 0.215751 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 94 | 0.222200 | 0.115539 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 95 | 0.370400 | 0.080235 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 96 | 0.592600 | 0.051954 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 97 | 0.740700 | 0.036962 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 98 | 0.888900 | 0.021724 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | | | |
| 1 | 0.014820 | 0.521084 | | | | | | | | | | | |
| 2 | 0.029640 | 0.362553 | | | | | | | | | | | |
| 3 | 0.044460 | 0.291650 | | | | | | | | | | | |
| 4 | 0.059280 | 0.247254 | | | | | | | | | | | |
| 5 | 0.074100 | 0.215751 | | | | | | | | | | | |
| # CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES # | | | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 15 Y = 0.162162 CHORD = 0.081081 | | | | | | | | | |

| WING | I | XB | CASE 1 | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|---|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| 99 | | 0.000000 | 0.355045 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 100 | | 0.074100 | 0.217624 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 101 | | 0.222000 | 0.116396 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 102 | | 0.370400 | 0.082942 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 103 | | 0.592600 | 0.052495 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 104 | | 0.740700 | 0.037537 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 105 | | 0.888900 | 0.021960 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |

DETAILED LEADING EDGE LOADING

| WING | I | XB | CASE 1 | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|---|----------|----------|--------|--------|--------|--------|--------|--------|--------|--------|---------|
| 1 | | 0.014820 | 0.525454 | | | | | | | | | |
| 2 | | 0.026540 | 0.566610 | | | | | | | | | |
| 3 | | 0.044480 | 0.294150 | | | | | | | | | |
| 4 | | 0.058280 | 0.249520 | | | | | | | | | |
| 5 | | 0.074100 | 0.217624 | | | | | | | | | |

***** CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES *****

SECTION 16 V = 0.054054 CHORD = 0.081081

| WING | I | XB | CASE 1 | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|---|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| 106 | | 0.000000 | 0.356321 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 107 | | 0.074100 | 0.218427 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 108 | | 0.148200 | 0.116396 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 109 | | 0.222000 | 0.082942 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 110 | | 0.296200 | 0.052495 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 111 | | 0.370400 | 0.037537 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 112 | | 0.888900 | 0.022060 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |

DETAILED LEADING EDGE LOADING

| WING | I | XB | CASE 1 | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|------|---|----------|----------|--------|--------|--------|--------|--------|--------|--------|--------|---------|
| 1 | | 0.014820 | 0.527246 | | | | | | | | | |
| 2 | | 0.026540 | 0.567346 | | | | | | | | | |
| 3 | | 0.044480 | 0.295200 | | | | | | | | | |
| 4 | | 0.059280 | 0.250299 | | | | | | | | | |
| 5 | | 0.074100 | 0.218427 | | | | | | | | | |

***** SPANWISE LOADING FOR FUNDAMENTAL CASE 1 *****

| SECTION | Y | CLG | LIFT | CLMU | CL | CDG | CDMU | CS | CD | CMU | GAMMA | ALFIN |
|---------|-----------|----------|----------|----------|----|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| 1 | 0.998498 | 0.059680 | 0.000000 | 0.039680 | x | 0.0006926 | 0.0000000 | 0.0005680 | 0.0001437 | 0.0000000 | 0.0006882 | 0.0572168 |
| 2 | 0.989489 | 0.060370 | 0.000000 | 0.060370 | x | 0.0011526 | 0.0000000 | 0.0008555 | 0.0002571 | 0.0000000 | 0.0012146 | 0.045104 |
| 3 | 0.954559 | 0.084560 | 0.000000 | 0.084560 | x | 0.0015613 | 0.0000000 | 0.001231 | 0.0002322 | 0.0000000 | 0.0017461 | 0.055317 |
| 4 | 0.891929 | 0.097630 | 0.000000 | 0.097630 | x | 0.0017421 | 0.0000000 | 0.0015949 | 0.0001463 | 0.0000000 | 0.0021785 | 0.019683 |
| 5 | 0.792793 | 0.102479 | 0.000000 | 0.102479 | x | 0.0017866 | 0.0000000 | 0.0016738 | 0.0001148 | 0.0000000 | 0.0025551 | 0.01043 |
| 6 | 0.682685 | 0.102628 | 0.000000 | 0.102628 | x | 0.0017612 | 0.0000000 | 0.0016775 | 0.0001157 | 0.0000000 | 0.0029741 | 0.0011086 |
| 7 | 0.576577 | 0.102320 | 0.000000 | 0.102320 | x | 0.0017258 | 0.0000000 | 0.0016682 | 0.0001177 | 0.0000000 | 0.0033328 | 0.0012267 |
| 8 | 0.468488 | 0.100461 | 0.000000 | 0.100461 | x | 0.0017534 | 0.0000000 | 0.0016117 | 0.0001416 | 0.0000000 | 0.0036720 | 0.0017259 |
| 9 | 0.400901 | 0.082149 | 0.000000 | 0.082149 | x | 0.0017524 | 0.0000000 | 0.0015237 | 0.0001911 | 0.0000000 | 0.0038208 | 0.0015151 |
| 10 | 0.3737874 | 0.081660 | 0.000000 | 0.081660 | x | 0.0017153 | 0.0000000 | 0.0015408 | 0.0001725 | 0.0000000 | 0.0039060 | 0.0020781 |
| 11 | 0.355856 | 0.079445 | 0.000000 | 0.079445 | x | 0.0017095 | 0.0000000 | 0.0015108 | 0.0001986 | 0.0000000 | 0.0039487 | 0.0019557 |
| 12 | 0.346847 | 0.081240 | 0.000000 | 0.081240 | x | 0.0017126 | 0.0000000 | 0.0015216 | 0.0001910 | 0.0000000 | 0.0039780 | 0.0026141 |
| 13 | 0.342424 | 0.088970 | 0.000000 | 0.088970 | x | 0.0017274 | 0.0000000 | 0.0015643 | 0.0001631 | 0.0000000 | 0.0040123 | 0.0025514 |
| 14 | 0.261261 | 0.100253 | 0.000000 | 0.100253 | x | 0.0017497 | 0.0000000 | 0.0016034 | 0.0001646 | 0.0000000 | 0.0040643 | 0.0020219 |
| 15 | 0.162162 | 0.101171 | 0.000000 | 0.101171 | x | 0.0017658 | 0.0000000 | 0.0016303 | 0.0001355 | 0.0000000 | 0.0041015 | 0.0017824 |
| 16 | 0.054054 | 0.101562 | 0.000000 | 0.101562 | x | 0.0017726 | 0.0000000 | 0.0016420 | 0.0001306 | 0.0000000 | 0.0041174 | 0.0016699 |

TOTAL 0.100170 0.000000 0.100170 x 0.0017483 0.0000000 0.0016073 0.0001410 0.0000000 0.0000962

| SECTION | Y | CMG | CMU | CMT | CM | .. LIFT CENTER .. |
|---------|-----------|-----------|----------|----------|-----------|---------------------|
| 1 | 0.998498 | -0.007753 | 0.000000 | 0.000000 | -0.007753 | x 0.195380 0.195380 |
| 2 | 0.989489 | -0.014751 | 0.000000 | 0.000000 | -0.014751 | x 0.223377 0.223377 |
| 3 | 0.954559 | -0.021497 | 0.000000 | 0.000000 | -0.021497 | x 0.240311 0.240311 |
| 4 | 0.891929 | -0.024496 | 0.000000 | 0.000000 | -0.024496 | x 0.246441 0.246441 |
| 5 | 0.792793 | -0.025154 | 0.000000 | 0.000000 | -0.025154 | x 0.245517 0.245517 |
| 6 | 0.682685 | -0.025181 | 0.000000 | 0.000000 | -0.025185 | x 0.245399 0.245399 |
| 7 | 0.576577 | -0.025104 | 0.000000 | 0.000000 | -0.025105 | x 0.245550 0.245550 |
| 8 | 0.468488 | -0.024260 | 0.000000 | 0.000000 | -0.024260 | x 0.245070 0.245070 |
| 9 | 0.400901 | -0.024160 | 0.000000 | 0.000000 | -0.024160 | x 0.245625 0.245625 |
| 10 | 0.3737874 | -0.024053 | 0.000000 | 0.000000 | -0.024053 | x 0.245625 0.245625 |
| 11 | 0.355856 | -0.024058 | 0.000000 | 0.000000 | -0.024058 | x 0.245446 0.245446 |
| 12 | 0.346847 | -0.024084 | 0.000000 | 0.000000 | -0.024084 | x 0.245084 0.245084 |
| 13 | 0.342424 | -0.024256 | 0.000000 | 0.000000 | -0.024256 | x 0.245225 0.245225 |
| 14 | 0.261261 | -0.024584 | 0.000000 | 0.000000 | -0.024584 | x 0.245399 0.245399 |
| 15 | 0.162162 | -0.024827 | 0.000000 | 0.000000 | -0.024827 | x 0.245464 0.245464 |

TOTAL -0.031169 0.000000 0.000000 -0.031169 (APEX) 0.311161 0.311161 (X/CREF)

-0.002065 0.000000 0.000000 -0.002065 (XMC) 0.021708 0.021708 (X/B/2)

| | CASE 1 | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| CCLG | 0.1001690 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CCJL | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| ** CCL | 0.1001690 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CCDG | 0.0017483 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CCDJ | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CCS | 0.0017483 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| ** CCD | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| ** CDI | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CCM | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CMCM | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CMCMC | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CMTMC | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| ** CMCMC | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CLLG | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CLLJ | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| * CLL | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CNJ | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| * CNIMC | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CCY | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CBGR | 0.0435954 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CEGL | 0.0435954 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CBJR | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 |
| CBRL | 0.0000000 | 0.000000 | | | | | | | | |

* THE PROGRAM HAS REACHED NORMAL TERMINATION *

* THE PROGRAM HAS REACHED NORMAL TERMINATION *

JETFLAP INPUT DATA FILE DOUGLAS.DAT

```
*** ONR SAMPLE CASE ***  RECTANGULAR WING   CMU = 1    WITH STABILITY DER
4.500      4.500      1.000      0.250      0.250
4 3 0 0 0 2 1 1
0.9750     0.88750    0.68750    0.2750
1 1 2 1
5 6
0.000      0.100      0.200      0.500      0.900
0.000      0.100      0.200      0.500      0.800      0.900
4.500      0.000      1.000
1 1 1 1
4
1.000      1.100      1.500      3.000
0 0 1 0 0
1.000      1.000      1.000      1.000
0 0 0 0 1
0 0 1 0
0.9000     0 1.000
1 0.00     2 10.00    3 10.00
9
1.000      1.000      1.000      1.000
9
```

PROGRAM OUTPUT DATA FOR DOUGLAS.DAT

```

*** ONR SAMPLE CASE *** RECTANGULAR WING CMU = 1 WITH STABILITY DER

      USED          INPUT
  AREA = 0.888889  4.500000
  SPAN = 2.000000  4.500000
  CREF = 0.444444  1.000000
  XMC = 0.111111  0.250000
  CHAC = 0.444444  0.666667
  ARATIO = 4.500000  4.500000
  XCG = 0.111111  0.250000

      NROWS = 4
      NCASES = 3
      ISYMM = 0
      1PRINT = 0
      JETFLG = 0
      IGTYPE = 0
      IHINGE = 0

      NUMBER OF WING ELEMENTS = 21
      NUMBER OF JET ELEMENTS = 16
      TOTAL NUMBER OF ELEMENTS = 37

*** ELEMENT GEOMETRY DATA AND FUNDAMENTAL CASE DATA FOR FUNDAMENTAL CASE 1 **

*** SECTION 1 *** Y = 0.975000 DELTA = 0.025000 XLEAD = 0.000000 XTRAIL = 0.444444 CHORD = 0.444444 TANLE = 0.000000
WING ELEMENTS NW = 5 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
  XB 0.000000 0.100000 0.200000 0.500000 0.900000
  XI 0.000000 0.044444 0.088889 0.222222 0.400000
  DEL 0.100000 0.100000 0.300000 0.266667 0.100000
  EPS 1.000000 1.000000 1.000000 1.000000 1.000000
  BETA 0.000000 0.000000 0.000000 0.000000 0.000000
  TYPE 20 10 10 10 10

JET ELEMENTS NJ = 4 D = 0.888889 DJ = 0.000000 ACTE = 0.000000 THETA = 1.000000
  XB 1.000000 1.100000 1.500000 3.000000
  XI 0.444444 0.488889 0.666667 1.333333
  DEL 0.100000 0.400000 1.500000
  EPS 0.000000 0.000000 0.000000
  BETA 0.000000 0.000000 0.000000
  TYPE 10 10 10 30

*** SECTION 2 *** Y = 0.887500 DELTA = 0.062500 XLEAD = 0.000000 XTRAIL = 0.444444 CHORD = 0.444444 TANLE = 0.000000
WING ELEMENTS NW = 5 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
  XB 0.000000 0.100000 0.200000 0.500000 0.900000
  XI 0.000000 0.044444 0.088889 0.222222 0.400000
  DEL 0.100000 0.100000 0.300000 0.240000 0.100000
  EPS 1.000000 1.000000 1.000000 1.000000 1.000000
  BETA 0.000000 0.000000 0.000000 0.000000 0.000000
  TYPE 20 10 10 10 10

JET ELEMENTS NJ = 4 D = 0.888889 DJ = 0.000000 ACTE = 0.000000 THETA = 1.000000
  XB 1.000000 1.100000 1.500000 3.000000
  XI 0.444444 0.488889 0.666667 1.333333
  DEL 0.100000 0.400000 1.500000
  EPS 0.000000 0.000000 0.000000
  BETA 0.000000 0.000000 0.000000
  TYPE 10 10 10 30

*** SECTION 3 *** Y = 0.687500 DELTA = 0.127500 XLEAD = 0.000000 XTRAIL = 0.444444 CHORD = 0.444444 TANLE = 0.000000
WING ELEMENTS NW = 6 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
  XB 0.000000 0.100000 0.200000 0.500000 0.800000 0.900000
  XI 0.000000 0.044444 0.088889 0.200000 0.355556 0.400000
  DEL 0.100000 0.100000 0.300000 0.200000 0.100000 0.100000
  EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
  BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
  TYPE 20 10 10 10 10

JET ELEMENTS NJ = 4 D = 0.888889 DJ = 0.000000 ACTE = 0.000000 THETA = 1.000000
  XB 1.000000 1.100000 1.500000 3.000000
  XI 0.444444 0.488889 0.666667 1.333333
  DEL 0.100000 0.400000 1.500000
  EPS 0.000000 0.000000 0.000000
  BETA 0.000000 0.000000 0.000000
  TYPE 10 10 10 30

*** SECTION 4 *** Y = 0.275000 DELTA = 0.275000 XLEAD = 0.000000 XTRAIL = 0.444444 CHORD = 0.444444 TANLE = 0.000000
WING ELEMENTS NW = 5 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
  XB 0.000000 0.100000 0.200000 0.500000 0.900000
  XI 0.000000 0.044444 0.088889 0.200000 0.400000
  DEL 0.100000 0.100000 0.300000 0.200000 0.100000
  EPS 1.000000 1.000000 1.000000 1.000000 1.000000
  BETA 0.000000 0.000000 0.000000 0.000000 0.000000
  TYPE 20 10 10 10 10

JET ELEMENTS NJ = 4 D = 0.888889 DJ = 0.000000 ACTE = 0.000000 THETA = 1.000000
  XB 1.000000 1.100000 1.500000 3.000000
  XI 0.444444 0.488889 0.666667 1.333333
  DEL 0.100000 0.400000 1.500000
  EPS 0.000000 0.000000 0.000000
  BETA 0.000000 0.000000 0.000000
  TYPE 10 10 10 30

*** ELEMENT GEOMETRY DATA AND FUNDAMENTAL CASE DATA FOR FUNDAMENTAL CASE 2 **

*** SECTION 1 *** Y = 0.975000 DELTA = 0.025000 XLEAD = 0.000000 XTRAIL = 0.444444 CHORD = 0.444444 TANLE = 0.000000
WING ELEMENTS NW = 5 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
  XB 0.000000 0.100000 0.200000 0.500000 0.900000
  EPS 0.000000 0.000000 0.000000 0.000000 0.000000
  BETA 0.000000 0.000000 0.000000 0.000000 0.000000
  TYPE 20 10 10 10 10

JET ELEMENTS NJ = 4 D = 0.888889 DJ = 1.000000 ACTE = 0.000000 THETA = 1.000000
  XB 1.000000 1.100000 1.500000 3.000000
  XI 0.444444 0.488889 0.666667 1.333333
  BETA 1.000000 0.000000 0.000000 0.000000 0.000000
  TYPE 10 10 10 30

*** SECTION 2 *** Y = 0.887500 DELTA = 0.062500 XLEAD = 0.000000 XTRAIL = 0.444444 CHORD = 0.444444 TANLE = 0.000000
WING ELEMENTS NW = 5 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
  XB 0.000000 0.100000 0.200000 0.500000 0.900000
  EPS 0.000000 0.000000 0.000000 0.000000 0.000000
  BETA 0.000000 0.000000 0.000000 0.000000 0.000000
  TYPE 20 10 10 10 10

JET ELEMENTS NJ = 4 D = 0.888889 DJ = 1.000000 ACTE = 0.000000 THETA = 1.000000
  XB 1.000000 1.100000 1.500000 3.000000
  BETA 1.000000 0.000000 0.000000 0.000000 0.000000
  TYPE 10 10 10 30

*** SECTION 3 *** Y = 0.687500 DELTA = 0.127500 XLEAD = 0.000000 XTRAIL = 0.444444 CHORD = 0.444444 TANLE = 0.000000
WING ELEMENTS NW = 6 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
  XB 0.000000 0.100000 0.200000 0.500000 0.800000 0.900000
  XI 0.000000 0.044444 0.088889 0.200000 0.355556 0.400000
  DEL 0.100000 0.100000 0.300000 0.200000 0.100000 0.100000
  EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
  BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
  TYPE 20 10 10 10 10
```


| WING | I | XB | CASE 1 | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | CASE 7 | CASE 8 | CASE 9 | CASE 10 | |
|------|---|----------|----------|-----------|----------|----------|----------|----------|----------|----------|----------|----------|--|
| JET | 1 | 0.000000 | 0.129570 | 0.015231 | 0.006761 | 0.028993 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 2 | 0.100000 | 0.095670 | 0.002579 | 0.000567 | 0.041840 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 3 | 0.050000 | 0.095611 | 0.000740 | 0.001624 | 0.041861 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 4 | 0.050000 | 0.017467 | 0.006730 | 0.004430 | 0.044420 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 5 | 0.000000 | 0.007476 | 0.016049 | 0.005106 | 0.035778 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| WING | 1 | 1.000000 | 0.005187 | 0.059876 | 0.003649 | 0.019742 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 2 | 1.000000 | 0.003201 | 0.009183 | 0.002402 | 0.008258 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 3 | 1.500000 | 0.001203 | 0.001247 | 0.000589 | 0.002077 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 4 | 0.000000 | 0.000220 | 0.003111 | 0.000266 | 0.000261 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 5 | 0.000000 | 0.000220 | 0.003111 | 0.000266 | 0.000261 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 6 | 0.000000 | 0.188771 | 0.022600 | 0.010283 | 0.047722 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 7 | 0.040000 | 0.127018 | 0.015844 | 0.007125 | 0.039565 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 8 | 0.060000 | 0.067175 | 0.015793 | 0.005823 | 0.039260 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 9 | 0.080000 | 0.077455 | 0.010931 | 0.005056 | 0.039619 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 10 | 0.100000 | 0.062479 | 0.009627 | 0.004523 | 0.041840 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| JET | * CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES * | | | | | | | | | | | | |
| | 1 | 0.000000 | 0.185800 | 0.024182 | 0.010750 | 0.056734 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 2 | 0.100000 | 0.107433 | 0.017094 | 0.008019 | 0.068596 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 3 | 0.200000 | 0.064708 | 0.013536 | 0.006439 | 0.067874 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 4 | 0.500000 | 0.029356 | 0.012062 | 0.007088 | 0.070153 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 5 | 0.900000 | 0.012979 | 0.027342 | 0.011415 | 0.051704 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 6 | 0.000000 | 0.273687 | 0.036243 | 0.016196 | 0.090728 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 7 | 0.040000 | 0.189277 | 0.028879 | 0.011673 | 0.071112 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 8 | 0.060000 | 0.150521 | 0.017196 | 0.009724 | 0.062293 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 9 | 0.080000 | 0.115940 | 0.018903 | 0.008644 | 0.066906 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 10 | 0.100000 | 0.107433 | 0.000287 | 0.000155 | 0.000326 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| WING | * DETAILED LEADING EDGE LOADING * | | | | | | | | | | | | |
| | 11 | 0.000000 | 0.230760 | 0.026268 | 0.014468 | 0.091938 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 12 | 0.100000 | 0.140897 | 0.025102 | 0.011157 | 0.095208 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 13 | 0.200000 | 0.089584 | 0.019426 | 0.009207 | 0.090417 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 14 | 0.500000 | 0.040428 | 0.018778 | 0.012471 | 0.089255 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 15 | 0.800000 | 0.025147 | 0.027981 | 0.020581 | 0.075300 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 16 | 0.900000 | 0.020025 | 0.015635 | 0.008562 | 0.062236 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 17 | 0.000000 | 0.134214 | 0.076281 | 0.026293 | 0.039216 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 18 | 1.000000 | 0.082328 | 0.019171 | 0.011524 | 0.019288 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 19 | 1.100000 | 0.002574 | 0.002923 | 0.001175 | 0.004705 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 20 | 0.000000 | 0.000548 | 0.000179 | 0.000040 | 0.000422 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| JET | * DETAILED LEADING EDGE LOADING * | | | | | | | | | | | | |
| | 1 | 0.020000 | 0.341408 | 0.052102 | 0.021835 | 0.143840 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 2 | 0.040000 | 0.238055 | 0.037555 | 0.015672 | 0.110579 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 3 | 0.060000 | 0.160841 | 0.031040 | 0.013322 | 0.039551 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 4 | 0.080000 | 0.161644 | 0.027486 | 0.011955 | 0.096198 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 5 | 0.100000 | 0.140897 | 0.025102 | 0.011257 | 0.095598 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 6 | 0.000000 | 0.267135 | 0.066586 | 0.017101 | 0.186564 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 7 | 0.040000 | 0.210954 | 0.041716 | 0.010073 | 0.147964 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 8 | 0.060000 | 0.171739 | 0.038001 | 0.008703 | 0.106704 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 9 | 0.080000 | 0.185516 | 0.032006 | 0.007930 | 0.117149 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 10 | 0.100000 | 0.162281 | 0.012006 | 0.007930 | 0.117149 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| WING | * SPANWISE LOADING FOR FUNDAMENTAL CASE 1 * | | | | | | | | | | | | |
| | 11 | 1.000000 | 0.021297 | 0.044329 | 0.011430 | 0.121581 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 12 | 0.100000 | 0.162281 | 0.032006 | 0.007930 | 0.117143 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 13 | 0.200000 | 0.105208 | 0.026359 | 0.005608 | 0.105312 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 14 | 0.500000 | 0.054242 | 0.022370 | 0.004252 | 0.101691 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 15 | 0.900000 | 0.025339 | 0.036868 | 0.002913 | 0.071827 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 16 | 0.000000 | 0.172423 | 0.078281 | 0.002094 | 0.044615 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 17 | 0.040000 | 0.106886 | 0.020564 | 0.001449 | 0.036600 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 18 | 0.060000 | 0.030524 | 0.005578 | 0.000592 | 0.030000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 19 | 0.080000 | 0.017453 | 0.0017453 | 0.017453 | 0.019453 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 20 | 0.000000 | 0.000403 | 0.000220 | 0.000081 | 0.000522 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| JET | * DETAILED LEADING EDGE LOADING * | | | | | | | | | | | | |
| | 1 | 0.020000 | 0.387135 | 0.066586 | 0.017101 | 0.186564 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 2 | 0.040000 | 0.210954 | 0.041716 | 0.010073 | 0.147964 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 3 | 0.060000 | 0.171739 | 0.038001 | 0.008703 | 0.106704 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 4 | 0.080000 | 0.185516 | 0.032006 | 0.007930 | 0.117149 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 5 | 0.100000 | 0.162281 | 0.012006 | 0.007930 | 0.117149 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 6 | 0.000000 | 0.267135 | 0.066586 | 0.017101 | 0.186564 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 7 | 0.040000 | 0.210954 | 0.041716 | 0.010073 | 0.147964 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 8 | 0.060000 | 0.171739 | 0.038001 | 0.008703 | 0.106704 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 9 | 0.080000 | 0.185516 | 0.032006 | 0.007930 | 0.117149 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 10 | 0.100000 | 0.162281 | 0.012006 | 0.007930 | 0.117149 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| WING | * SPANWISE LOADING FOR FUNDAMENTAL CASE 2 * | | | | | | | | | | | | |
| | 11 | 0.000000 | 0.134284 | 0.017453 | 0.017453 | 0.030710 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | 12 | | | | | | | | | | | | |

0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 0.000000 10.000000 10.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 *** NOTE *** EACH LEADING EDGE CP VALUE IS THE AVERAGE VALUE OF THE SINGULAR DISTRIBUTION
 DO NOT PLOT THESE LOADING POINTS DIRECTLY
 SECTION 1 Y = 0.975000 CHORD = 0.444444
 WING XB 0.000000 0.100000 0.200000 0.500000 0.900000
 CP(A=0) 0.219927 0.141560 0.108940 0.110104 0.211551
 CP(A=1) 0.129570 0.062479 0.036113 0.016367 0.007476
 JET XB 1.000000 1.100000 1.500000 3.000000
 CP(A=0) 0.826244 0.115851 0.018450 0.001371
 CP(A=1) 0.005187 0.003301 0.001203 0.000202
 SECTION 2 Y = 0. BB7500 CHORD = 0.444444
 WING XB 0.000000 0.100000 0.200000 0.500000 0.900000
 CP(A=0) 0.349322 0.251131 0.195344 0.206600 0.387550
 CP(A=1) 0.105800 0.107433 0.064708 0.029236 0.012979
 JET XB 1.000000 1.100000 1.500000 3.000000
 CP(A=0) 0.792271 0.205030 0.029491 0.001867
 CP(A=1) 0.008BB77 0.00549B 0.001876 0.000287
 SECTION 3 Y = 0.6B7500 CHORD = 0.444444
 WING XB 0.000000 0.100000 0.200000 0.500000 0.900000

CP(A=0) 0.491355 0.362287 0.287097 0.112489 0.602165 1.212604
 CP(A=1) 0.230760 0.140897 0.089584 0.044098 0.025147 0.020025
JET
 XB 1.000000 1.100000 1.500000 3.000000
 CP(A=0) 1.026741 0.305251 0.046979 0.00192
 CP(A=1) 0.013414 0.028238 0.000674 0.000548
 SECTION 4 Y = 0.275000 CHORD = 0.444444
WING
 XB 0.000000 0.100000 0.200000 0.500000 0.900000
 CP(A=0) 0.557693 0.393260 0.305599 0.156222 0.327806
 CP(A=1) 0.261297 0.162281 0.105208 0.054222 0.025306
JET
 XB 1.000000 1.100000 1.500000 3.000000
 CP(A=0) 0.837478 0.220025 0.042223 0.003008
 CP(A=1) 0.017243 0.010686 0.003242 0.000403
 # COMPOSITE CASE 1 #

FUNDAMENTAL CASE FACTORS

| A(1) | A(2) | A(3) | A(4) | A(5) | A(6) | A(7) | A(8) | A(9) | A(10) |
|----------|-----------|-----------|----------|----------|----------|----------|----------|----------|----------|
| 0.000000 | 10.000000 | 10.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |

SECTION Y LIFT PITCHING MOMENT LIFT CENTER

| SECTION | Y | LIFT | PITCHING | MOMENT | LIFT CENTER | |
|---------|----------|---------------------------------|-------------------------------|---|--|---|
| 1 | 0.975000 | CLG0 CLGU CLG1 CLM0 CLMU CLM1 | CMG0 CMHU CMT0 CM0 CMA0 CMA1 | 0.174533 0.051757 0.076843 0.017453 0.017453 0.000000 | -0.275379 0.007640 0.007640 0.007640 0.007640 0.000000 | 0.558167 0.775265 0.22834 0.485007 0.241956 0.525914 0.710901 |
| 2 | 0.887500 | CLG2 CLGU2 CLG3 CLM2 CLMU2 CLM3 | CMG2 CMHU2 CMT2 CM2 CMA2 CMA3 | 0.165954 0.076394 0.031342 0.017453 0.017453 0.000000 | -0.341487 0.013220 0.013220 0.013220 0.013220 0.000000 | 0.596364 0.754636 0.258957 0.419256 0.255912 0.394857 0.486797 0.645617 |
| 3 | 0.687500 | CLG4 CLGU4 CLG5 CLM4 CLMU4 CLM5 | CMG4 CMHU4 CMT4 CM4 CMA4 CMA5 | 0.159597 0.034906 0.017453 0.017453 0.017453 0.000000 | -0.454939 0.019453 0.019453 0.019453 0.019453 0.000000 | 0.596364 0.754636 0.258957 0.419256 0.255912 0.394857 0.486797 0.645617 |
| 4 | 0.275000 | CLG6 CLGU6 CLG7 CLM6 CLMU6 CLM7 | CMG6 CMHU6 CMT6 CM6 CMA6 CMA7 | 0.186587 0.017453 0.017453 0.017453 0.017453 0.000000 | -0.364120 0.023831 0.023831 0.023831 0.023831 0.000000 | 0.266070 0.385767 |
| TOTAL | 0.407093 | CLG0 CLGU CLG1 CLM0 CLMU CLM1 | CMG0 CMHU CMT0 CM0 CMA0 CMA1 | -0.216503 -0.222529 0.004800 0.004800 | -0.324558 (APEX) 0.000000 (APEX) | 0.531889 0.697375 0.000000 0.000000 |
| | 0.078903 | CLG2 CLGU2 CLG3 CLM2 CLMU2 CLM3 | CMG2 CMHU2 CMT2 CM2 CMA2 CMA3 | -0.114765 0.166897 0.004800 0.004800 | -0.376652 (XMC) 0.000000 (XMC) | 0.486395 0.509903 0.000000 0.000000 |
| | | | | -0.0000790 0.017090 0.013039 0.0000790 | 0.000000 (XMC) 0.000000 (XMC) | 0.115563 0.175155 |

SECTION Y INDUCED DRAG ALFINO CMU

| SECTION | Y | CD00 CD01 CD02 CS00 CS01 CS02 | CD10 CD11 CD12 CD20 CD21 CD22 | CDG0 CDG1 CDG2 CG00 CG01 CG02 | CGA0 CGA1 CGA2 CA00 CA01 CA2 | GAMMA2 ALFINA | CMU |
|---------|-----------|---|---|---|---|---|-----------|
| 1 | 0.975000 | 0.000909 0.015209 0.000942 0.015209 0.000942 0.015209 | 0.000561 0.000561 0.000561 0.000561 0.000561 0.000561 | 0.000994 0.000994 0.000994 0.000994 0.000994 0.000994 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.3582766 0.3064195 0.9856133 1.0000000 | 0.0000000 |
| 2 | 0.887500 | 0.000000 0.015209 0.000000 0.015209 0.000000 0.015209 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.0000000 | 0.0000000 |
| 3 | 0.687500 | 0.019540 0.060924 0.000000 0.060924 0.000000 0.060924 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.0000000 | 0.0000000 |
| 4 | 0.275000 | 0.000000 0.015209 0.000000 0.015209 0.000000 0.015209 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.0000000 | 0.0000000 |
| TOTAL | 0.053740 | 0.0277983 0.0044527 0.0287176 | 0.0451802 0.9712823 0.9999999 | 0.0000000 | 0.0000000 | 0.0000000 | |
| | 0.0071854 | 0.0058839 0.0042190 0.0068502 | 0.0101437 0.0000000 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | |
| | 0.0013771 | 0.0001523 0.0010010 0.0005255 | 0.0000000 0.0000000 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | |

TOTAL AERODYNAMIC COEFFICIENTS

| SECTION | Y | CD00 CD01 CD02 CS00 CS01 CS02 | CD10 CD11 CD12 CD20 CD21 CD22 | CDG0 CDG1 CDG2 CG00 CG01 CG02 | CGA0 CGA1 CGA2 CA00 CA01 CA2 | GAMMA2 ALFINA | CMU |
|---------|-----------|---|---|---|---|---|-----------|
| 1 | 0.975000 | 0.000909 0.015209 0.000942 0.015209 0.000942 0.015209 | 0.000561 0.000561 0.000561 0.000561 0.000561 0.000561 | 0.000994 0.000994 0.000994 0.000994 0.000994 0.000994 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.3582766 0.3064195 0.9856133 1.0000000 | 0.0000000 |
| 2 | 0.887500 | 0.000000 0.015209 0.000000 0.015209 0.000000 0.015209 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.0000000 | 0.0000000 |
| 3 | 0.687500 | 0.019540 0.060924 0.000000 0.060924 0.000000 0.060924 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.0000000 | 0.0000000 |
| 4 | 0.275000 | 0.000000 0.015209 0.000000 0.015209 0.000000 0.015209 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 | 0.0000000 | 0.0000000 |
| TOTAL | 0.053740 | 0.0277983 0.0044527 0.0287176 | 0.0451802 0.9712823 0.9999999 | 0.0000000 | 0.0000000 | 0.0000000 | |
| | 0.0071854 | 0.0058839 0.0042190 0.0068502 | 0.0101437 0.0000000 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | |
| | 0.0013771 | 0.0001523 0.0010010 0.0005255 | 0.0000000 0.0000000 0.0000000 | 0.0000000 | 0.0000000 | 0.0000000 | |

TABULATED TOTAL COEFFICIENTS FOR COMPOSITE CASE 1

| ALPHA | CCL CCL~2 CCL(MC) CLL CDITZ CCT CN1 CN CN CCY |
|-----------|---|
| -10.00000 | -0.3330355 0.1115131 -0.266985 0.0000000 -0.0057628 1.0057621 0.0000000 0.0000000 0.0000000 |
| -9.00000 | -0.2375801 0.0564443 -0.2697389 0.0000000 -0.0052130 1.0052128 0.0000000 0.0000000 0.0000000 |
| -8.00000 | -0.1412243 0.0194445 -0.2705293 0.0000000 -0.0036523 1.0036526 0.0000000 0.0000000 0.0000000 |
| -7.00000 | -0.0448685 0.0020132 -0.2713196 0.0000000 -0.0010837 1.0010834 0.0000000 0.0000000 0.0000000 |
| -6.00000 | -0.0514873 0.0026509 -0.2721100 0.0000000 -0.0024298 0.9975042 0.0000000 0.0000000 0.0000000 |
| -5.00000 | -0.1478431 0.0218576 -0.2729004 0.0000000 -0.0070951 0.9929148 0.0000000 0.0000000 0.0000000 |
| -4.00000 | -0.2441989 0.0596321 -0.2736908 0.0000000 -0.0126844 0.9873155 0.0000000 0.0000000 0.0000000 |
| -3.00000 | -0.3405547 0.1197975 -0.2744812 0.0000000 -0.0198235 0.9807064 0.0000000 0.0000000 0.0000000 |
| -2.00000 | -0.4269105 0.1908907 -0.2752715 0.0000000 -0.0269125 0.9730874 0.0000000 0.0000000 0.0000000 |
| -1.00000 | -0.5332662 0.2842729 -0.2760619 0.0000000 -0.0355414 0.96444585 0.0000000 0.0000000 0.0000000 |
| 0.00000 | -0.6296220 0.3946239 -0.2768523 0.0000000 -0.0451802 0.9548197 0.0000000 0.0000000 0.0000000 |
| 1.00000 | -0.7259778 0.5270438 -0.2776627 0.0000000 -0.0558289 0.9441710 0.0000000 0.0000000 0.0000000 |
| 2.00000 | -0.8223336 0.6762326 -0.2784330 0.0000000 -0.067874 0.9325125 0.0000000 0.0000000 0.0000000 |
| 3.00000 | -0.9186894 0.8439903 -0.2792224 0.0000000 -0.0801558 0.9198441 0.0000000 0.0000000 0.0000000 |
| 4.00000 | -1.0150452 1.0302164 -0.2800128 0.0000000 -0.0938242 0.9061657 0.0000000 0.0000000 0.0000000 |
| 5.00000 | -1.1114006 1.2352104 -0.2808042 0.0000000 -0.1085224 0.8914775 0.0000000 0.0000000 0.0000000 |

| | | | | | | | | | | | | |
|-----------|---|-----------|------------|------------|-----------|---|-----------|-----------|---|-----------|-----------|-----------|
| 6.000000 | * | 1.2077560 | 1.4586744 | -0.2815945 | 0.0000000 | * | 0.1242206 | 0.8757794 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 7.000000 | * | 1.3041124 | 1.7007054 | -0.2827849 | 0.0000000 | * | 0.1409285 | 0.8590714 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 8.000000 | * | 1.4004679 | 1.9613054 | -0.2831753 | 0.0000000 | * | 0.1586444 | 0.8413555 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 9.000000 | * | 1.4958233 | 2.2404795 | -0.2829656 | 0.0000000 | * | 0.1773741 | 0.8226258 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 10.000000 | * | 1.5931797 | 2.5382214 | -0.2827561 | 0.0000000 | * | 0.1971119 | 0.8028882 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 11.000000 | * | 1.6895551 | 2.8545284 | -0.2825546 | 0.0000000 | * | 0.2178532 | 0.7821407 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 12.000000 | * | 1.7858906 | 3.1894045 | -0.2823556 | 0.0000000 | * | 0.2326168 | 0.7605832 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 13.000000 | * | 1.8822460 | 3.5428495 | -0.2871272 | 0.0000000 | * | 0.2622841 | 0.7372615 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 14.000000 | * | 1.9786024 | 3.9124675 | -0.2879176 | 0.0000000 | * | 0.2881612 | 0.7138288 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 15.000000 | * | 2.0749578 | 4.3054493 | -0.2887073 | 0.0000000 | * | 0.3109483 | 0.6890516 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 16.000000 | * | 2.1713142 | 4.7144053 | -0.2894983 | 0.0000000 | * | 0.3337453 | 0.6632546 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 17.000000 | * | 2.2676697 | 5.1223253 | -0.2902887 | 0.0000000 | * | 0.3562552 | 0.6364478 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 18.000000 | * | 2.3640251 | 5.5386145 | -0.2910790 | 0.0000000 | * | 0.3913689 | 0.6086211 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 19.000000 | * | 2.4603815 | 5.9534763 | -0.2918694 | 0.0000000 | * | 0.4201955 | 0.5798045 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 20.000000 | * | 2.5597399 | 6.3569032 | -0.2926598 | 0.0000000 | * | 0.4500320 | 0.5499679 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 21.000000 | * | 2.6530294 | 6.7038885 | -0.2934502 | 0.0000000 | * | 0.4808784 | 0.5191215 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 22.000000 | * | 2.7444488 | 7.0559468 | -0.2942405 | 0.0000000 | * | 0.5173747 | 0.4872655 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 23.000000 | * | 2.8458047 | 7.4086133 | -0.2950310 | 0.0000000 | * | 0.5454608 | 0.4547650 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 24.000000 | * | 2.9421606 | 7.7615958 | -0.2958215 | 0.0000000 | * | 0.5734769 | 0.4205570 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 25.000000 | * | 3.0385160 | 8.1185794 | -0.2966120 | 0.0000000 | * | 0.6147628 | 0.3895627 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 26.000000 | * | 3.1349725 | 8.4754083 | -0.2974031 | 0.0000000 | * | 0.6502589 | 0.3596596 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 27.000000 | * | 3.2323953 | 10.1440830 | -0.2981932 | 0.0000000 | * | 0.6891632 | 0.3212875 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 28.000000 | * | 3.3297588 | 11.0728102 | -0.2989735 | 0.0000000 | * | 0.7250799 | 0.2749200 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 29.000000 | * | 3.4271395 | 11.7235562 | -0.2997735 | 0.0000000 | * | 0.7640054 | 0.2359245 | * | 0.0000000 | 0.0000000 | 0.0000000 |
| 30.000000 | * | 3.5202951 | 12.3924770 | -0.3005636 | 0.0000000 | * | 0.8039407 | 0.1940592 | * | 0.0000000 | 0.0000000 | 0.0000000 |

* SECOND RUN FOR STABILITY DERIVATIVE CASE *

* STABILITY DERIVATIVE DATA FOR FUNDAMENTAL CASE 1 *

ROLLING MOMENT COEFFICIENT DERIVATIVE DUE TO YAWING, CLLR = 0.0001168

YAWING MOMENT COEFFICIENT ABOUT XMC DUE TO YAWING ABOUT XCG, CN(R) MAY BE CALCULATED AS FOLLOWS

$$CN(R) = CNR \cdot R + CNR2 \cdot R^{**2}$$

WHERE $CNR = 0.000001049$
 $CNR2 = 0.0000000$

SIDE FORCE COEFFICIENT DUE TO YAWING, CY(R) MAY BE CALCULATED AS FOLLOWS

$$CY(R) = CYR \cdot R + CYR2 \cdot R^{**2}$$

WHERE $CYR = 0.000000000$
 $CYR2 = 0.0000000$

* STABILITY DERIVATIVE DATA FOR FUNDAMENTAL CASE 2 *

ROLLING MOMENT COEFFICIENT DERIVATIVE DUE TO YAWING, CLLR = 0.0000436

YAWING MOMENT COEFFICIENT ABOUT XMC DUE TO YAWING ABOUT XCG, CN(R) MAY BE CALCULATED AS FOLLOWS

$$CN(R) = CNR \cdot R + CNR2 \cdot R^{**2}$$

WHERE $CNR = 0.000000034$
 $CNR2 = 0.0000000$

SIDE FORCE COEFFICIENT DUE TO YAWING, CY(R) MAY BE CALCULATED AS FOLLOWS

$$CY(R) = CYR \cdot R + CYR2 \cdot R^{**2}$$

WHERE $CYR = 0.000000000$
 $CYR2 = 0.0000000$

* STABILITY DERIVATIVE DATA FOR FUNDAMENTAL CASE 3 *

ROLLING MOMENT COEFFICIENT DERIVATIVE DUE TO YAWING, CLLR = 0.0000344

YAWING MOMENT COEFFICIENT ABOUT XMC DUE TO YAWING ABOUT XCG, CN(R) MAY BE CALCULATED AS FOLLOWS

$$CN(R) = CNR \cdot R + CNR2 \cdot R^{**2}$$

WHERE $CNR = -0.000000100$
 $CNR2 = 0.0000000$

SIDE FORCE COEFFICIENT DUE TO YAWING, CY(R) MAY BE CALCULATED AS FOLLOWS

$$CY(R) = CYR \cdot R + CYR2 \cdot R^{**2}$$

WHERE $CYR = 0.000000000$
 $CYR2 = 0.0000000$

* STABILITY DERIVATIVE DATA FOR FUNDAMENTAL CASE 4 *

ROLLING MOMENT COEFF DERIVATIVE DUE TO ROLLING, CLLP = -0.0066949

YAWING MOMENT COEFFICIENT ABOUT XMC DUE TO ROLLING, CN(P) MAY BE CALCULATED AS FOLLOWS

$$CN(P) = CNP2 \cdot P^{**2}$$

WHERE $CNP2 = 0.0000000$

SIDE FORCE COEFFICIENT DUE TO ROLLING, CY(P) MAY BE CALCULATED AS FOLLOWS

$$CY(P) = CYP2 \cdot P^{**2}$$

```

WHERE CYP2 = 0.0000000
***** STABILITY DEPIVATIVE DATA FOR COMPOSITE CASE 1 *****
FUNDAMENTAL CASE FACTORS
A(1) A(2) A(3) A(4) A(5) A(6) A(7) A(8) A(9) A(10)
0.000000 10.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000

LIFT COEFFICIENT DERIVATIVE DUE TO PITCHING ABOUT XCG, CLQ = 0.089478
PITCHING MOMENT COEFFICIENT DERIVATIVE ABOUT ORIGIN DUE TO PITCHING ABOUT XCG, CMQ = -0.038412
PITCHING MOMENT COEFF DERIVATIVE ABOUT XMC DUE TO PITCHING ABOUT XCG, CMOMC = -0.016043

ROLLING MOMENT CCOEFF DERIVATIVE DUE TO ROLLING, CLLP = -0.0066949

YAWING MOMENT COEFFICIENT ABOUT XMC DUE TO ROLLING, CN(P) MAY BE CALCULATED AS FOLLOWS
CN(P) = CNP*P + CNP2*P**2
WHERE CNP = CNP0 + CNPA*ALPHA
    CNP0 = -0.0003521
    CNPA = -0.0000501
    CNP2 = 0.0000000

SIDE FORCE COEFFICIENT DUE TO ROLLING, CY(P) MAY BE CALCULATED AS FOLLOWS
CY(P) = CYP*P + CYP2*P**2
WHERE CYP = CYP0 + CYPAA*ALPHA
    CYP0 = 0.0000000
    CYPAA = 0.0000000
    CYP2 = 0.0000000

ROLLING MOMENT COEFF DERIVATIVE DUE TO YAWING ABOUT XCG, CLLR MAY BE CALCULATED AS FOLLOWS
CLLR = CLLR0 + CLLRA*ALPHA
WHERE CLLR0 = 0.0007805
    CLLRA = 0.00011e8

YAWING MOMENT COEFFICIENT ABOUT XMC DUE TO YAWING ABOUT XCG, CN(R) MAY BE CALCULATED AS FOLLOWS
CN(R) = CNR*R + CNR2*R**2
WHERE CNR = CNR0 + CNRA*ALPHA + CNRA2*ALPHA**2
    CNR0 = -0.000130
    CNRA = -0.0000055
    CNRA2 = 0.0000010
AND CNR2 = CNR0 + CNRA*ALPHA + CNRA2*ALPHA**2
    CNR0 = 0.0000000
    CNRA = 0.0000000
    CNRA2 = 0.0000000

SIDE FORCE COEFFICIENT ABOUT XMC DUE TO YAWING ABOUT XCG, CY(R) MAY BE CALCULATED AS FOLLOWS
CY(R) = CYR*R + CYR2*R**2
WHERE CYR = CYR0 + CYRA*ALPHA + CYRA2*ALPHA**2
    CYR0 = 0.0000000
    CYRA = 0.0000000
    CYRA2 = 0.0000000
AND CYR2 = CYR0 + CYRA*ALPHA + CYRA2*ALPHA**2
    CYR0 = 0.0000000
    CYRA = 0.0000000
    CYRA2 = 0.0000000

***** VARIATION OF STABILITY TERMS WITH ANGLE OF ATTACK *****

```

| ALPHA | CNP | CNP2 | CYP | CYP2 | CLLR | CNR | CNR2 |
|-----------|-----|------------|-----------|------|------------|------------|-----------|
| -10.00000 | * | 0.0002479 | 0.0000000 | * | -0.0003880 | 0.0001273 | 0.0000000 |
| -9.00000 | * | 0.0001879 | 0.0000000 | * | -0.0002712 | 0.0001038 | 0.0000000 |
| -8.00000 | * | 0.0001377 | 0.0000000 | * | -0.0001547 | 0.0000824 | 0.0000000 |
| -7.00000 | * | 0.0000876 | 0.0000000 | * | -0.0000575 | 0.0000632 | 0.0000000 |
| -6.00000 | * | 0.0000575 | 0.0000000 | * | -0.0000294 | 0.0000460 | 0.0000000 |
| -5.00000 | * | -0.0000526 | 0.0000000 | * | -0.0000161 | 0.0000309 | 0.0000000 |
| -4.00000 | * | -0.0001127 | 0.0000000 | * | -0.0000131 | 0.0000179 | 0.0000000 |
| -3.00000 | * | -0.0001728 | 0.0000000 | * | -0.0000430 | 0.0000070 | 0.0000000 |
| -2.00000 | * | -0.0002229 | 0.0000000 | * | -0.0000568 | 0.0000017 | 0.0000000 |
| -1.00000 | * | -0.0002630 | 0.0000000 | * | -0.0000684 | 0.0000000 | 0.0000000 |
| 0.00000 | * | -0.0003571 | 0.0000000 | * | -0.0000785 | -0.0000130 | 0.0000000 |
| 1.00000 | * | -0.0004132 | 0.0000000 | * | -0.0000873 | -0.0000155 | 0.0000000 |
| 2.00000 | * | -0.0004723 | 0.0000000 | * | -0.0001042 | -0.0000159 | 0.0000000 |
| 3.00000 | * | -0.0005332 | 0.0000000 | * | -0.0001131 | -0.0000142 | 0.0000000 |
| 4.00000 | * | -0.0005955 | 0.0000000 | * | -0.0001247 | -0.0000104 | 0.0000000 |
| 5.00000 | * | -0.0006556 | 0.0000000 | * | -0.0001364 | -0.0000045 | 0.0000000 |
| 6.00000 | * | -0.0007137 | 0.0000000 | * | -0.0001481 | -0.0000025 | 0.0000000 |
| 7.00000 | * | -0.0007738 | 0.0000000 | * | -0.0001594 | -0.0000016 | 0.0000000 |
| 8.00000 | * | -0.0008339 | 0.0000000 | * | -0.0001715 | -0.0000005 | 0.0000000 |
| 9.00000 | * | -0.0008940 | 0.0000000 | * | -0.0001823 | -0.0000040 | 0.0000000 |
| 10.00000 | * | -0.0009551 | 0.0000000 | * | -0.0001949 | -0.0000056 | 0.0000000 |
| 11.00000 | * | -0.0001014 | 0.0000000 | * | -0.0002058 | -0.0000075 | 0.0000000 |
| 12.00000 | * | -0.0001074 | 0.0000000 | * | -0.0002156 | -0.0000056 | 0.0000000 |
| 13.00000 | * | -0.0001134 | 0.0000000 | * | -0.0002246 | -0.0000118 | 0.0000000 |
| 14.00000 | * | -0.0001194 | 0.0000000 | * | -0.0002416 | -0.0000143 | 0.0000000 |
| 15.00000 | * | -0.0001254 | 0.0000000 | * | -0.0002522 | -0.0000169 | 0.0000000 |
| 16.00000 | * | -0.0001314 | 0.0000000 | * | -0.0002650 | -0.0000188 | 0.0000000 |
| 17.00000 | * | -0.0001374 | 0.0000000 | * | -0.0002769 | -0.0000209 | 0.0000000 |
| 18.00000 | * | -0.0001434 | 0.0000000 | * | -0.0002887 | -0.0000221 | 0.0000000 |
| 19.00000 | * | -0.0001495 | 0.0000000 | * | -0.0003006 | -0.0000234 | 0.0000000 |
| 20.00000 | * | -0.0001555 | 0.0000000 | * | -0.0003117 | -0.0000255 | 0.0000000 |
| 21.00000 | * | -0.0001615 | 0.0000000 | * | -0.0003241 | -0.0000275 | 0.0000000 |
| 22.00000 | * | -0.0001675 | 0.0000000 | * | -0.0003351 | -0.0000295 | 0.0000000 |
| 23.00000 | * | -0.0001735 | 0.0000000 | * | -0.0003468 | -0.0000314 | 0.0000000 |
| 24.00000 | * | -0.0001795 | 0.0000000 | * | -0.0003584 | -0.0000334 | 0.0000000 |
| 25.00000 | * | -0.0001855 | 0.0000000 | * | -0.0003707 | -0.0000354 | 0.0000000 |
| 26.00000 | * | -0.0001915 | 0.0000000 | * | -0.0003818 | -0.0000370 | 0.0000000 |
| 27.00000 | * | -0.0001975 | 0.0000000 | * | -0.0003928 | -0.0000381 | 0.0000000 |
| 28.00000 | * | -0.0002035 | 0.0000000 | * | -0.0004039 | -0.0000402 | 0.0000000 |
| 29.00000 | * | -0.0002090 | 0.0000000 | * | -0.0004160 | -0.0000425 | 0.0000000 |
| 30.00000 | * | -0.0002151 | 0.0000000 | * | -0.0004285 | -0.0000448 | 0.0000000 |

***** THE PROGRAM HAS REACHED NORMAL TERMINATION *****

***** THE PROGRAM HAS REACHED NORMAL TERMINATION *****

JETFLAP INPUT DATA FILE TAPER.DAT

TAPERED SWEPT WING, AR=8.0, SWEEP ANGLE 45, 10X10 W/SEMI-CIRCLE SPACING
50.0000 20.000 0.0 10.43 10.43
1001000001020000
.993844 .969372 .921032 .850012 .758062 .647446 .520888 .381504
.232726 .078217
010101010101010101
10
.0 .024472 .095492 .206107 .345492 .5000 .654508 .793893
.904508 .975528
8.0 45.0 0.45
9

PROGRAM OUTPUT DATA FOR TAPER.DAT

***** EVD JET - WING COMPUTER PROGRAM *****

TAPERED SWEPT WING, AR=8.0, SWEEP ANGLE 45, 10X10 W/SEM1-CIRCLE SPACING

| | USED | INPUT |
|---------|----------|-----------|
| AREA | 0.500000 | 50.000000 |
| SPAN | 2.000000 | 20.000000 |
| CREF | 0.261990 | 0.000000 |
| XMC | 1.043000 | 10.430000 |
| CMAC | 0.261794 | 2.617941 |
| ARATIO | 8.000000 | 8.000000 |
| XCG | 1.043000 | 10.430000 |
| NROWS | 10 | 10 |
| NCASEG | 1 | 1 |
| ISVMM | 0 | 0 |
| IPRINT | 0 | 0 |
| JETFLG | 1 | 1 |
| IGTYPE | 2 | 2 |
| IGHINGE | 0 | 0 |

NUMBER OF WING ELEMENTS = 100
NUMBER OF JET ELEMENTS = 0
TOTAL NUMBER OF ELEMENTS = 100

***** ELEMENT GEOMETRY DATA AND FUNDAMENTAL CASE DATA FOR FUNDAMENTAL CASE 1 *****

*** SECTION 1 *** Y = 0.993844 DELTA = 0.006156 XLEAD = 1.040966 XTRAIL = 1.197306 CHORD = 0.156340 TANLE = 1.047412
WING ELEMENTS NW = 10 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
X1 1.060965 1.044792 1.055885 1.073189 1.094980 1.119135 1.142392 1.165083 1.182377 1.192480
DEL 0.024472 0.071020 0.110615 0.129385 0.154508 0.154508 0.154508 0.110615 0.071020 0.024472
EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
TYPE 20 10 10 10 10 10 10 10 10 10

THIS ROW HAS NO JET
*** SECTION 2 *** Y = 0.969372 DELTA = 0.018316 XLEAD = 1.015334 XTRAIL = 1.176315 CHORD = 0.160981 TANLE = 1.047412
WING ELEMENTS NW = 10 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
X1 1.015534 1.019573 1.030706 1.048513 1.070511 1.095824 1.120697 1.145135 1.160942 1.175275
DEL 0.024472 0.071020 0.110615 0.139385 0.154508 0.154508 0.154508 0.110615 0.071020 0.024472
EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
TYPE 20 10 10 10 10 10 10 10 10 10

THIS ROW HAS NO JET
*** SECTION 3 *** Y = 0.921032 DELTA = 0.050024 XLEAD = 0.964702 XTRAIL = 1.134851 CHORD = 0.170149 TANLE = 1.047415
WING ELEMENTS NW = 10 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
X1 0.945702 0.968895 0.980877 0.982387 0.102387 1.04776 1.07606 1.097872 1.118603 1.130887
DEL 0.024472 0.071020 0.110615 0.139385 0.154508 0.154508 0.154508 0.110615 0.071020 0.024472
EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
TYPE 20 10 10 10 10 10 10 10 10 10

THIS ROW HAS NO JET
*** SECTION 4 *** Y = 0.859012 DELTA = 0.040996 XLEAD = 0.890314 XTRAIL = 1.073933 CHORD = 0.183618 TANLE = 1.047413
WING ELEMENTS NW = 10 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
X1 0.899314 0.898480 0.907848 0.928154 0.953753 0.982123 1.010694 1.03088 1.053589 1.085339
DEL 0.024472 0.071020 0.110615 0.139385 0.154508 0.154508 0.154508 0.110615 0.071020 0.024472
EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
TYPE 20 10 10 10 10 10 10 10 10 10

THIS ROW HAS NO JET
*** SECTION 5 *** Y = 0.758062 DELTA = 0.050954 XLEAD = 0.794005 XTRAIL = 0.995062 CHORD = 0.201057 TANLE = 1.047413
WING ELEMENTS NW = 10 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
X1 0.794005 0.798925 0.812304 0.824422 0.863468 0.894533 0.925598 0.952622 0.975862 0.990142
DEL 0.024472 0.071020 0.110615 0.139385 0.154508 0.154508 0.154508 0.110615 0.071020 0.024472
EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
TYPE 20 10 10 10 10 10 10 10 10 10

THIS ROW HAS NO JET
*** SECTION 6 *** Y = 0.647446 DELTA = 0.059662 XLEAD = 0.678144 XTRAIL = 0.900180 CHORD = 0.222036 TANLE = 1.047414
WING ELEMENTS NW = 10 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
X1 0.678144 0.683537 0.693246 0.723807 0.754856 0.789162 0.813468 0.854547 0.878977 0.895746
DEL 0.024472 0.071020 0.110615 0.139385 0.154508 0.154508 0.154508 0.110615 0.071020 0.024472
EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
TYPE 20 10 10 10 10 10 10 10 10 10

THIS ROW HAS NO JET
*** SECTION 7 *** Y = 0.520888 DELTA = 0.066896 XLEAD = 0.545585 XTRAIL = 0.793893 CHORD = 0.246038 TANLE = 1.047412
WING ELEMENTS NW = 10 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
X1 0.545585 0.551606 0.569080 0.596295 0.630590 0.688604 0.706619 0.740913 0.769129 0.785603
DEL 0.024472 0.071020 0.110615 0.139385 0.154508 0.154508 0.154508 0.110615 0.071020 0.024472
EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
TYPE 20 10 10 10 10 10 10 10 10 10

THIS ROW HAS NO JET
*** SECTION 8 *** Y = 0.381504 DELTA = 0.072488 XLEAD = 0.399593 XTRAIL = 0.672066 CHORD = 0.327247 TANLE = 1.047414
WING ELEMENTS NW = 10 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
X1 0.329585 0.406260 0.425612 0.455735 0.493730 0.535879 0.577939 0.615907 0.646057 0.685388
DEL 0.024472 0.071020 0.110615 0.139385 0.154508 0.154508 0.154508 0.110615 0.071020 0.024472
EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
TYPE 20 10 10 10 10 10 10 10 10 10

THIS ROW HAS NO JET
*** SECTION 9 *** Y = 0.232726 DELTA = 0.076290 XLEAD = 0.243760 XTRAIL = 0.544450 CHORD = 0.300690 TANLE = 1.047414
WING ELEMENTS NW = 10 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
X1 0.243760 0.251119 0.272474 0.305735 0.347446 0.394105 0.440564 0.482476 0.515757 0.537092
DEL 0.024472 0.071020 0.110615 0.139385 0.154508 0.154508 0.154508 0.110615 0.071020 0.024472
EPS 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
TYPE 20 10 10 10 10 10 10 10 10 10

```

*** THIS ROW HAS NO JET
*** SECTION 10 *** Y = 0.078217 DELTA = 0.078219 XLEAD = 0.081926 XTRAIL = 0.411919 CHORD = 0.329993 TANLE = 1.047414
WING ELEMENTS NW = 0.000000 TWIST = 0.000000 HL = 0.000000 THETA S = 0.000000
   XB 0.000000 0.024472 0.095492 0.206107 0.345492 0.500000 0.654508 0.793893 0.904508 0.975528
   XI 0.081926 0.090001 0.113437 0.149959 0.196586 0.265922 0.297909 0.343905 0.380407 0.403843
   DEL 0.024472 0.071020 0.110615 0.132935 0.156508 0.154508 0.139385 0.110615 0.071020 0.022272
   EPG 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000 1.000000
   BETA 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
   TYPE 20 10 10 10 10 10 10 10 10 10
THIS ROW HAS NO JET

```

THIS ROW HAS NO JET

| ROW | CMU |
|-----|----------|
| 1 | 0.000000 |
| 2 | 0.000000 |
| 3 | 0.000000 |
| 4 | 0.000000 |
| 5 | 0.000000 |
| 6 | 0.000000 |
| 7 | 0.000000 |
| 8 | 0.000000 |
| 9 | 0.000000 |
| 10 | 0.000000 |

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CAGES

DETAILED LEADING EDGE LOADING

此表列出了在不同条件下， Fe^{2+} 与 H_2O_2 的反应速率常数 $k_{\text{Fe}^{2+}/\text{H}_2\text{O}_2}$ （单位： $\text{M}^{-1}\text{s}^{-1}$ ）。

0.000000 0.000000 0.000000
DETAILED LEADING EDGE LOADING

| | |
|----------|----------|
| 0.004894 | 0.837965 |
| 0.009789 | 0.577136 |
| 0.014683 | 0.454951 |
| 0.019578 | 0.377306 |

www.nature.com/scientificreports/

* CHORDWISE LOADING FOR ALL FUNDAMENTAL CAGES *
 SECTION 3 Y = 0.921032 CHORD = 0.170149
 WING I X8 CASE 1 CASE 2 CASE 3 CASE 4 CASE 5 CASE 6 CASE 7 CASE 8 CASE 9 CASE 10
 1 0.000000 0.583867 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 2 0.0244476 0.341116 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 3 0.0488944 0.149001 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 4 0.07333107 0.082431 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 5 0.0977678 0.055031 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 6 0.1222046 0.032083 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 7 0.1466414 0.019071 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 8 0.1710782 0.012083 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 9 0.19551508 0.008202 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000
 10 0.2299519 0.006220 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000 0.000000

0.00000 0.00000 0.00000
0.00000 0.00000 0.00000

| | | |
|---|----------|----------|
| 1 | 0.004894 | 0.860751 |
| 2 | 0.009789 | 0.596198 |
| 3 | 0.014683 | 0.473635 |
| 4 | 0.019578 | 0.396586 |
| 5 | 0.024472 | 0.361612 |

XX

| * CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES * | | | | | | | | | | | | |
|---|---|----------|----------|-------------------------------|----------|----------|----------|----------|----------|----------|----------|---------|
| WING | I | X8 | CASE 1 | SECTION 4 Y = 0.850012 | | | | | | | | CASE 10 |
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | CASE 6 | CASE 7 | CASE 8 | CASE 9 | |
| 31 | | 0.000000 | 0.582747 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | | 0.024474 | 0.344284 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | | 0.054549 | 0.156110 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 34 | | 0.026107 | 0.090613 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | | 0.024546 | 0.059662 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 36 | | 0.500000 | 0.043749 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | | 0.654508 | 0.031802 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 39 | | 0.793893 | 0.022199 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| | | 0.904508 | 0.014177 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | |
| 40 | | 0.975528 | 0.006920 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000060 | 0.000000 | 0.000000 | 0.000000 | |
| | | | | DETAILED LEADING EDGE LOADING | | | | | | | | |

DETAILED LEADING EDGE LOADING

0.009789 0.596803
 0.014683 0.475350
 0.019578 0.399422
 0.024472 0.344834

| WING | I | XB | CASE 1 | SECTION 5 Y = 0.758062 | | CHORD = 0.201057 | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
|---|-----------|-----------|----------|-------------------------|----------|------------------|----------|----------|----------|----------|----------|
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | | | | |
| 61 | 0.000000 | 0.571170 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 62 | 0.024472 | 0.329773 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 63 | 0.095492 | 0.156167 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 64 | 0.345492 | 0.091825 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 65 | 0.345492 | 0.060024 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 66 | 0.500000 | 0.024228 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 67 | 0.6556500 | 0.023507 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 68 | 0.792683 | 0.024227 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 69 | 0.9045008 | 0.015957 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 70 | 0.975528 | 0.007778 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | |
| 1 | 0.004894 | 0.843248 | | | | | | | | | |
| 2 | 0.009789 | 0.585663 | | | | | | | | | |
| 3 | 0.014683 | 0.456981 | | | | | | | | | |
| 4 | 0.019578 | 0.352920 | | | | | | | | | |
| 5 | 0.024472 | 0.339773 | | | | | | | | | |
| * CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES * | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 6 Y = 0.647446 | | CHORD = 0.222036 | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | | | | |
| 61 | 0.000000 | 0.552733 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 62 | 0.024472 | 0.329515 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 63 | 0.095492 | 0.152388 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 64 | 0.345492 | 0.090126 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 65 | 0.345492 | 0.0589818 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 66 | 0.500000 | 0.0395056 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 67 | 0.6556500 | 0.0329053 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 68 | 0.792683 | 0.024227 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 69 | 0.9045008 | 0.0161626 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 70 | 0.975528 | 0.007745 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | |
| 1 | 0.004894 | 0.816171 | | | | | | | | | |
| 2 | 0.009789 | 0.567062 | | | | | | | | | |
| 3 | 0.014683 | 0.452333 | | | | | | | | | |
| 4 | 0.019578 | 0.350882 | | | | | | | | | |
| 5 | 0.024472 | 0.329515 | | | | | | | | | |
| * CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES * | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 7 Y = 0.520888 | | CHORD = 0.246038 | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | | | | |
| 61 | 0.000000 | 0.528120 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 62 | 0.024472 | 0.315010 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 63 | 0.095492 | 0.145907 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 64 | 0.345492 | 0.086468 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 65 | 0.345492 | 0.056458 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 66 | 0.500000 | 0.041378 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 67 | 0.6556500 | 0.031972 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 68 | 0.792683 | 0.023680 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 69 | 0.9045008 | 0.0165679 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 70 | 0.975528 | 0.007727 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | |
| 1 | 0.004894 | 0.779860 | | | | | | | | | |
| 2 | 0.009789 | 0.541859 | | | | | | | | | |
| 3 | 0.014683 | 0.427291 | | | | | | | | | |
| 4 | 0.019578 | 0.343581 | | | | | | | | | |
| 5 | 0.024472 | 0.315010 | | | | | | | | | |
| * CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES * | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 8 Y = 0.381504 | | CHORD = 0.272473 | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | | | | |
| 71 | 0.000000 | 0.495891 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 72 | 0.024472 | 0.295618 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 73 | 0.095492 | 0.126084 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 74 | 0.345492 | 0.061112 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 75 | 0.345492 | 0.035925 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 76 | 0.500000 | 0.0294707 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 77 | 0.6556500 | 0.0207079 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 78 | 0.792683 | 0.016845 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 79 | 0.9045008 | 0.0151625 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 80 | 0.975528 | 0.007489 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | |
| 1 | 0.004894 | 0.732114 | | | | | | | | | |
| 2 | 0.009789 | 0.508657 | | | | | | | | | |
| 3 | 0.014683 | 0.405773 | | | | | | | | | |
| 4 | 0.019578 | 0.341625 | | | | | | | | | |
| 5 | 0.024472 | 0.295628 | | | | | | | | | |
| * CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES * | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 9 Y = 0.222726 | | CHORD = 0.300690 | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | | | | |
| 81 | 0.000000 | 0.448660 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 82 | 0.024472 | 0.267565 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 83 | 0.095492 | 0.124018 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 84 | 0.345492 | 0.074038 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 85 | 0.345492 | 0.046507 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 86 | 0.500000 | 0.0375752 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 87 | 0.6556500 | 0.0295645 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 88 | 0.792683 | 0.0221425 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 89 | 0.9045008 | 0.0147433 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 90 | 0.975528 | 0.007798 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| DETAILED LEADING EDGE LOADING | | | | | | | | | | | |
| 1 | 0.004894 | 0.662517 | | | | | | | | | |
| 2 | 0.009789 | 0.460320 | | | | | | | | | |
| 3 | 0.014683 | 0.367232 | | | | | | | | | |
| 4 | 0.019578 | 0.309196 | | | | | | | | | |
| 5 | 0.024472 | 0.267585 | | | | | | | | | |
| * CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES * | | | | | | | | | | | |
| WING | I | XB | CASE 1 | SECTION 10 Y = 0.078217 | | CHORD = 0.329993 | | CASE 7 | CASE 8 | CASE 9 | CASE 10 |
| | | | | CASE 2 | CASE 3 | CASE 4 | CASE 5 | | | | |
| 91 | 0.000000 | 0.348952 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 92 | 0.024472 | 0.210196 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 93 | 0.095492 | 0.106887 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 94 | 0.345492 | 0.064371 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |
| 95 | 0.345492 | 0.0467291 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 | 0.000000 |

PROGRAM JETFLAP LISTING

```
PROGRAM JETFLAP
*** VERSION 3.0 MODIFIED BY J.A. CAMPBELL (JUL88) ***
*** PROGRAM REVISED TO RUN UNDER FORTRAN 77 ON THE MICROVAX/2000 ***
FINAL UPDATES MADE 14 SEP 88 - (JAC)

SCRATCH FILES ADDED AND "FIND!" STATEMENTS HAVE BEEN COMMENTED OUT
DATA INPUT IS READ BY OBTAINING AN AVAILABLE LOGICAL UNIT NUMBER (LUN)
INSTEAD OF ASSIGNING A READ DEVICE AS IS DONE ON THE IBM SYSTEM

OUTPUT VALIDATED WITH HISTORICAL DATA - RESULTS OF DOUGLAS COMPANY,
SODERMAN THESIS AND THE AE-4501 CLASS PROJECT OF S.M. WHITE (MAY 85)

*** VERSION 2.0 UNDER REVISION J.A. CAMPBELL (FEB 88) ***
COMPILED USING "FORTVS JTFLAP(LVL(66))" ON IBM WITH NO ERRORS 5/20/88
UPDATED EQN FOR CMG(K) IN SUBR SLOAD (TAPE VERSION DIFFERENT) 5/31/88
OUTPUT VALIDATED WITH HISTORICAL DATA - RESULTS OF DOUGLAS CONTRACT &
SODERMAN (NPS THESIS)

***** EVD JET-WING COMPUTER PROGRAM *****

THE DEVELOPMENT OF THE ELEMENTARY VORTEX DISTRIBUTION (EVD) JET-WING
COMPUTER PROGRAM FOR DETERMINING THE AERODYNAMIC CHARACTERISTICS OF
ARBITRARY JET FLAPPED WINGS WAS PERFORMED BY THE DOUGLAS AIRCRAFT
COMPANY, V/STOL TECHNOLOGY GROUP - AERODYNAMICS, OF THE MCDONNELL
DOUGLAS CORPORATION. ORIGINALLY DEVELOPED UNDER THE SPONSORSHIP OF
THE INDEPENDENT RESEARCH AND DEVELOPMENT PROGRAM OF MCDONNELL
DOUGLAS, THE DOUGLAS EVD JET WING LIFTING SURFACE THEORY HAS BEEN
THE SUBJECT OF EXTENSIONS AND IMPROVEMENTS WHICH HAVE BEEN
ACCOMPLISHED UNDER OFFICE OF NAVAL RESEARCH CONTRACT N00014-71-C-0250
(T. L. WILSON - PROJECT ENGINEER). WORK LEADING TO THE PRESENT
COMPUTER PROGRAM, WHICH INCORPORATES SEVERAL FEATURES ORIGINALLY
DEVELOPED BY THE DOUGLAS AIRCRAFT COMPANY, WAS ALSO CONDUCTED
UNDER THE SPONSORSHIP OF THIS CONTRACT.

IN SUMMARY, THE EVD JET WING COMPUTER PROGRAM WILL PROVIDE,
FOR ARBITRARY PLANFORMS, THE FOLLOWING -
1. SPANWISE AND CHORDWISE LOADING
2. SPANWISE VARIATION OF INDUCED DRAG
3. A CAPABILITY TO INVESTIGATE THE EFFECTS OF -
   A. PART SPAN FLAPS
   B. PART SPAN BLOWING
   C. ROLLING, YAWING, PITCHING AND SIDESLIP
4. TOTAL LIFT AND INDUCED DRAG (TREFFTZ PLANE METHOD),
   PITCHING, YAWING AND ROLLING MOMENTS, ETC.

COMPLETE DOCUMENTATION OF THE EVD JET WING LIFTING SURFACE THEORY
AND ASSOCIATED COMPUTER PROGRAM ARE CONTAINED IN DOUGLAS REPORT
J5519 -- A THEORETICAL METHOD FOR CALCULATING THE
AERODYNAMIC CHARACTERISTICS OF ARBITRARY JET FLAP WINGS

VOLUME I
THE ELEMENTARY VORTEX DISTRIBUTION JET-WING
LIFTING SURFACE THEORY

VOLUME II
EVD JET-WING COMPUTER PROGRAM USERS MANUAL

INTEGER*4 LUN
INTEGER*2 INFILE_SIZE, IOFILE_SIZE
INTEGER STATUS,NANS
CHARACTER*20 INFILE,OUTFILE
LOGICAL EXIST
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/11ARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/LUKE/TITLE(20)
COMMON/JOHNZ/AREA,SPAN,ARATIO,TR_SWEEP,CREF,CMAC,CBAR,XMC,XCG
COMMON/SPIRIT/NEWMAX,NEWCMU,NOALFA,LOGIC,IR
COMMON/INDATA/ARE,SPA,CRE,XM,CMA,XC,NRO,NC,ISY,IPR,JET,IGT,IHI
COMMON/GEOM1/Y(40),CHCRD(40),DELTA(40),XB(600),XI(600),DEL(600),
1 D(40),KKI(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
COMMON/FCASE2/TST(40,10),HL(40,10),DJ(40),ACTE(40),AC(20,40),
1 XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)
COMMON/SOLV1/B(600,10)
COMMON/COMPOS/FACTR(10,24),NCC
COMMON/DERIV/U0(40),CLQ,CMQ,CMQMC
COMMON/INDAT/LUN
C      DATA CHECK/'4H9'/
C      DATA CHECK/'9'/
C      DEFINE FILE 1(1000,1200,U,NEXT)
C FOLLOWING LINES FOR SCRATCH FILES ADDED BY J.A. CAMPBELL (JUL88)
2 OPEN (UNIT=1,FILE='JTFLAP1.DAT',
2 ORGANIZATION='SEQUENTIAL',
```

```

2      ACCESS= 'DIRECT',
2      RECORDTYPE= 'FIXED',
2      FORM= 'UNFORMATTED',
2      RECL= 600,
2      ASSOCIATE VARIABLE= NEXT,
2      STATUS= 'SCRATCH')
C OPEN SCRATCH FILE FOR MATRIX INPUT TO SOLN ROUTINE
OPEN (UNIT=2,FILE='JTF LAP2.DAT',
2      ORGANIZATION= 'SEQUENTIAL',
2      ACCESS= 'SEQUENTIAL',
2      RECORDTYPE= 'VARIABLE',
2      FORM= 'UNFORMATTED',
2      STATUS= 'SCRATCH')
C OPEN SCRATCH FILE FOR TEMP STORAGE DURING MATRIX SOLN
OPEN (UNIT=3,FILE='JTF LAP3.DAT',
2      ORGANIZATION= 'SEQUENTIAL',
2      ACCESS= 'SEQUENTIAL',
2      RECORDTYPE= 'VARIABLE',
2      FORM= 'UNFORMATTED',
2      STATUS= 'SCRATCH')
C OPEN SCRATCH FILE FOR TEMP STORAGE DURING MATRIX SOLN
OPEN (UNIT=4,FILE='JTF LAP4.DAT',
2      ORGANIZATION= 'SEQUENTIAL',
2      ACCESS= 'SEQUENTIAL',
2      RECORDTYPE= 'VARIABLE',
2      FORM= 'UNFORMATTED',
2      STATUS= 'SCRATCH')
C CALL LIBRARY ROUTINE TO CLEAR THE SCREEN, THEN PRINT HEADER
ISTAT = LIB$ERASE_PAGE (1,1)
PRINT *
PRINT *, ' PROGRAM JETFLAP : VERSION 3 : 31 JULY 88 '
PRINT *
PRINT *, ' THE ELEMENTARY VORTEX DISTRIBUTION (EVD) JET-WING'
PRINT *, ' COMPUTER PROGRAM FOR DETERMINING THE AERODYNAMIC'
PRINT *, ' CHARACTERISTICS OF ARBITRARY JET FLAPPED WINGS'
PRINT *
PRINT *
C ROUTINE TO PROVIDE NAME FOR AND OPEN INPUT DATA FILE
5 STATUS = LIB$GET_INPUT (INFILE, | The input file
2      ' ENTER THE DATA FILE NAME: ', | Prompt
2      INFILE_SIZE), | Filename size
IF (.NOT. STATUS) CALL LIB$SIGNAL (%VAL (STATUS))
C CHECK TO SEE IF THE FILE EXISTS BEFORE TRYING TO ACCESS IT
IF (INFILE .EQ. '999') GO TO 110
INQUIRE (FILE = INFILE (1:INFILE_SIZE), EXIST = EXIST)
IF (.NOT. EXIST) THEN
    PRINT *
    PRINT *, ' THAT FILE NAME DOES NOT EXIST.'
    PRINT *, '(ENTER 999 TO EXIT).'
    PRINT *
    GO TO 5
END IF
C GET A FREE LOGICAL UNIT NUMBER
STATUS = LIB$GET_LUN (LUN)
IF (.NOT. STATUS) CALL LIB$SIGNAL (%VAL (STATUS))
C OPEN FILE FOR DATA FILE INPUT
OPEN (UNIT=LUN,
2      FILE= INFILE (1:INFILE_SIZE),
2      ORGANIZATION= 'SEQUENTIAL',
2      ACCESS= 'SEQUENTIAL',
2      RECORDTYPE= 'VARIABLE',
2      FORM= 'FORMATTED',
2      STATUS= 'OLD')
C SEND OUTPUT TO SCREEN OR FILE
CALL CLRSCRN
PRINT *
PRINT *, '==> SEND THE RESULTS TO THE SCREEN OR A FILE?'
6 PRINT *, ' ENTER (S OR F)'
READ (5,'(A1)') ANS
IF (ANS.EQ.'F') THEN
    PRINT *
7   PRINT *
    PRINT *, '(ENTER 999 TO EXIT.)'
    STATUS = LIB$GET_INPUT (OUTFILE,
2      ' ENTER NAME OF OUTPUT FILE TO CREATE: ', | The OUTPUT file
2      IOFILE_SIZE), | Prompt
2      IOFILE_SIZE), | Filename size
C CHECK TO SEE IF THE FILE EXISTS BEFORE CREATING IT
IF (OUTFILE .EQ. '999') GO TO 110
INQUIRE (FILE = OUTFILE (1:IOFILE_SIZE), EXIST = EXIST)
IF (.EXIST) THEN
    PRINT *
    PRINT *, ' THAT FILE ALREADY EXISTS.'
    WRITE (6,1005)
    PRINT *, '(OR ENTER 999 TO RETURN TO EXIT OPTION).'
    PRINT *
8   CALL QUERY (NANS)
    ELSE
        GO TO 9
    END IF
    IF (NANS .EQ. 1) THEN
        GO TO 9
    ELSE IF(NANS .EQ. 2)THEN
        GO TO 7
    ELSE IF(NANS .EQ. 999)THEN
        GO TO 110

```

```

      ELSE
        PRINT *, ' INVALID RESPONSE - REENTER.'
        GO TO 6
      END IF
C OPEN FILE FOR RESULTS FROM PROGRAM JETFLAP.
 9  PRINT *, ' PROCESSING BEGINS . . .
  PRINT *
  PRINT *, ' DATA BEING WRITTEN TO FILE ',OUTFILE
  PRINT *, ' FILE WILL HAVE SUFFIX .DAT'
  OPEN (UNIT=6,FILE=OUTFILE,STATUS='UNKNOWN')
ELSE IF (ANS.EQ.'S') THEN
  GO TO 10
ELSE
  PRINT *, ' INVALID RESPONSE - REENTER.'
  GO TO 6
END IF
PRINT *
1005 FORMAT (1X,' DO YOU WISH TO OVERWRITE THIS FILE? 1 = YES;2 = NO')
1010 FORMAT(A4)
C READ THE TITLE FOR THIS CASE
10 READ(LUN, 20, END=100 ) TITLE
20 FORMAT(10A4)
C
C READ GENERAL GEOMETRY CONTROL DATA
30 READ(LUN, 40 ) AREA,SPAN,CREF,XMC,XCG
40 FORMAT(5F10.6)
READ(LUN,41) NROWS,NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE,IDERIV
41 FORMAT(10I2)
  ARE = AREA
  SPA = SPAN
  CRE = CREF
  XM = XMC
  XC = XCG
  NRO = NROWS
  NC = NCASES
  ISY = ISYMM
  IPR = IPRINT
  JET = JETFLG
  IGT = IGTYPE
  IH1 = IHINGE
C
C FIND OUT WHICH TYPE OF RUN IS REQUIRED
IF(IDERIV.NE. 0) GO TO 60
C
C A REGULAR RUN WILL BE EXECUTED
50 CALL APPLY1
  GO TO ( 60 , 70 , 100 , 120 ), IR
C
C A STABILITY DERIVATIVE RUN WILL BE EXECUTED
60 CALL APPLY2
  IF(IR .EQ. 2) GO TO 120
C
C*****
C THIS RUN HAS BEEN COMPLETED. THANK GOD FOR SMALL BLESSINGS.
C*****
C
C PRINT COMPLETION MESSAGE FOR THIS RUN AND GO BACK TO BEGIN A NEW RUN
70 WRITE(6, 80 )
80 FORMAT(1H0/// 32X,10(5H****), 3H***/ 32X,
1  53H* THE PROGRAM HAS REACHED NORMAL TERMINATION */
2  32X,10(5H****), 3H***)
C READ TO SEE IF THE NEXT CARD IS A TITLE OR AN OLD END OF CMU CARD
READ(LUN, 20, END=100 ) TITLE
90 IF(TITLE(1) .EQ. CHECK) GO TO 10
  GO TO 30
C
C PRINT COMPLETION MESSAGE AND STOP EXECUTION
100 WRITE(6, 80 )
110 STOP
C
C*****
C A FATAL ERROR HAS OCCURED. PRINT FINAL MESSAGE AND STOP EXECUTION.
C*****
120 WRITE(6, 130 )
130 FORMAT(1H0///62X,2(4H****)/31X,11(5H****)/
1  31X,55H* THE PROGRAM HAS REACHED ABNORMAL TERMINATION */
2  31X,11(5H****)/62X,2(4H****))
140 STOP
END
C*****
SUBROUTINE CLRSCRN
C
C LIBRARY ROUTINE TO CLEAR THE SCREEN.
C
  ISTAT = LIB$ERASE_PAGE (1,1)
  RETURN
END
C*****
SUBROUTINE QUERY(NANS)
C
C ROUTINE TO TRAP ERRORS CAUSED BY IMPROPER RESPONSES TO QUESTIONS.
C THE COMPUTER GENERATES AND ERROR WHEN A CHARACTER IS SUPPLIED TO
C A QUESTION EXPECTING AN INTEGER OR REAL VALUE.
C
  NQTEST=0
1  CONTINUE
  IF (NQTEST .GT. 0) THEN
    PRINT *, ' CHARACTER VALUES ARE NOT VALID.'
    PRINT *, ' PLEASE ENTER AN INTEGER VALUE.'
  END IF
  NQTEST = NQTEST + 1

```

```

READ (5,*),ERR=1 INANS
RETURN
END
C*****SUBROUTINE APPLY1*****
C THIS SUBROUTINE CONTROLS ALL ASPECTS OF CALCULATION OF REGULAR CASES
C COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
C COMMON/SPIRIT/ NEWMAX,NEWMU,NOALFA,LOGIC,IR
C DECIDE WHETHER OR NOT THERE IS AN ALPHA CASE
  NOALFA = 1
  IR = 1
  LOGIC = 1
  IF(ISYMM .LT. 0) NOALFA = 0
C INITIALIZE AND INCREMENT THE CMU CASE CONTROL COUNTER
  10 NEWMU = 0
  20 NEWMU = NEWMU + 1
C EXECUTE THE PROBLEM FORMATION STAGE
  30 CALL STAGE1
    GO TO ( 40 , 60 , 70 , 80 ), IR
C EXECUTE THE PROBLEM SOLUTION STAGE
  40 CALL STAGE2
    IF(IR .EQ. 2) GO TO 80
C EXECUTE THE AERODYNAMIC PARAMETER STAGE
  50 CALL STAGE3
C THE PROGRAM HAS BEEN EXECUTED SUCESSFULLY
C GO BACK AND DO A NEW CMU CASE
  IF(JETFLG .NE. 0) GO TO 60
  GO TO 20
C*****THIS RUN HAS BEEN COMPLETED. RETURN TO START A NEW RUN.
C THIS RUN HAS BEEN COMPLETED. NO FURTHER RUNS FOLLOW.
  60 IR = 2
    RETURN
C THIS RUN HAS BEEN COMPLETED. NO FURTHER RUNS FOLLOW.
  70 IR = 3
    RETURN
C A FATAL ERROR HAS OCCURED. RETURN AND QUIT.
  80 IR = 4
    RETURN
C*****END SUBROUTINE APPLY2*****
C THIS SUBROUTINE CONTROLS ALL ASPECTS OF CALCULATION OF
C STABILITY DERIVATIVES
C COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
C COMMON/SPIRIT/ NEWMAX,NEWMU,NOALFA,LOGIC,IR
C CHECK ON STATUS OF CONTROL FLAGS
  10 IHINGE = 0
  NOALFA = 1
  NEWMU = 1
  IF(ISYMM1 .GE. 0) GO TO 30
  ISYMM1 = 0
  WRITE(6, 20 )
  20 FORMAT(1H0//16X,41HTHE ISYMM FLAG INDICATED AN ANTI-SYMETRIC,
  1      48H CASE. HOWEVER, IT WILL BE TREATED AS SYMETRIC.)
C EXECUTE THE FIRST RUN
C FORMULATE THE PROBLEM AS USUAL
  30 CALL STAGE1
    GO TO ( 40 , 110 , 100 , 110 ), IR
C ADD THE EXTRA FUNDAMENTAL CASE FOR DERIVATIVES DUE TO PITCHING
  40 LOGIC = 1
  CALL STAGE4
C EXECUTE THE PROBLEM SOLUTION STAGE AS USUAL FOR THE FIRST RUN
  LOGIC = 1
  50 CALL STAGE2
  IF(IR .EQ. 2) GO TO 110
C EXECUTE THE AERODYNAMIC STAGE FOR THE FIRST RUN
C FUNDAMENTAL CASES
  60 LOGIC = 2
  CALL STAGE3
C THE FIRST RUN HAS BEEN COMPLETED
C EXECUTE THE SECOND RUN
C
  WRITE(6, 70 )
  70 FORMAT(1H1////////// 37X,11(4H****),2H** /
  1      37X,46H* SECOND RUN FOR STABILITY DERIVATIVE CASE * /
  2      37X,11(4H****),2H**)
C IF THIS IS A SYMETRIC WING, SWITCH IT TO ANTI-SYMETRIC FOR RUN 2
  80 IF(ISYMM .EQ. 0) ISYMM = -1
C STORE THE FIRST RUN SOLUTION ON UNIT 1, DEFINE THE FUNDAMENTAL CASES
C FOR YAWING AND ROLLING RATES, AND PRINT THE NEW FUND CASE GEOMETRY.
  90 LOGIC = 2

```

```

C CALL STAGE4
C SET UP AND SOLVE THE MATRIX SYSTEM FOR THE SECOND RUN
C   LOGIC = 2
C   CALL STAGE2
C   IF(IR .EQ. 2) GO TO 110
C CALCULATE AND PRINT THE DERIVATIVES FOR ALL FUNDAMENTAL
C AND COMPOSITE CASES
C   LOGIC = 3
C   IF(IPRINT .GE. 0) IPRINT = 2
C   CALL STAGE3
C ****
C THIS IS THE END OF THE LINE
C 100 IR = 1
C   RETURN
C A FATAL ERROR HAS OCCURED. RETURN ABNORMALLY TO MAIN.
C 110 IR = 2
C   RETURN
C ****
C END SUBROUTINE STAGE1
C THIS SUBROUTINE READS THE GENERAL GEOMETRY PARAMETERS AND FLAGS, AND
C CONTROLS THE CALLING OF THE SPECIALIZED GEOMETRY SUBROUTINES
C COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
C COMMON/MARK/NROWSJ,NINT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
C COMMON/SPIRIT/ NEWMAX,NEWCMU,NOALFA,LOGIC,IR
C CHECK WHETHER THIS IS THE FIRST CMU CASE
C   IF(NEWCMU .GT. 1) GO TO 50
C   IF((NROWS :GT. 40) .OR. (NROWS .LT. 3)) GO TO 80
C SECTIONAL INPUT
C 10 IF(IGTYPE .EQ. 1).OR.(IGTYPE .EQ. 2)CALL SGMAIN(NOALFA,IR)
C   GO TO ( 20 , 40 , 100 ), IR
C USER INPUT
C PRINT ERROR MESSAGE BECAUSE IGTYPE HAS THE WRONG VALUE
C 20 WRITE(6, 30 ) IGTYPE
C 30 FORMAT(1H1//44X,32HTHE IGTYPE FLAG HAS THE VALUE OF,I2/
C 1           44X,37HONLY THE VALUES 1 OR 2 ARE ACCEPTABLE//,
C 2           44X,29HTHIS CASE HAS BEEN TERMINATED)
C   GO TO 100
C READ THE COMPOSITE CASE REQUIREMENTS
C 40 CALL INCOMP(NCASES,IR)
C   IF(IR .EQ. 2) GO TO 100
C READ THE CMU DATA
C 50 CALL BLOWIN(JETFLG,IR)
C   GO TO ( 60 , 110 , 120 ), IR
C 60 CALL BOXJ(NEWMAX,IR)
C   IF(IR .EQ. 2) GO TO 50
C RETURN NORMALLY TO THE CONTROL PROGRAM
C 70 IR = 1
C   GO TO 130
C PRINT ERROR MESSAGE BECAUSE THE NROWS VALUE IS UNACCEPTABLE
C 80 WRITE(6, 90 ) NROWS
C 90 FORMAT(1H1/55X,7HNROWS =,I3)
C ****
C A FATAL ERROR HAS OCCURED. RETURN ABNORMALLY TO MAIN.
C 100 IR = 4
C   GO TO 130
C THIS RUN HAS BEEN COMPLETED. THANK GOD FOR SMALL BLESSINGS.
C RETURN TO MAIN AND BEGIN A COMPLETELY NEW RUN
C 110 IR = 2
C   GO TO 130
C RETURN TO MAIN AND STOP THE EXECUTION
C 120 IR = 3
C 130 RETURN
C ****
C END SUBROUTINE SGMAIN(NOALFA,IR)
C THIS SUBROUTINE CONTROLS ALL GEOMETRY CALCULATIONS FOR THE
C SECTIONAL GEOMETRY METHOD
C COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
C READ THE WING PLANFORM GEOMETRY DATA
C 10 CALL INPTS(IR)
C   IF(IR .EQ. 2) GO TO 100
C   IF(IGTYPE .EQ. 1) CALL XLETR1(IR)
C   IF(IR .EQ. 2) GO TO 100
C   IF(IGTYPE .EQ. 2) CALL XLETR2
C NORMALIZE THE WING PLANFORM GEOMETRY DATA
C 20 CALL NORM1
C READ THE JET SHEET GEOMETRY DATA

```

```

30 CALL INPUTJ(IR)
   IF(IR .EQ. 2) GO TO 100
C CONSTRUCT THE EVD ELEMENTS
40 CALL BOXS(IR)
   IF(IR .EQ. 2) GO TO 100
C CONSTRUCT THE SET OF FUNDAMENTAL GEOMETRIC CASES
DO 90 N = 1,NCASES
LCASE = N
C READ THE GEOMETRY FOR THIS CASE
50 CALL INCASE(LCASE,NOALFA)
C CONSTRUCT THE CASE DATA
60 CALL BEECEE(LCASE,NOALFA,IR)
   IF(IR .EQ. 2) GO TO 100
C PRINT THE GEOMETRY AND CONSTRUCTED CASE DATA IF REQUIRED
   IF(LCASE .EQ. 1) WRITE(6, 70 )
70 FORMAT(1H1)
80 CALL OUTI(LCASE)
90 CONTINUE
   IR = 2
   RETURN
C AN ERROR HAS OCCURED.  RETURN ABNORMALLY TO STAGE1.
100 IR = 3
   RETURN
END
SUBROUTINE INPTS(IR)
C THIS SUBROUTINE READS THE WING GEOMETRY DATA
FOR THE SECTIONAL GEOMETRY METHOD
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/GEOM1/Y(40),CHORD(40),DELT(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
COMMON/SG1/XBW(20,10),XBJ(20,10),ICTYPE(40),IJTYPE(40),
1 NWTYPE,NJTYPE
COMMON/INDAT/LUN
DIMENSION NI(10)
C READ THE SECTIONAL PLANFORM DATA
10 NWTYPE = 0
READ(LUN, 20 ) (Y(K),K=1,NROWS)
20 FORMAT(1F10.6)
READ(LUN, 30 ) (ICTYPE(K),K=1,NROWS)
30 FORMAT(40I2)
DO 40 K = 1,NROWS
   IF(ICTYPE(K) .GT. NWTYPE) NWTYPE = ICTYPE(K)
40 CONTINUE
   IF(NWTYPE .GT. 10) GO TO 80
READ(LUN, 30 )(NI(N),N=1,NWTYPE)
C READ THE CHORDWISE DIVISION DATA FOR EACH ROW TYPE
DO 50 N = 1,NWTYPE
NIN = NI(N)
IF((NIN .LT. 1) .OR. (NIN .GT. 20)) GO TO 100
READ(LUN, 20 )(XBW(L,N),L=1,NIN)
50 CONTINUE
C DEFINE THE NUMBER OF CHORDWISE DIVISIONS FOR EACH ROW
DO 70 K = 1,NROWS
ICK = ICTYPE(K)
60 NW(K) = NI(ICK)
70 CONTINUE
   IR = 1
   RETURN
C AN ERROR HAS OCCURED.  PRINT A MESSAGE AND QUIT.
80 WRITE(6, 90 ) NWTYPE
90 FORMAT(1H1/45X,26HNUMBER OF WING ROW TYPES =,I3)
   IR = 2
   RETURN
100 WRITE(6, 110 ) NIN,N
110 FORMAT(1H1/38X,I3,38H WING ELEMENTS PRESCRIBED FOR ROW TYPE,I3)
   IR = 2
   RETURN
END
SUBROUTINE INPUTJ(IR)
C THIS SUBROUTINE READS THE JET GEOMETRY INPUT
FOR THE SECTIONAL GEOMETRY METHOD
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/SG1/XBW(20,10),XBJ(20,10),ICTYPE(40),IJTYPE(40),
1 NWTYPE,NJTYPE
COMMON/INDAT/LUN
DIMENSION NI(10)
C READ THE TYPE OF DIVISION FOR EACH ROW
10 NJTYPE = 0
NROWSJ = 0
IF(JETFLG .NE. 0) GO TO 90
READ(LUN, 20 )(IJTYPE(K),K=1,NROWS)
20 FORMAT(40I2)
DO 30 K = 1,NROWS

```

```

      IF(IJTYPE(K) .GT. NJTYPE) NJTYPE = IJTYPE(K)
      IF(IJTYPE(K) .NE. 0) NROWSJ = NROWSJ + 1
 30 CONTINUE
      IF(NJTYPE .GT. 10) GO TO 110
C READ THE NUMBER OF CHORDWISE DIVISIONS IN EACH ROW TYPE
      READ(LUN, 40 ) (NI(N),N=1,NJTYPE)
      40 FORMAT(10I2)
C READ THE CHORDWISE DIVISION DATA FOR EACH ROW TYPE
      DO 60 N = 1,NJTYPE
      NI(N) = NI(N)
      IF((NI(N) .LT. 1) .OR. (NI(N) .GT. 20)) GO TO 130
      READ(LUN, 50 ) (XB(L,N),L=1,N)
      50 FORMAT(18F10.6)
      60 CONTINUE
C DEFINE THE NUMBER OF CHORDWISE DIVISIONS FOR EACH ROW
      DO 80 K = 1,NROWS
      NJ(K) = 0
      IF(IJTYPE(K) .EQ. 0) GO TO 80
      IJK = IJTYPE(K)
      70 NJ(K) = NI(IJK)
      80 CONTINUE
C CHECK FOR ROW CONSISTENCY ON EITHER SIDE OF JET
      ICOUNT = 1
      IF(NJ(1) .EQ. 0) ITEST = 0
      IF(NJ(1) .GT. 0) ITEST = 1
      DO 150 K = 2,NROWS
      IF(NJ(K) .EQ. 0) ICOMP = 0
      IF(NJ(K) .GT. 0) ICOMP = 1
      IF(ICOMP .EQ. ITEST) GO TO 160
      IF(ICOUNT .LT. 3) GO TO 170
      ICOUNT = 1
      IF(NJ(K) .EQ. 0) ITEST = 0
      IF(NJ(K) .GT. 0) ITEST = 1
      GO TO 150
 160 ICOUNT = ICOUNT + 1
 150 CONTINUE
      IF(ICOUNT .LT. 3) GO TO 170
      IR = 1
      RETURN
C THERE IS NO JET FOR THIS RUN
 90 DO 100 K = 1,NROWS
      IJTYPE(K) = 0
      NJ(K) = 0
 100 CONTINUE
      IR = 1
      RETURN
C AN ERROR HAS OCCURED. PRINT A MESSAGE AND QUIT.
 110 WRITE(6, 120 ) NJTYPE
 120 FORMAT(1H1/25HNUMBER OF JET ROW TYPES =,I3)
      IR = 2
      RETURN
 130 WRITE(6, 140 ) NJTYPE
 140 FORMAT(1H1/38X,I3,37H JET ELEMENTS PRESCRIBED FOR ROW TYPE,I3)
      IR = 2
      RETURN
 170 WRITE(6, 190 )
 190 FORMAT(1H1,29H3 ROW CONTINUITY RULE FAILURE)
      IR = 2
      RETURN
      END
      SUBROUTINE XLETR1(IR)

C THIS SUBROUTINE READS THE LEADING AND TRAILING EDGE COORDINATES
C AT SPANWISE STATIONS CONNECTED BY STRAIGHT LEADING AND TRAILING EDGES
C AND INTERPOLATES TO GET THE COORDINATES AT INTERMEDIATE SECTIONS
C
      COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
      COMMON/GEOM1/Y(40),CHORD(40),DELT(40),XB(600),XI(600),DEL(600),
      1 D(40),KK(600),ITYPE(600)
      COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
      COMMON/INDAT/LUN
      DIMENSION YP(40),XLE(40),XTR(40)

C READ XLEAD AND XTRAIL
      NX = 0
      DO 30 N = 1,NROWS
      READ(LUN, 10 )YP(N),XLE(N),XTR(N)
      10 FORMAT(3F10.6)
      20 IF(YP(N) .GT. 1.1) GO TO 40
      NX = NX + 1
 30 CONTINUE
C CHECK WHETHER THE Y VALUES ARE REALISTIC
      40 IF(ABS(YP(1)-Y(1)) .GT. 0.0001)GO TO 110
      IF(ABS(YP(NX)-Y(NROWS)) .GT. 0.0001)GO TO 110
C READ THE EXTRA 9 CARD IF NROWS CARDS HAVE BEEN INPUT
      IF(NX .EQ. NROWS) READ(LUN, 10 ) EXTRA9
C INTERPOLATE FOR XLEAD AND XTRAIL AT THE INTERMEDIATE SECTIONS
      K = 0
      DO 100 N = 1,NX
 50 K = K + 1
      IF(K .GT. NROWS) GO TO 110
      IF(ABS(YP(N)-Y(K)) .GT. 0.0001)GO TO 70
C XLE AND XTR WERE INPUT FOR ROW K
      60 XLEAD(K) = XLE(N)
      XTRAIL(K) = XTR(N)

```

```

      GO TO 100
C   XLE AND XTR MUST BE INTERPOLATED FOR ROW K
70   NM11 = N - 1
80   YRATIO = (Y(K)-YP(N)) / (YP(NM11)-YP(N))
     XLEAD(K) = XLE(N) + YRATIO * (XLE(NM11)-XLE(N))
90   XTRAIL(K) = XTR(N) + YRATIO * (XTR(NM11)-XTR(N))
GO TO 50
100 CONTINUE
     IR = 1
     RETURN
C   AN ERROR HAS OCCURED. PRINT A MESSAGE AND RETURN.
110 WRITE(6,120)
120 FORMAT(1H1//20X,38HAN INCONSISTENCY HAS BEEN FOUND IN THE,
1        42H SECTIONAL LEADING AND TRAILING EDGE INPUT)
     IR = 2
     RETURN
END
SUBROUTINE XLETR2
C   THIS SUBROUTINE READS THE FUNDAMENTAL PLANFORM PARAMETERS FOR A
C   TRAPEZOIDAL WING, AND CALCULATES THE LEADING AND TRAILING EDGE
C   COORDINATES AT EACH Y STATION. NOTE THAT THE PLANFORM OUTLINE
C   MUST BE SYMETRIC.
C
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/JOHN/ AREA,SPAN,ARATIO,TR,SHEEP,CREF,CMAC,CBAR,XMC,XCG
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
1           D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
COMMON/INDAT/LUN
C   READ THE FUNDAMENTAL PLANFORM PARAMETERS
READ(LUN, 10) ARATIO,SHEEP,TR
10 FORMAT(4F10.6)
C   COMPUTE THE GENERAL PLANFORM CHARACTERISTICS
B2 = SPAN / 2.00
SW = SHEEP / 57.295779
20 CROOT = 2.0 * SPAN / ((1.0+TR)*ARATIO)
AREA = (1.0+TR) * CROOT * B2
XLB2 = 0.250 * (1.0-TR) * CROOT + B2 * TAN(SW)
30 CMAC = 2.0 * CROOT * (1.0 + TR + TR*TR) / (3.0*(1.0+TR))
IF(CREF.EQ. 0.0) CREF = CMAC
CBAR=AREA/SPAN
C   COMPUTE THE LEADING AND TRAILING EDGE COORDINATES
40 DO 60 K = 1,NROWS
     YBAR = Y(K)
     IF(YBAR .LT. 0.0) YBAR = -YBAR
     XLEAD(K) = XLB2 * YBAR
50 C = CROOT * (1.0-(1.0-TR)*YBAR)
     XTRAIL(K) = XLEAD(K) + C
60 CONTINUE
     RETURN
END
SUBROUTINE NORM1
C   THIS SUBROUTINE NORMALIZES ALL WING PLANFORM GEOMETRY BY SPAN/2
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/JOHN/ AREA,SPAN,ARATIO,TR,SHEEP,CREF,CMAC,CBAR,XMC,XCG
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
1           D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
10 B2 = SPAN / 2.00
AREA = AREA / B2**2
CREF = CREF / B2
20 XMC = XMC / B2
XCG = XCG / B2
DO 40 K = 1,NROWS
30 XLEAD(K) = XLEAD(K) / B2
     XTRAIL(K) = XTRAIL(K) / B2
40 CONTINUE
     SPAN = 2.00
     ARATIO = SPAN * SPAN / AREA
     RETURN
END
SUBROUTINE BOXSI(IR)
C   THIS SUBROUTINE CONSTRUCTS THE GEOMETRIC PARAMETERS FOR ALL THE
EVDE ELEMENTS ON THE WING AND JET
C
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/JOHN/ AREA,SPAN,ARATIO,TR,SHEEP,CREF,CMAC,CBAR,XMC,XCG
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
1           D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
COMMON/SG1/XBN(20,10),XBJ(20,10),ICTYPE(40),IJTYPE(40),
1           NWTYPE,NJTYPE
C   CONSTRUCT THE ELEMENTS ON THE WING
C   COMPUTE SECTIONAL DATA
10 CHORD(1) = XTRAIL(1) - XLEAD(1)
     DELTA(1) = 1.00 - Y(1)
     CMAC = CHORD(1)**2 * DELTA(1)
     DO 30 K = 2,NROWS
20   CHORD(K) = XTRAIL(K) - XLEAD(K)
     DELTA(K) = Y(K-1) - Y(K) - DELTA(K-1)

```

```

IF(DELTA(K) .LT. 0.0) GO TO 190
CMAC = CMAC + CHORD(K)**2 * DELTA(K)
C 30 CONTINUE
C CHECK THE VALIDITY OF THE SECTIONAL ALIGNMENT
YD = Y(NROWS) - DELTA(NROWS)
IF((ISYMM1 .GE. 0) .AND. (ABS(YD) .GT. 0.0001)) GO TO 190
IF((ISYMM1 .EQ. 1) .AND. (ABS(YD+1.0) .GT. 0.0001)) GO TO 190
DSUM = DELTA(I)
DO 35 K = 2,NROWS
YL = Y(K) + DELTA(K)
YR = Y(K-1) - DELTA(K-1)
IF(ABS(YR-YL) .GT. 0.0001) GO TO 190
DSUM = DSUM + DELTA(K)
35 CONTINUE
IF(ABS(DSUM-0.5) .GT. 0.0001) GO TO 190
CMAC = 2.0 * CMAC / AREA
IF(ISYMM1 .LT. 1) CMAC = 2.0 * CMAC
IF(CREF .LT. 0.0001) CREF = CMAC
CALL TANS(TANLE,XLEAD,Y,NROWS)
C COMPUTE ALL CHORDWISE ELEMENT PARAMETERS FOR EACH SECTION
I = 0
DO 90 K = I,NROWS
C COMPUTE X-COORDINATES
NWK = NW(K)
DO 50 L = I,NWK
I = I + 1
ICK = ICTYPE(K)
40 XB(I) = XBW(L,ICK)
50 CONTINUE
C COMPUTE_ALL OTHER PARAMETERS
I = I - NWK
IW(K) = I + I
DO 80 L = I,NWK
I = I + 1
60 KK(I) = K
DEL(I) = XB(I+I) - XB(I)
70 XI(I) = XLEAD(K) + XB(I) * CHORD(K)
ITYPE(I) = IO
80 CONTINUE
C REDEFINE THE LAST DEL IN THIS SECTION, AND DEFINE THE L.E. EVD TYPE
DEL(I) = 1.00 - XB(I)
IWK = IW(K)
ITYPE(IWK) = 20
90 CONTINUE
NWT = I
C CONSTRUCT THE ELEMENTS ON THE JET SHEET
C COMPUTE ALL CHORDWISE ELEMENT PARAMETERS FOR EACH SECTION
IF(JETFLG .NE. 0) GO TO 180
DO 170 K = 1,NROWS
C COMPUTE X-COORDINATES
IJ(K) = 0
100 NJK = NJ(K)
IF(NJK .EQ. 0) GO TO 170
DO 120 L = I,NJK
I = I + 1
IJK = IJTYPE(K)
110 XB(I) = XBJ(L,IJK)
120 CONTINUE
C COMPUTE ALL OTHER PARAMETERS
I = I - NJK
130 IJ(K) = I + I
DO 160 L = I,NJK
I = I + 1
140 KK(I) = K
DEL(I) = XB(I+I) - XB(I)
150 XI(I) = XLEAD(K) + XB(I) * CHORD(K)
ITYPE(I) = IO
160 CONTINUE
C REDEFINE THE LAST DEL AND EVD TYPE AND THE D VALUE FOR THIS SECTION
DEL(I) = 1.0EIO
ITYPE(I) = 30
D(K) = XI(I) - XTRAIL(K)
170 CONTINUE
180 NMAX = I
IF(NMAX .GT. 600) GO TO 210
NJT = NMAX - NWT
IR = I
RETURN
C AN ERROR HAS OCCURED. PRINT A MESSAGE AND QUIT.
190 WRITE(6,200)
200 FORMAT(1HI/38X,44H PLEASE CHECK YOUR SECTION LOCATION (Y) INPUT )
IR = 2
RETURN
210 WRITE(6, 220) NMAX
220 FORMAT(1HI/48X,I4,2IH IS TOO MANY ELEMENTS)
IR = 2
RETURN
END
SUBROUTINE BOXJ(NEWMAX,IR)
C THIS SUBROUTINE COMPUTES THE JET BLOWING FACTOR CMUP
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40),
COMMON/GEO1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)

```

```

COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)
C COMPUTE THE NEW CMUP AND SAVE THE OLD VALUES AS CMUPP
10 NMAX = NMAX
ICOUNT = 0
DO 30 K = 1,NROWS
CMUPP(K) = CMUP(K)
IF(NJIK).EQ. 0) GO TO 30
IF(CMU(K).LT. 0.0001) GO TO 20
CMUP(K) = 2.00 / (CHORD(K)*CMU(K))
GO TO 30
20 ICOUNT = ICOUNT + 1
CMUP(K) = 0.00
30 CONTINUE
WRITE(6, 40 ) (K,CMU(K),K=1,NROWS)
40 FORMAT(1H1,40X,10(4H****)/ 41X,
1      40H* SECTIONAL JET BLOWING COEFFICIENTS * /41X,10(4H****)//
2      53X,3HROW,5X,3HCMU,40(/53X,I2,F12.6))
IF(ICOUNT .EQ. 0) GO TO 50
IF(ICOUNT .LT. NROWSJ) GO TO 60
NEWMAX = NWT
50 IR = 1
RETURN
C AN ERROR HAS OCCURED. PRINT A MESSAGE AND TRY AGAIN.
60 WRITE(6,70 )
70 FORMAT(1H0,43X,35HA ZERO VALUE OF CMU HAS BEEN INPUT.,
1      33H THIS CMU CASE HAS BEEN IGNORED.)
IR = 2
RETURN
END
SUBROUTINE TANS(TAN,X,Y,NROWS)
C THIS SUBROUTINE COMPUTES THE TANGENT OF THE LEADING OR TRAILING EDGE
C SWEEP ANGLE AT THE CENTERLINE OF EACH SECTION. IT IS ACCURATE FOR
C SECTIONS WITH STRAIGHT EDGES IN GROUPS OF THREE OR MORE.
C IT IS ONLY APPROXIMATE FOR CURVED EDGES.
C IT MAY RESULT IN ERRORS FOR SECTIONS ADJACENT TO WING BREAKS,
C IF STRAIGHT EDGES ARE IN ADJACENT GROUPS OF ONLY ONE OR TWO.
C
DIMENSION TAN(40),X(40),Y(40),S(40)
SLOP(XR,XL,YR,YL) = (XR-XL) / (YR-YL)
C
DO 50 K = 1,NROWS
KR = K-1
KL = K
IF(K .GT. 1) GO TO 30
KR = 1
KL = 2
30 SIKJ = SLOP(X(KR),X(KL),Y(KR),Y(KL))
50 CONTINUE
DO 200 K = 1,NROWS
IF(K .LT. 3) GO TO 150
IF(K .EQ. NROWS) GO TO 150
IF(K .EQ. (NROWS-1)) GO TO 160
C CHECK WHETHER THE RIGHT OR LEFT SIDES ARE STRAIGHT
IF(ABS(S(K) - S(K-1)).LT. 0.001) GO TO 150
IF(ABS(S(K+1) - S(K+2)).LT. 0.001) GO TO 160
C NEITHER SIDE IS CONCLUSIVELY STRAIGHT - CHECK FURTHER LEFT AND RIGHT
IF(K .EQ. 3) GO TO 160
IF(K .EQ. (NROWS-2)) GO TO 150
IF(ABS(S(K-1) - S(K-2)).LT. 0.001) GO TO 160
IF(ABS(S(K+2) - S(K+3)).LT. 0.001) GO TO 150
C THE TRUE SHAPE CANNOT BE DETERMINED - GIVE UP AND TAKE THE AVERAGE
TANIK = (S(K) + S(K+1)) / 2.00
GO TO 200
C THE RIGHT EDGE IS STRAIGHT
150 TANIK = S(K)
GO TO 200
C THE LEFT EDGE IS STRAIGHT
160 TANIK = S(K+1)
200 CONTINUE
RETURN
END
SUBROUTINE INCASE(LCASE,NOALFA)
C THIS SUBROUTINE READS THE FUNDAMENTAL GEOMETRIC CASE DATA
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/FCASE1/INPUTT,INPUTH,INPUTD,INPUTC,INPUTB
COMMON/FCASE2/TST(40,10),HL(40,10),DJ(40),ACTE(40),AC(20,40),
1 XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
COMMON/INDAT/LUN
DIMENSION NI(10),DUMMY(40)
C INITIALIZE SECTIONAL DATA
DO 30 K = 1,NROWS
10 TST(K,LCASE) = 0.00
HL(K,LCASE) = 0.00
DJ(K) = 0.00
ACTE(K) = 0.00
ICT(K) = 0
IHT(K) = 0
C INITIALIZE THE CAMBER ANGLES
NWK = NW(K)
DO 20 L = 1,NWK
AC(L,K) = 0.00
20 CONTINUE
30 CONTINUE
C INITIALIZE THE HINGE DATA
DO 50 N = 1,NROWS

```

```

DO 40 L = 1,4
XHB(L,N) = 0.00
BET(L,N) = 0.00
40 CONTINUE
50 CONTINUE
C     IF((LCASE .EQ. 1) .AND. (NOALFA .GT. 0)) RETURN
C     READ FUNDAMENTAL CASE CONTROL FLAGS
READ(LUN, 60 ) INPUTT,INPUTH,INPUTD,INPUTC,INPUTB
60 FORMAT(5I2)
C     READ SECTIONAL TWIST, HEIGHT AND JET DEFLECTION DATA
IF(INPUTT .NE. 0) READ(LUN, 70 ) (TST(K,LCASE),K=1,NROWS )
70 FORMAT(18F10.6)
IF(INPUTH .NE. 0) READ(LUN, 70 ) (HL(K,LCASE),K=1,NROWS )
IF(INPUTD .EQ. 0) GO TO 90
READ(LUN, 70 ) (DUMMY(K),K=1,NROWSJ)
C     DISTRIBUTE THE DUMMY VALUES PROPERLY IN THE DJ ARRAY
KP = 0
DO 80 K = 1,NROWS
IF(NJ(K) .EQ. 0) GO TO 80
KP = KP + 1
DJ(K) = DUMMY(KP)
80 CONTINUE
C     READ THE CAMBER ANGLES, IN DEGREES
90 IF(INPUTC .EQ. 0) GO TO 160
READ(LUN, 100 ) (ICT(K),K=1,NROWS )
100 FORMAT(40I2)
NCT = 0
DO 110 K = 1,NROWS
IF(ICT(K) .EQ. 0) GO TO 110
IF(ICT(K) .GT. NCT) NCT = ICT(K)
ICK = ICT(K)
NI(ICK) = NIN(K)
110 CONTINUE
DO 130 N = 1,NCT
NIN = NI(N)
120 READ(LUN, 70 ) (AC(L,N),L=1,NIN)
130 CONTINUE
140 IF(NROWSJ .GT. 0) READ(LUN, 70 ) (DUMMY(K),K=1,NROWSJ)
C     DISTRIBUTE THE DUMMY VALUES PROPERLY IN THE ACTE ARRAY
KP = 0
DO 150 K = 1,NROWS
IF(NJ(K) .EQ. 0) GO TO 150
KP = KP + 1
ACTE(K) = DUMMY(KP)
150 CONTINUE
C     READ THE HINGE LOCATION, TYPE AND TURNING ANGLE DATA
160 IF(INPUTB .EQ. 0) GO TO 210
170 READ(LUN, 100 ) (IHT(K),K=1,NROWS )
NHT = 0
DO 180 K = 1,NROWS
IF(IHT(K) .GT. NHT) NHT = IHT(K)
180 CONTINUE
DO 200 N = 1,NHT
READ(LUN, 190 ) (XHB(L,N),IFS(L,N),BET(L,N),L=1,4)
190 FORMAT(4(F10.6,I1,F9.6))
200 CONTINUE
210 RETURN
END
SUBROUTINE BEECEE(LCASE,NOALFA,IR)

C THIS SUBROUTINE CONSTRUCTS THE BOUNDARY CONDITION ARRAYS FOR THE
CCC FUNDAMENTAL GEOMETRIC CASES
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NH(40),NJ(40),IW(40),IJ(40)
COMMON/GEO1/Y(40),CHORD(40),DELTAL(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
COMMON/FCASE1/INPUTT,INPUTH,INPUTD,INPUTC,INPUTB
COMMON/FCASE2/TST(40,10),HL(40,10),DJ(40),ACTE(40),AC(20,40),
1 XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
DIMENSION NH(40)

C INITIALIZE THE BOUNDARY CONDITION ANGLES
DO 20 I = 1,NMAX
10 EPS(I,LCASE) = 0.00
BETA(I,LCASE) = 0.00
20 CONTINUE
DO 30 K = 1,NROWS
THETA(K,LCASE) = 0.00
THS(K,LCASE) = 0.00
30 CONTINUE
C DEFINE THE ANGLES FOR THE ANGLE-OF-ATTACK FUNDAMENTAL CASE
IF((LCASE .GT. 1) ,OR. (NOALFA .EQ. 0)) GO TO 60
DO 40 I = 1,NWT
EPS(I,1) = 1.00
40 CONTINUE
DO 50 K = 1,NROWS
IF(NJ(K) .GT. 0) THETA(K,1) = 1.000
50 CONTINUE
IR = 1
RETURN
C DEFINE THE ANGLES FOR ALL REMAINING FUNDAMENTAL CASES
C CAMBER CONTRIBUTION

```

```

60 IF(INPUTC .EQ. 0) GO TO 110
I = 0
DO 100 K = 1,NROWS
IF(NJ(K) .EQ. 0) GO TO 70
THETA(K,LCASE) = ACTE(K)
70 NWK = NH(K)
IFI(ICT(K) .EQ. 0) GO TO 90
DO 80 L = 1,NWK
I = I + 1
ICK = ICT(K)
EPSI(LCASE) = AC(L,ICK)
80 CONTINUE
GO TO 100
90 I = I + NWK
100 CONTINUE
C TWIST CONTRIBUTION
110 IF(INPUTT .EQ. 0) GO TO 160
I = 0
DO 150 K = 1,NROWS
IF(NJ(K) .EQ. 0) GO TO 120
THETA(K,LCASE) = THETA(K,LCASE) + TST(K,LCASE)
120 NWK = NH(K)
DO 140 L = 1,NWK
I = I + 1
130 EPSI(LCASE) = EPS(I,LCASE) + TST(K,LCASE)
140 CONTINUE
150 CONTINUE
C FLAP AND SLAT DEFLECTION CONTRIBUTION
160 IF(INPUTB .EQ. 0) GO TO 320
C SUM UP THE TOTAL SLAT ANGLE AND FIND THE NUMBER OF HINGES ON EACH ROW
DO 190 K = 1,NROWS
NH(K) = 0
IFI(IHT(K) .EQ. 0) GO TO 190
DO 180 L = 1,4
170 N = IHT(K)
IF(XHB(L,N) .LT. 0.001) GO TO 180
NH(K) = NH(K) + 1
IF(IFSL(N) .GT. 0) THS(K,LCASE) = THS(K,LCASE) + BET(L,N)
180 CONTINUE
190 CONTINUE
C COMPUTE INCIDENCE OF EACH ELEMENT AND FIND TURNING ANGLE AND EVD TYPE
C FOR EACH HINGE ELEMENT
I = 0
DO 310 K = 1,NROWS
NWK = NH(K)
N = IHT(K)
200 IF(N .EQ. 0) GO TO 300
LSTART = 1
B = 0.0
NHK = NH(K)
210 IF(NHK .EQ. 0) GO TO 360
C CYCLE THE HINGE POINTS IN CHORDWISE ORDER
DO 270 LH = 1,NHK
C CYCLE THE VORTEX POINTS IN CHORDWISE ORDER, LOOKING FOR NEXT HINGE
DO 250 L = LSTART,NWK
I = I + 1
C CHECK ON RELATIVE LOCATION OF VORTEX POINT AND HINGE POINT
220 XDIFF = XHB(LH,N) - XB(I)
IF(ABS(XDIFF) .LT. 0.001) GO TO 230
IF(XDIFF .GT. 0.001) GO TO 240
IF(XDIFF .LT. -0.001) GO TO 360
C THE ITH VORTEX POINT IS A HINGE POINT
230 B = B + BET(LH,N)
BETA(I,LCASE) = BET(LH,N)
EPSI(LCASE) = EPS(I,LCASE) - THS(K,LCASE) + B
ITYPE(I) = 42
IFI(FS(LH,N) .GT. 0) ITYPE(I) = 41
GO TO 260
C THE ITH VORTEX POINT IS NOT A HINGE POINT
240 EPSI(LCASE) = EPS(I,LCASE) - THS(K,LCASE) + B
250 CONTINUE
260 LSTART = I - NWK + 1
270 CONTINUE
C DEFINE THE INCIDENCE ANGLE FOR REMAINING POINTS BEHIND THE LAST HINGE
IFI(LSTART .EQ. NWK) GO TO 290
LSTART = LSTART + 1
DO 280 L = LSTART,NWK
I = I + 1
EPSI(LCASE) = EPS(I,LCASE) - THS(K,LCASE) + B
280 CONTINUE
C COMPUTE THE EFFECT OF THE HINGES ON THE JET ANGLE
290 IF(NJ(K) .GT. 0) THETA(K,LCASE) = THETA(K,LCASE) - THS(K,LCASE) + B
GO TO 310
300 I = I + NWK
310 CONTINUE
C JET DEFLECTION CONTRIBUTION
320 IF(INPUTD .EQ. 0) GO TO 350
DO 340 K = 1,NROWS
IFI(NJ(K) .EQ. 0) GO TO 340
I = IJ(K)
330 BETA(I,LCASE) = DJ(K)
IFI(ABS(DJ(K)) .GT. 0.0001) ITYPE(I) = 43
THETA(K,LCASE) = THETA(K,LCASE) + DJ(K)
340 CONTINUE

```

```

350 IR = 1
      RETURN
C AN ERROR HAS OCCURED. PRINT A MESSAGE AND QUIT.
C
360 WRITE(6, 370 ) LCASE,K,N
370 FORMAT(1H1//45X,26HFUNDAMENTAL GEOMETRIC CASE,I3/
1          18X,50HAN INCONSISTENCY HAS BEEN FOUND IN THE HINGE INPUT,
2          18H DATA FOR WING ROW,I3,10H, ROW TYPE,I3)
      IR = 2
      RETURN
      END
      SUBROUTINE OUT1(LCASE)
C THIS SUBROUTINE PRINTS OUT THE GEOMETRIC DATA DERIVED FROM THE
C SECTIONAL METHOD INPUT
C
      COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
      COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IJ(40)
      COMMON/LUKE/TITLE(20)
      COMMON/JOHN/AREA,SPAN,ARATIO,TR,SHEEP,CREF,CMAC,CBAR,XMC,XCG
      COMMON/GEOM1/Y(40),CHORD(40),DELT(40),XB(600),XI(600),DEL(600),
1           D(40),KK(600),ITYPE(600)
      COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
      COMMON/FCASE2/TST(40,10),HL(40,10),DJ(40),ACT(40),AC(20,40),
1           XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
      COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
      COMMON/INDATA/ARE,SPA,CREF,CRE,XMC,XCG,NR0,NC,ISY,IPR,JET,IGT,IHI
C
C PRINT CASE TITLE AND GENERAL GEOMETRIC PARAMETERS
      IF(LCASE .GT. 1) GO TO 60
10   WRITE(6, 20 ) TITLE
20   FORMAT(1H1,39X,10I4H****)/
1     40X,40H* EVD JET - WING COMPUTER PROGRAM */
2     40X,10(4H****)//20X,20A4)
      CMA = CMAC * SPA / 2.0
30   WRITE(6, 40 ) AREA,ARE,SPAN,SPA,CREF,CRE,XMC,XM,CMAC,CMA,ARATIO,
1           ARATIO,XCG,XC
40   FORMAT(1HO//54X,4HUSED,11X,5HINPUT /
1     41X,6HREA =,2F15.6 / 41X,6HSPAN =,2F15.6 /
1     41X,6HCREF =,2F15.6 / 42X,6HXMC =,2F15.6 /
1     41X,6HCMAC =,2F15.6 / 39X,6HARATIO =,2F15.6 /
42X,5HXCG =,2F15.6 )
      WRITE(6, 50 ) NROWS,NRO,NCASES,NC,ISYMM,IPRINT,IPR,JETFLG,JET,
1           IGTYPE,IGT,IHINGE,IHI,NWT,NJT,NMAX
50   FORMAT(1HO//48X,7HROWS =,I3,7X,I3 / 47X,8HNCASES =,I3,7X,I3 /
1     48X,7HSYMM =,I3,7X,I3 / 47X,8HPRINT =,I3,7X,I3 /
1     48X,8HJETFLG =,I3,7X,I3 / 47X,8HIGTYPE =,I3,7X,I3 /
1     47X,8HHINGE =,I3,7X,I3 // 43X,25HNUMBER OF WING ELEMENTS =,I4 /
5     43X,25HNUMBER OF JET ELEMENTS =,I4 /
5     42X,26HTOTAL NUMBER OF ELEMENTS =,I4)
60   J = 0
      JJ = NWT
C
C PRINT FUNDAMENTAL CASE HEADER
      WRITE(6, 70 ) LCASE
70   FORMAT(1H1,23X,1H*,19(4H****)/
1     24X,54H* ELEMENT GEOMETRY DATA AND FUNDAMENTAL CASE DATA FOR,
2     17H FUNDAMENTAL CASE,I3,3H */24X,1H*,19(4H****))
      ILINES = 3
      DO 260 K = 1,NROWS
C
C PRINT SECTIONAL DATA
      WRITE(6, 80 ) K,Y(K),DELT(K),XLEAD(K),XTRAIL(K),CHORD(K),TANLE(K)
80   FORMAT(1HO,11H*** SECTION,I3,4H ***,2X,3HY =,F10.6,2X,7HDELT =
1     F10.6,2X,7HXLEAD =,F10.6,2X,8HXTRAIL =,F10.6,2X,7HCHORD =,F10.6,
2     2X,7HTANLE -,F10.6)
C
C PRINT CHORDWISE DATA ON WING
      NWK = NJ(K)
      WRITE(6, 90 ) NWK,TST(K,LCASE),HL(K,LCASE),THS(K,LCASE)
90   FORMAT(1HO,21HWING ELEMENTS NW =,I3,5X,7HTWIST =,F10.6,5X,
1           4HHL =,F10.6,5X,9HTHETA S =,F10.6)
      WRITE(6, 100 ) (XB(J+L),L=1,NWK)
100  FORMAT(1H,14X,2HXB,10F11.6 / 17X,10F11.6)
      IF(LCASE .GT. 1) GO TO 130
      WRITE(6, 110 ) (XI(J+L),L=1,NWK)
110  FORMAT(1H,14X,2HXI,10F11.6/17X,10F11.6)
      WRITE(6, 120 ) (DEI(J+L),L=1,NWK)
120  FORMAT(1H,13X,3HDEI,10F11.6/17X,10F11.6)
130  IF(ICTC .EQ. 0) GO TO 150
      ICK = ICT(K)
      WRITE(6, 140 ) (AC(L,ICK),L=1,NWK)
140  FORMAT(1H,10X,6HCAMBER,10F11.6/17X,10F11.6)
150  WRITE(6, 160 ) (EPS(J+L,LCASE),L=1,NWK)
160  FORMAT(1H,13X,3HEPS,10F11.6/17X,10F11.6)
      WRITE(6, 170 ) (BETA(J+L,LCASE),L=1,NWK)
170  FORMAT(1H,12X,4HBETA,10F11.6/17X,10F11.6)
      WRITE(6, 180 ) (ITYPE(J+L),L=1,NWK)
180  FORMAT(1H,12X,4HTYPE,10(3X,I2,6X)/17X,10(3X,I2,6X))
      J = J + NWK
      IL = 1
      IF(NWK .GT. 9) IL = 2
      ILINES = ILINES + 4 + 4*IL
      IF(LCASE .EQ. 1) ILINES = ILINES + 2*IL
C
C PRINT CHORDWISE DATA ON JET
      NJK = NJ(K)
      IF(NJK .GT. 0) GO TO 200
      WRITE(6, 190 )

```

```

190 FORMAT(1H,8X,19HTHIS ROW HAS NO JET)
ILINES = ILINES + 1
GO TO 230
200 WRITE(6, 210) NJK,D(K),DJ(K),ACTE(K),THETA(K,LCASE)
210 FORMAT(1HO,1X,20HJET ELEMENTS NJ =,I3,5X,3HD =,F10.6,5X,4HDJ =,
1 F10.6,5X,6HACTE =,F10.6,5X,7HTHETA =,F10.6)
WRITE(6, 100) (XB(JJ+L),L=1,NJK)
IF(LCASE .GT. 1) GO TO 220
WRITE(6, 110) (XI(JJ+L),L=1,NJK)
WRITE(6, 120) (DEL(JJ+L),L=1,NJK)
220 WRITE(6, 170) (BETA(JJ+L),LCASE),L=1,NJK)
WRITE(6, 180) (ITYPE(JJ+L),L=1,NJK)
JJ = JJ + NJK
IL = 1
IF(NJK .EQ. 10) IL = 2
ILINES = ILINES + 1 + 3 * IL
IF(LCASE .EQ. 1) ILINES = ILINES + 2 * IL
230 IF(K .EQ. NROWS) GO TO 260
NWK1 = NW(K+1)
IL = 1
IF(NWK1 .GT. 9) IL = 2
NEXT = 4 + 4 * IL
IF(LCASE .EQ. 1) NEXT = NEXT + 2 * IL
NJK1 = NJ(K+1)
IL = 1
IF(NJK1 .EQ. 10) IL = 2
NEXT = NEXT + 1
IF(NJK1 .EQ. 0) GO TO 240
NEXT = NEXT + 1 + 3 * IL
IF(LCASE .EQ. 1) NEXT = NEXT + 2 * IL
240 IF((55-ILINES) .GE. NEXT) GO TO 260
WRITE(6, 250)
250 FORMAT(1H1)
ILINES = 1
260 CONTINUE
RETURN
END
SUBROUTINE INCOMP(NCASES,IR)

```

```

C THIS SUBROUTINE READS IN THE COMPOSITE CASE REQUIREMENTS
C WHICH DEFINE THE FUNDAMENTAL CASES AND THEIR DEFLECTION MAGNITUDE
C FOR SUPERPOSITION IN UP TO 24 COMBINATIONS
C
C COMMON/COMPOS/FACTOR(10,24),NCC
C COMMON/INDAT/LUN
C DIMENSION FUNNY(10),ND(10)
C
C INITIALIZE THE ARRAY OF FUNDAMENTAL CASE DEFLECTIONS
DO 20 M = 1,24
DO 10 N = 1,10
FACTOR(N,M) = 0.00
10 CONTINUE
20 CONTINUE
C
C READ THE COMPOSITE CASE DATA, CONSISTING OF FUNDAMENTAL CASE
C DEFLECTIONS, IN DEGREES
NCC = 0
30 NCC = NCC + 1
READ(LUN, 40, END=130) (ND(N),FUNNY(N),N=1,10)
40 FORMAT(10(BZ,I2,F6.4))
C
C CHECK THE VALIDITY OF THE DATA
50 IF(ND(1) .GT. 10) GO TO 100
IF(NCC .GT. 24) GO TO 110
DO 90 N = 1,10
IF(ND(N) .LT. 1) GO TO 70
IF(ND(N) .GT. NCASES) GO TO 70
IF(ND(N) .LT. 1) GO TO 90
C
C THE DATA IS OK. DEFINE FACTOR.
NDN = ND(N)
60 FACTOR(NDN,NCC) = FUNNY(N)
GO TO 90
70 WRITE(6, 80)
80 FORMAT(1H0,22X,76HAN INCORRECT COMPOSITE CASE INPUT VALUE HAS BEEN
1 FOUND. IT WILL BE IGNORED.)
90 CONTINUE
GO TO 30
C
C THE END OF THE INPUT DATA HAS BEEN REACHED
100 NCC = NCC - 1
IF(NCC .GT. 24) NCC = 24
IR = 1
RETURN
C
C TOO MANY COMPOSITE CASES HAVE BEEN REQUESTED. READ ON UNTIL AN END
C CARD IS FOUND.
110 WRITE(6, 120)
120 FORMAT(1HO,20X,47HMORE THAN 24 COMPOSITE CASES HAVE BEEN INPUT. ,
1 34HSUBSEQUENT INPUTS WILL BE IGNORED.)
GO TO 30
C
C AN END OF FILE HAS BEEN READ. PRINT A MESSAGE AND QUIT.
130 WRITE(6, 140)
140 FORMAT(1H1// 31X, 35HAN END OF FILE HAS BEEN READ DURING,
1 21H COMPOSITE CASE INPUT)
IR = 2
RETURN
END
SUBROUTINE BLOWIN(JETFLG,IR)
C
C THIS SUBROUTINE READS THE SECTIONAL JET BLOWING RATES
CMU(K) = J / (Q * CHORD(K))
C
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)

```

```

      DIMENSION DCMU(40)
      COMMON/INDAT/LUN
C      IF(JETFLG .NE. 0) GO TO 30
C      READ THE CMU DATA ONLY FOR THOSE SECTIONS WHICH HAVE A JET
      READ(LUN, 10, END=60) (DCMU(K),K=1,NROWSJ)
  10  FORMAT(18F10.6)
  20  IF(DCMU(1) .LT. 800.0) GO TO 30
      IR = 2
      RETURN
C      REARRANGE THE DATA INTO THE PROPER SEQUENCE
  30  KP = 0
      DO 50 K = 1,NROWS
  40  CMU(K) = 0.00
      IF(NJK(K) .EQ. 0) GO TO 50
      KP = KP + 1
      CMU(K) = DCMU(KP)
  50  CONTINUE
      IR = 1
      RETURN
C      AN END OF FILE HAS BEEN READ. THIS RUN IS COMPLETELY FINISHED.
  60  WRITE(6,70)
  70  FORMAT(1H1//41X,37HNO MORE CMU CASES HAVE BEEN REQUESTED)
      IR = 3
      RETURN
      END
      SUBROUTINE STAGE2
C      THIS PROGRAM CONTROLS THE FORMATION AND SOLUTION OF
C      THE SYSTEM OF LINEAR EQUATIONS
C      COMMON/SPIRIT/ NEWMAX,NEWCMU,NOALFA,LOGIC,IR
C      FORM THE SYSTEM OF LINEAR EQUATIONS
  10  CALL STG2D
C      SOLVE THE SYSTEM OF LINEAR EQUATIONS
  20  CALL STG2S
      IF(IR .EQ. 2) GO TO 30
C      THE SOLUTION HAS NOW BEEN COMPLETED. RETURN NORMALLY TO MAIN.
C      *** HALLELUIAH ***
      IR = 1
      GO TO 40
C*****
C      A FATAL ERROR HAS OCCURED. RETURN ABNORMALLY TO MAIN.
  30  IR = 2
  40  RETURN
C*****
C      END
      SUBROUTINE STG2D
C      THIS PROGRAM CONTROLS THE CALCULATION OF ALL EVD DOWNWASH
C      INFLUENCE COEFFICIENTS AND THE FORMATION OF THE LEFT AND RIGHT SIDE
C      MATRICES.
C      COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
C      COMMON/MARK/NRONS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
C      COMMON/SPIRIT/ NEWMAX,NEWCMU,NOALFA,LOGIC,IR
      DIMENSION W(610)
C      IF THIS IS A NEW CMU CASE, AUGMENT THE EXISTING DOWNWASH MATRIX ROWS
C      ON THE JET
      ISIZE = NEWMAX
      IF(NENCMU .EQ. 1) GO TO 10
      IF(NENMAX .GT. NNT) CALL SHUFL2(W,ISIZE,NEWMAX)
      GO TO 30
C      CALCULATE THE DOWNWASH INFLUENCE COEFFICIENTS AT ALL CONTROL POINTS
C      DUE TO ALL TRIANGULAR, LEADING EDGE AND FAR-JET EVD ELEMENTS
  10  ISIZE = NMAX
      IF((LOGIC .EQ. 2) .AND. (ISYMM .GT. 0)) GO TO 30
      CALL DRNKSH(W,ISIZE)
C      AUGMENT THE MATRIX ROWS FOR CONTROL POINTS ON THE JET.
C      NOTE THAT THIS MUST BE DONE EVEN THOUGH CMU MAY BE 0.0,
C      IN ORDER TO PREPARE FOR FUTURE NONZERO CMU CASES.
  20  IF(NMAX .GT. NWT) CALL SHUFL1(W,ISIZE)
C      DEVELOP THE RIGHT SIDE COLUMN MATRIX
  30  ISIZE = NEWMAX
      DO 80 N = 1,NCASES
          LCASE = N
C      DEFINE THE LCASE COLUMN, NOT INCLUDING THE INFLUENCE OF ANY HINGES
  40  CALL COLUM1(LCASE)
C      COMPUTE THE HINGE DOWNWASH INFLUENCE FACTORS
      IF((LCASE .EQ. 1) .OR. (IHINGE .EQ. 0)) GO TO 80
      DO 50 I = 1,NEWMAX
          W(I) = 0.00
  50  CONTINUE
  60  CALL HINGE(W,ISIZE,NEWMAX,LCASE)
C      MODIFY THE LCASE COLUMN TO INCLUDE THE INFLUENCE OF ALL HINGES
  70  CALL COLUM2(W,ISIZE,NEWMAX,LCASE)

```

```

80 CONTINUE
C THE MATRIX DEVELOPMENT IS NOW COMPLETE.
C PUT THE MATRIX SYSTEM IN THE PROPER FORM FOR SOLUTION.
90 ISIZE = NEWMAX + NCASES
100 CALL PREP(W,ISIZE,NEWMAX)
    RETURN
END
SUBROUTINE DWNWSH(W,ISIZE)
C THIS SUBROUTINE CALCULATES THE DOWNWASH INFLUENCE COEFFICIENT MATRIX.
C THE MATRIX IS STORED ON THE DIRECT ACCESS SCRATCH FILE.
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NRONSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
1 DIMENSION W(ISIZE)

C COMPUTE ALL THE DOWNWASH COEFFICIENTS
IWRITE = 0
IF(IPRINT .LT. 0) WRITE(6, 10)
10 FORMAT(1H1,38X,44HWING - DUE - TO - WING - AND - JET DOWNWASH/)
C CYCLE THE DOWNWASH CONTROL POINTS ON THE WING AND JET
DO 190 I = 1,NMAX
    IWRITE = IWRITE + 1
    FIND(I'IWRITE) *** COMMENTED OUT BY JAC ***
    KI = KK(I)
C CYCLE THE VORTEX POINTS ON THE WING AND JET
DO 150 J = 1,NMAX
C COMPUTE THE GENERAL GEOMETRIC PARAMETERS
    KJ = KK(J)
    20 X = XI(I) + DEL(I)*CHORD(KI)/2.00 - XI(J)
    YY = Y(KI) - Y(KJ)
    IT = ITYPE(J)/10
C DECIDE WHICH EVD TYPE TO USE. ONLY THE TRIANGULAR PART OF HINGES
C WILL BE CONSIDERED AT THIS TIME.
    GO TO ( 50, 80, 110, 50 ), IT
30 WRITE(6, 40) J,IT
40 FORMAT(1H ,35X,21H** WARNING ** ELEMENT,I4,19H HAS AN ITYPE VALUE,
1      3H OF,I3/39X,42HAN EQUIVALENT TRIANGULAR DOWNWASH WAS USED)
C REGULAR TRIANGULAR EVD (INCLUDING TRIANGULAR PART OF HINGE EVD)
50 D1 = DEL(J-1) * CHORD(KJ)
    IN1 = IW(KJ) + NW(KJ) - 1
    IF(J .EQ. IJ(KJ)) D1 = DEL(IN1) * CHORD(KJ)
    D2 = DEL(J) * CHORD(KJ)
60 W(J) = EVD1(X,YY,D1,D2,DELTA(KJ))
C SUPERIMPOSE THE DOWNWASH FROM THE LEFT SIDE OF THE WING IF THIS IS A
C SYMETRIC OR ANTI-SYMETRIC CASE
    IF(ISYMM .GT. 0) GO TO 150
    YY = Y(KI) + Y(KJ)
70 WDUMMY = EVD1(X,YY,D1,D2,DELTA(KJ))
    IF(ISYMM .LT. 0) WDUMMY = -WDUMMY
    GO TO 140
C LEADING EDGE EVD
80 D2 = DEL(J) * CHORD(KJ)
90 W(J) = EVD2(X,YY,D2,DELTA(KJ))
C SUPERIMPOSE DOWNWASH
    IF(ISYMM .GT. 0) GO TO 150
    YY = Y(KI) + Y(KJ)
100 WDUMMY = EVD2(X,YY,D2,DELTA(KJ))
    IF(ISYMM .LT. 0) WDUMMY = -WDUMMY
    GO TO 140
C FAR - JET EVD
110 D1 = DEL(J-1) * CHORD(KJ)
120 W(J) = EVD3(X,YY,D1,D(KJ),DELTA(KJ))
C SUPERIMPOSE DOWNWASH
    IF(ISYMM .GT. 0) GO TO 150
    YY = Y(KI) + Y(KJ)
130 WDUMMY = EVD3(X,YY,D1,D(KJ),DELTA(KJ))
    IF(ISYMM .LT. 0) WDUMMY = -WDUMMY
140 W(J) = W(J) + WDUMMY
150 CONTINUE
C STORE THE DOWNWASH AT CONTROL POINT I ON THE DIRECT ACCESS UNIT
160 WRITE(I'IWRITE) W
    IF(IPRINT .GE. 0) GO TO 190
    IF(I .EQ. NWT+1) WRITE(6, 170 )
170 FORMAT(1H1,38X,43HJET - DUE - TO - WING - AND - JET DOWNWASH/)
    WRITE(6, 180 ) I,W
180 FORMAT(1H0,55X,10HMATRIX ROW,I4,60(/1X,10E13.5))
190 CONTINUE
RETURN
C THE DIRECT ACCESS UNIT NOW CONTAINS THE FOLLOWING -
C WING-DUE-TO-WING-AND-JET DOWNWASH COEFFICIENTS (NWT RECORDS)
C JET - DUE-TO-WING-AND-JET DOWNWASH COEFFICIENTS (NJT RECORDS)
C END
FUNCTION EVD1(X,Y,D1,D2,DELTA)
C THIS FUNCTION CALCULATES THE DOWNWASH AT ANY POINT X,Y

```

```

C DUE TO A REGULAR TRIANGULAR EVD ELEMENT WITH UNIT PEAK VORTICITY,
C LOCATED AT THE ORIGIN 0,0
C R(A,B) = SQRT(A*A + B*B)
C CALCULATE THE BASIC GEOMETRICAL PARAMETERS
  IF(Y .LT. 0.0) Y = -Y
  YMD = Y - DELTA
  YPD = Y + DELTA
  PART1 = (D1 + D2) * (1.0/YMD - 1.0/YPD)
  IF(X*(0.50*(D1+D2)) .GT. 100.0) GO TO 90
10 XPD = X + D1
  XMD = X - D2
20 ROP = R(X,YMD)
  R1P = R(XPD,YMD)
  R2P = R(XMD,YD)
30 ROPP = R(X,YPD)
  R1PP = R(XPD,YPD)
  R2PP = R(XMD,YPD)
C CALCULATE THE DOWNWASH
40 PART2 = (XPD/D1) * ((R1P-ROP)/YMD - (R1PP-ROPP)/YPD)
  PART3 = (XMD/D2) * ((R2P-ROP)/YMD - (R2PP-ROPP)/YPD)
  YRATIO = (YPD+ROPP) / (YMD+ROP)
50 PART4 = (XPD/D1) * ALOG(((YMD+R1P)/(YPD+R1PP)) * YRATIO)
  PART5 = (XMD/D2) * ALOG(((YMD+R2P)/(YPD+R2PP)) * YRATIO)
60 PART6 = YMD * ALOG((XPD+R1P)/(X+ROP))
  PART7 = YPD * ALOG((XPD+R1PP)/(X+ROPP))
70 PART8 = YMD * ALOG((XMD+R2P)/(X+ROP))
  PART9 = YPD * ALOG((XMD+R2PP)/(X+ROPP))
80 EVD1 = -(PART1 + (PART2 + PART3) - 2.0*(PART4 + PART5))
1  EVD1 = -(PART6 - PART7)/D1 + (PART8 - PART9)/D2) / 25.13274
1  RETURN
90 EVD1 = -PART1 / 12.56673
100 RETURN
END
FUNCTION EVD2(X,Y,DEL,DELTA)
C THIS FUNCTION CALCULATES THE DOWNWASH AT ANY POINT X,Y
C DUE TO A LEADING EDGE EVD ELEMENT WITH UNIT AVERAGE VORTICITY,
C LOCATED AT THE ORIGIN 0,0
C DIMENSION SI(9),FACTOR(9)
C R(A,B) = SQRT(A*A + B*B)
  G(A) = 1.00/SQRT(A) - A
  S(A) = ABS(A) / A
C DATA SI/-0.9681602,-0.8360311,-0.6133714,-0.3242534,0.0,
1  0.3242534,0.6133714,0.8360311,0.9681602/
1  DATA FACTOR/0.0812744,0.1806482,0.2606107,0.3123471,0.3302394,
1  0.3123471,0.2606107,0.1806482,0.0812744/
C CALCULATE THE BASIC GEOMETRICAL PARAMETERS
10 XB = X / DEL
  YB = Y / DEL
  DB = DELTA / DEL
  YPD = YB + DB
  YMD = YB - DB
20 IF(XB .GT. 100.0) GO TO 280
  XM1 = XB - 1.00
30 ROP = R(XB,YMD)
40 ROPP = R(XB,YPD)
C CALCULATE RK(XB)
  IF(ABS(XB) .LT. 1.0E-04) GO TO 100
  IF(ABS(XM1) .LT. 1.0E-06) GO TO 80
50 PART1 = ALOG(ABS(XM1/XB))
  PART1 = XB * PART1 + 1.00
  IF(XB .GT. 0.00) GO TO 70
60 SQX = SQRT(-XB)
  RK = -2.00 / SQX * ATAN(1.00/SQX) + PART1
  GO TO 60
70 SQX = SQRT(XB)
  RK = -ALOG(ABS((1.00-SQX) / (1.00+SQX))) / SQX + PART1
  GO TO 90
80 RK = 2.386294
C CALCULATE P(XB)
90 PART2 = ROP/YMD - ROPP/YPD
  P = PART2 * RK
  GO TO 110
100 P = 0.00
C CALCULATE F(XB) BY GAUSSIAN INTEGRATION.
110 IF((XB .GT. 0.0) .AND. (XB .LT. 1.00)) GO TO 150
C XB IS NOT WITHIN THE X DIMENSIONS OF THE ELEMENT.
  F = 0.00
  DO 140 N = 1,9
120 SB = (SI(N)+1.00) / 2.00
  XMS = XB - SB
  GS = G(SB)
130 PART3 = (GS*(R(XMS,YMD)-ROP))/YMD - (GS*(R(XMS,YPD)-ROPP))/YPD
  F = F + FACTOR(N) * PART3 / XMS
140 CONTINUE
  F = 0.50 * F
  GO TO 270
C XB IS WITHIN THE X DIMENSIONS OF THE ELEMENT.  CALCULATE FO.
150 FO = 0.00
  GPX = 0.00

```

```

GPPX = 0.00
IF(XB .LT. 1.0E-04) GO TO 170
GX = G(XB)
GPX = GX * (ABS(YMD) - ROP)
GPPX = GX * (ABS(YPD) - ROPP)
IF(XM1 .GT. -1.0E-06) GO TO 170
160 FO = -(GPX/YMD - GPPX/YPD) * PART
C CALCULATE F1 BY GAUSSIAN INTEGRATION.
170 F1 = 0.00
DO 250 N = 1,9
180 SB = SI(N)+1.00) / 2.00
XMS = XB - SB
190 IF(ABS(XMS) .LT. 1.0E-04) GO TO 220
GS = G(SB)
200 PART4 = (GS*(R(XMS,YMD)-ROP) - GPX) / XMS
210 PART5 = (GS*(R(XMS,YPD)-ROPP) - GPPX) / XMS
PART6 = PART4/YMD - PART5/YPD
GO TO 240
220 PART4 = S(YMD) - S(YPD) - PART2
PART5 = 1.00 + 0.50 / (SQRT(XB))**3
230 PART6 = PART4 * PART5
240 F1 = F1 + FACTOR(N) * PART6
250 CONTINUE
260 F = FO + 0.50 * F1

C CALCULATE THE DOWNWASH INFLUENCE COEFFICIENT.
270 EVD2 = -(1.50 * (1.00/YMD - 1.00/YPD) + P + F) / 18.84956
RETURN
280 EVD2 = -(1.00/YMD - 1.00/YPD) / 6.283185
RETURN
END

FUNCTION EVD3(X,Y,DEL,D,DELTA)
C THIS FUNCTION CALCULATES THE DOWNWASH AT ANY POINT X,Y DUE TO A
C FAR-JET EVD ELEMENT WITH UNIT PEAK VORTICITY, LOCATED AT THE ORIGIN
C R(A,B) = SQRT(A*A + B*B)
C CALCULATE THE BASIC GEOMETRICAL PARAMETERS
IF(Y .LT. 0.0) Y = -Y
YMD = Y - DELTA
YPD = Y + DELTA
10 XPD = X + D
20 PART1 = (DEL/2.00 + D) * (1.00/YMD - 1.00/YPD)
C CHECK ON INFINITY
IF((XPD/YMD)**2 .GT. 1.0E06) GO TO 160
XPD1 = X/DEL
XD = X/DEL
ROP = R(X,YMD)
ROPP = R(X,YPD)
30 RIP = R(XPD1,YMD)
RIPP = R(XPD1,YPD)
ROP = R(XPD,YMD)
RDPP = R(XPD,YPD)

C CALCULATE FO
40 PART2 = ROP/YMD - ROPP/YPD
PART3 = 0.50 * (XD+1.00) * ((RIP-ROP)/YMD - (RIPP-ROPP)/YPD)
50 PART4 = ALOG(ABS((YMD+RIP)/(YPD+RIPP))) * ((YPD+ROPP)/(YMD+ROP)))
PART5 = YMD/DEL * ALOG((XPD1+RIP)/(X+ROP))
60 PART6 = YPD/DEL * ALOG((XPD1+RIPP)/(X+ROPP))
70 FO = PART1 - 0.50*PART2 + PART3 - (XD+1.00)*PART4
1 - 0.50*(PART5-PART6)

C CALCULATE F1
IF(ABS(XPD/D) .LT. 1.0E-02) GO TO 130
C X IS NOT NEAR -D
Q = D/XPD
80 PART1 = -D * Q * (1.00/YMD - 1.00/YPD)
PART2 = Q * PART2
90 PART3 = Q * Q * ALOG(ABS((YMD+ROP)/(YPD+ROPP)))
100 PART4 = YMD/RDP*ALOG(ABS((-XPD+RDP*((ROP+RDP)/D))/(RDP-XPD)))
110 PART5 = YPD/RDPP*ALOG(ABS((-XPD+RDPP*((ROPP+RDPP)/D))/(RDPP-XPD)))
120 F1 = PART1 + PART2 - PART3 + Q * Q * (PART4 - PART5)
GO TO 150
C X IS NEAR -D
130 X = -D
ROP = R(X,YMD)
ROPP = R(X,YPD)
PART2 = ROP/YMD - ROPP/YPD
PART3 = (X/YMD)**2 * ALOG(ABS((YMD+ROP)/X))
PART4 = (X/YPD)**2 * ALOG(ABS((YPD+ROPP)/X))
140 F1 = -0.50*PART2 - 0.50*(PART3 - PART4)

C CALCULATE THE DOWNWASH INFLUENCE COEFFICIENT
150 EVD3 = -(FO + F1) / 12.56637
RETURN
160 EVD3 = -PART1 / 6.283185
RETURN
END

FUNCTION EVD4(X,Y,D1,D2,DELTA)
C THIS FUNCTION CALCULATES THE DOWNWASH AT ANY POINT X,Y
C DUE TO A HINGE EVD ELEMENT WITH ONE RADIAN TURNING ANGLE
C LOCATED AT THE ORIGIN 0,0
C
DIMENSION SI(9),FACTOR(9)
R(A,B) = SQRT(A*A + B*B)
CHANGE(A,B,C) = 0.50 * (C * (B-A) + (A+B))
S(A) = ABS(A) / A
SO(T) = 0.50 * (-D1L/D1*(1.00-S(T)) + D2L/D2*(1.00+S(T)))

```

```

G(A) = ALOG(ABS(A)) - SO(A) * A
1 DATA SI/-0.9681602,-0.8360311,-0.6133714,-0.3242534,0.0,
1          0.3242534,0.6133714,0.8360311,0.9681602/
1 DATA FACTOR/0.0812744,0.1806482,0.2606107,0.3123471,0.3302394,
1          0.3123471,0.2606107,0.1806482,0.0812744/
C CALCULATE THE BASIC GEOMETRICAL PARAMETERS.
DB = 0.50 * (D1 + D2)
10 XB = X / DB
XMD = X - D2
XPD = X + D1
20 YMD = Y - DELTA
YPD = Y + DELTA
30 ROP = R(X,YMD)
ROPP = R(X,YPD)
AX = ABS(X)
AXB = ABS(XB)
D1L = ALOG(D1)
D2L = ALOG(D2)
XD1 = X/D1
XD2 = X/D2
40 PART5 = 1.00/YMD - 1.00/YPD
PART6 = -(D1+D2) + 0.50 * (D1*D1L + D2*D2L)
C CALCULATE RK(X)
IF(AXB .LT. 7.5) GO TO 70
N = 0
RK = 0.00
D1X = D1/X
D2X = D2/X
DO 60 N1 = 1,100,2
RKN = 0.000
DO 50 N2 = 1,2
N = N + 1
RN = N
RNN = N * (N+1)
RKN = RKN + (-1.0)**(N+1) * (D1L/RNN - 1.0/(RN*RN)) * D1X**N
1      +(D2L/RNN - 1.0/(RN*RN)) * D2X**N
50 CONTINUE
RK = RK + RKN
IF(ABS(RKN/RK) .LT. 1.0E-07) GO TO 190
60 CONTINUE
70 IF(AXB .LT. 1.0E-04) GO TO 200
SX = S(X)
RK1 = 0.00
RK2 = 0.00
RK3 = 0.00
RK4 = 0.00
RK1P = ABS(XD1+1.00)
80 IF(RK1P .LT. 1.0E-06) GO TO 90
RK1 = (ALOG(ABS(XD1)) + (XD1+1.00) * D1L) * ALOG(ABS(XPD/X))
90 RK2P = ABS(XD2-1.00)
IF(RK2P .LT. 1.0E-06) GO TO 100
RK2 = -(ALOG(ABS(XD2)) - (XD2-1.00) * D2L) * ALOG(ABS(XMD/X))
100 IF(ABS(D1/AX-1.00) .LT. 1.0E-04) GO TO 140
C CALCULATE RK3 BY GAUSSIAN INTEGRATION.
AL = 1.00
BL = D1/AX
DO 130 N = 1,9
110 T = CHANGE(AL,BL,SI(N))
120 RK3 = RK3 + FACTOR(N) * (ALOG(T) / (SX+T))
130 CONTINUE
RK3 = 0.50 * (BL-AL) * RK3
C CALCULATE RK4 BY GAUSSIAN INTEGRATION.
140 IF(ABS(D2/AX-1.00) .LT. 1.0E-04) GO TO 180
AL = 1.00
BL = D2/AX
DO 170 N = 1,9
150 T = CHANGE(AL,BL,SI(N))
160 RK4 = RK4 + FACTOR(N) * (ALOG(T) / (SX-T))
170 CONTINUE
RK4 = 0.50 * (BL-AL) * RK4
180 RK = -2.467401 * SX - (D1L-D2L) + (RK1 + RK2) + (RK3 + RK4)
190 P = (ROP/YMD - ROPP/YPD) * RK
GO TO 210
200 P = 0.00
C CALCULATE F(X) BY GAUSSIAN INTEGRATION.
210 IF(X .GT. -D1) AND (X .LT. D2) GO TO 290
C X IS NOT WITHIN THE DIMENSIONS OF THE ELEMENT.
C LEFT SIDE INTEGRAL.
FL = 0.00
AL = -D1
BL = 0.00
DO 240 N = 1,9
220 SY = CHANGE(AL,BL,SI(N))
XMS = X - SY
GS = G(SY)
230 PART1 = GS * (R(XMS,YMD)-ROP) / YMD - GS * (R(XMS,YPD)-ROPP) / YPD
FL = FL + FACTOR(N) * PART1 / XMS
240 CONTINUE
FL = 0.50 * (BL-AL) * FL
C RIGHT SIDE INTEGRAL
FR = 0.00
AL = 0.00
BL = D2
DO 270 N = 1,9
250 SY = CHANGE(AL,BL,SI(N))
XMS = X - SY
GS = G(SY)
260 PART1 = GS * (R(XMS,YMD)-ROP) / YMD - GS * (R(XMS,YPD)-ROPP) / YPD

```

```

FR = FR + FACTOR(N) * PART1 / XMS
270 CONTINUE
    FR = 0.50 * (BL-AL) * FR
280 F = FL + FR
GO TO 460

C X IS WITHIN THE DIMENSIONS OF THE ELEMENT
C CALCULATE FO
290 FO = 0.00
    GPX = 0.00
    GPPX = 0.00
    IF(AXB .LT. 1.0E-04) GO TO 310
    SOX = SO(X) - 1.00/X
    GX = G(X)
    GPX = GX * (ABS(YMD)-ROP)
    GPPX = GX * (ABS(YPD)-ROPP)
    IF(((1.00-XD2) .LT. 1.0E-06) .OR. ((XD1+1.00) .LT. 1.0E-06))
1 GO TO 310
300 FO = -(GPX/YMD - GPPX/YPD) * ALOG(ABS(XMD/XPD))

C CALCULATE F1
C LEFT SIDE INTEGRAL
310 FL = 0.00
    AL = -D1
    BL = 0.00
    DO 370 N = 1,9
320 SY = CHANGE(AL,BL,SI(N))
    XMS = X - SY
    IF(ABS(XMS/DB) .LT. 1.0E-04) GO TO 350
    GS = G(SY)
    PART2 = (GS * (R(XMS,YMD)-ROP) - GPX) / XMS
    PART3 = (GS * (R(XMS,YPD)-ROPP) - GPPX) / XMS
    PART4 = PART2/YMD - PART3/YPD
    GO TO 360
    PART2 = ROP/YMD - ROPP/YPD
    PART4 = (S(YMD) - S(YPD)) - PART2 * SOX
360 FL = FL + FACTOR(N) * PART4
370 CONTINUE
    FL = 0.50 * (BL-AL) * FL

C RIGHT SIDE INTEGRAL
380 FR = 0.00
    AL = 0.00
    BL = D2
    DO 440 N = 1,9
390 SY = CHANGE(AL,BL,SI(N))
    XMS = X - SY
    IF(ABS(XMS/DB) .LT. 1.0E-04) GO TO 420
    GS = G(SY)
    PART2 = (GS * (R(XMS,YMD)-ROP) - GPX) / XMS
    PART3 = (GS * (R(XMS,YPD)-ROPP) - GPPX) / XMS
    PART4 = PART2/YMD - PART3/YPD
    GO TO 430
    PART2 = ROP/YMD - ROPP/YPD
    PART4 = (S(YMD) - S(YPD)) - PART2 * SOX
430 FR = FR + FACTOR(N) * PART4
440 CONTINUE
    FR = 0.50 * (BL-AL) * FR
450 F = FL + FR + FO

C CALCULATE THE DOWNWASH INFLUENCE COEFFICIENT
460 EVD4 = (PART5 * PART6 + P + F) / 19.739202
RETURN
END
SUBROUTINE SHUFL1(W,ISIZE)

C THIS SUBROUTINE READS THE PORTION OF THE DOWNWASH MATRIX WHICH
C CONTAINS THE DOWNWASH DUE TO THE JET, AUGMENTS IT ACCORDING TO
C THE CURRENT CMU VALUES, AND WRITES IT BACK ON UNIT 1
C BEHIND THE DOWNWASH MATRIX

COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NRONSJ,NNT,NJT,NMAX,NJ(40),NJ(40),IW(40),IJ(40),
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)
DIMENSION A(600),AIM1(600),W(ISIZE)

C
NWT1 = NWT + 1
FIND(1'NWT1)
IF(IPRINT .LT. 0) WRITE(6, 10)
10 FORMAT(1H1,42X,36HAUGMENTED PORTION OF SOLUTION MATRIX//)

C PREPARE THE SOLUTION MATRIX FOR ROWS ON THE JET
    I IS THE COUNTER FOR IDENTIFYING ELEMENTS ON THE JET
    IREAD IS THE COUNTER FOR DOWNWASH ROWS ON THE JET STORED ON UNIT 1
    IWRITE IS THE COUNTER FOR AUGMENTED ROWS TO BE WRITTEN ON UNIT 1
20 IREAD = NWT
    IWRITE = NMAX
    C1 = 0.125000
    C3 = 0.375000
    DO 150 I = NWT1,NMAX
30 IM1 = I - 1
    IP1 = I + 1
    IREAD = IREAD + 1
    IWRITE = IWRITE + 1
    K = KK(I)

C READ THE ITH ROW OF THE DOWNWASH MATRIX (IREADTH RECORD)

```

```

C 40 READ(1'IREAD) W
C FIND THE PLACE TO WRITE THE ITH AUGMENTED ROW (IWRITETH RECORD)
C ***COMMENTED OUT BY JAC ***
C
C SAVE THE EXISTING ROW OF SIMPLE DOWNWASH COEFFICIENTS
DO 50 J = 1,NMAX
A(J) = W(J)
50 CONTINUE
C
C SUBTRACT THE PREVIOUS ROW FROM THE PRESENT ROW IF THE DOWNWASH POINT
C IS NOT ON A LEADING JET ELEMENT
PROD1 = CMUP(K) * DEL(I) * CHORD(K)
PROD2 = CMUP(K) * DEL(IM1) * CHORD(K)
60 IF(I.EQ. IJ(K)) GO TO 90
DO 70 J = 1,NMAX
W(J) = W(J) - AIM1(J)
70 CONTINUE
C
C MODIFY THE TWO OR THREE SPECIAL ELEMENTS FURTHER
IF(I.EQ. (IJ(K)+NJ(K)-1)) GO TO 100
C DOWNWASH CONTROL POINT IS ON A REGULAR JET ELEMENT
80 W(IM1) = W(IM1) + C1 * PROD2
W(I) = W(I) + C3 * [PROD1 + PROD2]
W(IP1) = W(IP1) + C1 * PROD1
GO TO 110
C DOWNWASH CONTROL POINT IS ON A LEADING JET ELEMENT
90 W(I) = W(I) + C3 * PROD1
W(IP1) = W(IP1) + C1 * PROD1
GO TO 110
C DOWNWASH CONTROL POINT IS ON A TRAILING JET ELEMENT
100 W(IM1) = W(IM1) + C1 * PROD2
W(I) = W(I) + C3 * PROD2 + CMUP(K) * D(K)
C
C STORE THE AUGMENTED ITH ROW ON UNIT 1 (IWRITETH RECORD)
110 WRITE(1'IWRITE) W
C FIND THE PLACE TO READ THE NEXT DOWNWASH ROW (IREAD+1ST RECORD)
FIND(1'IREAD+1)
C PRINT THE AUGMENTED PORTION OF THE MATRIX
IF(IPRINT.LT.0) WRITE(6,120) I,W
120 FORMAT(1H0,55X,10HMATRIX ROW,I4,60/1X,10E13.5))
C
C SAVE THE ITH ROW FOR USE AS THE I-1 ROW ON THE NEXT PASS
130 DO 140 J = 1,NMAX
AIM1(J) = A(J)
140 CONTINUE
150 CONTINUE
RETURN
C
C DIRECT ACCESS UNIT 1 NOW CONTAINS THE FOLLOWING -
C WING-DUE-TO-WING-AND-JET DOWNWASH COEFFICIENTS (NWT RECORDS)
C JET-DUE-TO-WING-AND-JET DOWNWASH COEFFICIENTS (NJT RECORDS)
C JET-DUE-TO-WING-AND-JET AUGMENTED DOWNWASH COEFFICIENTS (NJT RECS)
END
SUBROUTINE SHUFL2(W,ISIZE,NEWMAX)
C
C THIS SUBROUTINE READS EACH MATRIX ROW CORRESPONDING TO A DOWNWASH
C CONTROL POINT ON THE JET, MODIFIES IT ACCORDING TO THE NEW VALUES
C OF CMU, AND RESTORES IT IN ITS ORIGINAL PLACE
C
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/GEOM1/Y(40),CHORD(40),DELTAL(40),XB(600),XI(600),DEL(600),
D(40),KK(600),ITYPE(600)
COMMON/JCASE/CMUI(40),CMUP(40),CMUPP(40)
DIMENSION W(ISIZE)
C
IF(IPRINT .LT. 0) WRITE(6, 10 )
10 FORMAT(1H1,42X,36HAUGMENTED PORTION OF SOLUTION MATRIX)
C
C CYCLE THE AUGMENTED MATRIX ROWS
IREAD = NMAX
NWT1 = NWT + 1
DO 100 I = NWT1,NEWMAX
IREAD = IREAD + 1
FIND(1'IREAD)
20 IM1 = I - 1
IP1 = I + 1
K = KK(I)
30 CMUDIF = (CMUP(K) - CMUPP(K)) * CHORD(K)
C
C READ THE ITH AUGMENTED MATRIX ROW
40 READ(1'IREAD) W
FIND(1'IREAD)
C
C MODIFY THE TWO OR THREE SPECIAL ELEMENTS ACCORDING TO THE NEW CMU
IF(I.EQ. IJ(K)) GO TO 60
IF(I.EQ. (IJ(K)+NJ(K)-1)) GO TO 70
C DOWNWASH CONTROL POINT IS ON A REGULAR JET ELEMENT
50 W(IM1) = W(IM1) + 0.1250 * DEL(IM1) * CMUDIF
W(I) = W(I) + 0.3750 * (DEL(IM1)+DEL(I)) * CMUDIF
W(IP1) = W(IP1) + 0.1250 * DEL(I) * CMUDIF
GO TO 80
C DOWNWASH CONTROL POINT IS ON A LEADING JET ELEMENT
60 W(I) = W(I) + 0.3750 * DEL(I) * CMUDIF
W(IP1) = W(IP1) + 0.1250 * DEL(I) * CMUDIF
GO TO 80
C DOWNWASH CONTROL POINT IS ON A TRAILING JET ELEMENT
70 W(IM1) = W(IM1) + 0.1250 * DEL(IM1) * CMUDIF

```

```

C W(I) = W(I) + (0.3750*DEL(IM1) + D(K)/CHORD(K)) * CMUDIF
C WRITE THE REVISED ITH ROW ON UNIT 1
80 WRITE(1,'IREAD') W
  IF(IPRINT .LT. 0) WRITE(6,90) I,W
90 FORMAT(1H0,55X,10HMATRIX ROW,I4,60(/1X,10E13.5))
100 CONTINUE
  RETURN
END
SUBROUTINE COLUM1(LCASE)
C THIS SUBROUTINE SETS UP THE RIGHT SIDE COLUMN MATRIX WITHOUT
C CONSIDERATION OF ANY HINGE DOWNWASH INFLUENCE
C COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/GEOM1/Y(40),CHORD(40),DETA(40),XB(600),XI(600),DEL(600),
1 D(40),KK1(600),ITYPE(600)
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
COMMON/SOLV1/B(600,10)
C DEFINE THE ELEMENTS ON THE WING
DO 10 I = 1,NWT
  B(I,LCASE) = EPS(I,LCASE) / 57.295779
10 CONTINUE
C DEFINE THE ELEMENTS ON THE JET
I = NWT
DO 40 K = 1,NROWS
  NJK = NJ(K)
  IF(NJK .EQ. 0) GO TO 40
C FIRST JET ELEMENT
  I = I + 1
  KKI = KK1(I)
20 B(I,LCASE) = THETA(KKI,LCASE) / 57.295779
C REMAINING JET ELEMENTS
DO 30 L = 2,NJK
  I = I + 1
  B(I,LCASE) = 0.00
30 CONTINUE
40 CONTINUE
  RETURN
END
SUBROUTINE COLUM2(H,ISIZE,NEWMAX,LCASE)
C THIS SUBROUTINE ADDS THE APPROPRIATE HINGE DOWNWASH INFLUENCE
C TO THE RIGHT SIDE COLUMN MATRIX
C COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/GEOM1/Y(40),CHORD(40),DETA(40),XB(600),XI(600),DEL(600),
1 D(40),KK1(600),ITYPE(600)
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)
COMMON/SOLV1/B(600,10)
  DIMENSION H(ISIZE)
C DEFINE THE ELEMENTS ON THE WING
DO 10 I = 1,NEWMAX
  B(I,LCASE) = B(I,LCASE) - H(I)
10 CONTINUE
C DEFINE THE ELEMENTS ON THE JET
IF(NEWMAX .EQ. NWT) RETURN
I = NWT
DO 90 K = 1,NROWS
20 NJK = NJ(K)
  IF(NJK .EQ. 0) GO TO 90
C COMPUTE THE CMU INFLUENCE FACTORS H1 AND H2
  I = I + 1
  H1 = 0.00
  H2 = 0.00
  BTA = BETA(I,LCASE)
  IF(ABS(BTA) .LT. 0.00001) GO TO 50
  BTA = BTA / 57.295779
30 D2 = DEL(I) * CHORD(K)
  DL = ALOG(D2)
  PROD = -CMUP(K) * D2 * BTA / 3.1415927
40 H1 = PROD * (1.6931472 - 0.750 * DL)
  H2 = PROD * (0.3068528 - 0.250 * DL)
C FIRST POINT ON THE JET
50 B(I,LCASE) = B(I,LCASE) + H1
C SECOND POINT ON THE JET
  I = I + 1
60 B(I,LCASE) = B(I,LCASE) + H(I-1) + H2
C REMAINING POINTS ON THE JET
  IF(NJK .LT. 3) GO TO 90
  DO 80 L = 3,NJK
    I = I + 1
70 B(I,LCASE) = B(I,LCASE) + H(I-1)
80 CONTINUE
90 CONTINUE
  RETURN
END
SUBROUTINE HINGE(H,ISIZE,NEWMAX,LCASE)
C THIS SUBROUTINE CALCULATES THE DOWNWASH INFLUENCE COEFFICIENTS
C AT EACH DOWNWASH CONTROL POINT DUE TO ALL DEFLECTED HINGE ELEMENTS.
C FOR EACH CONTROL POINT THE INFLUENCE COEFFICIENTS ARE MULTIPLIED BY
C THEIR RESPECTIVE DEFLECTION ANGLE AND SUMMED UP TO OBTAIN THE
C COMPLETE HINGE-INDUCED DOWNWASH.
C COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE

```

```

COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/GEO1/Y(40),CHORD(40),DELT(A(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
DIMENSION HISIZE)
C
IF(LCASE .GT. 2) GO TO 20
IF(IPRINT .LT. 0) WRITE(6, 10 )
10 FORMAT(1H1)
ILINES = 1
C CYCLE THE DOWNWASH CONTROL POINTS ON THE WING AND JET
20 DO 110 I = 1,NEWMAX
   KI = KK(I)
C CYCLE THE VORTEX POINTS ON THE WING AND JET
DO 100 J = 1,NEWMAX
C CHECK WHETHER THERE IS A DEFLECTED HINGE AT ELEMENT J
30 B = BETA(J,LCASE)
IF(ABS(B) .LT. 0.0001) GO TO 100
B = B / 57.295779
C COMPUTE THE GEOMETRIC PARAMETERS
KJ = KK(J)
40 X = XI(I) + DEL(I)*CHORD(KI)/2.00 - XI(J)
YY = Y(KI) - Y(KJ)
50 D2 = DEL(J) * CHORD(KJ)
DI = DEL(J-1) * CHORD(KJ)
IN1 = IW(KJ) + NW(KJ) - 1
60 IF(ITYPE(J) .EQ. 43) DI = DEL(IN1) * CHORD(KJ)
C COMPUTE AND SUM UP THE INFLUENCE OF ELEMENT J
70 H(I) = H(I) + EVD4(X,YY,DI,D2,DELTA(KJ)) * B
C SUPERIMPOSE DOWNWASH FOR SYMMETRIC OR ANTI-SYMMETRIC GEOMETRY
IF(ISYMM .GT. 0) GO TO 100
YY = Y(KI) + Y(KJ)
80 HDUMMY = EVD4(X,YY,DI,D2,DELTA(KJ))
IF(ISYMM .LT. 0) HDUMMY = - HDUMMY
90 H(I) = H(I) + HDUMMY * B
100 CONTINUE
110 CONTINUE
C PRINT OUT THE DOWNWASH IF REQUIRED
IF(IPRINT .GE. 0) RETURN
NEXT = NEWMAX/10 + 3
IF(((ILINES+NEXT) .LT. 56) .OR. (ILINES .EQ. 1)) GO TO 120
WRITE(6, 10 )
ILINES = 1
120 IF(IPRINT .LT. 0) WRITE(6, 130 ) LCASE,H
130 FORMAT(1H0,35X,44HHINGE INFLUENCE COEFFICIENTS FOR FUNDAMENTAL,
1 5H CASE, I3,60(1X,10E13.5))
ILINES = ILINES + NEXT
RETURN
END
SUBROUTINE STG2S
C THIS PROGRAM CONTROLS SOLUTION OF THE MATRIX SYSTEM
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/SPIRIT/NEWMAX,NEWMCMU,NOALFA,LOGIC,IR
COMMON/SOLV1/GAMMA(600,10)
COMMON/SOLV2/WKAREA(10000)
DIMENSION W(600),SUMMER(600)
C
IF(IPRINT .LT. 0) WRITE(6, 10 )
10 FORMAT(1H1,53X,14HGAMMA SOLUTION)
C SOLVE THE MATRIX FOR GAMMA USING MATRIX
NSIZE = 10000
NIN = 2
NSCR1 = 3
NSCR2 = 4
20 CALL MATRIX(NEWMAX,NCASES,NSIZE,NIN,NSCR1,NSCR2,IR)
IF(IR .EQ. 2) GO TO 90
C MATRIX HAS STORED THE SOLUTION IN THE FIRST STORAGE LOCATIONS OF THE
C WKAREA ARRAY. TRANSFER THIS DATA INTO THE GAMMA ARRAY.
ISUM = 0
30 DO 70 N = 1,NCASES
   DO 40 J = 1,NEWMAX
      GAMMA(J,N) = WKAREA(ISUM+J)
40 CONTINUE
IF(IPRINT .LT. 0) WRITE(6, 50 ) N,(GAMMA(J,N),J=1,NEWMAX)
50 FORMAT(1H0,50X,16HFUNDAMENTAL CASE,I4,60(1X,10E13.5))
60 ISUM = ISUM + NEWMAX
70 CONTINUE
C IF REQUIRED, CHECK THE SOLUTION BY BACK SUBSTITUTION
80 IF(IPRINT .LT. 0) CALL BAKSUB(W,SUMMER,NEWMAX)
   IR = 1
   GO TO 110
C PRINT THE MATRIX ERROR MESSAGE
90 WRITE(6, 100 )
100 FORMAT(1H1,40X,40HMATRIX DOES NOT HAVE ENOUGH CORE TO WORK/
1 45X,29HTHIS CASE HAS BEEN TERMINATED)
   IR = 2
110 RETURN
END
SUBROUTINE PREP(TRANS,ISIZE,NEWMAX)
C THIS SUBROUTINE PREPARES THE FINAL MATRIX FOR SOLUTION BY
CONCATINATING IT WITH THE RIGHT SIDE MATRIX AND STORING IT

```

```

C ON SCRATCH UNIT 2 FOR INPUT TO MATRIX.
C
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHNGE
COMMON/MARK/NROWS,NROWSJ,NNT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/SOLV1/B(600,10)
DIMENSION TRANS(I$IZE)

C
IREAD = 0
FIND(1,IREAD+1)
REWIND 2

C READ THE MATRIX COEFFICIENTS
DO 40 I = 1,NEWMAX
IF(I .EQ. NW+1) IREAD = NEWMAX
IREAD = IREAD + 1
IF(I$IZE .GT. 600) GO TO 5
READ(I,IREAD) TRANS
GO TO 10
5 READ(I,IREAD) (TRANS(J),J=1,NEWMAX)

C PULL OUT THE RIGHT SIDE MATRIX COEFFICIENTS AND CONCATINATE THEM
10 DO 20 N = 1,NCASES
TRANS(NEWMAX+N) = B(I,N)
20 CONTINUE
C THE MATRIX ROW HAS NOW BEEN ASSEMBLED AND FILLS THE TRANS ARRAY.
C WRITE THE CONCATINATED ROW ON ON UNIT 2 FOR INPUT TO MATRIX.
30 WRITE(2) TRANS
40 CONTINUE
C THE SYSTEM OF LINEAR EQUATIONS IS NOW READY FOR SOLUTION
RETURN
END
SUBROUTINE MATRIX(ND, MD, KD, NI, MM, NO, IR)
C
D I R E C T M A T R I X S O L U T I O N
C
COMMON/SOLV2/A(10000)
LOGICAL LAST

C
N = ND
M = MD
KORE = KD
NPM = N + M
IF (MAX0(3 * NPM, M * N) .LT. KORE) GO TO 20
IR = 2
RETURN
20 MT = MM
REWIND MT
NIN = NI
REWIND NIN
NOUT = NO
REWIND NOUT
MP1 = M + 1
NN = N
NEL = NPM
C - - CALCULATE THE MAXIMUM NO. OF ROWS, 'K'
30 K = (KORE - NEL) / NEL
C - - TEST TO SEE IF THE REST OF THE MATRIX WILL FIT IN CORE
C
LAST = K .GE. NN
IF (LAST) K = NN
C - - READ 'K' ROWS OF THE AUGMENTED 'A' MATRIX
C
40 NT = 0
DO 50 IB = 1, K
NS = NT + 1
NT = NT + NEL
50 CALL GETT(NIN, 1, NEL, A(NS), 1, AA2)
C - - CHECK TO SEE IF WE WERE UNLUCKY ENOUGH TO END UP WITH ONLY ONE ROW
C
IF (K .EQ. 1) GO TO 110
C - - 'K' IS GREATER THAN '1' SO WE CAN START THE TRIANGULARIZATION
C
NELP1 = NEL + 1
NS = - NEL
NELP2 = NELP1 + 1
C - - FORM THE 'TRAPEZOIDAL' ARRAY (8)
C
DO 60 IB = 2, K
NP = NELP2 - IB
NS = NS + NELP1
NT = NS
DO 60 IO = IB, K
NT = NT + NEL
MN = NT
NB = NS
A(NT) = (-A(NT)) / A(NS)
DO 60 NF = 2, NP
MN = MN + 1
NB = NB + 1
60 A(MN) = A(MN) + A(NT) * A(NB)
IF (LAST) GO TO 110
C - - WRITE THE 'TRAPEZOIDAL' MATRIX ON TAPE
C

```

```

NT = 0
NP = NEL
NS = - NEL
DO 70 IO = 1, K
NS = NS + NELP1
NT = NT + NEL
CALL SAVE(MT, 2, NP, NP, A(NS), 1, AA2)
70 NP = NP - 1
NP = NP - M
NS = KORE - NEL + 1
C -- READ ANOTHER ROW
C DO 100 IO = 1, NP
CALL GETT(NIN, 1, NEL, A(NS), 1, AA2)
C -- MODIFY THIS ROW BY THE 'TRAPEZOIDAL' ARRAY
C
NT = 1
MN = NS
DO 90 IB = 1, K
NB = NT
NF = MN + 1
A(MN) = (-A(MN)) / A(NT)
DO 80 NN = NF, KORE
NB = NB + 1
80 A(NN) = A(NN) + A(MN) * A(NB)
MN = NF
90 NT = NT + NELP1
C -- WRITE THE MODIFIED ROW ON TAPE
C
NN1 = KORE - MN + 1
100 CALL SAVE(NOUT, 1, NN1, NN1, A(MN), 1, AA2)
REWIND NOUT
REWIND NIN
C -- SWITCH THE TAPES
C
NT = NIN
NIN = NOUT
NOUT = NT
C -- RE-CALCULATE ROW LENGTH AND LOOP BACK
C
NEL = NEL - K
NN = NEL - M
GO TO 30
C -- REWIND ALL TAPES
C
110 REWIND MT
REWIND NIN
REWIND NOUT
C -- CONDENSE THE MATRIX
C
NN = NEL
NL = NEL + 1
IF (K .EQ. 1) GO TO 130
NS = 1
NT = NEL
DO 120 IB = 2, K
NS = NS + NELP1
NT = NT + NEL
DO 120 IO = NS, NT
A(NL) = A(IO)
120 NL = NL + 1
130 N1 = KORE - K * M + 1
C -- THERE, NOW WE CAN START THE BACK-SOLUTION
C * * NOTE..THE FIRST AVAILABLE LOCATION FOR THE SOLUTIONS IS A(N1)
C
NREM = N
NEL = NPM
LAST = K.EQ. N
NPASS = 0
C -- SOLVE FOR THE ANSWERS CORRESPONDING TO 'K' ROWS
C
140 KM1 = K - 1
KP1 = K + 1
NS = NL - MP1
NPASS = NPASS + 1
DO 170 MN = 1, M
NF = NS + MN
A(NF) = A(NF) / A(NS)
NT = NS
IF (KM1 .EQ. 0) GO TO 170
DO 160 IB = 1, KM1
NF = NF - IB - M
NT = NT - MP1 - IB
SUM = 0.0
NP = NF
N2 = MP1 + IB
DO 150 IO = 1, IB
NN = NT + IO
NP = NP + N2 - IO
150 SUM = SUM + A(NN) * A(NP)
160 A(NF) = (A(NF) - SUM) / A(NT)

```

```

170 CONTINUE
C - - MOVE THE SOLUTIONS TO CONTIGUOUS LOCATIONS STARTING AT A(N1)
C
      N1 = KORE + 1
      DO 190 NN = 1, K
      DO 180 MN = 1, M
      NL = NL - 1
      NI = NI - 1
180  A(N1) = A(NL)
190  NL = NL - NN
C - - WRITE THE SOLUTIONS ON TAPE
C
      WRITE (NIN) K
      NS = NI - 1
      DO 200 MN = 1, M
      NT = NS + MN
200  WRITE (NIN) (A(IO), IO = NT, KORE, M)
C - - TEST IF THIS IS THE LAST PASS
C
      IF (LAST) GO TO 280
C - - WE MUST NOW MODIFY THE TRIANGULAR MATRIX TO REFLECT THE EFFECT OF
C     THE SOLUTIONS OBTAINED SO FAR (EQ 21)
C * * NOTE..LOCATIONS A(1) TO A(N1-1) ARE NOW FREE TO USE
C - - CALCULATE THE NEXT VALUES OF 'NEL' AND 'NREM'
C
      NELOLD = NEL
      KOLD = K
      NEL = NEL - K
      NREM = NREM - K
C
      CALCULATE NEW K, B AND C (REAL) WILL ALWAYS BE INTEGERS.
      K WILL BE CALCULATED REAL AND TRUNCATED -- GOOD.
C
      B = 1 + 2*M
      C = 2*(KOLD*(M+1) - KORE)
      K = (-B + SQRT(B**2 - 4*C))/2.0
      NROW = NREM - K + 1
      IF (K .LT. NREM) GO TO 210
      LAST = TRUE.
      NROW = 1
      K = NREM
210  NS = 1
      NT = NELOLD + 1
C - - READ IN THE ROWS TO BE MODIFIED
C
      DO 270 IB = 1, NREM
      NT = NT - 1
      IF (IB .LE. NROW) GO TO 220
      NS = NS + NN
      NT = NT + NN
C
C*****ADDED NEXT LINE AND MODIFIED CALL, A.P. SODERMAN, 8/10/76*****
C
220  NN=NT-NS+1
      CALL GETT(MT, 2, NN, A(NS), 1, AA2)
      NP = NI - 1
      NF = NT - M - KOLD
      NM = NN - KOLD
      DO 240 MN = 1, M
      N2 = NF
      NA = NP + MN
      NB = NA
      SUM = 0.0
      DO 230 IO = 1, KOLD
      SUM = SUM + A(N2) * A(NA)
      N2 = N2 + 1
230  NA = NA + M
      N2 = N2 + MN - 1
240  A(N2) = A(N2) - SUM
C - - WRITE THE MODIFIED ROW ON TAPE OR CONDENSE THE ROW
C
      NL = NT - M + 1
      IF (IB .GE. NROW) GO TO 250
      NF = NL - KPI
      NN1 = NF - NS + 1
      NN2 = NT - NL + 1
      CALL SAVE(NOUT, 4, NN, NN1, A(NS), NN2, A(NL))
      GO TO 270
250  NF = NL - KOLD
      DO 260 MN = NL, NT
      A(NF) = A(MN)
260  NF = NF + 1
270  CONTINUE
      REWIND MT
      REWIND NOUT
C - - SWITCH THE TAPES
C
      NT = MT
      MT = NOUT
      NOUT = NT
C - - LOOP BACK THRU THE SOLUTION

```

```

NL = NF
GO TO 140
C - - START TO WRAP IT UP
C 280 REWIND NIN
N2 = N
C * * NOTE.. AT THIS POINT ALL LOCATIONS A(1) THRU A(KORE) ARE FREE
C     DO 300 IB = 1, NPASS
READ (NIN) K
N1 = N2 - K + 1
NS = N1
NT = N2
C - - READ IN THE SOLUTIONS
C     NM = NT - NS + 1
DO 290 IO = 1, M
CALL GETT(NIN, 1, NM, A(NS), 1, AA2)
290 NS = NS + N
300 N2 = N1 - 1
TR = 1
RETURN
END
SUBROUTINE SAVE(IU, IT, N, N1, A1, N2, A2)
C     DIMENSION A1(N1), A2(N2)
C     GO TO ( 10 , 20 , 30 , 40 ), IT
C WRITE A1
10 WRITE(IU) A1
RETURN
C WRITE N AND A1
20 WRITE(IU) N, A1
RETURN
C WRITE A1 AND A2
30 WRITE(IU) A1, A2
RETURN
C WRITE N, A1, AND A2
40 WRITE(IU) N, A1, A2
RETURN
END
SUBROUTINE GETT(IU, IT, N1, A1, N2, A2)
C     DIMENSION A1(N1), A2(N2)
C     GO TO ( 10 , 20 , 30 , 40 ), IT
C READ A1
10 READ(IU) A1
RETURN
C READ N1 AND A1
20 READ(IU) N1, A1
RETURN
C READ A1 AND A2
30 READ(IU) A1, A2
RETURN
C READ IDUM AND A1
40 READ(IU) IDUM, A1
RETURN
END
SUBROUTINE BAKSUB(TRANS,SUMMER,NEWMAX)
C THIS SUBROUTINE BACK SUBSTITUTES THE COEFFICIENT MATRIX AND THE
C GAMMA SOLUTION TO OBTAIN THE RIGHT SIDE MATRIX FOR THE PURPOSE OF
C CHECKING THE MATRIX SOLUTION.
C COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHNGE
COMMON/MARK/NROWS,NROWSJ,NNT,NJT,NMAX,NH(40),NJ(40),IW(40),IJ(40)
COMMON/SOLV1/GAMMA(600,10)
DIMENSION TRANS(NEWMAX),SUMMER(NEWMAX)
C     WRITE(6,10)
10 FORMAT(1H1,47X,26HBACK SUBSTITUTION SOLUTION)
C CYCLE THE RIGHT HAND SIDES
DO 60 N = 1,NCASES
IREAD = 0
FIND(1'IREAD+1)
C CYCLE THE MATRIX ROWS CORRESPONDING TO ELEMENTS ON THE WING
DO 40 I = 1,NEWMAX
C READ THE COEFFICIENT MATRIX ROW
IF(I .EQ. NWT+1) IREAD = NMAX
IREAD = IREAD + 1
20 READ(1'IREAD) TRANS
C SUM UP THE TERMS FOR THIS ROW AND RIGHT SIDE
SUMMER(I) = 0.00
DO 30 J = 1,NEWMAX
SUMMER(I) = SUMMER(I) + TRANS(J) * GAMMA(J,N)
30 CONTINUE

```

```

C 40 CONTINUE
C PRINT THE NTH RIGHT SIDE COLUMN
  WRITE(6, 50) N,SUMMER
  50 FORMAT(1H0,50X,17HRIGHT SIDE COLUMN,I4,60(/1X,10E13.5))
  60 CONTINUE
  RETURN
  END
  SUBROUTINE STAGE3
C THIS SUBROUTINE CONTROLS CALCULATION OF ALL LOADINGS FOR THE
C FUNDAMENTAL AND COMPOSITE CASES
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NRONSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/JOHN/ AREA,SPAN,ARATIO,TR,SHEEP,CREF,CMAC,CBAR,XMC,XCG
COMMON/SPIRIT/ NEWMAX,NEWCMU,NOALFA,LOGIC IR
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
  1 D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTAIL(40),TANLE(40),TANTE(40)
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
COMMON/COMPOS/FACTOR(10,24),NCC
COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)
COMMON/DERIV/U(0:40),CLQ,CMQ,CMQMC
DIMENSION CPREAD(610),CPO(600),CPA(600),CPRA(600),
  1 CPP(600)
EQUIVALENCE (BETA(1,1),CPO(1)),(BETA(1,2),CPA(1)),
  1 (BETA(1,3),CPRA(1)),(BETA(1,4),CPRA(1)),(BETA(1,5),CPP(1))
C IF(LOGIC .EQ. 3) GO TO 80
C CALCULATE AND PRINT THE LOADING FOR ALL FUNDAMENTAL CASES
  10 CALL STG3FC(NEWMAX)
  DO 30 N = 1,NCASES
  LCASE = N
  20 CALL STG3FS(CLQ,CMQ,CMQMC,DUM4,NEWMAX,NOALFA,LCASE)
  30 CONTINUE
  IF(LOGIC .EQ. 2) WRITE(6, 40) CLQ,CMQ,CMQMC
  40 FORMAT(1H0/ 26X,43HLIFT COEFFICIENT DERIVATIVE DUE TO PITCHING,
  1      17H ABOUT XCG, CLQ =,F10.6 /
  2      14X,51HPITCHING MOMENT COEFFICIENT DERIVATIVE ABOUT ORIGIN,
  3      33H DUE TO PITCHING ABOUT XCG, CMQ =,F10.6 /
  4      16X,42HPITCHING MOMENT COEFF DERIVATIVE ABOUT XMC,
  5      35H DUE TO PITCHING ABOUT XCG, CMQMC =, F10.6)
  CALL STG3FT
C CALCULATE AND PRINT THE LOADING FOR ALL COMPOSITE CASES
  IF(NCC .LT. 1) GO TO 100
  DO 60 M = 1,NCC
  MCASE = M
  50 CALL STG3C(NEWMAX,MCASE,NOALFA)
  60 CONTINUE
  70 GO TO 100
C CALCULATE AND PRINT THE COEFFICIENTS AND DERIVATIVES FOR ALL
C FUNDAMENTAL CASES
  80 CALL FUNDER(EPS,CPO,CPA,CPRA,CPP,DEL,CHORD,Y,DELTA,CMU,AREA,
  1     CLQ,CMQ,CMQMC,CLLP,CNP2,NW,IJ,NMAX,NJT,NEWMAX,NCASES,NOALFA,
  2     NROWS,ISYMM,XLEAD,TANLE,XMC)
C CALCULATE AND PRINT THE STABILITY DERIVATIVES FOR ALL COMPOSITE CASES
  90 CALL COMDER(EPS,CPO,CPA,CPRA,CPP,CPREAD,DEL,CHORD,Y,CMU,
  1     DELTA,AREA,CLQ,CMQ,CMQMC,CLLP,CNP2,NW,IJ,NMAX,NJT,NEWMAX,
  2     NCASES,NROWS,ISYMM,XLEAD,TANLE,XMC)
  100 RETURN
  END
  SUBROUTINE STG3FC(NEWMAX)
C THIS SUBROUTINE CONTROLS CALCULATION OF CHORDWISE LOADING
C FOR FUNDAMENTAL CASES
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NRONSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
  1 D(40),KK(600),ITYPE(600)
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)
COMMON/SOLV1/CP(600,10)
DIMENSION XBB(5),CPEXP(5,10)
C CALCULATE AND PRINT THE CHORDWISE LOADING OF THE FUNDAMENTAL CASES
C INITIALIZE THE UNUSED VALUES OF CP FOR PRINTING
  NC1 = NCASES + 1
  IF(NC1 .GT. 10) GO TO 30
  DO 20 N = NC1,10
  DO 10 I = 1,NEWMAX
  CP(I,N) = 0.00
  10 CONTINUE
  20 CONTINUE
  30 I = 0
  II = NWT
  DO 320 K = 1,NROWS
  IF(IPRINT .GT. 0) GO TO 70
  WRITE(6, 40)
  40 FORMAT(1H1,35X,12(4H****),1H*/
  1      36X,49H* CHORDWISE LOADING FOR ALL FUNDAMENTAL CASES */
  2      36X,12(4H****),1H*)
  WRITE(6, 50) K,Y(K),CHORD(K),(N,N=1,10)
  50 FORMAT(1H0,35X,7HSECTION,I3,5X,3HY =,F10.6,5X,7HCHORD =,F10.6/

```

```

      1      8X,1HI,5X,2HXB,3X,9(5X,4HCASE,I2),5X,4HCASE,I3)
C ON THE WING
      WRITE(6, 60 )
 60  FORMAT(1H+,4HWING)
 70  NWK = NW(K)
      DO 100 L = 1,NWK
      I = I + 1
      DO 80 N = 1,NCASES
      CP(I,N) = 2.00 * CP(I,N)
 80  CONTINUE
      IF(IPRINT .LT. 1) WRITE(6, 90 ) I,XB(I),(CP(I,N),N=1,10)
 90  FORMAT(1H ,I8,11F1.6)
100 CONTINUE
      ILINES = NWK + 4
C ON THE JET
      NJK = NJ(K)
      IF(CMU(K) .LT. 0.0001) GO TO 140
      IF(IPRINT .LT. 1) WRITE(6, 110 )
110  FORMAT(1H ,IX,3HJET)
      DO 130 L = 1,NJK
      II = II + 1
      DO 120 N = 1,NCASES
      CP(II,N) = 2.00 * CP(II,N)
120  CONTINUE
      IF(IPRINT .LT. 1) WRITE(6, 90 ) II,XB(II),(CP(II,N),N=1,10)
130  CONTINUE
      ILINES = ILINES + NJK + 1
C PRINT THE DETAILED LOADING ON THE SINGULAR ELEMENTS
C LEADING EDGE
140 IF(IPRINT .GT. 0) GO TO 320
      WRITE(6, 150 )
150  FORMAT(1H0,45X,29HDETAILED LEADING EDGE LOADING)
      IP = IW(K)
      DO 160 N = 1,NCASES
      LCASE = N
      CALL EXPLE(LCASE,CP(IP,LCASE),CP(IP+1,LCASE),DEL(IP),XBB,CPEXP)
160  CONTINUE
      DO 170 M = 1,5
      WRITE(6, 90 ) M,XBB(M),(CPEXP(M,N),N=1,NCASES)
170  CONTINUE
      ILINES = ILINES + 7
C HINGES
      IF(IHINGE .EQ. 0) GO TO 320
      J = IW(K) - 1
      DO 250 L = 1,NWK
      J = J + 1
      IF(ITYPE(J) .LT. 40) GO TO 250
      DO 180 N = 1,NCASES
      LCASE = N
      CALL EXPH1(LCASE,CP(J,N),CP(J-1,N),DEL(J-1),BETA(J,N),
1     CHORD(K),XB(J),XBB,CPEXP)
180  CONTINUE
      IF(ILINES .LT. 46) GO TO 200
      WRITE(6, 190 )
190  FORMAT(1H1)
      ILINES = 1
200  WRITE(6, 210 ) J
210  FORMAT(1H0,42X,33HDETAILED HINGE LOADING ON ELEMENT,I4)
      DO 220 M = 1,5
      WRITE(6, 90 ) M,XBB(M),(CPEXP(M,N),N=1,NCASES)
220  CONTINUE
      DO 230 N = 1,NCASES
      LCASE = N
      CALL EXPH2(LCASE,CP(J,N),CP(J+1,N),DEL(J),BETA(J,N),
1     CHORD(K),XB(J),XBB,CPEXP)
230  CONTINUE
      DO 240 M = 6,10
      WRITE(6, 90 ) M,XBB(M-5),(CPEXP(M-5,N),N=1,NCASES)
240  CONTINUE
      ILINES = ILINES + 12
250  CONTINUE
      IF((NJ(K) .EQ. 0) .OR.(CMU(K) .LT. 0.0001)) GO TO 320
      J = IW(K)
      IF(ITYPE(J) .NE. 43) GO TO 320
      DO 260 N = 1,NCASES
      LCASE = N
      II = IW(K) + NW(K) - 1
      CALL EXPH1(LCASE,CP(J,N),CP(II,N),DEL(II),BETA(J,N),
1     CHORD(K),XB(J),XBB,CPEXP)
260  CONTINUE
      IF(ILINES .LT. 46) GO TO 270
      WRITE(6, 190 )
      ILINES = 1
270  WRITE(6, 280 ) J
280  FORMAT(1H0,40X,37HDETAILED JET HINGE LOADING ON ELEMENT,I4)
      DO 290 M = 1,5
      WRITE(6, 90 ) M,XBB(M),(CPEXP(M,N),N=1,NCASES)
290  CONTINUE
      DO 300 N = 1,NCASES
      LCASE = N
      CALL EXPH2(LCASE,CP(J,N),CP(J+1,N),DEL(J),BETA(J,N),
1     CHORD(K),XB(J),XBB,CPEXP)
300  CONTINUE
      DO 310 M = 6,10
      WRITE(6, 90 ) M,XBB(M-5),(CPEXP(M-5,N),N=1,NCASES)
310  CONTINUE

```

```

      ILINES = ILINES + 12
320  CONTINUE
      RETURN
      END
      SUBROUTINE STG3FS(CLQ,CMQ,CMQMC,CLLP,NEWMAX,NOALFA,LC)
C THIS SUBROUTINE CONTROLS CALCULATION OF ALL SPANWISE AND TOTAL
C LOADING FOR FUNDAMENTAL CASES
      COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
      COMMON/MARK/NROWS,NROWSJ,NAT,NJT,NMAX,NH(40),NJ(60),TH(40),IJ(40)
      COMMON/JOHN/ AREA,SPAN,ARATIO,TR,SHEEP,CREF,CMAC,CBAR,XMC,XCG
      COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
     1 D(40),KK(600),ITYPE(600)
      COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
      COMMON/FCASE2/TST(40,10),HL(40,10),DJ(40),ACTE(40),AC(20,40),
     1 XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
      COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
      COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)
      COMMON/SOLV1/CP(600,10)
      COMMON/LOAD1/TWIST(40),HO(40),TH(40),THETS(40),
     1 BTA(600),EP(600),CPD(600)
      COMMON/LOAD2/CLG(40),CLMU(40),CL(40),CDMU(40),CDG(40),CDI(40),
     1 CS(40),CMG(40),CMU(40),CMT(40),CM(40),XBCP(40),XBCL(40)
      COMMON/LOAD3/CCLG(10),CCLJ(10),CCL(10),CCMG(10),CCMJ(10),
     1 CCMT(10),CM(10),CMGMC(10),CMJMC(10),CMTMC(10),CMCMC(10)
     2 CXCP(10),CXCL(10),CCJ(10),CDCG(10),CDCJ(10),CCS(10),CCD(10),
     3 CDITZ(10),CLLG(10),CLLJ(10),CLL(10),CNJ(10),CNI(10),CCY(10),
     4 CXCPB(10),CXCLB(10)
      COMMON/LOAD4/CLG(40),CLMU0(40),CL(40),CDMU0(40),CDG0(40),
     1 CDI0(40),CS0(40),CTO(40),CMG0(40),CMU0(40),CMT0(40),CM0(40),
     2 XBCP0(40),XBCLO(40),FACT(10)
      COMMON/LOAD5/CGAM(40),CGAM0(40),ALFINF(40),ALFINO(40),DUMB(40)
      COMMON/LOAD7/CBGR(10),CBGL(10),CBJR(10),CBJL(10),
     1 CBR(10),CBL(10),CPEMR(10),CPBML(10),CL2R(10),CL2L(10)

C 10 N = LC
C  LCASE = LC

C LOAD THOSE GEOMETRIC PARAMETERS WHICH ARE DIFFERENT FOR EACH CASE
C INTO THEIR RESPECTIVE DUMMY ARRAYS
      DO 30 K = 1, NROWS
        TWIST(K) = TST(K,LCASE)
      20 TH(IK) = THETA(K,LCASE)
        THETS(IK) = THS(K,LCASE)
        HO(K) = HL(K,LCASE)
        DU1B(K) = 0.00
      30 CONTINUE
      DO 50 I = 1, NEWMAX
        BTA(I) = BETA(I,LCASE)
        EP(I) = EPS(I,LCASE)
        CPD(I) = CP(I,LCASE)
      50 CONTINUE

C COMPUTE SECTIONAL COEFFICIENTS
      ALPHA = 0.00
      IF((LCASE .EQ. 1) .AND. (NOALFA .NE. 0)) ALPHA = 1.00
      60 CALL SLOAD(ALPHA,IJ,NH,NJ,CHORD,CMU,TH,THETS,TWIST,
     1 XB,DEL,BTA,EP,CPD,CL,CLG,CLMU,CM,CMG,CMU,CMT,XBCP,XBCL,
     2 CDI,CDMU,CDG,CS,CTO,NROWS,IHINGE)

C COMPUTE SECTIONAL VORTICITY OF WING-JET SYSTEM
      CALL SLOADG(CPD,DEL,BTA,CHORD,D,CMU,NJ,IJ,CLG,CGAM,NROWS,IHINGE)

C COMPUTE SECTIONAL DOWNWASH AT INFINITY
      70 CALL TREFTZ(Y,DELTA,CMU,CGAM,ALFINF,NROWS,ISYMM)

C COMPUTE TOTAL LINEAR COEFFICIENTS
      80 CALL TLOAD(ALPHA,AREA,CREF,XMC,Y,DELTA,CHORD,HO,XB,XLEAD,BTA,
     1 CLG,CLMU,CMG,CMU,CMT,CMU,CCLG(N),CCL(N),CCMG(N),
     2 CCMJ(N),CCMT(N),CMJ(N),CMGMC(N),CMJMC(N),CMTMC(N),CMCMC(N),
     3 CXCP(N),CXCL(N),CXCPB(N),CXCLB(N),CCJ(N),CLLG(N),CLLJ(N),
     4 CLL(N),ITYPE,IH,NH,NROWS,ISYMM,
     5 CBGR(N),CBGL(N),CBJR(N),CBJL(N),CBR(N),CBL(N),
     6 CPBML(N),CPBML1(N),CL2R(N),CL2L(N))

C COMPUTE TOTAL NONLINEAR COEFFICIENTS
      90 CALL TLOADX(AREA,CHORD,DELTA,Y,CMU,CDG,CDMU,CS,CDI,CL,DUMB,
     1 CCDCG(N),CCDJ(N),CCS(N),CCDI(N),CDITZ(N),DUMB,ALFINF,DUMMY,CCJ(1),
     2 CNJ(N),CNI(N),CCY(N),XLEAD,TANLE,XMC,NROWS,ISYMM)

C DEFINE THE CONSTANT STABILITY DERIVATIVES
      CLQ = CCLG(NCASES)
      CMQ = CCMG(NCASES)
      CMQMC = CMGMC(NCASES)
      CLLP = CLLG(NCASES)

C PRINT LIFT AND DRAG COEFFICIENTS
      IF(IPRINT .GT. 1) RETURN
      WRITE(6, 100) LCASE
100  FORMAT(1H1,36X,11(4H****),2H**/37X,23H* SPANWISE LOADING FOR,
     1 17H FUNDAMENTAL CASE,I3,3H */37X,11(4H****),2H**)
      WRITE(6, 110)
110  FORMAT(1H ,19X,29H          LIFT
     1 2H .7(4H...),14H INDUCED DRAG .8(4H...),5X,
     2 1X, 7HSECTION, 5X,1HY,8X,3HCLG,7X,4HCLMU,6X,2HCL,5X,
     3 4H * ,3X,3HCDG,8X,4HCDMU,7X,2HCS,9X,2HCD,9X,3HCMU,
     4 8X,5HGAMMA,6X,5HALFIN)
      WRITE(6, 120) (K,Y(K),CLG(K),CLMU(K),CL(K),CDG(K),CDMU(K),
     1 CS(K),CDI(K),CMU(K),CGAM(K),ALFINF(K),K=1,NROWS)
120  FORMAT(1H ,I4, 4X, 4F10.6, 4H * ,7F11.7)

```

```

      WRITE(6, 130) CCLG(N),CCLJ(N),CCL(N),CCDG(N),CCDJ(N),CCS(N),
1      CCI(N),CCJ(N),COITZ(N)
130 FORMAT(1H, 8X, 4(10H -----),4H * ,7(11H -----)/
1      12X,5HTOTAL,2X,3F10.6,4H * ,5F11.7,11X,F11.7)
C PRINT PITCHING MOMENT AND CENTER OF LIFT DATA
140 IF(NROWS .GT. 21) WRITE(6, 140)
140 FORMAT(1H1)
140 WRITE(6, 150)
150 FORMAT(1H0,24X,39H
1      20H LIFT CENTER... PITCHING MOMENT .....,10X,
1      6X, 7HSECTION,5X,1HY,8X,3HCMG,7X,4HCMMU,6X,3HCMT,7X,2HCM,
1      5X,10H * * * 3X,5HXCP/C 5X,5HXCL/C)
1      WRITE(6, 160) (K,Y(K),CMG(K),CMMU(K),CMT(K),CM(K),XBCP(K),XBCL(K)
1      K=1,NROWS)
160 FORMAT(1H,10,4X,5F10.6,10H * * * ,2F10.6)
160 WRITE(6, 170) CCMG(N),CCMJ(N),CCMT(N),CCM(N),CXCP(N),CXCL(N),
1      CMGC(N),CMJMC(N),CMTMC(N),CMMC(N),CXCPB(N),CXCLB(N)
170 FORMAT(1H,13X,5(10H -----),10H * * * ,2(10H -----)/
1      17X,5HTOTAL,2X, 4F10.6, 10H (APEX) ,2F10.6,9H (X/CREF)/
2      24X,4F10.6,10H (XMC) ,2F10.6,8H (X/B/2))
1      RETURN
1      ENO
1      SUBROUTINE STG3FT
C THIS SUBROUTINE PRINTS A TABLE OF ALL TOTAL COEFFICIENTS
C FOR ALL FUNDAMENTAL COSES
C
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/LDA03/ CCLG(10),CCLJ(10),CCL(10),CCDG(10),CCDJ(10),
1      CCM(10),CCM(10),CMG(10),CMJMC(10),CMTMC(10),CMMC(10),
2      CXCP(10),CXCL(10),CCJ(10),CCDG(10),CCS(10),CCDI(10),
3      CDITZ(10),CLLG(10),CLLJ(10),CLL(10),CNJ(10),CNI(10),CCY(10),
4      CXCPB(10),CXCLB(10)
CHARACTER*8 COEFF(35)
COMMON/LDA06/COEFF
COMMON/LDA07/CBGR(10),CBGL(10),CBJR(10),CBJL(10),
1      CBR(10),CBL(10),CPBMR(10),CPBML(10),CL2R(10),CL2L(10)
C INITIALIZE ALL UNUSED TOTAL COEFFICIENTS TO ZERO FOR PRINTING
1      IF(NCASES .EQ. 10) GO TO 20
1      NC1 = NCASES + 1
1      DO 10 N = NC1,10
1      CCLG(N) = 0.00
1      CCLJ(N) = 0.00
1      CCL(N) = 0.00
1      CCOG(N) = 0.00
1      CCOJ(N) = 0.00
1      CCS(N) = 0.00
1      CCOI(N) = 0.00
1      CDITZ(N) = 0.00
1      CCJ(N) = 0.00
1      CCMG(N) = 0.00
1      CCMJ(N) = 0.00
1      CCMT(N) = 0.00
1      CCM(N) = 0.00
1      CXCP(N) = 0.00
1      CXCL(N) = 0.00
1      CXCPB(N) = 0.00
1      CXCLB(N) = 0.00
1      CMGC(N) = 0.00
1      CMJMC(N) = 0.00
1      CMTMC(N) = 0.00
1      CMMC(N) = 0.00
1      CLLG(N) = 0.00
1      CLLJ(N) = 0.00
1      CLL(N) = 0.00
1      CNJ(N) = 0.00
1      CNI(N) = 0.00
1      CCY(N) = 0.00
1      CBGR(N) = 0.00
1      CBGL(N) = 0.00
1      CBJR(N) = 0.00
1      CBJL(N) = 0.00
1      CBR(N) = 0.00
1      CBL(N) = 0.00
1      CPBMR(N) = 0.00
1      CPBML(N) = 0.00
10 CONTINUE
10      WRITE(6, 30) (N,N=1,10)
30 FORMAT(1H1,41X,8(4H****)/
1      42X,36H* TOTAL AERODYNAMIC COEFFICIENTS * /42X,9(4H****)//)
1      14X,9(4HCASE,I2,5X), 4HCASE,I3)
40 FORMAT(1H0, 2X,A8,10F11.7,34(/3X,A8,10F11.7))
40 WRITE(6, 40) COEFF( 1), CCLG, COEFF( 2), CCLJ, COEFF( 3), CCL,
1      COEFF( 4), CCDG, COEFF( 5), CCOJ, COEFF( 6), CCS,
2      COEFF( 7), CCDI, COEFF( 8), CDITZ, COEFF( 9), CCJ,
3      COEFF(10), CCMG, COEFF(11), CCMJ, COEFF(12), CCMT,
4      COEFF(13), CCM, COEFF(14), CXCP, COEFF(15), CXCL,
5      COEFF(16), CXCPB, COEFF(17), CXCLB, COEFF(18), CMGMC,
6      COEFF(19), CMJMC, COEFF(20), CMTMC, COEFF(21), CMMC,
7      COEFF(22), CLLG, COEFF(23), CLLJ, COEFF(24), CLL,
8      COEFF(25), CNJ, COEFF(26), CNI, COEFF(27), CCY,
9      COEFF(28), CBGR, COEFF(29), CBGL, COEFF(30), CBJR,
0      COEFF(31), CBJL, COEFF(32), CBR, COEFF(33), CBL,
1      COEFF(34), CPBMR, COEFF(35), CPBML
C
1      50 RETURN
1      END
1      SUBROUTINE STG3C(NEWMAX,M,NOALFA)

```

```

C THIS SUBROUTINE CONTROLS CALCULATION OF CHORDWISE, SPANWISE AND
C TOTAL LOADING FOR THE REQUIRED COMPOSITE CASES
C
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NNJ(40),NJ(40),IW(40),IJ(40)
COMMON/JOHN/ AREA,SPAN,ARATIO,TR,SWEET,CREF,CMAC,CBAR,XMC,XCG
COMMON/GEOM1/Y(40),CHORD1(40),DELTAL(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
COMMON/FCASE2/TST(40,10),HL(40,10),DJ(40),ACTE(40),AC(20,40),
1 XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
COMMON/JCASE/CMJ(40),CMJP(40),CMUPP(40)
COMMON/SOLV1/CP(600,10)
COMMON/COMPOS/FACTOR(10,24),NCC
COMMON/LOAD1/TWIST(40),HO(40),TH(40),THETS(40),
1 BTA(600),EP(600),CP0(600)
COMMON/LOAD2/ CLG(40),CLMU(40),CL(40),COMU(40),COG(40),COI(40),
1 CS(40),CMG(40),CMU(40),CMT(40),CM(40),XBCP(40),XBCL(40)
COMMON/LOAD3/ CCLG(10),CCLJ(10),CCL(10),CCMG(10),CCMJ(10),
1 CCMT(10),CMC(10),CMGMC(10),CMJMC(10),CMTMC(10),CMMC(10),
2 CXCP(10),CXCL(10),CCJ(10),CCDG(10),CCDJ(10),CCS(10),CCOI(10),
3 CDITZ(10),CLLG(10),CLLJ(10),CLL(10),CNJ(10),CNI(10),CCY(10),
4 CXCPB(10),CXCLB(10)
COMMON/LOAD4/ CLGO(40),CLMU(40),CL0(40),COMUO(40),CDGO(40),
1 CDIO(40),CSO(40),CT0(40),CMG0(40),CMUO(40),CMT0(40),CM0(40),
2 XBCP0(40),XBCL0(40),FACT(10)
COMMON/LOAD5/ CGAM(40),CGAO(40),ALFINF(40),ALFINO(40),OUMB(40)
CHARACTER*8 COEFF(35)
COMMON/LOAD6/COEFF
COMMON/LOAD7/CBGR(10),CBGL(10),CBJR(10),CBJL(10),
1 CBR(10),CBL(10),CPBMR(10),CPBML(10),CL2R(10),CL2L(10)
DIMENSION CMUX(40),CDGX(40),CDIX(40),CSX(40),CPA(600)
EQUIVALENCE (CP(1,1),CPA(1))

C CALCULATE AND PRINT THE CHORDWISE LOADING FOR ALL COMPOSITE CASES
C
I = 0
II = NWT
ILINES = 6
WRITE(6,10) M
10 FORMAT(1H1,36X,11(4H****),1H*/
1 37X,39H CHORDWISE LOADING FOR COMPOSITE CASE,I3,3H */
2 37X,11(4H****),1H*)
WRITE(6,20) (N,N=1,10), (FACTOR(N,M),N=1,10)
20 FORMAT(1H,48X,24HFUNDAMENTAL CASE FACTORS/10X,9(5X,2HA(,I1,1H),
1 3X),5X,2HA(,,2,1H)/10X,10F12.6)
WRITE(6,25)
25 FORMAT(1H0,7X,47H*** NOTE *** EACH LEADING EDGE CP VALUE IS THE,
1 43H AVERAGE VALUE OF THE SINGULAR DISTRIBUTION)
IF(IHINGE .NE. 0) WRITE(6,26)
26 FORMAT(1H,21X,47H IF A HINGE IS DEFLECTED THE LOADING IS SINGULAR,
1 58H AND THE CP(A=0) VALUE IS FOR THE REGULAR EVO PORTION ONLY)
WRITE(6,27)
27 FORMAT(1H,21X,41H DO NOT PLOT THESE LOADING POINTS DIRECTLY)
OO 190 K = 1,NROWS

C ON THE WING
NWK = NW(K)
DO 50 L = 1,NWK
I = I + 1
30 CP0(I) = 0.00
DO 40 N = 1,NCASES
FACT(N) = FACTOR(N,M)
CP0(I) = CP0(I) + CP(I,N) * FACT(N)
40 CONTINUE
50 CONTINUE
NC1 = NCASES + 1
IF(NC1 .GT. 10) GO TO 70
DO 60 N = NC1,10
FACT(N) = 0.00
60 CONTINUE
70 J1 = IH(K)
J2 = IW(K) + NWK - 1
NEXT = 3 + (2+NOALFA) * (NWK/10+1)
IF(CMJK(K) .GT. 0.0) NEXT = NEXT + (2+NOALFA) * (NJ(K)/10+1) + 1
ILINES = ILINES + NEXT
IF((ILINES .LT. 56) .OR. (K .EQ. 1)) GO TO 90
WRITE(6,80)
80 FORMAT(1H1)
ILINES = 1
90 WRITE(6,100) K,Y(K),CHORD(K)
100 FORMAT(1H0,35X,7HSECTION,I3,5X,3HY =,F10.6,5X,7HCHORD =,F10.6/
1 2X,4HINGE)
WRITE(6,110) (XB(J),J=J1,J2)
110 FORMAT(1H,7X,2HXB,10F12.6,3(/10X,10F12.6))
WRITE(6,120) (CP0(J),J=J1,J2)
120 FORMAT(1H ,2X, 7HCP(A=0),10F12.6,3(/10X,10F12.6))
IF(NOALFA .GT. 0) WRITE(6,130) (CPA(J),J=J1,J2)
130 FORMAT(1H ,2X, 7HCP(A=1),10F12.6,3(/10X,10F12.6))

C ON THE JET
NJK = NJ(K)
IF(CMU(K) .LT. 0.0001) GO TO 190
OO 160 L = 1,NJK
II = II + 1
140 CP0(II) = 0.00
DO 150 N = 1,NCASES
CP0(II) = CP0(II) + CP(II,N) * FACT(N)
150 CONTINUE
160 CONTINUE

```

```

170 J1 = IJ(K)
171 J2 = IJ(K) + NJK - 1
172 WRITE(6, 180)
173 FORMAT(1H ,4H JET)
174 WRITE(6, 110 ) (XB(J),J=J1,J2)
175 WRITE(6, 120 ) (CPO(J),J=J1,J2)
176 IF(NOALFA .GT. 0) WRITE(6, 130 ) (CPA(J),J=J1,J2)
177 CONTINUE
C COMPUTE AND PRINT SPANWISE AND TOTAL LOADINGS FOR EACH COMPOSITE CASE
C DEFINE THE FUNDAMENTAL CASE VARIABLES FOR ALPHA = 1
178 IF(NOALFA .EQ. 0) GO TO 250
179 DO 210 K = 1,NROWS
200 TWIST(K) = TST(K,1)
201 TH(K) = THETA(K,1)
202 THETS(K) = THS(K,1)
210 CONTINUE
DO 230 I = 1,NEWMAX
220 BTA(I) = BETA(I,1)
221 EP(I) = EPS(I,1)
230 CONTINUE
C COMPUTE SECTIONAL COEFFICIENTS FOR ALPHA = 1
231 ALPHA = 1.0
240 CALL SLOAD(1,ALPHA,IJ,NW,NJ,CHORD,CMU,TH,THETS,TWIST,
241 XB,DEL,BTA,EP,CPA,CL,GLG,C1MU,CM,CMG,CMMU,CMT,XBCP,XBCL,
242 CDI,CDMU,CDG,CS,CTO,NROWS,IHINGE)
C COMPUTE SECTIONAL VORTICITY FOR ALPHA = 1
243 CALL SLOADG(CPA,DEL,BTA,CHORD,D,CMU,NJ,IJ,GLG,CGAM,NROWS,IHINGE)
C COMPUTE SECTIONAL DOWNWASH AT INFINITY FOR ALPHA = 1
244 CALL TREFTZ(Y,DELTA,CMU,CGAM,ALFINF,NROWS,ISYMM)
C MODULATE AND SUM THE FUNDAMENTAL CASE VARIABLES FOR ALPHA = 0
250 DO 280 K = 1,NROWS
251 THIST(K) = 0.00
252 TH(K) = 0.00
253 THETS(K) = 0.00
254 HO(K) = 0.00
DO 270 N = 1,NCASES
255 TWIST(K) = TWIST(K) + TST(K,N) * FACT(N)
256 TH(K) = TH(K) + THETA(K,N) * FACT(N)
257 THETS(K) = THETS(K) + THS(K,N) * FACT(N)
258 HO(K) = HO(K) + HL(K,N) * FACT(N)
270 CONTINUE
280 CONTINUE
DO 320 I = 1,NEWMAX
281 BTA(I) = 0.00
282 EP(I) = 0.00
DO 310 N = 1,NCASES
300 BTA(I) = BTA(I) + BETA(I,N) * FACT(N)
301 EP(I) = EP(I) + EPS(I,N) * FACT(N)
310 CONTINUE
320 CONTINUE
C COMPUTE SECTIONAL COEFFICIENTS FOR ALPHA = 0
321 ALPHA = 0.00
322 IF(NOALFA .GT. 0) ALPHA = FACT(1)
330 CALL SLOAD(1,ALPHA,IJ,NW,NJ,CHORD,CMU,TH,THETS,TWIST,
331 XB,DEL,BTA,EP,CP0,CL0,GLG0,CLM0,CM0,CMG0,CMM0,CMT0,
332 XBCP0,XBCL0,CDI0,CDMU0,CDG0,CS0,CT0,NROWS,IHINGE)
C COMPUTE SECTIONAL VORTICITY FOR ALPHA = 0
340 CALL SLOADG(CP0,DEL,BTA,CHORD,D,CMU,NJ,IJ,GLG0,CGAM0,NROWS,IHINGE)
C COMPUTE SECTIONAL DOWNWASH AT INFINITY FOR ALPHA = 0
350 CALL TREFTZ(Y,DELTA,CMU,CGAM0,ALFIN0,NROWS,ISYMM)
C COMPUTE SECTIONAL NONLINEAR CROSS-PRODUCT COEFFICIENTS
351 IF(NOALFA .EQ. 0) GO TO 370
360 CALL TLOADDX(CPA,CPG,DEL,EP,CMU,TH,NW,NJ,IJ,
361 CLG0,CDGX,CDI0,XCSX,CDIX,NROWS)
C COMPUTE TOTAL LINEAR COEFFICIENTS FOR ALPHA = 0
370 CALL TLOAD(1,CREF,CCLG,CCLJ,CCMG,CCMJ,CCHT,CCMGC,CCMJC,CCMTMC,
371 CLLG,CLLJ,FACT,CCLG0,CCLJ0,CCL0,CCMG0,CCMJ0,CCHT0,CCM0,
372 CMG0,CMJ0,CCMTMC0,CM10,CXCP0,CXCL0,CXCPB0,CXLB0,
373 CLLG0,CLLJ0,CLL0,NCASES,ISYMM1,
374 CBGR,CBGL,CBJR,CBBL,CBL,CPBMR,CPBML,CL2R,CL2L,
375 CBGR0,CBGL0,CBJR0,CBBL0,CBL0,CPBMR0,CPBML0,CL2R0,CL2L0)
C COMPUTE TOTAL NONLINEAR COEFFICIENTS FOR ALPHA = 0
380 CALL TLOADX(1,AREA,CHORD,DELTA,Y,CMU,CDGX,CDMUX,CSX,CDIX,CL,CL0,
381 CCDG0,CCDJ0,CCSO,CCDIO,CDITZ0,DUMB,ALFIN0,CCT0,CCJ(1),
382 DUMMY,CN10,CCY0,XLEAD,TANLE,XMC,NROWS,ISYMM)
C COMPUTE TOTAL NONLINEAR CROSS-PRODUCT COEFFICIENTS
383 IF(NOALFA .EQ. 0) GO TO 400
390 CALL TLOADX(1,AREA,CHORD,DELTA,Y,CMU,CDGX,CDMUX,CSX,CDIX,CL,CL0,
391 CCDG0,CCDJX,CCSX,CCDIX,CDITZ0,ALFIN0,ALFIN0,DUMMY,CCJ(1),
392 DUMMY,CN1X,CCYX,XLEAD,TANLE,XMC,NROWS,ISYMM)
C PRINT THE SECTIONAL AND TOTAL COEFFICIENTS
400 WRITE(6, 410 ) M
410 FORMAT(1H1,47X,6(4H****)/48X,18H* COMPOSITE CASE,I3,3H */
411 1          48X,6(4H****))
412 WRITE(6, 420 ) (N,N=1,10),(FACT(N),N=1,10)
420 FORMAT(1H ,48X,24HFUNDAMENTAL CASE FACTORS/10X,9(4X,2HA(,I1,1H),

```

```

1      WRITE(6, 430)
430 FORMAT(1H, 3X, 2HA(,I2,1H)/10X,10F10.6/)
1      LIFT.....,11H * * *,  

1      3H.....PITCHING MOMENT.....,10H * * *,  

1      20H.....(IFT CENTER / 2X,7HSÉCTION,EX,1HY,8X,4HCLG0,6X,  

1      5HCLM0,5X,3HCL0,4X,10H * * *,3X,4HCMG0,6X,5HCMU0,5X,  

1      4HCMTO,6X,3HCM0,4X,10H * * *,3X,6HXCP0/C,4X,6HXCL0/C)
1      IF(NOALFA .GT. 0) WRITE(6, 440)
440 FORMAT(1H  

1      22X,4HCLGA,6X,5HCLMUA,5X,3HCLA,4X,10H * * *,3X,4HCMGA,  

1      6X,5HCMU0,5X,4HCMTA,6X,3HCMCA,4X,10H * * *,3X,6HXCPA/C,  

1      4X,6HXCLA/C)  

1      DO 470 K = 1,NROWS  

1      WRITE(6, 450 ) K,Y(K),CLGO(K),CLMU0(K),CLO(K),CMGO(K),CMMU0(K),  

1      CMT0(K),CM0(K),XBCP0(K),XBCL0(K)
450 FORMAT(1H, I5,4X,4F10.6,10H * *,4F10.6,10H * *,2F10.6)
1      IF(NOALFA .GT. 0) WRITE(6, 460 ) CLG(K),CLMU(K),CLC(K),  

1      CMG(K),CMMU(K),CMT(K),CM(K),XBCP(K),XBCL(K)
460 FORMAT(1H, 19X,3F10.6,10H * *,4F10.6,10H * *,2F10.6)
470 CONTINUE  

1      WRITE(6, 480 ) CCLG0,CCLJ0,CCL0,CCMG0,CCMJO,CCMTO,CXCP0,CXCL0
480 FORMAT(1H, 9X,4(10H -----),10H * *,4(10H -----),  

1      10H * *,2(10H -----)/13X,5HTOTAL,2X,3F10.6,  

1      2 10H * *,4F10.6,10H (APEX),2F10.6)
1      IF(NOALFA .GT. 0) WRITE(6, 490 ) CCLG(1),CLC(1),CCL(1),  

1      CCMG(1),CCM(1),CCMT(1),CCM(1),CXCP(1),CXCL(1)
490 FORMAT(1H, 19X,3F10.6,  

1      10H * *,4F10.6,10H (APEX),2F10.6)
1      WRITE(6, 500 ) CMGMC0,CMJMC0,CMTMC0,CMMCO,CXCPB0,CXCLB0
500 FORMAT(1H,49X,  

1      10H * *,4F10.6,10H (XMC) ,2F10.6)
1      IF(NOALFA .GT. 0) WRITE(6, 510 )
1      CMGMC(1),CMJMC(1),CMTMC(1),CMMC(1),CXCPB(1),CXCLB(1)
510 FORMAT(1H,49X,10H * *,4F10.6,10H (XMC) ,2F10.6)
1      WRITE(6, 520 )
520 FORMAT(1H,25X,9(4H...),15H INDUCED DRAG,9(4H...)/  

1      7X,7HSÉCTION,6X,1HY,7X,4HCDG0,7X,5HCDM0,6X,3HCS0,8X,3HCD0,  

1      2 8X,6HGAMMA0,5X,HALFINA0,5X,3HCT0,8X,3HCMU)
1      IF(NOALFA .GT. 0) WRITE(6, 530 )
530 FORMAT(1H,27X,4HCDGX,7X,5HCDMUX,6X,3HCSX,8X,3HCDX/  

1      28X,5HCDGA2,6X,6HCDMUA2,5X,4HCSA2,7X,4HCDA2,7X,6HGAMMA2,  

1      5X,6HALFINA)
1      DO 560 K = 1,NROWS  

1      WRITE(6, 540 ) K,Y(K),CDGO(K),CDMU0(K),CSO(K),CDIO(K),  

1      CGAMO(K),ALFINO(K),CTO(K),CMU(K)
540 FORMAT(1H, 6X,I4,4X,F10.6,8F11.7)
1      IF(NOALFA .GT. 0) WRITE(6, 550 )
1      CDGX(K),CCDMUX(K),CSX(K),CDIX(K),CDG(K),CDMU(K),CS(K),  

1      CDI(K),CGAMIK),ALFINF(K)
550 FORMAT(1H,24X,4F11.7/25X,6F11.7)
560 CONTINUE  

1      WRITE(6, 570 ) CCDG0,CCDJ0,CCSO,CCDIO,CDITZ0,CCT0,CCJ(1)
570 FORMAT(1H,24X,8(1H -----)/18X,5HTOTAL,2X,4F11.7,11X,3F11.7)
1      IF(NOALFA .GT. 0) WRITE(6, 580 ) CCDGX,  

1      CCDJX,CCSX,CCDIX,CDITZ,CCDG(1),CCDJ(1),CCS(1),CCDI(1),CDITZ(1)
580 FORMAT(1H,24X,4F11.7,11X,F11.7/25X,4F11.7,11X,F11.7)

C PRINT A TABLE OF ALL TOTAL COEFFICIENTS FOR ALPHA = 0,ALPHA,ALPHA**2
C
1      WRITE(6, 590 )
590 FORMAT(1H1,41X,9(4H****)/42X,20H* TOTAL AERODYNAMIC,  

1      16H COEFICIENTS * /42X,9(4H****)/  

1      42X,7HALPHA=0, 8X, SHALPHA,10X, 8HALPHA**2)
1      IF(NOALFA .GT. 0) GO TO 630
600 FORMAT(1H,25X,A8,F15.7)
1      WRITE(6, 600 ) COEFF( 1),CCLG0,COEFF( 2),CCLJ0,COEFF( 3),CCL0,  

1      COEFF( 4),CCDG0,COEFF( 5),CCDJ0,COEFF( 6),CCS0,  

1      COEFF( 7),CCDIO,COEFF( 8),CDITZ0,COEFF( 9),CCJ(1),  

1      COEFF(10),CCMGO,COEFF(11),CCMJO,COEFF(12),CMT0,  

1      COEFF(13),CCMO,COEFF(14),CXCP0,COEFF(15),CXCL0,  

1      COEFF(16),CXCPB,COEFF(17),CXCLB,COEFF(18),CMGMC0,  

1      COEFF(19),CMJMC0,COEFF(20),CMTMC0,COEFF(21),CMMCO,  

1      COEFF(22),CLLG0,COEFF(23),CLLJ0,COEFF(24),CLL0,  

1      COEFF(25),CNJ(1),COEFF(26),CNIO,COEFF(27),CCY0,  

1      COEFF(28),CBGR0,COEFF(29),CBGL0,COEFF(30),CBJR0,  

1      COEFF(31),CBLJ0,COEFF(32),CBRO,COEFF(33),CBLO,  

1      COEFF(34),CPBMRO,COEFF(35),CPBML0

C RETURN
C
610 FORMAT(1H ,25X,A8,3F15.6)
620 FORMAT(1H ,25X,A8,1X,3F15.7)
630 WRITE(6, 610 ) COEFF( 1),CCLG0,CCLG(1)
1      WRITE(6, 610 ) COEFF( 2),CCLJ0,CCL(1)
1      WRITE(6, 610 ) COEFF( 3),CCL0,CCL(1)
1      WRITE(6, 620 ) COEFF( 4),CCDG0,CCDGX,CCDG(1)
1      WRITE(6, 620 ) COEFF( 5),CCDJO,CCDJX,CCDJ(1)
1      WRITE(6, 620 ) COEFF( 6),CCSO,CCSX,CCS(1)
1      WRITE(6, 620 ) COEFF( 7),CCDIO,CCDIX,CCDI(1)
1      WRITE(6, 620 ) COEFF( 8),CDITZ0,CDITZ,CDITZ(1)
1      WRITE(6, 620 ) COEFF( 9),CCJ(1)
1      WRITE(6, 610 ) COEFF(10),CCMGO,CCMGS(1)
1      WRITE(6, 610 ) COEFF(11),CCMJO,CCMJ(1)
1      WRITE(6, 610 ) COEFF(12),CCMTO,CMT(1)
1      WRITE(6, 610 ) COEFF(13),CCMO,CMM(1)
1      WRITE(6, 610 ) COEFF(14),CXCP0,CXCP(1)
1      WRITE(6, 610 ) COEFF(15),CXCL0,CXCL(1)
1      WRITE(6, 610 ) COEFF(16),CXCPB0,CXCPB(1)
1      WRITE(6, 610 ) COEFF(17),CXCLB0,CXCLB(1)
1      WRITE(6, 610 ) COEFF(18),CMGMC0,CMGMC(1)
1      WRITE(6, 610 ) COEFF(19),CMJMC0,CMJMC(1)
1      WRITE(6, 610 ) COEFF(20),CMTMC0,CMTMC(1)

```

```

      WRITE(6, 610 )COEFF(21), CMMCO,CMMC(1)
      WRITE(6, 610 )COEFF(22), CLLGO,CLLG(1)
      WRITE(6, 610 )COEFF(23), CLLJO,CLLJ(1)
      WRITE(6, 610 )COEFF(24), CLLO,CLL(1)
      WRITE(6, 610 )COEFF(25), CNJ(1)
      WRITE(6, 610 )COEFF(26), CNIO,CNIX,CNI(1)
      WRITE(6, 610 )COEFF(27), CCY0,CCYX,CCY(1)
      WRITE(6, 610 )COEFF(28), CBGR0, CBGR(1)
      WRITE(6, 610 )COEFF(29), CBGL0, CBGL(1)
      WRITE(6, 610 )COEFF(30), CBJR0, CBJR(1)
      WRITE(6, 610 )COEFF(31), CBJL0, CBJL(1)
      WRITE(6, 610 )COEFF(32), CBR0, CBR(1)
      WRITE(6, 610 )COEFF(33), CBL0, CBL(1)
      WRITE(6, 610 )COEFF(34), CPBMRO, CPBMR(1)
      WRITE(6, 610 )COEFF(35), CPBML0, CPBML(1)

C COMPUTE AND PRINT A TABLE OF THE VARIATION OF THE TOTAL COEFFICIENTS
C WITH ANGLE OF ATTACK
 640 CALL TABLE(CCL0,CCL(1),CMMCO,CMMC(1),CLLG,CLL(1),CDITZ0,CDITZX,
 1           CDITZ(1),CCJ(1),CNIO,CNIX,CNI(1),CNJ(1),
 2           CCY0,CCYX,CCY(1),M)
C
C RETURN
END
BLOCK DATA
CHARACTER*8 COEFF(35)
COMMON/LOAD6/COEFF
DATA COEFF/   CCLG,    CCLJ,    ** CCL,    CCDG,    CCDJ,
 1       CCS,     CCD,    ** CDITZ,   ** CCJ,    CCMG,
 2       CCMJ,    CCMT,    CCM,     CXCP,    CXCL,
 3       CXCPB,   CXCLB,   CCMGMC,  CCMJMC,  CCMTC,
 4       ** CMMC,   CLLG,    CLLJ,    * CLL,    CNJ,
 5       * CNMC,    CCY,     CBL,    CBJR,    CBJL,
 6       CBGR,    CBGL,    CBL,    CPBMRO,  CPBML,
 7       CBR,     CBL,    CPBMR,   CPBML/
END
SUBROUTINE EXPLE(LCASE,CPI,CPI1,DEL,XBB,CPEXP)
C THIS SUBROUTINE COMPUTES THE CP VALUE OF A LEADING EDGE EVD
C AT 5 INTERMEDIATE POINTS ON THE ELEMENT
C
C DIMENSION XBB(5),CPEXP(5,10)
C
 10 DN = 0.20
  DO 40 N = 1,5
 20 X = DN * N
  XBB(N) = X * DEL
 30 CPEXP(N,LCASE) = 0.666666*CPI*(1.0/SQRT(X)-X) + CPI1*X
 40 CONTINUE
  RETURN
END
SUBROUTINE EXPH1(LCASE,CPI,CPI1,DEL,BTA,C,XB,XBB,CPEXP)
C THIS SUBROUTINE COMPUTES THE CP VALUE OF THE FORWARD HALF OF A HINGE
C EVD AT 5 INTERMEDIATE POINTS ON THE ELEMENT
C
C DIMENSION XBB(5),CPEXP(5,10)
C
  DN = 0.20
  DO 30 N = 1,5
 10 X = XB - DEL + (N-1)*DN*DEL
  DX = X - XB
  XBB(N) = X
 20 CPEXP(N,LCASE) = -1.273240*BTA/57.295779*(ALOG(-C*DX)
 1      + ALOG(C*DEL)*DX/DEL) + (CPI + (CPI-CPI1)*DX/DEL)
 30 CONTINUE
  RETURN
END
SUBROUTINE EXPH2(LCASE,CPI,CPI1,DEL,BTA,C,XB,XBB,CPEXP)
C THIS SUBROUTINE COMPUTES THE CP VALUE OF THE REAR HALF OF A HINGE
C EVD AT 5 INTERMEDIATE POINTS ON THE ELEMENT
C
C DIMENSION XBB(5),CPEXP(5,10)
C
  DN = 0.20
  DO 30 N = 1,5
 10 DX = N*DN*DEL
  X = XB + DX
  XBB(N) = X
 20 CPEXP(N,LCASE) = -1.273240*BTA/57.295779*(ALOG(C*DX)
 1      - ALOG(C*DEL)*DX/DEL) + (CPI - (CPI-CPI1)*DX/DEL)
 30 CONTINUE
  RETURN
END
SUBROUTINE SLOAD(ALPHA,IJ,NW,NJ,CHORD,CMU,THETA,THETAS,TST,
 1   XB,DEL,BETA,EPS,CP,CL,CLG,CLMU,CM,CMG,CMMU,CMT,XBCP,XBCL,
 2   CDI,CDMU,CDG,CS,CT,NROWS,IHINGE)
C THIS SUBROUTINE COMPUTES THE SPANWISE VARIATION OF LIFT, PITCHING
C MOMENT, AND INDUCED DRAG FOR EITHER A FUNDAMENTAL OR A COMPOSITE CASE
C
C DIMENSION IJ(40),NW(40),NJ(40)
C DIMENSION CHORD(40),CMU(40),THETA(40),THETAS(40),TST(40)
C DIMENSION CP(600),XB(600),DEL(600),BETA(600),EPS(600)
C DIMENSION CLG(40),CLMU(40),CL(40),CMG(40),CMMU(40),CMT(40),CM(40),
 1   XBCP(40),XBCL(40),CDG(40),CDMU(40),CS(40),CDI(40),CT(40)
C
C INTEGRATE THE CHORDWISE PRESSURES FOR EACH SPANWISE SECTION
 10 I = 0
  IF(IHINGE .GT. 1) IHINGE = 1

```

```

      DO 150 K = 1,NROWS
C LEADING EDGE CONTRIBUTIONS
  20 CLI = DEL(I) * (CP(I)+0.50*CP(I+1))
  CLG(K) = CLI
  CMG(K) = -DEL(I)**2 * (0.6666667*CP(I)+CP(I+1)) / 3.00
  CDG(K) = CLI * EPS(I)/57.295779
  30 CS(K) = 0.1745329 * DEL(I) * CP(I)**2
C
  BCF = 0.00
  NWK = NW(K)
  DO 100 L = 2,NWK
  I = I + 1
  CPI = CP(I)
  IF(L .EQ. NWK) GO TO 40
  CPI1 = CP(I+1)
  GO TO 50
C DEFINE TRAILING EDGE CP VALUE
  40 CPI1 = 0.0
  IF((NJ(K) .EQ. 0) .OR. (CMU(K) .LT. 0.0001)) GO TO 50
  IJK = IJK
  CPI1 = CP(IJK)
C REGULAR EVD CONTRIBUTIONS
  50 CLI = 0.50 * DEL(I) * (CPI+CPI1)
  CLG(K) = CLG(K) + CLI
  CMG(K) = CMG(K) - CLI*X(B(I)) - (CPI+2.0*CPI1)*DEL(I)**2/6.00
  60 CDG(K) = CDG(K) + CLI * EPS(I)/57.295779
  BCF = BCF + BETA(I) * (1.0-XB(I))
C HINGE CONTRIBUTIONS
  IF(IHINGE .EQ. 0) GO TO 100
  B2 = BETA(I+1)
  IF(L .LT. NWK) GO TO 70
  B2 = 0.00
  IJK = IJK
  IF(CMU(K) .GT. 0.0001) B2 = BETA(IJK)
  70 IF((ABS(BETA(I)) .LT. 0.0001).AND.(ABS(B2) .LT. 0.0001)) GO TO 100
  CLI = 0.00
  CMI = 0.00
  DL = ALOG(DEL(I) * CHORD(K))
  CON = 0.6366198 * DEL(I) / 57.295779
  IF(ABS(BETA(I)) .LT. 0.0001) GO TO 80
  CLI = CON * BETA(I) * (2.00 - DL)
  CMI = BETA(I) * (0.50-DL/3.00)
  80 IF(ABS(B2) .LT. 0.0001) GO TO 90
  CLI = CLI + CON * B2 * (2.00 - DL)
  CMI = CMI + 2.00 * B2 * (0.7500 - DL/3.00)
  90 CLG(K) = CLG(K) + CLI
  CMG(K) = CMG(K) - CON * DEL(I) * CMI - CLI * XB(I)
  CDG(K) = CDG(K) + CLI * EPS(I)/57.295779
  100 CONTINUE
C COMPUTE THE SECTIONAL COEFFICIENTS
  110 CLMU(K) = CMU(K) * THETALK/57.295779
  CL(K) = CLG(K) + CLMU(K)
  120 CMMU(K) = -CMU(K) * THETALK/57.295779
  CMT(K) = CMU(K) * (ALPHA+TST(K)-THETAS(K)+BCF)/57.295779
  CM(K) = CMG(K) + CMMU(K) + CMT(K)
  XBCP(K) = 0.00
  XBCL(K) = 0.00
  130 IF(CLG(K) .NE. 0.00) XBCP(K) = -CMG(K) / CLG(K)
  IF(CL(K) .NE. 0.00) XBCL(K) = -(CMG(K)+CMMU(K)) / CL(K)
  140 CDMU(K) = CMU(K) * (THETAK/57.295779)**2 / 2.00
  CDI(K) = CDG(K) + CDMU(K) - CS(K)
  CT(K) = CMU(K) - CDI(K)
  150 CONTINUE
  160 RETURN
END
SUBROUTINE SLOADX(CPA,CPO,DEL,EPS,CMU,TH,NW,NJ,IJ,
  1 CLG,CDGX,CDMUX,CSX,CDIX,NROWS)
C THIS SUBROUTINE CALCULATES THE SECTIONAL CROSS-PRODUCT VALUES
C OF THE NONLINEAR DRAG COEFFICIENTS
C
  DIMENSION CPA(600),CPO(600),DEL(600),EPS(600)
  DIMENSION CMU(40),TH(40),NW(40),NJ(40),IJ(40)
  DIMENSION CLG(40),CDGX(40),CDMUX(40),CSX(40),CDIX(40)
C
  I = 0
  DO 70 K = 1,NROWS
C LEADING EDGE EVD CONTRIBUTION
  I = I + 1
  10 CDGX(K) = DEL(I)*(CPA(I)+0.50*CPA(I+1))*EPS(I)/57.295779
  20 CSX(K) = 0.3490658 * DEL(I) * (CPO(I) * CPA(I))
  NWK = NW(K)
  DO 50 L = 2,NWK
  I = I + 1
  30 CPI1 = CPA(I+1)
C DEFINE TRAILING EDGE CP VALUE
  IF(L .LT. NWK) GO TO 40
  CPI1 = 0.0
  IF((NJ(K) .EQ. 0) .OR. (CMU(K) .LT. 0.0001)) GO TO 40
  IJK = IJK
  CPI1 = CPA(IJK)
C REGULAR EVD CONTRIBUTION
  40 CDGX(K) = CDGX(K) + 0.50*DEL(I)*(CPA(I)+CPI1)*EPS(I)/57.295779
  50 CONTINUE
C COMPUTE THE REMAINING SECTIONAL COEFFICIENTS

```

```

60 CDGX(K) = CDGX(K) + CLGO(K)/57.295779
CDMUX(K) = CMU(K) * TH(K)/57.295779**2
CDIX(K) = CDGX(K) + CDMUX(K) - CSX(K)
70 CONTINUE
RETURN
END
SUBROUTINE SLOADG(CP,DEL,BETA,CHORD,D,CMU,NJ,IJ,CLG,CGAM,
1 NROWS,IHINGE)
C THIS SUBROUTINE COMPUTES THE SPANWISE VARIATION OF TOTAL VORTICITY
C ON THE WING-JET SYSTEM
C
DIMENSION CP(600),DEL(600),BETA(600)
DIMENSION CHORD(40),D(40),CMU(40),NJ(40),IJ(40)
DIMENSION CLG(40),CGAM(40)
C
DO 60 K = 1,NROWS
C COMPUTE THE SECTIONAL JET VORTICITY, INTEGRATED FROM T.E. TO INFINITY
10 CGAM(K) = 0.00
IF(CMU(K) .LT. 0.0001) GO TO 50
II = IJ(K)
C HINGE EVD CONTRIBUTION
IF(IHINGE .EQ. 0) GO TO 20
IF(BETA(II) .NE. 0.00) CGAM(K) = 0.6366198 * DEL(II) *
1 BETA(II)/57.295779 * (2.00-ALOG(CHORD(K)*DEL(II)))
C REGULAR EVD CONTRIBUTION
20 NJK1 = NJ(K) - 1
II = II - 1
DO 40 L = 1,NJK1
II = II + 1
30 CGAM(K) = CGAM(K) + 0.50 * DEL(II) * (CP(II)+CP(II+1))
40 CONTINUE
C FAR-JET EVD CONTRIBUTION
II = II + 1
CGAM(K) = CGAM(K) +
D(K) / CHORD(K) * CP(II)
C SUM UP THE WING AND JET CONTRIBUTIONS
50 CGAM(K) = 0.50 * CHORD(K) * (CGAM(K)+CLG(K))
60 CONTINUE
RETURN
END
SUBROUTINE TLOAD(ALPHA,AREA,CREF,XMC,Y,DELTA,C,H0,XB,XLEAD,BETA,
1 CLG,CLMU,CMG,CMU,CMT,CMU,CCLG,CCLJ,CCL,CCM,CCMJ,CCMT,CCM,
2 CMGIC,CMJMC,CMTC,CMMC,CXCP,CXCL,CXCPB,CXCLB,CCJ,CLLG,CLLJ,
3 CLL,IW,NW,NROWS,ISYMM,
4 CBGR,CBGL,CBJR,CBJL,CBR,CBL,CPBMR,CPBML,CL2R,CL2L)
C THIS SUBROUTINE CALCULATES ALL OF THE TOTAL LOADING PARAMETERS
C FOR A FUNDAMENTAL CASE
C
DIMENSION Y(40),DELTA(40),C(40),H0(40),XLEAD(40),IW(40),NW(40)
DIMENSION XB(600),BETA(600),ITYPE(600)
DIMENSION CLG(40),CLMU(40),CMG(40),CMU(40),CMT(40),CMU(40)
C
C INITIALIZE THE TOTAL COEFFICIENTS
10 CCLG = 0.00
CCLJ = 0.00
CCMG = 0.00
CCMJ = 0.00
CCMT = 0.00
CXCP = 0.00
CXCL = 0.00
CXCPB = 0.00
CXCLB = 0.00
CCJ = 0.00
CLLG = 0.00
CLLJ = 0.00
CLL = 0.00
CBGR = 0.00
CBGL = 0.00
CBJR = 0.00
CBJL = 0.00
CBR = 0.00
CBL = 0.00
CL2R = 0.00
CL2L = 0.00
CPBMR = 0.00
CPBML = 0.00
C
C INTEGRATE THE SECTIONAL VALUES OVER THE SPAN
DO 100 K = 1,NROWS
20 CDEL = C(K)* DELTA(K)
IF(ISYMM .LT. 0) GO TO 80
C
C LIFT COEFFICIENTS
CCLG = CCLG + CDEL * CLG(K)
30 CCLJ = CCLJ + CDEL * CLMU(K)
C
C PITCHING MOMENT COEFFICIENTS
CCDEL = CDEL * C(K)
XLB = XLEAD(K) / C(K)
C
C COMPUTE LEADING EDGE HEIGHT ABOVE WING APEX
40 I = IW(K) - 1
NWK = NW(K)
XDS = 0.00
DO 60 L = 1,NWK
I = I + 1
IF(ITYPE(I) - 41) 60, 50, 70
50 XDS = XDS + XB(I) * BETA(I)/57.295779
60 CONTINUE

```

```

70 HLB = HO(K) - XLB * ALPHA/57.295779 - XDS
CCMG = CCMG + CCDEL * (CMG(K) - CLG(K)*XLB)
CCMJ = CCMJ + CCDEL * (CMMU(K) - CLMU(K)*XLB)
CCMT = CCMT + CCDEL * (CMT(K) - CMU(K)*HLB)
80 CCJ = CCJ + CDEL * CMU(K)

C ROLLING MOMENT COEFFICIENTS AND ROOT BENDING MOMENTS
CDELY = CDEL * Y(K)
90 IF(ISYMM .EQ. 0) GO TO 95
CLLG = CLLG + CDELY * CLG(K)
CLLJ = CLLJ + CDELY * CLMU(K)
95 IF(Y(K) .LT. 0.0) GO TO 96
CBGR = CBGR + CDELY * CLG(K)
CBJR = CBJR + CDELY * CLMU(K)
CL2R = CL2R + CDEL * (CLG(K)+CLMU(K))
GO TO 100
96 CBGL = CBGL - CDELY * CLG(K)
CBJL = CBJL - CDELY * CLMU(K)
CL2L = CL2L + CDEL * (CLG(K)+CLMU(K))
100 CONTINUE

C COMPUTE THE FINAL VALUES OF ALL THE TOTAL COEFFICIENTS
FACTOR = 2.00 / AREA
IF(ISYMM .LT. 1) FACTOR = 4.00 / AREA
110 CCLG = FACTOR * CLLG
CCLJ = FACTOR * CLLJ
CCL = CCLG + CCLJ
120 CCJ = FACTOR * CCJ
130 FACTOR = FACTOR / CREF
CCMG = FACTOR * CCMG
CCMJ = FACTOR * CCMJ
CCMT = FACTOR * CCMT
CCM = CCMG + CCMJ + CCMT
IF(ISYMM .LT. 0) GO TO 140
IF(CCLG .NE. 0.00) CXCP = -CCMG / CCLG
IF(CCL .NE. 0.00) CXCL = -(CCMG+CCMJ) / CCL
CXCPB = CXCP * CREF
CXCLB = CXCL * CREF
140 FACTOR = XIC / CREF
IF(ISYMM .LT. 0) FACTOR = 0.00
CMGMC = CCMG + CCLG * FACTOR
CMJMC = CCMJ + CCLJ * FACTOR
CMTMC = CCJ * FACTOR * ALPHA/57.295779
CMMC = CMGMC + CMJMC + CMTMC
150 IF(ISYMM .EQ. 0) GO TO 160
FACTOR = -1.00 / AREA
IF(ISYMM .LT. 0) FACTOR = -2.00 / AREA
CLLG = FACTOR * CLLG
CLLJ = FACTOR * CLLJ
CCL = CLLG + CLLJ
160 FACTOR = 4.0 / AREA
CBGR = FACTOR * CBGR
CBJR = FACTOR * CBJR
CL2R = FACTOR * CL2R
IF(ISYMM .GT. 0) GO TO 170
IF(ISYMM .LT. 0) GO TO 180
CBGL = CBGR
CBJL = CBJR
CL2L = CL2R
GO TO 160
170 CBGL = FACTOR * CBGL
CBJL = FACTOR * CBJL
CL2L = FACTOR * CL2L
GO TO 190
180 CBGL = -CBGR
CBJL = -CBJR
CL2L = -CL2R
190 CBR = CBGR + CBJR
CBL = CBGL + CBJL
IF(CL2R .NE. 0.0) CPBMR = CBR/CL2R
IF(CL2L .NE. 0.0) CPBML = CBL/CL2L
RETURN
END
SUBROUTINE TLOADX(AREA,CHORD,DELTA,Y,CMU,CDG,CDMU,CS,CDI,CL,CLO,
1                 CCDG,CCDJ,CCS,CDI,CDITZ,ALFINF,ALFINO,CCT,CCJ,
2                 CNJ,CNI,CCY,XLEAD,TANLE,XMC,NROWS,ISYMM)
THIS SUBROUTINE CALCULATES THE NONLINEAR TOTAL LOADING COEFFICIENTS
FOR ALPHA = 0 BY SPANNISH INTEGRATION OF THE NONLINEAR
SECTIONAL COEFFICIENTS
DIMENSION CHORD(40),DELTA(40),Y(40),CMU(40),XLEAD(40),TANLE(40)
DIMENSION CDG(40),CDMU(40),CS(40),CDI(40),CL(40),CLO(40)
DIMENSION ALFINF(40),ALFINO(40)

C INITIALIZE THE COEFFICIENTS
10 CCDG = 0.00
CCDJ = 0.00
CCS = 0.00
CDITZ = 0.00
CNJ = 0.00
CNI = 0.00
CCY = 0.00

C INTEGRATE THE SECTIONAL VALUES OVER THE SPAN
DO 40 K = 1,NROWS
20 CDEL = CHORD(K) * DELTA(K)
CCDG = CCDG + CDEL * CDG(K)
CCDJ = CCDJ + CDEL * CDMU(K)
30 CCS = CCS + CDEL * CS(K)
CDITZ = CDITZ + CDEL * (CL(K)*ALFINO(K) + CLO(K)*ALFINF(K))

```

```

IF(ISYMM .LT. 1) GO TO 40
CNJ = CNJ + CDEL * Y(K) * CMU(K)
CNI = CNI + CDEL * (Y(K)*CDI(K) - CS(K)*TANL(K)*(XLEAD(K)-XMC))
CCY = CCY + CDEL * CS(K) * TANL(K)
40 CONTINUE
C COMPUTE THE FINAL VALUES OF THE TOTAL COEFFICIENTS
FACTOR = 2.00 / AREA
IF(ISYMM .LT. 1) FACTOR = 4.00 / AREA
50 CCDG = FACTOR * CCDG
CCDJ = FACTOR * CCDJ
CCS = FACTOR * CCS
CDITZ = FACTOR * CDITZ / 2.00
CCDI = CCDG + CCDJ - CCS
CCT = CCJ - CCDI
60 IF(ISYMM .LT. 1) RETURN
FACTOR = 1.00 / AREA
CNJ = -FACTOR * CNJ
CNI = FACTOR * CNI
CCY = FACTOR * CCY
70 RETURN
END
SUBROUTINE TLOAD0(CREF,CCLG,CCLJ,CCMG,CCMJ,CCMT,CMGMC,CMJMC,CMTMC,
1 CLLG,CCLJ,FACT,CCLG0,CCLJ0,CCL0,CCM0,CCMJ0,CCMT0,CCM0,
2 CMGMC0,CMJMC0,CMTMC0,CMC0,CXCP0,CXCL0,CXCPB0,CXCLB0,
3 CLLG0,CCLJ0,CCL0,NCASES,ISYMM,
4 CBGR,CBGL,CBJR,CBR,CBL,CPBMR,CPBML,CL2R,CL2L
5 CBGR0,CBGL0,CBJR0,CBR0,CBL0,CPBMR0,CPBML0,CL2R0,CL2L0)
C THIS SUBROUTINE CALCULATES THE LINEAR TOTAL LOADING COEFFICIENTS
C FOR ALPHA = 0. LINEAR QUANTITIES ARE MODULATED AND SUMMED
C ACCORDING TO THE COMPOSITE CASE REQUIREMENTS.
C
DIMENSION CCLG(10),CCLJ(10),CCMG(10),CCMJ(10),CCMT(10),
1 DIMENSION CBGR(10),CBGL(10),CBJR(10),CBJL(10),CBR(10),CBL(10),
1 CPBMR(10),CPBML(10),CL2R(10),CL2L(10)
C
C INITIALIZE THE COEFFICIENTS
10 CCLG0 = 0.00
CCLJ0 = 0.00
CCM0 = 0.00
CCMJ0 = 0.00
CCMT0 = 0.00
CMGMC0 = 0.00
CMJMC0 = 0.00
CMTMC0 = 0.00
CLLG0 = 0.00
CCLJ0 = 0.00
CXCP0 = 0.00
CXCL0 = 0.00
CXCPB0 = 0.00
CXCLB0 = 0.00
CBGR0 = 0.00
CBGL0 = 0.00
CBJR0 = 0.00
CBJL0 = 0.00
CBR0 = 0.00
CBL0 = 0.00
CL2R0 = 0.00
CL2L0 = 0.00
CPBMR0 = 0.00
CPBML0 = 0.00
C
C MODULATE AND SUM THE TOTAL COEFFICIENTS
DO 40 N = 1,NCASES
20 CCLG0 = CCLG0 + CCLG(N) * FACT(N)
CCLJ0 = CCLJ0 + CCLJ(N) * FACT(N)
CCM0 = CCM0 + CCMG(N) * FACT(N)
CCMJ0 = CCMJ0 + CCMJ(N) * FACT(N)
CCMT0 = CCMT0 + CCMT(N) * FACT(N)
30 CMGMC0 = CMGMC0 + CMGMC(N) * FACT(N)
CMJMC0 = CMJMC0 + CMJMC(N) * FACT(N)
CMTMC0 = CMTMC0 + CMTMC(N) * FACT(N)
CLLG0 = CLLG0 + CLLG(N) * FACT(N)
CCLJ0 = CCLJ0 + CCLJ(N) * FACT(N)
CBGR0 = CBGR0 + CBGR(N) * FACT(N)
CBGL0 = CBGL0 + CBGL(N) * FACT(N)
CBJR0 = CBJR0 + CBJR(N) * FACT(N)
CBJL0 = CBJL0 + CBJL(N) * FACT(N)
CL2R0 = CL2R0 + CL2R(N) * FACT(N)
CL2L0 = CL2L0 + CL2L(N) * FACT(N)
40 CONTINUE
C DEFINE THE REMAINING TOTAL COEFFICIENTS
50 CCL0 = CCLG0 + CCLJ0
CCM0 = CCM0 + CCMJ0 + CCMT0
CBR0 = CBGR0 + CBJR0
CBL0 = CBGL0 + CBJL0
IF(CL2R0 .NE. 0.0) CPBMR0 = CBR0 / CL2R0
IF(CL2L0 .NE. 0.0) CPBML0 = CBL0 / CL2L0
IF(ISYMM .LT. 0) GO TO 60
IF(CCLG0 .NE. 0.00) CXCP0 = - CCM0 / CCLG0
IF(CCL0 .NE. 0.00) CXCL0 = - (CCM0+CCM0) / CCL0
CXCPB0 = CXCP0 * CREF
CXCLB0 = CXCL0 * CREF
60 CMGMC0 = CMGMC0 + CMJMC0 + CMTMC0
CCL0 = CLLG0 + CCLJ0
70 RETURN
END
SUBROUTINE TREFTZ(Y,DELTA,CMU,GAMB,ALFINF,NROWS,LIKE)
DIMENSION Y(40),DELTA(40),CMU(40),GAMB(40),ALFINF(40)
DIMENSION E(40),B(40),C(40),DP(40),DM(40),DGAM(40)

```

```

LOGICAL Z1,Z2,Z3,Z4,Z5,Z6,ZT1,ZT2
C FIND COEFFICIENTS OF CURVES
J=0
DO 60 I=1,NROWS
Z1=I.EQ.1
Z2=LIKE.GT.0.AND.I.EQ.NROWS
Z3=(LIKE.LE.0.AND.I.EQ.NROWS).OR.(LIKE.GT.0.AND.I.NE.NROWS.AND.
1Y(I).GT.0.0.AND.Y(I+1).LT.0.0)
Z4=LIKE.GT.0.AND.I.GT.1.AND.Y(I).LT.0.0.AND.Y(I-1).GT.0.0
Z5=(I.NE.NROWS).AND.((CMU(I).LT.0.0001.AND.CMU(I+1).GT.0.0).OR.
1(CMU(I).GT.0.0.AND.CMU(I+1).LT.0.0001).OR.
1(CMU(I).LT.0.0001.AND.CMU(I-1).GT.0.0))
Z6=(I.GT.1).AND.((CMU(I+1).LT.0.0001).OR.
1(CMU(I).LT.0.0001.AND.CMU(I-1).GT.0.0)))
D1=SQRT(1.0-ABS(Y(I)))
ZT1=Z1.OR.Z4.OR.Z6
ZT2=Z2.OR.Z3.OR.Z5
IF(J.EQ.1)GO TO 10
IF(ZT1)J=1
IF(ZT1)GO TO 40
J=0
10 CONTINUE
IF(ZT2) GO TO 30
D2=SQRT(1.0-ABS(Y(I+1)))
D3=SQRT(1.0-ABS(Y(I-1)))
G1=GAI(B1)
G2=GAMB(I+1)
G3=GAI(B(I-1))
D13=D1**3
D23=D2**3
D33=D3**3
D15=D1**5
D25=D2**5
D35=D3**5
F1=D23*D35-D33*D25
F2=D13*D35-D33*D15
F3=D13*D25-D23*D15
E(I)=G1*F1-G2*F2+G3*F3)/(D1*F1-D2*F2+D3*F3)
B(I)=(G1-E(I)*D1)*D25-(G2-E(I)*D2)*D15)/(D13*D25-D23*D15)
C(I)=(G1-E(I)*D1-B(I)*D13)/D15
IF(J.EQ.0) GO TO 40
20 E(I-1)=E(I)
B(I-1)=B(I)
C(I-1)=C(I)
J=0
GO TO 40
30 E(I)=E(I-1)
B(I)=B(I-1)
C(I)=C(I-1)
40 CONTINUE
IF(Y(I).LT.0.0) GO TO 50
DP(I)=SQRT(ABS(D1**2-DELTA(I)))
DM(I)=SQRT(D1**2+DELTA(I))
GO TO 60
50 DP(I)=SQRT(D1**2+DELTA(I))
DM(I)=SQRT(D1**2-DELTA(I))
60 CONTINUE
C CALCULATE STRENGTH OF DISCRETE VORTICIES
DO 80 I=1,NROWS
IF(I.LT.NROWS.AND.((CMU(I).LT.0.0001.AND.CMU(I+1).GT.0.0).OR.
1(CMU(I).GT.0.0.AND.CMU(I+1).LT.0.0001))) GO TO 70
DGAM(I)=0.0
GO TO 80
70 DGAM(I)=(E(I+1)-E(I))*DM(I)+(B(I+1)-B(I))*DM(I)**3+(C(I+1)-C(I))
1*DM(I)**5
80 CONTINUE
C CALCULATE DOWNWASH
DO 100 I=1,NROWS
ALFIN(I)=0.0
F2=SQRT(1.0-Y(I))
F4=SQRT(1.0+Y(I))
DO 90 J=1,NROWS
IF(Y(J).LT.0.0) F2=F4
CON=1.0
IF(Y(J).LT.0.0) CON=-1.0
F1=ALOG(ABS(((DP(J)-F2)*(DM(J)+F2))/((DP(J)+F2)*(DM(J)-F2))))
S1=CON*F1/F2
S2=(2.0*(DP(J)-DM(J))+F2*F1)*CON
S3=CON*(2.0*(DP(J)**3-DM(J)**3)/3.0)+F2**2*S2
DELG=-DGAM(J)/(Y(I)-Y(J)+DELTA(J))
IF(LIKE.GT.0) GO TO 90
F3=ALOG(ABS(((DP(J)-F4)*(DM(J)+F4))/((DP(J)+F4)*(DM(J)-F4))))
S2P=2.0*(DP(J)-DM(J))+F4*F3
IF(LIKE.LT.0) SY=-1.0
IF(LIKE.EQ.0) SY=1.0
S1=S1+SY*F3/F4
S2=S2+SY*S2P
S3=S3+SY*((2.0*(DP(J)**3-DM(J)**3)/3.0)+F4**2*S2P)
DELG=DELG-SY*DGM(J)/(-Y(I)-Y(J)+DELTA(J))
90 ALFIN(I)=ALFIN(I)+0.1591549*(0.5*E(J)*S1+1.5*B(J)*S2+2.5*C(J)*
1S3+DELG)
100 CONTINUE
RETURN
END
SUBROUTINE TABLE(CLO,CLA,CMO,CMA,CLL0,CLLA,CDIO,CDIX,CDIA2,CJ,
1 CNI0,CNIX,CNIA2,CNJ,CY0,CYX,CYA2,MCASE)
C THIS SUBROUTINE COMPUTES AND PRINTS A TABLE OF TOTAL COEFFICIENTS
C FOR A RANGE OF ANGLES OF ATTACK

```

```

C COMPUTE THE COEFFICIENTS
 10 WRITE(6,10) MCASE
    10 FORMAT(1H1,31X,14(4H****),/32X,27H* TABULATED TOTAL COEFFICI,
    1      23HENTS FOR COMPOSITE CASE, I3, 3H */32X,14(4H****)//,
    2      2 4X,5HALPHA,10X,3HCCL,8X,6HCCL**2,5X,7HCCM(MC),4X,3HCLL,13X,
    3      5HCDITZ,6X,3HCCT,13X,3HCNI,8X,2HCHN,9X,3HCCY)
    ALPHA = -11.00
    DO 60 M = 1,41
    20 ALPHA = ALPHA + 1.00
    ALPHA2 = ALPHA * ALPHA
C LINEAR COEFFICIENTS
    30 CL = CLO + CLA * ALPHA
    CL2 = CL * CL
    CM = CMO + CMA * ALPHA
    CLL = CLL0 + CLLA * ALPHA
C NONLINEAR COEFFICIENTS
    40 CDI = CDIO + CDIX * ALPHA + CDIA2 * ALPHA2
    CT = CJ - CDI
    CNI = CNIO + CNIX * ALPHA + CNIA2 * ALPHA2
    CN = CNJ + CNI
    CY = CYO + CYX * ALPHA + CYA2 * ALPHA2
C PRINT THE TABLE
    50 WRITE(6,50) ALPHA,CL,CL2,CM,CLL,CDI,CT,CNI,CN,CY
    50 FORMAT(1H , F10.6,5H * ,4F11.7,5H * ,2F11.7,5H * ,3F11.7)
    60 CONTINUE
    RETURN
    END
    SUBROUTINE FUNDER(EPS,CPO,CPA,CPRO,CPRA,CPP,DEL,CHORD,Y,DELTA,CMU,
    1 AREA,CLQ,CMQ,CMQMC,CLLP,CNP2,NW,IJ,NMAX,NJT,NEWMAX,NCASES,NOALFA,
    2 NROWS,ISYMM1,XL,TL,XMC)
C THIS SUBROUTINE CONTROLS CALCULATION OF ALL AERODYNAMIC COEFFICIENTS
C AND STABILITY DERIVATIVES FOR THE FUNDAMENTAL CASES
C COMMON/SOLV1/CP(600,10)
    DIMENSION CPO(NEWMAX),CPA(NEWMAX),CPR0(600),CPRA(600),CPP(600)
    DIMENSION DEL(600),EPS(600,10),EP(600)
    DIMENSION CHORD(40),Y(40),DELTA(40),CMU(40),XL(40),TL(40)
    DIMENSION NW(40),IJ(40)
C FIND THE SPOT WHERE THE SOLUTION OF THE FIRST RUN WAS STORED
    IREAD = NMAX + NJT
    IFUDGE = 0
    CLLP = 0.00
    CNP2 = 0.00
    CNPO = 0.00
C CALCULATE THE CHORDWISE LOADING
    10 CALL STG3FC(NEWMAX)
C DEFINE THE DUMMY CP ARRAYS FOR THE ALPHA CASE
C AND THE CP ARRAY FOR THE ROLLING FUNDAMENTAL CASE
    DO 20 I = 1,NEWMAX
    CPA(I) = 0.0
    CPRA(I) = 0.0
    CPP(I) = CP(I,NCASES)
    20 CONTINUE
    DO 120 N = 1,NCASES
    LCASE = N
    IREAD = IREAD + 1
    FIND(I,IREAD)
C CALCULATE THE SPANWISE AND TOTAL LOADING
    30 IF(N .EQ. NCASES)
    1     CALL STG3FS(DUM1,DUM2,DUM3,CLLP,NEWMAX,NOALFA,LCASE)
C READ THE FIRST RUN SOLUTION
    READ(I,IREAD) CPO
C DEFINE CP AND EP ARRAYS FOR THE PRESENT SECOND RUN FUNDAMENTAL CASE
    DO 40 I = 1,NEWMAX
    CPR0(I) = CP(I,LCASE)
    EP(I) = EPS(I,LCASE)
    40 CONTINUE
C CALCULATE THE STABILITY DERIVATIVES
    CALL SUMIT1(CPO,CPA,CPP,CPR0,CPRA,DEL,EP,CHORD,Y,DELTA,CMU,XL,TL,
    1 XMC,AREA,DUM1,DUM2,CNP2,CLLR0,DUM3,DUM5,DUM6,CYP2,
    2 NW,IJ,NROWS,ISYMM,NEWMAX,IFUDGE)
    IF(N .LT. NCASES) GO TO 50
    CNPO = DUM1
    GO TO 100
    50 CALL SUMIT2(CPO,CPA,CPR0,CPRA,DEL,EP,CHORD,Y,DELTA,AREA,CMU,XL,TL,
    1 XMC,CNR0,DUM1,DUM2,CNR20,DUM3,DUM4,CYR0,DUM5,DUM6,
    2 CYR20,DUM7,DUM8,NW,IJ,NROWS,ISYMM,NEWMAX)
C PRINT THE STABILITY DERIVATIVE DATA
    60 WRITE(6,70) LCASE
    70 FORMAT(1H1,32X,13(4H****), 3H*** / 33X,
    1      49H* STABILITY DERIVATIVE DATA FOR FUNDAMENTAL CASE, I3,
    2      3H * / 33X,13(4H****), 3H*** /)
    WRITE(6,80) CLLR0
    80 FORMAT(1H0/ 25X, 44HROLLING MOMENT COEFFICIENT DERIVATIVE DUE TO,
    1      15H YAWING, CLLR =, F12.7)
    WRITE(6,90) CNR0,CNR20
    90 FORMAT(1H0/12X,42HYAWING MOMENT COEFFICIENT ABOUT XMC DUE TO,
    1      53H YAWING ABOUT XCG, CNR) MAY BE CALCULATED AS FOLLOWS //
    2      49X, 25HCNRI = CNR*R + CNR2*R**2 //
    3      49X, 13HWHERE CNR =,F14.9 / 56X, 6HCNR2 =,F12.7)
    WRITE(6,95) CYR0,CYR20

```

```

95 FORMAT(1HO/, 23X, 43HSIDE FORCE COEFFICIENT DUE TO YAWING, CY(R),
1      29H MAY BE CALCULATED AS FOLLOWS//,
2      49X, 25HCY(R) = CYR*R + CYR2*R**2//
3      49X, 13HWHERE CYR = ,F14.9/ 56X, 6HCYR2 = ,F12.7)
GO TO 120
100 WRITE(6, 70) LCASE
    WRITE(6, 110) CLLP, CNP2, CYP2
110 FORMAT(1HO/ 28X, 33HROLLING MOMENT COEFF DERIVATIVE DUE TO,
1      16H ROLLING, CLLP =, F12.7 //,
2      17X, 42HYAWING MOMENT COEFFICIENT ABOUT XMC DUE TO,
3      44H ROLLING, CNP(P) MAY BE CALCULATED AS FOLLOWS //
4      53X, 17HCN(P) = CNP2*P**2 //
5      53X, 13HWHERE CNP2 =, F12.7 //,
6      20X, 44HSIDE FORCE COEFFICIENT DUE TO ROLLING, CY(P),
7      29H MAY BE CALCULATED AS FOLLOWS//,
8      53X, 17HCY(P) = CYP2*P**2 //
9      53X, 13HWHERE CYP2 =, F12.7)
120 CONTINUE
    RETURN
END
SUBROUTINE COMDER(EPS,CPO,CPA,CPR0,CPRA,CPP,CPREAD,DEL,CHORD,Y,
1      CMU,DELTA,AREA,CLQ,CMQC,CLLP,CNP2,NW,IJ,NMAX,NJT,NEWMAX,
2      NROWS,ISYMM,XL,TL,XMC)
C THIS SUBROUTINE CONTROLS CALCULATION OF STABILITY DERIVATIVES
C FOR ALL COMPOSITE CASES
COMMON/SOLV1/CP(600,10)
COMMON/COMPOS/FACTOR(10,24),NCC
DIMENSION CPO(NEWMAX),CPA(NEWMAX),CPR0(600),CPRA(600),CPP(600),
1      CPREAD(NEWMAX)
1 DIMENSION DEL(600),EPS(600,10),EP(600)
DIMENSION CHORD(40),Y(40),DELTA(40),CMU(40),XL(40),TL(40)
DIMENSION NW(40),IJ(40)
C CYCLE THROUGH ALL COMPOSITE CASES
IFUDGE = 1
DO 100 M = 1,NCC
MCASE = M
NC1 = NCASES - 1
C FIND THE SPOT WHERE THE SOLUTION OF THE FIRST RUN WAS STORED
IREAD = NMAX + NJT + 1
FIND(1,IREAD)
C DEFINE CP AND EP ARRAYS FOR THIS SECOND RUN COMPOSITE CASE
C NOTE THAT CPP HAS PREVIOUSLY BEEN DEFINED IN FUNDER
DO 20 I = 1,NEWMAX
CPO(I) = 0.00
EP(I) = 0.00
CPRA(I) = CP(I,1)
DO 10 N = 1,NC1
CPO(I) = CPO(I) + FACTOR(N,M) * CP(I,N)
EP(I) = EP(I) + FACTOR(N,M) * EPS(I,N)
10 CONTINUE
20 CONTINUE
C DEFINE CP FOR THE FIRST RUN COMPOSITE CASE
IF(M .EQ. 1) READ(1,IREAO) CPA
DO 30 I = 1,NEWMAX
CPO(I) = 0.00
30 CONTINUE
IREAD = IREAD - 1
DO 60 N = 1,NC1
IREAD = IREAD + 1
FIND(1,IREAD)
IF(FACTOR(N,M) .EQ. 0.0) GO TO 60
40 READ(1,IREAD) CPREAD
DO 50 I = 1,NEWMAX
CPO(I) = CPO(I) + FACTOR(N,M) * CPREAD(I)
50 CONTINUE
60 CONTINUE
C CALCULATE THE COMPOSITE CASE DERIVATIVES
70 CALL SUMIT1(CPO,CPA,CPP,CPR0,DEL,EP,CHORD,Y,DELTA,CMU,XL,TL,
1      XMC,AREA,CNPO,CNP2,CLLR0,CLLR2,CYPO,CYP2,
2      NW,IJ,NROWS,ISYMM,NEWMAX,IFUDGE)
80 CALL SUMIT2(CPO,CPA,CPR0,CPRA,DEL,EP,CHORD,Y,DELTA,AREA,CMU,XL,TL,
1      XMC,CNR0,CNR2,CNR20,CNR2A,CNR2A2,CYR0,CYRA,CYRA2,
1      CYR20,CYR2A,CYR2A2,NW,IJ,NROWS,ISYMM,NEWMAX)
C PRINT A SUMMARY TABLE OF ALL STABILITY DERIVATIVES
90 CALL STABLE(CLQ,CMQ,CMQMC,CLLP,CNPO,CNP2,CYPO,CYP2,
1      CLLR0,CLLR2,CNR0,CNR2,CNR20,CNR2A,CNR2A2,
1      CYR0,CYRA,CYRA2,CYR20,CYR2A,CYR2A2,MCASE)
100 CONTINUE
    RETURN
END
SUBROUTINE SUMIT1(CPO,CPA,CPP,CPR0,CPRA,DEL,EP,CHORD,Y,DELTA,CMU,
1      XL,TL,XMC,AREA,CNPO,CNP2,CLLR0,CLLR2,CYPO,CYP2,CYP2,
2      NW,IJ,NROWS,ISYMM,NEWMAX,IFUDGE)
C THIS SUBROUTINE INTEGRATES CP, CHORDWISE AND SPANWISE TO CALCULATE
C THE TERMS OF CNP AND CLLR DERIVATIVES
COMMON /DERIV/ U0(40),CLQ,CMQ,CMQMC
DIMENSION CPO(NEWMAX),CPA(NEWMAX),CPP(600),CPR0(600),CPRA(600)
DIMENSION DEL(600),EPS(600)
DIMENSION CHORD(40),Y(40),DELTA(40),CMU(40),XL(40),TL(40)
DIMENSION NW(40),IJ(40)
C INITIALIZE THE DERIVATIVE TERMS
10 CNPO = 0.00

```

```

CNPA = 0.00
CNP2 = 0.00
CYPO = 0.00
CYPA = 0.00
CYP2 = 0.00
CLLRO = 0.00
CLLRA = 0.00
C INTEGRATE THE COEFFICIENT TERMS SPANWISE
I = 0
DO 100 K = 1,NROWS
C INTEGRATE THE COEFFICIENT TERMS CHORDWISE
C LEADING EDGE CONTRIBUTION
I = I + 1
C YAWING DUE TO ROLLING
20 TERMP = DEL(I) * (CPP(I) + 0.50*CPP(I+1))
EP = -EPS(I) / (57.295779 * U0(K))
DPO = TERMP * EP
DPA = TERMP
SPO = 0.3490658 * DEL(I) * CPP(I) * CPO(I)
SPA = 0.3490658 * DEL(I) * CPP(I) * CPA(I)
SP2 = 0.1745329 * DEL(I) * CPP(I)**2
C ROLLING DUE TO YAWING
30 CLGO = DEL(I) * (CPRO(I) + 0.50*CPRO(I+1))
CLGA = DEL(I) * (CPRA(I) + 0.50*CPRA(I+1))
C REGULAR EVD CONTRIBUTIONS
40 NMK = NW(K)
DO 70 L = 2,NMK
I = I + 1
CPP1 = CPP(I+1)
CPR01 = CPRO(I+1)
CPRA1 = CPRA(I+1)
IFIL .LT. NMK GO TO 50
CPP1 = 0.00
CPR01 = 0.00
CPRA1 = 0.00
IF(CMU(K) .LT. 0.0001) GO TO 50
IJK = IJK(K)
CPP1 = CPP(IJK)
CPR01 = CPRO(IJK)
CPRA1 = CPRA(IJK)
50 EP = -EPS(I) / (57.295779 * U0(K))
TERMP = 0.50 * DEL(I) * (CPP(I) + CPP1)
DPO = DPO + TERMP * EP
DPA = DPA + TERMP
60 CLGO = CLGO + 0.50 * DEL(I) * (CPR01 + CPR01)
CLGA = CLGA + 0.50 * DEL(I) * (CPRA1 + CPRA1)
70 CONTINUE
C INTEGRATE THE COEFFICIENT TERMS SPANWISE
FACTOR = CHORD(K) * Y(K) * DELTA(K)
FACTO = CHORD(K) * DELTA(K) * TL(K)
FACT = FACTO * (XL(K)-XMC)
80 CNPO = CNPO + (DPO - SPO) * FACTOR - SPO * FACT
CNPA = CNPA + (DPA/57.295779 - SPA) * FACTOR - SPA * FACT
CNP2 = CNP2 + SP2 * FACTOR + SP2 * FACT
CYPO = CYPO + SPO * FACTO
CYPA = CYPA + SPA * FACTO
CYP2 = CYP2 + SP2 * FACTO
90 CLLRO = CLLRO + CLGO * FACTOR
CLLRA = CLLRA + CLGA * FACTOR
100 CONTINUE
C PUT THE TERMS IN FINAL FORM
FACTOR = 1.00 / AREA
IF(ISYMM .LT. 0) FACTOR = 2.00 / AREA
110 CNPO = FACTOR * CNPO
CNPA = FACTOR * CNPA
CNP2 = -FACTOR * CNP2
CLLRO = -FACTOR * CLLRO
CLLRA = -FACTOR * CLLRA
FACTOR = 2.00 * FACTOR
CYPO = FACTOR * CYPO
CYPA = FACTOR * CYPA
CYP2 = FACTOR * CYP2
IF(IFUDGE .NE. 0) GO TO 115
CNPO = 0.00
CYPO = 0.00
115 IF(ISYMM .GE. 0) GO TO 120
CNP2 = 0.00
CYP2 = 0.00
120 RETURN
END
SUBROUTINE SUMIT2(CPO,CPA,CPRO,CPRA,DEL,EPS,CHORD,Y,DELTA,AREA,
1 CMU,XL,TL,XMC,CNRO,CNRA,CNR2A,CNR20,CNR2A2,CYR0,CYRA,
2 CYRA2,CYR20,CYR2A,CYR2A2,NW,IJ,NROWS,ISYMM,NEWMAX)
C THIS SUBROUTINE INTEGRATES CP CHORDWISE AND SPANWISE TO CALCULATE
C THE TERMS OF THE YAWING AND SIDE FORCE COEFFICIENTS DUE TO YAWING
C COMMON /DERIV/ U0(40),CLQ,CMQ,CMQM
DIMENSION CPO(NEWMAX),CPA(NEWMAX),CPRO(600),CPRA(600)
DIMENSION DEL(600),EPS(600)
DIMENSION CHORD(40),Y(40),DELTA(40),CMU(40),XL(40),TL(40)
DIMENSION NW(40),IJ(40)
C INITIALIZE THE YAWING COEFFICIENT TERMS
10 CNRO = 0.00
CNRA = 0.00

```

```

CNRA2 = 0.00
CNR20 = 0.00
CNR2A = 0.00
CNR2A2 = 0.00
CYR0 = 0.00
CYRA = 0.00
CYRA2 = 0.00
CYR20 = 0.00
CYR2A = 0.00
CYR2A2 = 0.00
C
      I = 0
      DO 100 K = 1,NROWS
C INTEGRATE THE COEFFICIENT TERMS CHORDWISE
C LEADING EDGE CONTRIBUTIONS
      I = I + 1
 20 TERMO = DEL(I) * (CPRO(I) + 0.50*CPRO(I+1))
      TERMA = DEL(I) * (CPRA(I) + 0.50*CPRA(I+1))
      EP = -EPS(I) / (57.295779 * U0(K))
      DRO = TERMO * EP
      DRA = TERMO/57.295779 + TERMA * EP
      DRA2 = TERMA
 30 SRO = 0.3490658 * DEL(I) * CPRO(I) * CPO(I)
      SRA = 0.3490658 * DEL(I) * (CPRO(I)*CPA(I) + CPRA(I)*CPO(I))
      SRA2 = 0.3490658 * DEL(I) * (CPRA(I)*CPA(I))
      IF(ISYMM .LT. 0) GO TO 40
      SR20 = 0.1745329 * DEL(I) * CPRO(I)**2
      SR2A = 0.3490658 * DEL(I) * CPRO(I)*CPRA(I)
      SR2A2 = 0.1745329 * DEL(I) * CPRA(I)**2
C REGULAR EVD CONTRIBUTIONS
 40 NWK = NW(K)
      DO 70 L = 2,NWK
      I = I + 1
      CPR01 = CPRO(I+1)
      CPR11 = CPRA(I+1)
      IF(L .LT. NWK) GO TO 50
      CPR01 = 0.00
      CPR11 = 0.00
      IF(CMU(K) .LT. 0.0001) GO TO 50
      IJK = IJ(K)
      CPR01 = CPRO(IJK)
      CPR11 = CPRA(IJK)
 50 EP = -EPS(I) / (57.295779 * U0(K))
C REGULAR EVD CONTRIBUTIONS
      TERMO = 0.50 * DEL(I) * (CPRO(I)+CPR01)
 60 TERMA = 0.50 * DEL(I) * (CPRA(I)+CPRA1)
      DRO = DRO + TERMO * EP
      DRA = DRA + TERMO/57.295779 + TERMA * EP
      DRA2 = DRA2 + TERMA
 70 CONTINUE
C INTEGRATE THE COEFFICIENT TERMS SPANWISE
      FACTOR = CHORD(K) * Y(K) * DELTA(K)
      FACTO = CHORD(K) * TL(K) * DELTA(K)
      FACT = FACTO * (XL(K)-XMC)
 80 CNRO = CNRO + (DRO-SRO) * FACTOR - SRO * FACT
      CNRA = CNRA + (DRA-SRA) * FACTOR - SRA * FACT
      CNRA2 = CNRA2 + (DRA2/57.295779-SRA2) * FACTOR - SRA2 * FACT
      CYRO = CYRO + SRO * FACTO
      CYRA = CYRA + SRA * FACTO
      CYRA2 = CYRA2 + SRA2 * FACTO
      CYR20 = CYR20 + SR20 * FACTO
      CYR2A = CYR2A + SR2A * FACTO
      CYR2A2 = CYR2A2 + SR2A2 * FACTO
      IF(ISYMM1 .LT. 0) GO TO 100
 90 CNR20 = CNR20 - SR20 * FACTOR - SR20 * FACT
      CNR2A = CNR2A - SR2A * FACTOR - SR2A * FACT
      CNR2A2 = CNR2A2 - SR2A2 * FACTOR - SR2A2 * FACT
      CYR20 = CYR20 + SR20 * FACTO
      CYR2A = CYR2A + SR2A * FACTO
      CYR2A2 = CYR2A2 + SR2A2 * FACTO
 100 CONTINUE
C PUT THE TERMS IN FINAL FORM
      FACTOR = 1.00 / AREA
      IF(ISYMM .LT. 0) FACTOR = 2.00 / AREA
 110 CNRO = FACTOR * CNRO
      CNRA = FACTOR * CNRA
      CNRA2 = FACTOR * CNRA2
      CNR20 = FACTOR * CNR20
      CNR2A = FACTOR * CNR2A
      CNR2A2 = FACTOR * CNR2A2
      FACTOR = 2.00 * FACTOR
      CYRO = FACTOR * CYRO
      CYRA = FACTOR * CYRA
      CYRA2 = FACTOR * CYRA2
      CYR20 = FACTOR * CYR20
      CYR2A = FACTOR * CYR2A
      CYR2A2 = FACTOR * CYR2A2
 120 RETURN
END
SUBROUTINE STABLE(CLQ,CMQ,CMQMC,CLLP,CNPO,CNPA,CNP2,CYPO,CYPA,
 1      CYP2,CLLRO,CLLRa,CNRO,CNRA,CNRA2,CNR20,CNR2A,CNR2A2,
 2      CYRO,CYRA,CYRA2,CYR20,CYR2A,CYR2A2,MCASE)
C THIS SUBROUTINE CALCULATES AND PRINTS A COMPLETE SUMMARY TABLE
C OF ALL STABILITY DERIVATIVE DATA FOR EACH COMPOSITE CASE
C COMMON/COMPOS/FACTOR(10,24),NCC
C PRINT ALL CONSTANT DERIVATIVES
      WRITE(6, 10 ) MCASE

```

```

10 FORMAT(1H1,33X,13(4H****),1H* / 34X,
1      47H* STABILITY DERIVATIVE DATA FOR COMPOSITE CASE, I3,
2      3H */ 34X,13(4H****),1H* /)
2 WRITE(6, 20) (N,N=1,10), (FACTORN,MCASE),N=1,10)
20 FORMAT(1H,48X,24HFUNDAMENTAL CASE FACTORS/ 10X,9(4X,2HA(,I1,1H),
1      2X,3X,2HA( I2,I1)/ 10X,10F10.6)
1 WRITE(6, 30) CLQ,CMQ,CMQMC
30 FORMAT(1HO/ 26X,43HLIFT COEFFICIENT DERIVATIVE DUE TO PITCHING,
1      17H ABOUT XCG, CLQ =,F10.6 /
2      14X,51HPITCHING MOMENT COEFFICIENT DERIVATIVE ABOUT ORIGIN,
3      3H DUE TO PITCHING ABOUT XCG, CMQ =,F10.6 /
4      16X,42HPITCHING MOMENT COEFF DERIVATIVE ABOUT XMC,
5      35H DUE TO PITCHING ABOUT XCG, CMQMC =, F10.6)
1 WRITE(6, 40) CLLP,CNP0,CNP1,CNP2
40 FORMAT(1HO/28X,38HROLLING MOMENT COEFF DERIVATIVE DUE TO,
1      16H ROLLING, CLLP =,F12.7 /**
2      17X,51HYAWING MOMENT COEFFICIENT ABOUT XMC DUE TO ROLLING,,,
3      35H CN(P) MAY BE CALCULATED AS FOLLOWS /
4      48X,25HCN(P) = CNP*xP + CNP2*xP**2 /
5      42X,31HWHERE CNP = CNP0 + CNP1*ALPHA /
6      52X, 6HCNP0 =,F12.7/52X, 6HCNP1 =,F12.7/52X,6HCNP2 =,F12.7)
1 WRITE(6, 45) CYPO,CYP1,CYP2
45 FORMAT(1HO/26X,44HSIDE FORCE COEFFICIENT DUE TO ROLLING, CY(P),
1      29H MAY BE CALCULATED AS FOLLOWS/
2      48X,25HCY(P) = CYP*xP + CYP2*xP**2 /
3      42X,31HWHERE CYP = CYPO + CYP1*ALPHA /
4      52X, 6HCYPO =,F12.7/52X,6HCYPO =,F12.7/52X,6HCYP2 =,F12.7)
1 WRITE(6, 50) CLLR0,CLLR1
50 FORMAT(1HO/15X,38HROLLING MOMENT COEFF DERIVATIVE DUE TO,
1      15H YAWING ABOUT XCG, CLLR MAY BE CALCULATED AS FOLLOWS /
2      48X,26HCLLR = CLLR0 + CLLRA*ALPHA /
3      48X,15HWHERE CLLR0 =,F13.7 / 56X,7HCNLLRA =,F13.7)
1 WRITE(6, 60) CNR0,CNRA,CNRA2,CNR20,CNR2A,CNR2A2
60 FORMAT(1HO/12X,42HYAWING MOMENT COEFFICIENT ABOUT XMC DUE TO,
1      15H YAWING ABOUT XCG, CNR1) MAY BE CALCULATED AS FOLLOWS /
2      48X,25HCN(R) = CNR*xR + CNR2*xR**2 /
3      36X,48HWHERE CNR = CNR0 + CNRA*ALPHA + CNRA2*ALPHA**2 /
4      52X, 6HCNR0 =,F13.7/52X,6HCNRA =,F13.7/51X,7HCNRA2 =,F13.7/
5      36X,51HAND CNR2 = CNR20 + CNR2A*ALPHA + CNR2A2*ALPHA**2/
6      51X,7HCNR20 =,F13.7/51X,7HCNR2A =,F13.7/50X,8HCNR2A2 =,F13.7)
1 WRITE(6, 65) CYR0,CYRA,CYRA2,CYR20,CYR2A,CYR2A2
65 FORMAT(1HO/15X,34HSIDE FORCE COEFFICIENT ABOUT XMC DUE TO,
1      15H YAWING ABOUT XCG, CY(R) MAY BE CALCULATED AS FOLLOWS /
2      48X,25HCY(R) = CYR*xR + CYR2*xR**2 /
3      36X,48HWHERE CYR = CYR0 + CYRA*ALPHA + CYRA2*ALPHA**2 /
4      52X, 6HCYR0 =,F13.7/52X,6HCYRA =,F13.7/51X,7HCYRA2 =,F13.7/
5      36X,51HAND CYR2 = CYR20 + CYR2A*ALPHA + CYR2A2*ALPHA**2/
6      51X,7HCYR20 =,F13.7/51X,7HCYR2A =,F13.7/50X,8HCYR2A2 =,F13.7)

C PRINT TABLE OF DERIVATIVE TERMS WHICH DEPEND ON ALPHA
1 WRITE(6, 70)
70 FORMAT(1H1,32X,3H***,10(5H*****),/,,
1      33X,53H* VARIATION OF STABILITY TERMS WITH ANGLE OF ATTACK *,/,
2      33X,3H***,10(5H*****),/,,
3      9X,5HALPHA,12X,3HCNP,10X,4HCNP2,14X,3HCYP,10X,4HCYP2,
4      14X,4HCLLR, 9X,3HCNR,10X,4HCNR2)
ALPHA = -11.00
DO 120 M = 1,41
80 ALPHA = ALPHA + 1.00
  CNP = CNP0 + CNPA * ALPHA
  CYP = CYPO + CYPA * ALPHA
  CLLR = CLLR0 + CLLRA * ALPHA
  CNR = CNR0 + CNRA * ALPHA + CNRA2 * ALPHA**2
  CNR2 = CNR20 + CNR2A * ALPHA + CNR2A2 * ALPHA**2
100 WRITE(6, 110) ALPHA,CNP,CNP2,CYP,CYP2,CLLR,CNR,CNR2
110 FORMAT(1H 5X,F10.6,5H * ,2F13.7,5H * ,2F13.7,5H * ,
1      3F13.7)
120 CONTINUE
RETURN
END
SUBROUTINE STAGE4
C THIS PROGRAM CONTROLS THE EXECUTION OF UTILITY ROUTINES AND
CC BOUNDARY CONDITION SETUP FOR STABILITY DERIVATIVE RUNS
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IJ(40)
COMMON/JOHN/ AREA,SPAN,ARATI0,TR,SNEEP,CREF,CMAC,CBAR,XMC,XCG
COMMON/SPIRIT/ NEWMAX,NEWMCU,NOALFA,LOGIC IR
COMMON/GEOM1/Y(40),CHORD(40),DELTAY(40),XB(600),XI(600),DEL(600),
1          D(40),KK(600),ITYPE(600)
COMMON/FCASE2/TST(40,10),HL(40,10),DJ(40),ACTE(40),AC(20,40),
1          XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
COMMON/SOLV1/CP(600,10)
DIMENSION CPREAD(600)

C ADD THE EXTRA FUNDAMENTAL CASE FOR DERIVATIVES DUE TO PITCHING
IF(LOGIC .GT. 1) GO TO 60
10 IF(NCASES .LT. 10) GO TO 30
1 WRITE(6, 20)
20 FORMAT(1HO//14X,44HFUNDAMENTAL CASE 10 HAS BEEN REPLACED BY THE,
1      47H FOLLOWING CASE FOR DERIVATIVES DUE TO PITCHING)
GO TO 40
30 NCASES = NCASES + 1
40 CALL BCPICH(XCG,CREF,XI,DEL,EPS,BETA,CHORD,KK,THETA,THS,TST,HL,
1      NW,IW,NJ,IJ,NWT,NMAX,NROWS,NCASES)
50 CALL OUT2(NCASES)
GO TO 100

C SAVE THE FIRST RUN SOLUTION ON UNIT 1

```

```

60 ISIZE = NEWMAX
   CALL SAVECP(CP,CPREAD,NMAX,NJT,ISIZE,NCASES)
C DEFINE THE FUNDAMENTAL CASES FOR YAWING DERIVATIVES
   NC1 = NCASES
100 CALL BCYAWIEPS,BETA,THETA,THS,Y,KK,NWT,NMAX,NROWS,NC1)
C DEFINE THE LAST FUNDAMENTAL CASE FOR ROLLING DERIVATIVES
   70 CALL BCROLL(EPS,BETA,THETA,TST,Y,NW,NWT,NMAX,NROWS,NCASES)
C PRINT THE FUNDAMENTAL CASE GEOMETRY
   IF(IPRINT .GE. 0) GO TO 100
   DO 90 N = 1,NCASES
      LCASE = N
      CALL OUT2(LCASE)
90 CONTINUE
100 RETURN
END
SUBROUTINE OUT2(LCASE)
C THIS SUBROUTINE PRINTS OUT THE GEOMETRIC DATA DERIVED FROM THE
C SECTIONAL METHOD INPUT
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NROWS,NAT,NJT,NMAX,NW(40),NJ(40),IW(40)
COMMON/LUKE/TITLE(20)
COMMON/JOHN/AREA,SPAN,ARATIO,TR,SWEET,CREF,CMAC,CBAR,XMC,XCG
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
   D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
COMMON/FCASE2/TST(40,10),HL(40,10),DJ(40),ACTE(40),AC(20,40),
   XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
COMMON/INDATA/ARE,SPA,CRE,XM,CMA,XC,NRO,NC,ISY,IPR,JET,IGT,IHI
C PRINT CASE TITLE AND GENERAL GEOMETRIC PARAMETERS
   IF(LCASE .GT. 1) GO TO 60
10 WRITE(6,20) TITLE
20 FORMAT(1H1,39X,10(4H****))
   1 40X,40H* EVD JET - WING COMPUTER PROGRAM */
   2 40X,10I4H****) // 20X,20A4)
   CMA = CMAC * SPA / 2.0
30 WRITE(6, 40) AREA,ARE,SPAN,SPA,CRE,XM,CMA,CMAC,CMA,ARATIO,
   ARATIO,XCG,XC
40 FORMAT(1H0//54X,4HUSED,11X,5HINPUT /
   1 41X,GHAREA =,2F15.6 / 41X,6HSPAN =,2F15.6 /
   2 41X,GHCREF =,2F15.6 / 42X,5HXMC =,2F15.6 /
   3 41X,GHCMAC =,2F15.6 / 39X,8HARATIO =,2F15.6 /
   4 42X,5HXCG =,2F15.6 )
   WRITE(6, 50) NROWS,NRO,NCASES,NC,ISYMM,ISY,IPRINT,IPR,JETFLG,JET,
   1 1GTYPE,1HTYPE,IHINGE,IHI,NWT,NJT,NMAX
50 FORMAT(1H0/ 48X,7HNROWS =,I3,7X,I3 / 47X,8HNCASES =,I3,7X,I3 /
   1 48X,7HISYMM =,I3,7X,I3 / 47X,8HIPRINT =,I3,7X,I3 /
   2 47X,8HJETFLG =,I3,7X,I3 / 47X,8HIGTYPE =,I3,7X,I3 /
   3 47X,8HHINGE =,I3,7X,I3 /**
   4 43X,25HNUMBER OF WING ELEMENTS =,I4 /
   5 43X,25HNUMBER OF JET ELEMENTS =,I4 /
   6 42X,26HTOTAL NUMBER OF ELEMENTS =,I4)
60 J = 0
   JJ = NWT
C PRINT FUNDAMENTAL CASE HEADER
   WRITE(6,70) LCASE
70 FORMAT(1H1,23X,1H*,19(4H****))
   1 24X,54H* ELEMENT GEOMETRY DATA AND FUNDAMENTAL CASE DATA FOR,
   2 17H FUNDAMENTAL CASE,I3,3H */24X,1H*,19(4H****))
   ILINES = 3
   DO 260 K = 1,NROWS
C PRINT SECTIONAL DATA
   WRITE(6, 80) K,Y(K),DELTA(K),XLEAD(K),XTRAIL(K),CHORD(K),TANLE(K)
80 FORMAT(1H0,11H*** SECTION,I3,4H***,2X,3HY =,F10.6,2X,7HDELTA =,
   1 F10.6,2X,7HXLEAD =,F10.6,2X,8HXTRAIL =,F10.6,2X,7HCHORD =,F10.6,
   2 2X,7HTANLE =,F10.6)
C PRINT CHORDWISE DATA ON WING
   NWK = NWK(1)
   WRITE(6, 90) NWK,TST(K,LCASE),HL(K,LCASE),THS(K,LCASE)
90 FORMAT(1H0,21HWING ELEMENTS NW =,I3,5X, 7HTWIST =,F10.6,5X,
   1 4HHL =,F10.6,5X, 9HTHETAS =,F10.6)
   WRITE(6, 100) (XB(J+L),L=1,NWK)
100 FORMAT(1H,14X,2HXB, 10F11.6/17X,10F11.6)
   IF(LCASE .GT. 1) GO TO 130
   WRITE(6, 110) (XI(J+L),L=1,NWK)
110 FORMAT(1H,14X,2HXI,10F11.6/17X,10F11.6)
   WRITE(6, 120) (DEL(J+L),L=1,NWK)
120 FORMAT(1H,13X,3HDEL,10F11.6/17X,10F11.6)
130 IF(ICT(K) .EQ. 0) GO TO 150
   ICK = ICT(K)
   WRITE(6, 140) (AC(L,ICK),L=1,NWK)
140 FORMAT(1H,10X,6HCAMBER,10F11.6/17X,10F11.6)
150 WRITE(6, 160) (EPS(J+L,LCASE),L=1,NWK)
160 FORMAT(1H,13X,3HEPS,10F11.6/17X,10F11.6)
   WRITE(6, 170) (BETA(J+L,LCASE),L=1,NWK)
170 FORMAT(1H,12X,4HBETA,10F11.6/17X,10F11.6)
   WRITE(6, 180) (ITYPE(J+L),L=1,NWK)
180 FORMAT(1H,12X,4HTYPE,10(3X,I2,6X)/17X,10(3X,I2,6X))
   J = J + NWK
   IL = 1
   IF(NWK .GT. 9) IL = 2
   ILINES = ILINES + 4 + 4*IL

```

```

C IF(LCASE .EQ. 1) ILINES = ILINES + 2*IL
C PRINT CHORDWISE DATA ON JET
  NJK = NJ(K)
  IF(NJK .GT. 0) GO TO 200
  WRITE(6, 190)
190 FORMAT(1H,8X,19HTHIS ROW HAS NO JET)
  ILINES = ILINES + 1
  GO TO 230
200 WRITE(6, 210) NJK,D(K),DJ(K),ACTE(K),THETA(K,LCASE),
210 FORMAT(1H0,1X,20HJET ÉLÉMENTS ,NJ =,I3,5X,3HD =,F10.6,5X,4HDJ =,
1 F10.6,5X,6HACTE =,F10.6,5X,7HTHETA =,F10.6)
  WRITE(6, 100) (XB(JJ+L),L=1,NJK)
  IF(LCASE .GT. 1) GO TO 220
  WRITE(6, 110) (XI(JJ+L),L=1,NJK)
  WRITE(6, 120) (DEL(JJ+L),L=1,NJK)
220 WRITE(6, 170) (BETA(JJ+L,LCASE),L=1,NJK)
  WRITE(6, 180) (ITYPE(JJ+L),L=1,NJK)
  JJ = JJ + NJK
  IL = 1
  IF(NJK .EQ. 10) IL = 2
  ILINES = ILINES + 1 + 3 * IL
  IF(LCASE .EQ. 1) ILINES = ILINES + 2*IL
230 IF(K .EQ. NROWS) GO TO 260
  NWK1 = NW(K+1)
  TL = 1
  IF(NWK1 .GT. 9) IL = 2
  NEXT = 4 + 4*IL
  IF(LCASE .EQ. 1) NEXT = NEXT + 2*IL
  NJK1 = NJ(K+1)
  IL = 1
  IF(NJK1 .EQ. 10) IL = 2
  NEXT = NEXT + 1
  IF(NJK1 .EQ. 0) GO TO 240
  NEXT = NEXT + 1 + 3*IL
  IF(LCASE .EQ. 1) NEXT = NEXT + 2*IL
240 IF((55-ILINES) .GE. NEXT) GO TO 260
250 FORMAT(1H1)
260 CONTINUE
  RETURN
END
SUBROUTINE SAVECP(CP,DUMMY,NMAX,NJT,ISIZE,NCASES)
C THIS SUBROUTINE SAVES THE CP SOLUTION FOR ALL FUNDAMENTAL CASES
C OF THE FIRST STABILITY DERIVATIVE RUN BY STORING ON DIRECT ACCESS
C DIMENSION CP(600,10),DUMMY(ISIZE)
C FIND THE PROPER PLACE TO WRITE THE OLD SOLUTION
10 IWRITE = NMAX + NJT
C FIND(1'IWRITE+1) *** COMMENTED OUT BY JAC***
C DEFINE THE DUMMY ARRAY
DO 30 N = 1,NCASES
  IWRITE = IWRITE + 1
  DO 20 I = 1,ISIZE
    DUMMY(I) = CP(I,N)
20 CONTINUE
C SAVE THE DATA
  WRITE(1'IWRITE) DUMMY
30 CONTINUE
  RETURN
END
SUBROUTINE BCPICH(XCG,CREF,XI,DEL,EPS,BETA,C,KK,THETA,THS,TST,HL,
1 NN,IW,NJ,IJ,NIT,NMAX,NROWS,N)
C THIS SUBROUTINE DEFINES THE BOUNDARY CONDITIONS FOR
C THE PITCHING RATE DERIVATIVE FUNDAMENTAL CASE
C DIMENSION XI(600),DEL(600),C(40),KK(600)
C DIMENSION NN(40),IW(40),NJ(40),IJ(40)
C DIMENSION EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
C DIMENSION TST(40,10),HL(40,10)
C DEFINE THE CAMBER ANGLES WHICH RESULT FROM PITCHING
DO 20 I = 1,NIT
  KKI = KK(I)
10 EPS(I,N) = 2.00 * (XI(I)+(DEL(I)/2.0)*C(KKI)-XCG) / CREF
  BETA(I,N) = 0.00
20 CONTINUE
  IF(NWT .EQ. NMAX) GO TO 50
  NWT1 = NWT + 1
  DO 40 I = NWT1,NMAX
30 EPS(I,N) = 0.00
  BETA(I,N) = 0.00
40 CONTINUE
C DEFINE THE JET ANGLES WHICH RESULT FROM PITCHING
50 DO 70 K = 1,NROWS
60 THETA(K,N) = 0.00
  IJK = IJ(K)
  IF(NJ(K) .GT. 0) THETA(K,N) = 2.00 * (XI(IJK) - XCG) / CREF
  THS(K,N) = 0.00
  TST(K,N) = 0.00
  HL(K,N) = 0.00
70 CONTINUE
  RETURN
END

```

```

SUBROUTINE BCROLL(EPS,BETA,THETA,THS,TST,Y,
1 NW,NNT,NMAX,NROWS,NCASES)
C THIS SUBROUTINE DEFINES THE BOUNDARY CONDITIONS FOR
C THE ROLLING RATE DERIVATIVE FUNDAMENTAL CASE
C
1 DIMENSION EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10),
1 TST(40,10)
1 DIMENSION Y(40),NW(40)
C DEFINE THE TWIST AND CAMBER ANGLES WHICH RESULT FROM ROLLING
N = NCASES
I = 0
DO 40 K = 1,NROWS
10 TST(K,N) = Y(K)
THETA(K,N) = TST(K,N)
THS(K,N) = 0.00
NW(K) = NW(K)
DO 30 L = 1,NWT
I = I + 1
20 EPS(I,N) = TST(K,N)
20 CONTINUE
40 CONTINUE
C DEFINE THE ANGLES ON THE JET
IF(NMAX .EQ. NWT) RETURN
NWT1 = NWT + 1
DO 60 I = NWT1,NMAX
50 EPS(I,N) = 0.00
60 CONTINUE
RETURN
END
SUBROUTINE BCYAW (EPS,BETA,THETA,THS,Y,KK,
1 NW,NMAX,NROWS,NCASES)
C THIS SUBROUTINE DEFINES THE BOUNDARY CONDITIONS FOR ALL OF THE
C YAWING RATE DERIVATIVE FUNDAMENTAL CASES
C
COMMON /DERIV/ U0(40),CLQ,CMQ,CMQMC
DIMENSION EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
DIMENSION Y(40),KK(600)
C DEFINE THE SECTIONAL NORMALIZED VELOCITY INDUCED BY YAWING
DO 10 K = 1,NROWS
U0(K) = Y(K) / 57.295779
10 CONTINUE
C DEFINE THE ANGLES FOR ALL FUNDAMENTAL CASES
DO 80 N = 1,NCASES
DO 30 I = 1,NWT
KKI = KK(I)
20 EPS(I,N) = -U0(KKI) * EPS(I,N)
BETA(I,N) = 0.00
30 CONTINUE
C
DO 50 K = 1,NROWS
40 THETA(K,N) = -U0(K) * THETA(K,N)
THS(K,N) = 0.00
50 CONTINUE
IF(NMAX .EQ. NWT) GO TO 80
NWT1 = NWT + 1
DO 70 I = NWT1,NMAX
60 EPS(I,N) = 0.00
BETA(I,N) = 0.00
70 CONTINUE
80 CONTINUE
RETURN
END
OVERLAY ALPHA
INSERT STAGE1,SGMAIN,INPTS,INPUTJ,XLETR1,XLETR2,NORM1,BOXS
INSERT INCASE,BEECEE,OUT1,INCOMP,BLOWIN,BOXJ,TANS
INSERT FCASE1,SG1
OVERLAY ALPHA
INSERT STAGE2
OVERLAY BETA
INSERT STG2D,DWNWSH,EVD1,EVD2,EVD3,EVD4,SHUFL1,SHUFL2,HINGE
INSERT COLUM1,COLUM2,PREP
OVERLAY BETA
INSERT STG2S,MATRIX,SAVE,GETT,BAKSUB,SOLV2
OVERLAY ALPHA
INSERT STAGE3,STG3FC,STG3FS,STG3FT,STG3C,EXPL,EXPH1,EXPH2
INSERT SLOAD,SLOADX,SLOADG,TLOAD,TLOADO,TLOADX,TREFTZ,TABLE
INSERT FUNDER,COMDER,SUMIT1,SUMIT2,STABLE
INSERT LOAD1,LOAD2,LOAD3,LOAD4,LOAD5,LOAD6
OVERLAY ALPHA
INSERT STAGE4,OUT2,SAVECP,BCPICH,BCROLL,BCYAW
C
C** ONR SAMPLE CASE *** RECTANGULAR WING CMU = 1 WITH STABILITY DER
C4.500    4.500    1.000    0.250    0.250
C4 3 0 0 0 2 1 1
C0.9750   0.88750   0.68750   0.2750
C1 1 2 1
C5 6
C0.000    0.100    0.200    0.500    0.900
C0.000    0.100    0.200    0.500    0.800    0.900
C4.500    0.000    1.000
C1 1 1 1
C4
C1.000    1.100    1.500    3.000
C0 0 1 0 0

```

C1.000 1.000 1.000
C0.000 0.100 1.000
C0.9000 0.1.000
C1.0.00 2.10.00 3.10.00
C1.000 1.000 1.000
C9

PROGRAM JETFLAPIN LISTING

```
PROGRAM JETFLAPIN
C *** JETFLAPIN INPUT PROGRAM DEVELOPED BY J.A. CAMPBELL (AUG88) ***
C *** PROGRAM DESIGNED TO RUN UNDER FORTRAN 77 ON THE MICROVAX/2000 ***
C FINAL UPDATES MADE 14 SEP 88 - (JAC)
C
C THIS PROGRAM IS USED INTERACTIVELY TO PRODUCE AN INPUT FILE FOR THE
C EVD JET WING COMPUTER PROGRAM, JETFLAP. THE JETFLAP PROGRAM CALLS
C THE FILE CREATED BY THIS PROGRAM AND WILL PROVIDE THE FOLLOWING
C FOR WINGS OF ARBITRARY PLANFORM -
C
C 1. SPANWISE AND CHORDWISE LOADING
C 2. SPANWISE VARIATION OF INDUCED DRAG
C 3. A CAPABILITY TO INVESTIGATE THE EFFECTS OF -
C    A. PART SPAN FLAPS
C    B. PART SPAN BLOWING
C    C. ROLLING, YAWING, PITCHING AND SIDESLIP
C 4. TOTAL LIFT AND INDUCED DRAG (TREFFITZ PLANE METHOD),
C    PITCHING, YAWING AND ROLLING MOMENTS, ETC.
C
C COMPLETE DOCUMENTATION OF THE EVD JET WING LIFTING SURFACE THEORY
C AND THE ASSOCIATED COMPUTER PROGRAM ARE CONTAINED IN DOUGLAS REPORT
C
C J5519 -- A THEORETICAL METHOD FOR CALCULATING THE
C AERODYNAMIC CHARACTERISTICS OF ARBITRARY JET FLAP WINGS
C
C          VOLUME I
C          THE ELEMENTARY VORTEX DISTRIBUTION JET-WING
C          LIFTING SURFACE THEORY
C
C          VOLUME II
C          EVD JET-WING COMPUTER PROGRAM USERS MANUAL
C ****
C
C INTEGER*4 LUN
C INTEGER*2 INFILE_SIZE, IOFILE_SIZE
C INTEGER STATUS_NANS
C CHARACTER*20 INFILE, OUTFILE
C CHARACTER*4 CHECK
C LOGICAL EXIST
C COMMON/MATHEN/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
C COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
C COMMON/LUKE/ TITLE(20)
C COMMON/JOHN/ AREA,SPAN,ARATIO,TR,SWEET,CREF,CMAC,CBAR,XMC,XCG
C COMMON/SPIRIT/ NEWMAX,NEWCMU,NOALFA,LOGIC,IR
C COMMON/INDATA/ARE,SPA,CRE,XH,CMA,XC,NRO,NC,ISY,IPR,JET,IGT,IHI,
C COMMON/GEO/1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
C           D(40),KK(600),ITYPE(600)
C COMMON/GECM12/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
C COMMON/FCASE2/TWIST(40,10),HL(40,10),DJ(40),ACTE(40),AC(20,40),
C           XB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
C COMMON/FCASE3/BPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)
C COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)
C COMMON/SOLVI/B(600,10)
C COMMON/COMPOS/FACTOR(10,24),NCC
C COMMON/DERIV/U(40),CLQ,CMQ,CMQMC
C COMMON/INDAT/LUN
C DATA CHECK/'9'
C DATA LUN/7/
C
C-----CALL LIBRARY ROUTINE TO CLEAR THE SCREEN, THEN PRINT HEADER
C-----TITLE PAGE AND INSTRUCTIONS
C-----CALL CLRSCRN
PRINT *
PRINT *, ' PROGRAM JETFLAPIN : VERSION 1 : 6 AUGUST 88 '
PRINT *, ' THIS PROGRAM DEVELOPS THE INPUT FILE REQUIRED BY '
PRINT *, ' THE EVD JET-WING COMPUTER PROGRAM, JETFLAP.'
PRINT *, ' DOUGLAS AIRCRAFT COMPANY CREATED PROGRAM JETFLAP.'
PRINT *, ' THE ELEMENTARY VORTEX DISTRIBUTION (EVD) JET-WING '
PRINT *, ' COMPUTER PROGRAM FOR DETERMINING THE AERODYNAMIC '
PRINT *, ' CHARACTERISTICS OF ARBITRARY JET FLAPPED WINGS'
PRINT *, ' A SIGNIFICANT AMOUNT OF INFORMATION REGARDING '
PRINT *, ' YOUR WING PLANFORM IS REQUIRED BY THIS PROGRAM.'
PRINT *, ' IF YOU HAVE NOT READ THE USERS MANUAL, YOU ARE '
PRINT *, ' ENCOURAGED TO ANSWER NO TO THE FOLLOWING QUESTION '
PRINT *, ' AND RETURN WITH YOUR PREPARED PLANFORM DATA.'
PRINT *
C 1 WRITE (6,1241)
C     CALL QUERY (NANS)
C     IF (NANS .EQ. 1) THEN
C       GO TO 2
C     ELSE IF(NANS .EQ. 2)THEN
C       GO TO 110
C     ELSE
C       WRITE (6,1242)
C       GO TO 1
C     END IF
6410 FORMAT (1X,'=====')
6440 FORMAT (//,8X,'ENTER DATA FOR THE JETFLAP PROGRAM IN FREE FORMAT.
1',8X,'AFTER EACH QUESTION THE FORMAT IS GIVEN: (R) - REAL,
2,2X,(I) - INTEGER.',/,8X,'EXAMPLE: (R,R) INPUT 2.9,6.789',
```

```

3'OR (I) INPUT 5',//)
1241 FORMAT (1X,' DO YOU WISH TO RUN THIS PROGRAM? 1 = YES;2 = NO')
1242 FORMAT (1X,'           INVALID RESPONSE - REENTER')
C-----C FOLLOWING LINES OPEN THE INPUT FILE TO BE CREATED
C-----C
2 CONTINUE
CALL CLRSCRN
PRINT *
PRINT *
PRINT *, '(ENTER 999 TO EXIT.)'
STATUS = LIB$GET_INPUT (OUTFILE, | The OUTPUT file
? ENTER NAME OF OUTPUT FILE TO CREATE: , | Prompt
? IOFILE_SIZE) | Filename size
C CHECK TO SEE IF THE FILE EXISTS BEFORE CREATING IT
IF (OUTFILE.EQ.'999') GO TO 1
INQUIRE (FILE = OUTFILE (1:IOFILE_SIZE), EXIST = EXIST)
IF (.NOT. EXIST) THEN
PRINT *
PRINT *, ' THAT FILE ALREADY EXISTS.'
WRITE (6,1243)
PRINT *, '(OR ENTER 999 TO RETURN TO EXIT OPTION).'
PRINT *
3 CALL QUERY (NANS)
ELSE
GO TO 4
END IF
IF (NANS.EQ.1) THEN
GO TO 4
ELSE IF (NANS.EQ.2) THEN
GO TO 2
ELSE IF (NANS.EQ.999) THEN
GO TO 1
ELSE
WRITE (6,1242)
GO TO 3
END IF
1243 FORMAT (1X,' DO YOU WISH TO OVERWRITE THIS FILE? 1 = YES;2 = NO')
C OPEN FILE THAT BECOMES INPUT FILE FOR PROGRAM JETFLAP
4 OPEN (UNIT=LUN,
? FILE=OUTFILE,
? ORGANIZATION='SEQUENTIAL',
? ACCESS='SEQUENTIAL',
? RECORDTYPE='VARIABLE',
? FORM='FORMATTED',
? STATUS='UNKNOWN')
C-----C INFORM USER OF DESIRED INPUT FORMATS AND ENTER FIRST LINE INPUT DATA
C-----C FIRST LINE INPUT DATA--THE PROBLEM TITLE FOR THIS CASE
C-----C
8 CALL CLRSCRN
WRITE (6,6410)
WRITE (6,6440)
WRITE (6,6410)
WRITE (6,6450)
WRITE (6,6460)
READ (5,1000, END=100) TITLE
6450 FORMAT (1X,'***** JETFLAP INPUT PARAMETERS ',*
1'*****',/1)
6460 FORMAT (1X,25H=> ENTER THE PROBLEM TITLE:,/,5X,20H(80 LETTERS MAX
1IMUM))
1000 FORMAT (20A4)
1001 FORMAT (1X,20A4)
C-----C SUMMARY OF FIRST LINE OF INPUT DATA
C-----C
CALL CLRSCRN
WRITE (6,570)
570 FORMAT (1X,'SUMMARY OF FIRST LINE OF INPUT DATA?',*
1/,1X,25H=> ENTER 1 = YES; 2 = NO)
CALL QUERY (NANS)
IF (.NOT. NANS.GE.2) GO TO 10
WRITE (6,571)
WRITE (6,501) TITLE
WRITE (6,575)
CALL QUERY (NANS)
IF (NANS.EQ.1) GO TO 8
571 FORMAT (1X,7X,'THE TITLE CARD FOR THIS DATA IS:')
575 FORMAT (1X,' DO YOU WISH TO CHANGE FIRST LINE OF INPUT DATA?',*
1/,1X,25H=> ENTER 1 = YES; 2 = NO)
10 CONTINUE
C-----C WRITE DATA TO FILE
WRITE(LUN,1000) TITLE
C-----C SECOND LINE INPUT DATA--GENERAL PLANFORM PARAMETERS
C-----C
C-----C READ GENERAL GEOMETRY CONTROL DATA
CALL CLRSCRN
PRINT *, '==> ENTER THE WING AREA, IN UNITS OF SPAN**2.'
PRINT *, ' IF SPAN IS IN FEET, ENTER AREA IN SQUARE FEET.(R)'
READ (5,*) AREA
PRINT *
PRINT *, '==> ENTER THE WING SPAN SEEN BY THE FREESTREAM'
PRINT *, ' VELOCITY. USE ANY DESIRED UNITS.(R)'
READ (5,*) SPAN
PRINT *
PRINT *, '==> ENTER CREF, THE WING REFERENCE CHORD. THIS WILL BE'
PRINT *, ' USED FOR NORMALIZING VARIOUS AERODYNAMIC COEFFICIENT
+S.
PRINT *, ' USE THE SAME UNITS AS SPAN. IF YOU ENTER ZERO,'*
PRINT *, ' THE MEAN AERODYNAMIC CHORD WILL BE USED.(R)'

```

```

READ (5,*) CREF
PRINT *
PRINT *, '==> ENTER XMC, THE POINT ABOUT WHICH PITCHING MOMENTS W
+ILL BE'
PRINT *, ' TAKEN, MEASURED FROM THE WING APEX (ORIGIN).'
PRINT *, ' USE THE SAME UNITS AS SPAN.(R)'
READ (5,*) XMC
PRINT *
PRINT *, '==> ENTER XCG, THE WING CENTER OF GRAVITY LOCATION, MEAS
+URED'
PRINT *, ' FROM THE WING APEX (ORIGIN). THIS WILL BE USED AS TH
+E'
PRINT *, ' PITCHING AXIS FOR COMPUTING THE STABILITY DERIVATIVE
+S'
PRINT *, ' DUE TO PITCHING. SAME UNITS AS SPAN.(R)'
PRINT *, ' NOTE: THIS VALUE IS REQUIRED IF IDERIV IS NON-ZERO.'
PRINT *, ' IF STABILITY DERIVATIVES NOT REQUIRED, ENTER 0.'
PRINT *
READ (5,*) XCG
C-----  

C SUMMARY OF SECOND LINE INPUT DATA
C-----  

CALL CLRSCRN
WRITE (6,580)
580 FORMAT (1X,'SUMMARY OF SECOND LINE OF INPUT DATA?',
1/,1X,25H=> ENTER 1 = YES; 2 = NO)
CALL QUERY (NANS)
IF (NANS.GE.2) GO TO 20
WRITE (6,581)
WRITE (6,582) AREA,SPAN,CREF,XMC,XCG
WRITE (6,580)
CALL QUERY (NANS)
IF (NANS.EQ.1) GO TO 10
581 FORMAT (1X,5X,'AREA',7X,'SPAN',7X,'CREF',7X,'XMC',8X,'XCG')
582 FORMAT (1X,5(1X,F10.3))
590 FORMAT (//,1X,32HCHANGE SECOND LINE OF INPUT DATA?,
1/,1X,25H=> ENTER 1 = YES; 2 = NO)
20 CONTINUE
C-----  

C WRITE DATA TO FILE
WRITE(LUN,40) AREA,SPAN,CREF,XMC,XCG
4D FORMAT(5F10.4)
C-----  

C THIRD LINE INPUT DATA--GENERAL CONTROL PARAMETERS (FLAGS)
C-----  

CALL CLRSCRN
PRINT *, '==> ENTER NROWS, THE NUMBER OF SPANWISE SECTIONS THE WIN
+G'
PRINT *, ' IS DIVIDED INTO. REQUIREMENT:(3.LE.NROWS.LE.40).(I)'
READ (5,*) NROWS
PRINT *
PRINT *, '==> ENTER NCASES, THE TOTAL NUMBER OF FUNDAMENTAL CASES.'
PRINT *, ' NCASES MUST BE ONE MORE THAN THE NUMBER OF CASES FOR
PRINT *, ' WHICH DATA INPUT WILL BE GIVEN TO ALLOW FOR THE ANGLE
+
PRINT *, ' OF ATTACK CASE. REQUIREMENT:(1.LE.NCASES.LE.10).(I)'
READ (5,*) NCASES
PRINT *
PRINT *, '==> ENTER ISYMM, THE X-AXIS SYMMETRY INDICATOR FLAG.(I)'
PRINT *, ' = 0 WING AND JET ARE SYMMETRIC.'
PRINT *, ' > 0 WING OR JET ARE NON-SYMMETRIC.
PRINT *, ' < 0 WING AND JET ARE ANTI-SYMMETRIC.'
READ (5,*) ISYMM
PRINT *
PRINT *, '==> ENTER IPRINT, THE PRINTED OUTPUT CONTROL FLAG.(I)'
PRINT *, ' > 1 PRINT GEOMETRY DETAILS AND TOTAL AERO COEFFS.'
PRINT *, ' = 1 IN ADDITION, PRINT SPANWISE LOADING.'
PRINT *, ' = 0 IN ADDITION, PRINT CHORDWISE LOADING.'
PRINT *, ' < 0 IN ADDITION, PRINT ALL MATRICES, BACK SUBSTITUTION CHECK AND OTHER DETAILS. (RESERVED FOR
PRINT *, ' TROUBLESHOOTING-VERY LARGE AMOUNTS OF OUTPUT.)'
READ (5,*) IPRINT
PRINT *
PRINT *, '==> ENTER JETFLG, THE JET INDICATOR FLAG.(I)'
PRINT *, ' *** WARNING: THIS VERSION NOT TESTED FOR JET INPUTS.**'
PRINT *, ' = 0 THERE IS A JET SHEET.'
PRINT *, ' = 1 THERE IS NO JET SHEET. NO JET INPUTS WILL BE RE
+AD.
READ (5,*) JETFLG
PRINT *
PRINT *, '==> ENTER IGTYPE, THE WING PLANFORM GEOMETRY INDICATOR F
+LAG.(I);'
PRINT *, ' = 1 WING PLANFORM IS COMPLETELY ARBITRARY, AND SECT
+IONAL'
PRINT *, ' LEADING AND TRAILING EDGE COORDINATES WILL BE R
+EAD'
PRINT *, ' TO DEFINE THE PLANFORM.'
PRINT *, ' = 2 WING PLANFORM IS TRAPEZOIDS, AND SIMPLIFIED'
PRINT *, ' PLANFORM INPUT WILL BE READ.
READ (5,*) IGTYPE
PRINT *
PRINT *, '==> ENTER IHINGE, THE HINGE EVD INDICATOR FLAG.(I)'
PRINT *, ' = 0 REGULAR EVD ONLY WILL BE USED ON ALL HINGE ELEM
+ENTS.'
PRINT *, ' > 0 HINGE EVD WILL BE USED ON ALL HINGE ELEMENTS.
+THIS'
PRINT *, ' OPTION IS NOT PERMITTED FOR USE IN COMPUTING TH
+E'
PRINT *, ' DYNAMIC STABILITY DERIVATIVES (IDERIV>0).'
READ (5,*) IHINGE
PRINT *
PRINT *, '==> ENTER IDERIV, THE DYNAMIC STABILITY DERIVATIVE FLAG.'

```

```

PRINT *, ' = 0 A BASIC RUN WILL BE EXECUTED WITH NO STABILITY'
PRINT *, ' > 0 DERIVATIVES COMPUTED.'
PRINT *, ' > 0 A BASIC RUN WILL BE EXECUTED FOLLOWED BY A'
PRINT *, ' DYNAMIC STABILITY DERIVATIVE RUN.'
READ (5,*), IDERIV
PRINT *

C-----  

C SUMMARY OF THIRD LINE INPUT DATA  

C-----  

CALL CLRSCRN
WRITE (6,600)
600 FORMAT (1X,'SUMMARY OF THIRD LINE OF INPUT DATA?',  

1//,1X,25H=> ENTER 1 = YES; 2 = NO)
CALL QUERY (NANS)
IF (NANS.GE.2) GO TO 30
WRITE (6,601)
WRITE (6,602) NROWS,NCASES,ISYMM,IPRINT
WRITE (6,603)
WRITE (6,602) JETFLG,IGTYPE,IHINGE,IDERIV
WRITE (6,604)
CALL QUERY (NANS)
IF (NANS.EQ.1) GO TO 20
601 FORMAT (1X,'NROWS',2X,'NCASES',1X,'ISYMM',2X,'IPRINT')
602 FORMAT (1X,412X,I2,2X),/
603 FORMAT (1X,'JETFLG',1X,'IGTYPE',1X,'IHINGE',1X,'IDERIV')
604 FORMAT (1//,1X,32HCHANGE THIRD LINE OF INPUT DATA?,  

1//,1X,25H=> ENTER 1 = YES; 2 = NO)
30 CONTINUE
C WRITE DATA TO FILE
WRITE(LUN,41) NROWS,NCASES,ISYMM,IPRINT,  

1 JETFLG,IGTYPE,IHINGE,IDERIV
41 FORMAT(10I2)
C-----  

ARE = AREA
SPA = SPAN
CRE = CREF
XM = XMC
XC = XCG
NRO = NROWS
NC = NCASES
ISY = ISYMM
IPR = IPRINT
JET = JETFLG
IGT = IGTYPE
IHI = IHINGE
C DETERMINE WHICH TYPE OF RUN IS DESIRED
IF(IDERIV.NE.0) GO TO 60
C A REGULAR RUN WILL BE EXECUTED
50 CALL APPLY1
GO TO ( 60 , 70 , 100 , 120 ), IR
C A STABILITY DERIVATIVE RUN WILL BE EXECUTED
60 CALL APPLY2
IF(IR.EQ.2) GO TO 120
C*****  

C PRINT COMPLETION MESSAGE FOR THIS RUN AND GO BACK TO BEGIN A NEW RUN
70 WRITE(6,80)
80 FORMAT(1HO/// 32X,10(5H****), 3H***/ 32X,  

1 53H* THE PROGRAM HAS REACHED NORMAL TERMINATION */  

2 32X,10(5H****),3H***)
C PUT IN AN OPTION TO DO ANOTHER RUN OR PRINT A '9' CARD AND QUIT.***
C
READ(5,20, END=100) TITLE
90 IF(TITLE(1).EQ. CHECK) GO TO 10
C GO TO 30

C
PRINT *, '==> DO YOU WISH TO ENTER ANOTHER SET OF DATA? (Y OR N)'
90 READ (5,(A1)) ANS
IF (ANS.EQ.'Y') THEN
GO TO 4
ELSE IF (ANS.EQ.'N') THEN
WRITE(LUN,1010) CHECK
ELSE
PRINT *, ' INVALID RESPONSE - REENTER.'
GO TO 90
END IF
PRINT *
1010 FORMAT(A4)
C
PRINT COMPLETION MESSAGE AND STOP EXECUTION
100 WRITE(6, 80 )
110 STOP
C*****  

C A FATAL ERROR HAS OCCURED. PRINT FINAL MESSAGE AND STOP EXECUTION.
C*****  

120 WRITE(6, 130 )
130 FORMAT(1HO///62X,2(4H****)/31X,11(5H****)/  

1 31X,55H* THE PROGRAM HAS REACHED ABNORMAL TERMINATION */
2 31X,11(5H****)/62X,2(4H****))
140 STOP
C*****  

END
SUBROUTINE CLRSCRN
C

```

```

C LIBRARY ROUTINE TO CLEAR THE SCREEN.
C
C      ISTAT = LIB$ERASE_PAGE (1,1)
C      RETURN
C*****
C      END
C      SUBROUTINE QUERY(NANS)
C
C      ROUTINE TO TRAP ERRORS CAUSED BY IMPROPER RESPONSES TO QUESTIONS.
C      THE COMPUTER GENERATES AND ERROR WHEN A CHARACTER IS SUPPLIED TO
C      A QUESTION EXPECTING AN INTEGER OR REAL VALUE.
C
C      NQTEST=0
C      1 CONTINUE
C          IF (NQTEST .GT. 0) THEN
C              PRINT *, 'CHARACTER VALUES ARE NOT VALID.'
C              PRINT *, 'PLEASE ENTER A VALUE OF 1 OR 2.'
C          END IF
C          NQTEST = NQTEST + 1
C          READ (5,* ,ERR=1)NANS
C          RETURN
C*****
C      END
C      SUBROUTINE APPLY1
C
C      THIS SUBROUTINE CONTROLS ALL ASPECTS OF INPUT FOR REGULAR CASES
C
C      COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHNGE
C      COMMON/SPIRIT/ NEWMAX,NEWCMU,NOALFA,LOGIC,IR
C
C      DECIDE WHETHER OR NOT THERE IS AN ALPHA CASE
C      NOALFA = 1
C      IR = 1
C      LOGIC = 1
C      IF(ISYMM .LT. 0) NOALFA = 0
C
C      INITIALIZE AND INCREMENT THE CMU CASE CONTROL COUNTER
C      10 NEWCMU = 0
C      20 NEWCMU = NEWCMU + 1
C
C      EXECUTE THE PROBLEM FORMATION STAGE
C      30 CALL STAGE1
C          GO TO ( 40 , 60 , 70 , 80 ), IR
C      40 CONTINUE
C
C      THE PROGRAM HAS BEEN EXECUTED SUCESSFULLY
C      GO BACK AND DO A NEW CMU CASE
C          IF(JETFLG .NE. 0) GO TO 60
C          GO TO 20
C
C*****
C      THIS RUN HAS BEEN COMPLETED. RETURN TO START A NEW RUN.
C      60 IR = 2
C          RETURN
C
C      THIS RUN HAS BEEN COMPLETED. NO FURTHER RUNS FOLLOW.
C      70 IR = 3
C          RETURN
C
C      A FATAL ERROR HAS OCCURED. RETURN AND QUIT.
C      80 IR = 4
C          RETURN
C*****
C      END
C      SUBROUTINE APPLY2
C
C      THIS SUBROUTINE CONTROLS ALL ASPECTS OF INPUT FOR
C      STABILITY DERIVATIVES
C
C
C      CHECK ON STATUS OF CONTROL FLAGS
C      10 IHNGE = 0
C          NOALFA = 1
C          NEWCMU = 1
C          IF(ISYMM1 .GE. 0) GO TO 30
C          ISYMM = 0
C          WRITE(6, 20)
C      20 FORMAT(1H0//16X,41HTHE ISYMM FLAG INDICATED AN ANTI-SYMETRIC,
C          1     48H CASE. HOWEVER, IT WILL BE TREATED AS SYMETRIC.)
C
C      EXECUTE THE FIRST RUN
C
C      FORMULATE THE PROBLEM AS USUAL
C      30 CALL STAGE1
C          GO TO ( 40, 110, 100, 110), IR
C      40 LOGIC = 1
C
C          WRITE(6, 70)
C      70 FORMAT(1H1/////////// 37X,11(4H****),2H** /
C          1     37X,46H* SECOND RUN FOR STABILITY DERIVATIVE CASE * /
C          2     37X,11(4H****),2H** )
C
C      IF THIS IS A SYMETRIC WING, SWITCH IT TO ANTI-SYMETRIC FOR RUN 2
C      80 IF(ISYMM .EQ. 0) ISYMM = -1
C
C*****
C      THIS IS THE END OF THE LINE
C      100 IR = 1
C          RETURN
C
C      THE FOLLOWING LINE SHOULD NOT BE REACHED. INCLUDED FOR CONTINUITY.
C
C      A FATAL ERROR HAS OCCURED. RETURN ABNORMALLY TO MAIN.
C      110 IR = 2
C          RETURN
C*****
C      END

```

```

SUBROUTINE STAGE1
C THIS SUBROUTINE READS THE GENERAL GEOMETRY PARAMETERS AND FLAGS, AND
C CONTROLS THE CALLING OF THE SPECIALIZED GEOMETRY SUBROUTINES
COMMON/MATHEW/NCASES,ISYMM1,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NRCKS,NROWSJ,NIT,NJT,NMAX,NJ(40),IJ(40),IW(40)
COMMON/SPIRIT/ NEWMAX,NEWCMU,NOALFA,LOGIC,IR
C CHECK WHETHER THIS IS THE FIRST CMU CASE
IF(NEWCMU .GT. 1) GO TO 50
IF((NROWS .GT. 40).OR.(NROWS .LT. 3)) GO TO 80
C SECTIONAL INPUT
10 IF(IGTYPE .EQ. 1).OR.(IGTYPE .EQ. 2)CALL SGMAIN(NOALFA,IR)
GO TO ( 20 , 40 , 100 ), IR
C USER INPUT ERROR
C PRINT ERROR MESSAGE BECAUSE IGTYPE HAS THE WRONG VALUE
20 WRITE(6, 30 ) IGTYPE
30 FORMAT(1H1//44X,32HTHE IGTYPE FLAG HAS THE VALUE OF ,I2/
1        44X,37HONLY THE VALUES 1 OR 2 ARE ACCEPTABLE//,
2        44X,15HPLEASE REENTER.)
READ(5,* ) IGTYPE
GO TO 10
C READ THE COMPOSITE CASE REQUIREMENTS
40 CALL INCOMP(NCASES,IR)
IF(IR .EQ. 2) GO TO 100
C READ THE CMU DATA
50 CALL BLOWIN(JETFLG,IR)
GO TO ( 60 , 110 , 120 ), IR
60 CALL BOXJ(NEWMAX,IR)
IF(IR .EQ. 2) GO TO 50
C RETURN NORMALLY TO THE CONTROL PROGRAM
70 IR = 1
GO TO 130
C PRINT ERROR MESSAGE BECAUSE THE NROWS VALUE IS UNACCEPTABLE
80 WRITE(6, 90 ) NROW
90 FORMAT(1H1/55X,7HNROWS =,I3)
C **** A FATAL ERROR HAS OCCURED. RETURN ABNORMALLY TO MAIN.
100 IR = 4
GO TO 130
C RETURN TO MAIN AND BEGIN A COMPLETELY NEW RUN
110 IR = 2
GO TO 130
C RETURN TO MAIN AND STOP THE EXECUTION
120 IR = 3
130 RETURN
C **** END
SUBROUTINE SGMAIN(NOALFA,IR)
C THIS SUBROUTINE CONTROLS ALL GEOMETRY CALCULATIONS FOR THE
C SECTIONAL GEOMETRY METHOD
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
C READ THE WING PLANFORM GEOMETRY DATA
10 CALL INPTS(IR)
IFI(IR .EQ. 2) GO TO 100
IFI(IGTYPE .EQ. 1) CALL XLETR1(IR)
IFI(IR .EQ. 2) GO TO 100
IFI(IGTYPE .EQ. 2) CALL XLETR2
C NORMALIZE THE WING PLANFORM GEOMETRY DATA
20 CALL NORM1
C READ THE JET SHEET GEOMETRY DATA
30 CALL INPUTJ(IR)
IFI(IR .EQ. 2) GO TO 100
C CONSTRUCT THE EVD ELEMENTS
40 CALL BOXS(IR)
IFI(IR .EQ. 2) GO TO 100
C CONSTRUCT THE SET OF FUNDAMENTAL GEOMETRIC CASES
DO 90 N = 1,NCASES
LCASE = N
C READ THE GEOMETRY FOR THIS CASE
50 CALL INCASE(LCASE,NOALFA)
C PRINT THE GEOMETRY AND CONSTRUCTED CASE DATA IF DESIRED
IFI(LCASE .EQ. 1) WRITE(6, 70 )
70 FORMAT(1H1)
C CALL CLRSCRN
PRINT *
PRINT *, '==> DO YOU WISH TO SEE THE CONSTRUCTED CASE DATA?'
PRINT *, '           ENTER (Y OR N)'
75 READ (5,'(A1)') ANS
IFI (ANS.EQ.'Y') THEN
GO TO 80

```

```

ELSE IF (ANS.EQ.'N') THEN
  GO TO 90
ELSE
  PRINT *, ' INVALID RESPONSE - REENTER.'
  GO TO 75
END IF
PRINT *
1010 FORMAT(A4)
C   80 CALL OUT1(LCASE)
90 CONTINUE
IR = 2
RETURN
C AN ERROR HAS OCCURED. RETURN ABNORMALLY TO STAGE1.
C 100 IR = 3
RETURN
*****END SUBROUTINE INPTS(IR)
C THIS SUBROUTINE READS THE WING GEOMETRY DATA FROM THE KEYBOARD
C FOR THE SECTIONAL GEOMETRY METHOD
C COMMON/MARK/NROWS,NROHSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40),
COMMON/GEOM1/Y(40),CHORD(40),DELT(40),XB(600),XI(600),DEL(600),
D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANL(40),TANTE(40),
COMMON/SG1/XBW(20,10),EBJ(20,10),ICTYPE(40),IJTYPE(40),
  1          NJTYPE
COMMON/INDAT/LUN
DIMENSION NI(10)
C INPUT THE SECTIONAL PLANFORM DATA
10 NJTYPE = 0
C-----SECTION CENTERLINE LOCATION CARDS
C-----CALL CLRSCRN
PRINT *
PRINT *, ' SECTION CENTERLINE LOCATION VALUES'
PRINT *, '==> ENTER Y, THE SPANWISE DISTANCE FROM THE CENTERLINE,
PRINT *, '(X-AXIS), TO THE SECTION CENTERLINE NORMALIZED BY '
PRINT *, ' THE HALF-SPAN, SPAN/2. REQUIREMENT: (-1.0<Y<1.0).(R)'
PRINT *, ' BEGIN AT THE RIGHT WING TIP AND WORK TOWARD:
PRINT *, '    a) WING CENTERLINE FOR SYMETRIC OR ANTSYMETRIC W
+INGS.
PRINT *, '    b) LEFT WING TIP FOR NON-SYMETRIC WINGS.'
PRINT *, ' A MAXIMUM OF 40 SECTIONS IS ALLOWED.'
PRINT *
DO 15 K = 1,NROWS
WRITE(6,12) K,NROWS
READ(5,* ) Y(K)
12 FORMAT(1X,' ENTER SECTION CENTERLINE ',I2,' OF ',I2,' SECTIONS.',,
+/)
PRINT *
15 CONTINUE
C-----SUMMARY OF SECTION CENTERLINE INPUT DATA
C-----CALL CLRSCRN
PRINT *
PRINT *, ' *** YOU ARE ENCOURAGED TO CHECK THIS DATA! *** '
PRINT *, ' IF THE SECTION CENTERLINE VALUES ARE NOT VALID'
PRINT *, ' AN ERROR WILL BE DETECTED BY SUBROUTINE BOXS'
PRINT *, ' THE PROGRAM WILL TERMINATE, AND YOU WILL HAVE TO'
PRINT *, ' REENTER ALL YOUR DATA. THE CHOICE IS YOURS...'
PRINT *
WRITE(6,13)
13 FORMAT(1X,'SUMMARY OF SECITON CENTERLINE INPUT DATA?',,
1/,1X,25H=> ENTER 1 = YES; 2 = NO)
CALL QUERY (NANS)
IF (NANS.GE.2) GO TO 20
  WRITE(6,14)
  WRITE(6,19) (K, Y(K),K=1,NROWS)
  WRITE(6,16)
  CALL QUERY (NANS)
  IF (NANS.EQ.1) GO TO 10
14 FORMAT(1X,7X,'THE SECTION CENTERLINE DATA IS:')
16 FORMAT(1/,1X,'DO YOU WISH TO CHANGE/REENTER THIS INPUT DATA?',,
1/,1X,25H=> ENTER 1 = YES; 2 = NO)
20 CONTINUE
C-----WRITE DATA TO FILE
  WRITE(LUN, 18 ) (Y(K),K=1,NROWS)
18 FORMAT(8F10.6)
19 FORMAT(1X,5X,'SECTION =',I2,3X,'CENTERLINE =',F10.6)
C-----WING SECTION TYPE CARDS
C-----CALL CLRSCRN
PRINT *
PRINT *, ' WING SECTION TYPES'
PRINT *
PRINT *, '==> ENTER ICTYPE, THE TYPE NUMBER OF EACH WING SECTION.'
PRINT *, ' THE ARRANGEMENT OF EVD ELEMENTS IN A ROW DETERMINES
PRINT *, ' THE WING ROW TYPE. ANY SECTIONS HAVING THE SAME NUMB

```

```

+ER'
PRINT *, ' OF ELEMENTS, ALL WITH THE SAME SPACING FROM THE SECT
+ION'
PRINT *, ' LEADING EDGE ARE OF THE SAME ICTYPE. BEGIN WITH A TY
+PE'
PRINT *, ' 1 AND WORK IN SEQUENCE, 2,3,...(ASCENDING ORDER).(I)'
PRINT *, ' A MAXIMUM OF 10 SECTION TYPES IS ALLOWED.'
23 PRINT *, 'DO 24 K = 1,NROWS
      WRITE(6,22) K,NROWS
      READ(5,* ) ICTYPE(K)
      IF(ICTYPE(K) .GT. NWTYPE) NWTYPE = ICTYPE(K)
      IF(NWTYPE .GT. 8) THEN
         WRITE(6,21) NWTYPE
         PRINT *, ' A MAXIMUM OF 10 SECTION TYPES IS ALLOWED.'
         PRINT *, ' ***** W A R N I N G *****'
         PRINT *, ' YOU MAY ENTER ONLY ONE MORE DIFFERENT TYPE.'
      END IF
21 FORMAT(1X,5X,26HNUMBER OF WING ROW TYPES =,I3)
22 FORMAT(1X,13HENTER SECTION TYPE FOR SECTION ',I2,' SECTI
+ONS ,/)
24 CONTINUE
C-----SUMMARY OF WING SECTION TYPE INPUT DATA
C-----CALL CLRSCRN
      WRITE(6,26)
26 FORMAT(1X,13HSUMMARY OF WING SECTION TYPE INPUT DATA?',,
1/1X,25H==> ENTER 1 = YES; 2 = NO)
      CALL QUERY (NANS)
      IF (NANS.GE.2) GO TO 25
      WRITE(6,27)
      WRITE(6,29) (K,ICTYPE(K),K=1,NROWS)
      WRITE(6,16)
      CALL QUERY (NANS)
      IF (NANS.EQ.1) GO TO 23
27 FORMAT(1X,7X,'THE WING SECTION TYPE DATA IS: ')
29 FORMAT(1X,5X,'SECTION =',I2,3X,'SECTION TYPE =',I2)
25 CONTINUE
C-----WRITE DATA TO FILE
      WRITE(LUN,301) (ICTYPE(K),K=1,NROWS)
301 FORMAT(40I2)
C-----NUMBER OF CHORDWISE WING ELEMENTS CARD
C-----CALL CLRSCRN
      PRINT *
      PRINT *, ' CHORDWISE WING ELEMENTS'
      PRINT *, ' ==> ENTER NI, THE NUMBER OF CHORDWISE WING EVD ELEMENTS'
      PRINT *, ' FOR EACH WING SECTION TYPE. THE NUMBER OF ELEMENTS M
+UST
      PRINT *, ' BE ENTERED IN ASCENDING ORDER BY ICTYPE. THERE MAY B
+E AS'
      PRINT *, ' FEW AS 2 ELEMENTS PER SECTION TYPE OR AS MANY AS 20.
+ (I)'
33 PRINT *
      DO 30 N = 1,NWTYPE
      WRITE(6,32) N,NWTYPE
28 READ(5,* ) NI(N)
      NIN = NI(N)
      IF((NIN .LT. 2) .OR. (NIN .GT. 20)) THEN
         WRITE(6,31) NIN
         PRINT *, ' A MINIMUM OF 2 AND A MAXIMUM OF 20'
         PRINT *, ' ELEMENTS ARE ALLOWED.'
         PRINT *, ' PLEASE REENTER'
         GO TO 28
      END IF
31 FORMAT(1X,5X,36HNUMBER OF ELEMENTS IN THIS SECTION =,I3)
32 FORMAT(1X,13HENTER NUMBER OF EVD ELEMENTS FOR ICTYPE ',I2,' OF ',I
+2,/)
30 CONTINUE
C-----SUMMARY OF CHORDWISE WING ELEMENTS INPUT DATA
C-----CALL CLRSCRN
      WRITE(6,36)
36 FORMAT(1X,13HSUMMARY OF CHORDWISE WING ELEMENTS INPUT DATA?',,
1/1X,25H==> ENTER 1 = YES; 2 = NO)
      CALL QUERY (NANS)
      IF (NANS.GE.2) GO TO 35
      WRITE(6,37)
      WRITE(6,39) (N,NI(N),N=1,NWTYPE)
      WRITE(6,16)
      CALL QUERY (NANS)
      IF (NANS.EQ.1) GO TO 33
37 FORMAT(1X,7X,'THE CHORDWISE WING ELEMENTS DATA IS: ')
39 FORMAT(1X,5X,'SECTION =',I2,3X,'CHORDWISE ELEMENTS =',I2)
35 CONTINUE
C-----WRITE DATA TO FILE
      WRITE(LUN,301) (NI(N),N=1,NWTYPE)
C-----READ THE CHORDWISE DIVISION DATA FOR EACH ROW TYPE
C-----WING CHORDWISE ELEMENT COORDINATES CARD
C-----CALL CLRSCRN
      PRINT *
      PRINT *, ' WING CHORDWISE ELEMENT COORDINATES'
      PRINT *

```

```

PRINT *, '==> ENTER XBW, THE CHORDWISE COORDINATE OF EACH VORTEX P
+OINT'
PRINT *, ' THE VORTEX POINT IS DEFINED AS THE LEADING EDGE FOR'
PRINT*, : LEADING EDGE EVD'S AND THE "PEAK" POINT FOR REGULAR'
PRINT*, : HINGE AND JET EVD'S. A SET OF COORDINATES IS REQUIRED FOR EACH WING SECTI
+ON TYPE.'
PRINT*, ' THE NUMBER OF OF COORDINATES WILL CORRESPOND TO THE
+NUMBER'
PRINT*, ' OF ELEMENTS ENTERED ON THE PREVIOUS CARD.'
PRINT*, ' THE LEADING EDGE COORDINATE MUST BE 0.0 AND WILL AUT
+OMATICALLY' BE ENTERED FOR YOU. THE LAST VALUE MUST BE LESS THAN
+1.0.(R)'
PRINT*
DO 50 N = 1,NWTYPE
NIN = NI(N)
XBW(1,N) = 0.0
DO 45 L = 2,NIN
WRITE(6,42) N
WRITE(6,43) L,NIN
XBWN = XBW(L,N)
IF((XBWN .LT. 0.0) .OR. (XBWN .GE. 1.0)) THEN
WRITE(6,41) XBWN
PRINT *, ' COORDINATE VALUE MUST LIE BETWEEN 0.0 AND 1.0'
PRINT *, ' PLEASE REENTER'
GO TO 46
END IF
45 CONTINUE
CALL CLRSCRN
PRINT *
PRINT *, ' *** LEADING EDGE VALUE OF 0.0 ENTERED FOR EVD',
ELEMENT 1 ***
50 CONTINUE
41 FORMAT(1X,5X,30HCHORDWISE ELEMENT COORDINATE =,F10.6)
42 FORMAT(1X,' FOR WING SECTION TYPE NUMBER ',I2)
43 FORMAT(1X,' ENTER CHORDWISE COORDINATE FOR EVD ELEMENT ',I2,' OF
+',I2,/)
C-----C
C SUMMARY OF CHORDWISE ELEMENT COORDINATE INPUT DATA
C
CALL CLRSCRN
WRITE(6,47)
47 FORMAT(1X,'SUMMARY OF ELEMENT COORDINATE INPUT DATA?',1/1X,25H=> ENTER 1 = YES; 2 = NO)
CALL QUERY (NANS)
IF (NANS.GE.2) GO TO 60
54 CALL CLRSCRN
WRITE(6,48) NWTYPE
READ (5,* ) NSEC
WRITE(6,49) (L,XBW(L,NSEC),L=1,NI(NSEC))
WRITE(6,16)
CALL QUERY (NANS)
IF (NANS.EQ.1) THEN
N = NSEC
NIN = NI(N)
XBW(1,N) = 0.0
DO 55 L = 2,NIN
WRITE(6,42) NSEC
WRITE(6,43) L,NIN
56 READ(5,* ) XBWN(L,N)
XBWN = XBW(L,N)
IF((XBWN .LT. 0.0) .OR. (XBWN .GE. 1.0)) THEN
WRITE(6,41) XBWN
PRINT *, ' COORDINATE VALUE MUST LIE BETWEEN 0.0 AND 1.0'
PRINT *, ' PLEASE REENTER'
GO TO 56
END IF
55 CONTINUE
GO TO 50
ELSE
PRINT *, ' DO YOU WISH TO CHECK ANOTHER SECTION?'
PRINT *. ==> ENTER 1 = YES; 2 = NO'
CALL QUERY (NANS)
IF (NANS.EQ.1) GO TO 54
CONTINUE
END IF
48 FORMAT(1X,7X,'WHICH SECTION TYPE DO YOU WANT TO LOOK AT?'
1,/1X,7X,'ENTER A VALUE BETWEEN 1 AND ',I2,'')
49 FORMAT(1X,5X,'ELEMENT NUMBER =',I2,3X,'COORDINATE =',F10.6)
60 CONTINUE
C DEFINE THE NUMBER OF CHORDWISE DIVISIONS FOR EACH ROW, USED LATER
DO 70 K = 1,NROWS
ICK = ICTYPE(K)
NW(K) = NI(ICK)
70 CONTINUE
C WRITE DATA TO FILE
DO 80 N = 1,NWTYPE
NIN = NI(N)
WRITE(LUN, 18 ) (XBW(L,N),L=1,NIN)
80 CONTINUE
C
IR = 1
RETURN
C*****
END
SUBROUTINE INPUTJ(IR)
C THIS SUBROUTINE READS THE JET ELEMENT GEOMETRY INPUT

```

```

C THE NUMBER AND CHORDWISE SPACING OF THE JET ELEMENTS ARE READ
C
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
1 COMMON/SG1/XBH(20,10),XBJ(20,10),ICTYPE(40),IJTYPE(40),
NNTYPE,NJTYPE
COMMON/INDAT/LUN
DIMENSION NI(10)
C
C READ THE TYPE OF DIVISION FOR EACH ROW
10 NJTYPE = 0
NROHSJ = 0
IF(JETFLG .NE. 0) GO TO 90
C-----JET SECTION TYPE CARDS-----C
CALL CLRSCRN
PRINT *
PRINT *, ' JET SECTION TYPE NUMBERS'
PRINT *, : THIS IS VERY SIMILAR TO THE WING SECTION TYPE DATA'
PRINT *, : COMPLETED PREVIOUSLY.
PRINT *
PRINT *, ' THE ARRANGEMENT OF JET ELEMENTS IN A SECTION DETERMI
+NES'
PRINT *, ' THE JET SECTION TYPE. ANY SECTIONS HAVING THE SAME N
+NUMBER'
PRINT *, ' OF ELEMENTS, ALL WITH THE SAME SPACING WITH RESPECT'
PRINT *, ' TO'
PRINT *, ' THE WING SECTIONAL CHORD TO WHICH THEY ARE ATTACHED'
PRINT *, ' ARE'
PRINT *, ' OF THE SAME TYPE. BEGIN WITH A TYPE NUMBER OF 1 AND'
PRINT *, ' WORK'
PRINT *, ' IN SEQUENCE, 2,3,...(ASCENDING ORDER).'
PRINT *
PRINT *, ' A SECTION WITH NO JET HAS A TYPE OF 0 (ZERO).'
PRINT *
PRINT *, ' A MAXIMUM OF 10 JET SECTION TYPES IS ALLOWED. THERE'
PRINT *, ' IS A REQUIREMENT THAT THE SECTIONS WITH JETS AND'
PRINT *, ' WITHOUT JETS MUST BE IN GROUPS OF THREE OR MORE.'
PRINT *
PRINT *, '==> ENTER IJTYPE, THE TYPE NUMBER OF EACH JET SECTION.(I
+)
20 PRINT *
DO 25 K = 1,NROWS
WRITE(6,32) K,NROWS
READ(5,*), IJTYPE(K)
IF(IJTYPE(K) .GT. NJTYPE) NJTYPE = IJTYPE(K)
IF(IJTYPE(K) .NE. 0) NROHSJ = NROHSJ + 1
IF(NJTYPE .GT. 8) THEN
WRITE(6,31) NJTYPE
PRINT *, ' A MAXIMUM OF 10 JET SECTION TYPES IS ALLOWED.'
PRINT *, ' ***** WARNING *****'
PRINT *, ' YOU MAY ENTER ONLY ONE MORE DIFFERENT TYPE.'
END IF
31 FORMAT(1X,5X,29HNUMBER OF JET SECTION TYPES =,I3)
32 FORMAT(1X,' ENTER JET SECTION TYPE FOR SECTION ',I2,' OF ',I2,' S
+ECTIONS',/)
25 CONTINUE
C-----SET UP FOR ROW CONSISTENCY CHECK-----C
C DEFINE THE NUMBER OF CHORDWISE DIVISIONS FOR EACH ROW
DO 80 K = 1,NROWS
NJK(K) = 0
IF(IJTYPE(K) .EQ. 0) GO TO 80
IJK = IJTYPE(K)
70 NJIK = NJ(IJK)
80 CONTINUE
C-----CHECK FOR ROW CONSISTENCY ON EITHER SIDE OF JET-----C
ICOUNT = 1
IF(NJ(1) .EQ. 0) ITEST = 0
IF(NJ(1) .GT. 0) ITEST = 1
DO 150 K = 2,NROWS
IF(NJ(K) .EQ. 0) ICOMP = 0
IF(NJ(K) .GT. 0) ICOMP = 1
IF(ICOMP .EQ. ITEST) GO TO 160
IF(ICOUNT .LT. 3) GO TO 170
ICOUNT = 1
IF(NJ(K) .EQ. 0) ITEST = 0
IF(NJ(K) .GT. 0) ITEST = 1
GO TO 150
160 ICOUNT = ICOUNT + 1
150 CONTINUE
IF(ICOUNT .LT. 3) GO TO 170
GO TO 190
C-----AN ERROR HAS OCCURED. PRINT A MESSAGE AND ENTER DATA AGAIN.-----C
170 PRINT *, ' ROW CONTINUITY RULE FAILURE!'
PRINT *, ' REVIEW YOUR JET SECTION DATA. JET SECTIONS MUST BE'
PRINT *, ' IN GROUPS OF 3 OR MORE AND THERE MUST BE AT LEAST 3.'
PRINT *, ' UNBLOWN WING SECTIONS INBOARD OR OUTBOARD OF ANY JET.'
GO TO 20
190 CONTINUE
C-----SUMMARY GOES HERE-----C
C-----NUMBER OF CHORDWISE JET ELEMENTS CARD-----C
CALL CLRSCRN

```

```

PRINT *, ' CHORDWISE JET ELEMENTS'
PRINT *, '==> ENTER NJ, THE NUMBER OF CHORDWISE JET EVD ELEMENTS'
PRINT *, ' FOR EACH JET SECTION TYPE. THE NUMBER OF ELEMENTS',
+'MUST'
PRINT *, ' BE AS
PRINT *, ' FEW AS 2 ELEMENTS PER SECTION TYPE OR AS MANY AS 10'
+',(I)
PRINT *
C READ THE NUMBER OF CHORDWISE DIVISIONS (ELEMENTS) IN EACH ROW TYPE
DO 30 N = 1,NJTYPE
WRITE(6,22) N,NJTYPE
28 READ(5,* ) NJ(N)
NIN = NJ(N)
IF((NIN LT. 2) OR. (NIN .GT. 10)) THEN
  WRITE(6,21) NIN
  PRINT *, ' A MINIMUM OF 2 AND A MAXIMUM OF 10'
  PRINT *, ' ELEMENTS ARE ALLOWED.
  PRINT *, ' PLEASE REENTER'
  GO TO 28
END IF
21 FORMAT(IX,5X,40HNUMBER OF JET ELEMENTS IN THIS SECTION =,I3)
22 FORMAT(IX,' ENTER NUMBER OF JET ELEMENTS FOR IJTYPE ',I2,', OF ',I
+2,/)
30 CONTINUE
C SUMMARY GOES HERE
C-----JET CHORDWISE ELEMENT COORDINATES CARD
C-----CALL CLRSCRN
PRINT *
PRINT *, ' JET CHORDWISE ELEMENT COORDINATES'
PRINT *, ' A SET OF COORDINATES IS REQUIRED FOR EACH JET ',
+'SECTION TYPE.'
PRINT *, ' THE NUMBER OF COORDINATES WILL CORRESPOND TO ',
+'THE NUMBER'
PRINT *, ' OF ELEMENTS ENTERED ON THE PREVIOUS CARD.'
PRINT *, ' THE FIRST PEAK POINT FOR EACH JET SECTION OCCURS ',
+'AT THE
PRINT *, ' TRAILING EDGE. ITS COORDINATE MUST BE 1.0 AND WILL',
+'AUTOMATICALLY'
PRINT *, ' BE ENTERED FOR YOU. THERE IS NO MAXIMUM VALUE.'
PRINT *, '==> ENTER XBJ, THE CHORDWISE COORDINATE OF EACH VORTEX',
+' POINT.
PRINT *, ' THE VORTEX POINT IS DEFINED AS THE "PEAK" POINT ',
+'FOR JET EVD' S.(R)'
PRINT *
C READ THE CHORDWISE DIVISION DATA FOR EACH ROW TYPE
DO 50 N = 1,NJTYPE
NIN = NJ(N)
XBJ(1,N) = 1.0
DO 45 L = 2,NIN
  WRITE(6,42) NJTYPE
  WRITE(6,43) L,NIN
  PRINT *, ' NOTE: THIS IS WITH RESPECT TO THE CHORD OF ',
+', THIS SECTION.'
46 READ(5,* ) XBJ(L,N)
  XBJN = XBJ(L,N)
  IF(XBJN .LE. 1.0) THEN
    WRITE(6,41) XBJN
    PRINT *, ' COORDINATE VALUE MUST BE GREATER THAN 1.0'
    PRINT *, ' PLEASE REENTER'
    GO TO 46
  END IF
  PRINT *
45 CONTINUE
50 CONTINUE
41 FORMAT(IX,5X,30HCHEODWISE ELEMENT COORDINATE =,F10.6)
42 FORMAT(IX,' FOR JET SECTION TYPE NUMBER ',I2)
43 FORMAT(IX,' ENTER CHODWISE COORDINATE FOR JET EVD ELEMENT ',I2,
+', OF ',I2,/)
C SUMMARY GOES HERE
C IR = 1
RETURN
C THERE IS NO JET FOR THIS RUN
90 DO 100 K = 1,NROWS
  IJTYPE(K) = 0
  NJ(K) = 0
100 CONTINUE
IR = 1
RETURN
*****END SUBROUTINE XLETR1(IR)
C THIS SUBROUTINE READS THE LEADING AND TRAILING EDGE COORDINATES AT
C SPANWISE STATIONS CONNECTED BY STRAIGHT LEADING AND TRAILING EDGES.
C THE MAIN PROGRAM INTERPOLATES TO GET COORDINATES FOR INTERMEDIATE
C SECTIONS
COMMON/MARK/NROWS,NROWSJ,NHT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),

```

```

1 D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
COMMON/INDAT/LUN
DIMENSION YP(40),XLE(40),XTR(40)

C----- LEADING AND TRAILING EDGE COORDINATES
C----- CALL CLRSCRN
PRINT *
PRINT *, ' LEADING AND TRAILING EDGE COORDINATES'
PRINT *, ' FOR A WING OF ARBITRARY PLANFORM'
PRINT *, ' PRINT *, '==> ENTER AS A MINIMUM THE COORDINATES FOR THE TIP AND',
+ ' ROOT SECTIONS.'
PRINT *, ' COORDINATES ARE ALSO REQUIRED FOR SECTIONS WHICH ',
+ ' DEFINE A'
PRINT *, ' BREAK IN THE LEADING OR TRAILING EDGES.'
PRINT *, ' THE COORDINATES REFER TO THE CHORDWISE DISTANCE, ',
+ ' MEASURED AT '
PRINT *, ' THE SECTION CENTERLINE, FROM THE Y-AXIS TO THE ',
+ ' RESPECTIVE EDGE'
PRINT *, ' IN UNITS OF SPAN.'
PRINT *, ' THE PROGRAM ASSUMES A STRAIGHT EDGE EXISTS BETWEEN',
+ ' SECTIONS'
PRINT *, ' ENTERED HERE AND WILL INTERPOLATE BETWEEN THE INPUT',
+ ' VALUES.'
PRINT *, ' THE SECTION CENTERLINE COORDINATE IS AUTOMATICALLY',
+ ' WRITTEN'
PRINT *, ' TO THE DATA FILE FROM YOUR PREVIOUS INPUT.(R,R)'

5 NX = 0
C READ NUMBER OF SECTIONS TO INPUT
9 PRINT *, ' HOW MANY WING SECTIONS WILL YOU BE ENTERING',
+ ' COORDINATES FOR?'
10 READ(5, *) NSECT
IF (NSECT .GT. NROWS) THEN
  WRITE(6,11) NROWS
  PRINT *, ' PLEASE REENTER'
  GO TO 10
END IF

C CHANGE TO CORRECT NSECT IF IMPROPER VALUE ENTERED
PRINT *
WRITE(6,31) NSECT
WRITE(6,16)
CALL QUERY(NANS)
IF (NANS.EQ.1) GO TO 9

C READ XLEAD AND XTRAIL
PRINT *, ' BEGIN AT TIP AND WORK IN. TIP SECTION = 1.'
PRINT *
DO 30 N = 1,NSECT
IF (N .NE. 1) CALL CLRSCRN
WRITE(6,46) N,NSECT
20 READ(5, *) I
C RETRIEVE AND PRINT CENTERLINE COORDINATE DATA
YP(I) = Y(1)
WRITE(6,42) I
WRITE(6,43) YP(N)
PRINT *
WRITE(6,44) I
READ(5, *) XLE(N)
PRINT *
WRITE(6,45) I
READ(5, *) XTR(N)
PRINT *

30 CONTINUE
11 FORMAT(1X,5X,'THE NUMBER OF SECTIONS MUST NOT BE MORE THAN ',I2,/,)
31 FORMAT(1X,5X,'THE NUMBER OF SECTIONS YOU WILL BE ENTERING DATA',
1, ' FOR ',I2)
41 FORMAT(1X,5X,30CHORDWISE ELEMENT COORDINATE =,F10.6)
42 FORMAT(1X,1, 'FOR SECTION (ROW) NUMBER ',I2)
43 FORMAT(1X,1, ' SECTION CENTERLINE COORDINATE = ',F10.6)
44 FORMAT(1X,1, ' ENTER THE LEADING EDGE COORDINATE FOR SECTION ',I2)
45 FORMAT(1X,1, ' ENTER THE TRAILING EDGE COORDINATE FOR SECTION ',I2)
46 FORMAT(1X,1, ' ENTER THE WING SECTION NUMBER ASSOCIATED WITH ',
1, 'COORDINATE SET ',I2, ' OF ',I2,/,)
C----- C----- SUMMARY OF LEADING AND TRAILING EDGE COORDINATES DATA
C----- CALL CLRSCRN
WRITE(6,47)
47 FORMAT(1X,'SUMMARY OF LEADING/TRAILING EDGE COORDINATE DATA?',1,
1,1X,25H=> ENTER 1 = YES; 2 = NO)
CALL QUERY(NANS)
IF (NANS.GE.2) GO TO 60
  WRITE(6,48)
  WRITE(6,49)
  WRITE(6,52) (YP(N),XLE(N),XTR(N),N=1,NSECT)
  WRITE(6,16)
  CALL QUERY(NANS)
  IF (NANS.EQ.1) GO TO 5
48 FORMAT(1X,7X,'THE COORDINATE DATA IS:',/)
49 FORMAT(1X,25H=> ENTER 1 = YES; 2 = NO)
52 FORMAT(1X,5X,'CENTERLINE',5X,'LEADING EDGE',3X,'TRAILING EDGE',/,)
52 FORMAT(3(5X,F10.6))
60 CONTINUE
C----- WRITE DATA TO FILE
DO 70 N = 1,NSECT
  WRITE(LUN, 101) YP(N),XLE(N),XTR(N)

```

```

101 FORMAT(3F10.6)
70 CONTINUE
C   OUTPUT A 9 CARD AFTER NSECT SETS OF COORDINATES HAVE BEEN INPUT
    WRITE(LUN, 102 )
102 FORMAT('9')
C   IR = 1
RETURN
C*****
END
SUBROUTINE XLETR2
C THIS SUBROUTINE READS THE FUNDAMENTAL PLANFORM PARAMETERS FOR A
C TRAPEZOIDAL WING. NOTE THAT THE PLANFORM OUTLINE MUST BE SYMETRIC.
C
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/JOHN/ AREA,SPAN,ARATIO,TR,SHEEP,CREF,CMAC,CBAR,XMC,XCG
COMMON/GEOM1/Y(40),CHORD(40),DELT(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
COMMON/INDAT/LUN
C
C--TRAPEZOIDAL WING PLANFORM PARAMETERS
C-----CALL CLRSCRN
PRINT *
PRINT *, ' TRAPEZOIDAL WING PLANFORM PARAMETERS'
PRINT *, ' NOTE: PLANFORM MUST BE SYMETRIC'
PRINT *
C CALCULATE ASPECT RATIO FROM PREVIOUSLY SUPPLIED DATA
ARATIO = SPAN * SPAN / AREA
PRINT *, '==> THE CALCULATED WING ASPECT RATIO, ARATIO =', ARATIO
GO TO 15
C READ THE FUNDAMENTAL PLANFORM PARAMETERS
PRINT *, '==> ENTER THE WING ASPECT RATIO, ARATIO (R).'
READ (5,*) ARATIO
15 PRINT *
PRINT *, '==> ENTER SWEEP, THE SWEEP ANGLE OF THE QUARTER-CHORD'
PRINT *, ' LINE, IN DEGREES.(R)'
READ (5,*) SWEEP
PRINT *
PRINT *, '==> ENTER TR, THE WING TAPER RATIO. THIS IS DEFINED AS'
PRINT *, ' THE CHORD AT THE WING TIP DIVIDED BY THE CHORD AT'
PRINT *, ' THE AXIS OF SYMMETRY, THE WING ROOT.(R)'
READ (5,*) TR
PRINT *
C-----C SUMMARY OF TRAPEZOIDAL WING PLANFORM PARAMETERS INPUT DATA
C-----CALL CLRSCRN
WRITE(6,11)
11 FORMAT(1X,'SUMMARY OF TRAPEZOIDAL PLANFORM PARAMETERS DATA?',
1//,1X,25H=> ENTER 1 = YES; 2 = NO)
CALL QUERY (NANS)
IF (NANS.EQ.2) GO TO 20
PRINT *
WRITE (6,12) ARATIO,SWEEP,TR
WRITE (6,13)
CALL QUERY (NANS)
IF (NANS.EQ.1) GO TO 10
12 FORMAT (1X,'ASPECT RATIO =',F10.6,3X,'SWEEP =',F10.6,
13X,'TAPER RATIO =',F10.6,/)
16 FORMAT (//,1X,25H=> DO YOU WISH TO CHANGE/REENTER THIS INPUT DATA?,
1//,1X,25H=> ENTER 1 = YES; 2 = NO)
20 CONTINUE
C   WRITE TO DATA FILE
    WRITE(LUN, 100 ) ARATIO,SWEEP,TR
100 FORMAT(3F10.6)
C-----C PROCESS VALUES FOR USE BY CHECKING ROUTINES
C-----C COMPUTE THE GENERAL PLANFORM CHARACTERISTICS
B2 = SPAN / 2.00
SW = SHEEP / 57.295779
CROOT = 2.0 * SPAN / ((1.0+TR)*ARATIO)
AREA = (1.0+TR) * CROOT * B2
XLB2 = 0.250 * (1.0-TR) * CROOT + B2 * TAN(SW)
CMAC = 2.0 * CROOT * (1.0 + TR + TR*TR) / (3.0*(1.0+TR))
IF(CREF .EQ. 0.0) CREF = CMAC
CBAR=AREA/SPAN
C-----C COMPUTE THE LEADING AND TRAILING EDGE COORDINATES
DO 60 K = 1,NROWS
    YBAR = Y(K)
    IF(YBAR .LT. 0.0) YBAR = -YBAR
    XLEAD(K) = XLB2 * YBAR
    C = CROOT * (1.0-(1.0-TR)*YBAR)
    XTRAIL(K) = XLEAD(K) + C
60 CONTINUE
C-----C RETURN
C*****
END
SUBROUTINE NORM1
C THIS SUBROUTINE NORMALIZES ALL WING PLANFORM GEOMETRY BY SPAN/2

```

```

COMMON/MARK/NROWS,NPOWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/JOHN/ AREA,SPAN,ARATIO,TRSWEEP,CREF,CMAC,CBAR,XMC,XCG
COMMON/GEO:11/Y(40),CHORD(40),DELT(A(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
1 COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
10 B2 = SPAN / 2.00
10 AREA = AREA / B2**2
10 CREF = CREF / B2
20 XMC = XMC / B2
20 XCG = XCG / B2
DO 40 K = 1,NROWS
30 XLEAD(K) = XLEAD(K) / B2
30 XTRAIL(K) = XTRAIL(K) / B2
40 CONTINUE
SPAN = 2.00
ARATIO = SPAN * SPAN / AREA
RETURN
C*****END SUBROUTINE BOXS(IR)
C THIS SUBROUTINE CONSTRUCTS THE GEOMETRIC PARAMETERS FOR ALL THE
C EVD ELEMENTS ON THE WING AND JET
C COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NROWS,NPOWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/JOHN/ AREA,SPAN,ARATIO,TRSWEEP,CREF,CMAC,CBAR,XMC,XCG
COMMON/GEO:11/Y(40),CHORD(40),DELT(A(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
1 COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
1 COMMON/SGL/XBW(20,10),XBJ(20,10),ICTYPE(40),IJTYPE(40),
1 NWTYPE,NJTYPE
C CONSTRUCT THE ELEMENTS ON THE WING
C COMPUTE SECTIONAL DATA
10 CHORD(1) = XTRAIL(1) - XLEAD(1)
10 DELTA(1) = 1.00 - Y(1)
10 CMAC = CHORD(1)**2 * DELTA(1)
DO 30 K = 2,NROWS
20 CHORD(K) = XTRAIL(K) - XLEAD(K)
20 DELTA(K) = Y(K-1) - Y(K) - DELTA(K-1)
IF(DELTA(K) .LT. 0.0) GO TO 190
20 CMAC = CMAC + CHORD(K)**2 * DELTA(K)
30 CONTINUE
C CHECK THE VALIDITY OF THE SECTIONAL ALIGNMENT
YD = Y(NROWS) - DELTA(NROWS)
IF((ISYMM .GE. 0) AND (ABS(YD) .GT. 0.0001)) GO TO 190
IF((ISYMM .EQ. 1) AND (ABS(YD+1.0) .GT. 0.0001)) GO TO 190
DSUM = DELTA(1)
DO 35 K = 2,NROWS
35 YL = Y(K) + DELTA(K)
35 YR = Y(K-1) - DELTA(K-1)
35 IF(ABS(YR-YL) .GT. 0.0001) GO TO 190
35 DSUM = DSUM + DELTA(K)
35 CONTINUE
35 IF(ABS(DSUM-0.50) .GT. 0.0001) GO TO 190
35 CMAC = 2.0 * CMAC / AREA
35 IF(ISYMM .LT. 1) CMAC = 2.0 * CMAC
35 IF(CREF .LT. 0.0001) CREF = CMAC
35 CALL TANS(TANLE,XLEAD,Y,NROWS)
C COMPUTE ALL CHORDWISE ELEMENT PARAMETERS FOR EACH SECTION
I = 0
DO 90 K = 1,NROWS
C COMPUTE X-COORDINATES
NJK = NW(K)
DO 50 L = 1,NWK
50 I = I + 1
50 ICK = ICTYPE(K)
50 XB(I) = XBW(L,ICK)
50 CONTINUE
C COMPUTE ALL OTHER PARAMETERS
I = I - NWK
IW(K) = I + 1
DO 80 L = 1,NWK
80 I = I + 1
60 KK(I) = K
60 DEL(I) = XB(I+1) - XB(I)
70 XI(I) = XLEAD(K) + XB(I) * CHORD(K)
70 ITYPE(I) = 10
80 CONTINUE
C REDEFINE THE LAST DEL IN THIS SECTION, AND DEFINE THE L.E. EVD TYPE
80 DEL(I) = 1.00 - XB(I)
80 IWK = IW(K)
80 ITYPE(IWK) = 20
90 CONTINUE
NWT = I
C CONSTRUCT THE ELEMENTS ON THE JET SHEET
C COMPUTE ALL CHORDWISE ELEMENT PARAMETERS FOR EACH SECTION
IF(JETFLG .NE. 0) GO TO 180
DO 170 K = 1,NROWS
C COMPUTE X-COORDINATES
IJK = 0
100 NJK = NJ(K)
100 IF(NJK .EQ. 0) GO TO 170
100 DO 120 L = 1,NJK
120 I = I + 1
120 IJK = IJTYPE(K)
110 XB(I) = XBJ(L,IJK)

```

```

C 120 CONTINUE
C COMPUTE ALL OTHER PARAMETERS
  I = I - NJK
130 IJ(K) = I + 1
  DO 160 L = 1,NJK
  I = I + 1
140 KK(I) = K
  DEL(I) = XB(I+1) - XB(I)
150 XI(I) = XLEAD(K) + XB(I) * CHORD(K)
  ITYPE(I) = 10
C 160 CONTINUE
C REDEFINE THE LAST DEL AND EVD TYPE AND THE D VALUE FOR THIS SECTION
  DEL(I) = 1.0E10
  ITYPE(I) = 30
  D(K) = XI(I) - XTRAIL(K)
C 170 CONTINUE
180 NMAX = I
  IF(NMAX .GT. 600) GO TO 210
  NJT = NMAX - NWT
  IR = 1
  RETURN
C AN ERROR HAS OCCURED. PRINT A MESSAGE AND QUIT.
190 WRITE(6, 200)
200 FORMAT(1H1/38X,44H PLEASE CHECK YOUR SECTION LOCATION (Y) INPUT)
  IR = 2
  RETURN
210 WRITE(6, 220) NMAX
220 FORMAT(1H1/48X,I4,21H IS TOO MANY ELEMENTS)
  IR = 2
  RETURN
END
SUBROUTINE BOXJ(NEWMAX,IR)

C THIS SUBROUTINE COMPUTES THE JET BLOWING FACTOR CMUP
C
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40),
COM110N/GEO(11/Y(40),CHORD(40),DELT(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600))
COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)

C COMPUTE THE NEW CMUP AND SAVE THE OLD VALUES AS CMUPP
10 NEWMAX = NMAX
  ICOUNT = 0
  DO 30 K = 1,NROWS
    CMUPP(K) = CMUPI(K)
    IF(NJK) .EQ. 0) GO TO 30
    IF(CMU(K) < 0.0001) GO TO 20
    CMUPI(K) = 2.00 / (CHORD(K)*CMU(K))
    GO TO 30
  20 ICOUNT = ICOUNT + 1
    CMUP(K) = 0.00
  30 CONTINUE
C
  PRINT *, '==> DO YOU WISH TO SEE THE JET BLOWING COEFFICIENTS?'
  PRINT *, 'ENTER (Y OR N)'
  35 READ (5,'(A1)') ANS
  IF (ANS.EQ.'Y') THEN
    WRITE(6, 40)(K,CMU(K),K=1,NROWS)
  ELSE IF (ANS.EQ.'N') THEN
    GO TO 45
  ELSE
    PRINT *, ' INVALID RESPONSE - REENTER.'
    GO TO 35
  END IF
1010 FORMAT(A4)
C
40 FORMAT(1H1,40X,10(4H****)/ 41X,
1      60H* SECTIONAL JET BLOWING COEFFICIENTS  */41X,10(4H****)//)
2      55X,3HROW,5X,3HCMU,40//53X,I2,F12.6)
45 IF(ICOUNT .EQ. 0) GO TO 50
  IF(ICOUNT .LT. NROWSJ) GO TO 60
  NEWMAX = NWT
  50 IR = 1
  RETURN
C AN ERROR HAS OCCURED. PRINT A MESSAGE AND TRY AGAIN.
60 WRITE(6, 70)
70 FORMAT(1H0,43X,35H A ZERO VALUE OF CMU HAS BEEN INPUT.,
1      33H THIS CMU CASE HAS BEEN IGNORED.)
  IR = 2
  RETURN
C*****
END
SUBROUTINE TANS(TAN,X,Y,NROWS)

C THIS SUBROUTINE COMPUTES THE TANGENT OF THE LEADING OR TRAILING EDGE
C SWEET ANGLE AT THE CENTERLINE OF EACH SECTION. IT IS ACCURATE FOR
C SECTIONS WITH STRAIGHT EDGES IN GROUPS OF THREE OR MORE.
C IT IS ONLY APPROXIMATE FOR CURVED EDGES.
C IT MAY RESULT IN ERRORS FOR SECTIONS ADJACENT TO WING BREAKS,
C IF STRAIGHT EDGES ARE IN ADJACENT GROUPS OF ONLY ONE OR TWO.
C
DIMENSION TAN(40),X(40),Y(40),S(40)
SLOP(XR,XL,YR,YL) = (XR-XL) / (YR-YL)
C
DO 50 K = 1,NROWS
  KR = K-1
  KL = K

```

```

IF(K .GT. 1) GO TO 30
KR = 1
KL = 2
30 S(K) = SLOP(X(KR),X(KL),Y(KR),Y(KL))
50 CONTINUE
DO 200 K = 1,NROWS
IF(K .LT. 3) GO TO 150
IF(K .EQ. NROWS) GO TO 150
IF(K .EQ. (NROWS-1)) GO TO 160
C CHECK WHETHER THE RIGHT OR LEFT SIDES ARE STRAIGHT
IF(ABS(S(K) - S(K-1)) .LT. 0.001) GO TO 150
IF(ABS(S(K+1) - S(K+2)) .LT. 0.001) GO TO 160
C NEITHER SIDE IS CONCLUSIVELY STRAIGHT - CHECK FURTHER LEFT AND RIGHT
IF(K .EQ. 3) GO TO 160
IF(ABS(S(K-1) - S(K-2)) .LT. 0.001) GO TO 150
IF(ABS(S(K+2) - S(K+3)) .LT. 0.001) GO TO 150
C THE TRUE SHAPE CANNOT BE DETERMINED - GIVE UP AND TAKE THE AVERAGE
TAN(K) = (S(K) + S(K+1)) / 2.00
GO TO 200
C THE RIGHT EDGE IS STRAIGHT
150 TAN(K) = S(K)
GO TO 200
C THE LEFT EDGE IS STRAIGHT
160 TAN(K) = S(K+1)
200 CONTINUE
RETURN
*****
END
SUBROUTINE INCASE(LCASE,NOALFA)

C THIS SUBROUTINE READS THE FUNDAMENTAL GEOMETRIC CASE DATA
CHARACTER*1 ANS
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NH(40),NJ(40),IH(40),IJ(40)
COMMON/FCASE1/INTINST,INHITE,INDELJ,INCAMB,INBETA
COMMON/FCASE2/TWIST(40,10),HL(40,10),DJ(40,10),ACTE(40),AC(20,40),
1 XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
COMMON/INDAT/LUN
DIMENSION NI(10),DUMMY(40)
C IF((LCASE .EQ. 1) .AND. (NOALFA .GT. 0)) RETURN
C CALL CLRSCRN
PRINT *
WRITE(6,5) LCASE
5 FORMAT(1X,4X,'FUNDAMENTAL CASE CONTROL FLAGS FOR CASE ',I2,'.')
PRINT *,'=> THE FOLLOWING QUESTIONS ARE USED TO SET THE CONTROL
+ FLAGS.
PRINT *, 'THESE FLAGS IDENTIFY THE TYPES OF LINEAR GEOMETRIC V
+ARIATIONS.
PRINT *, 'TO BE INCLUDED IN EACH FUNDAMENTAL CASE.'
PRINT *, 'THE ANGLE OF ATTACK CASE IS ALREADY INCLUDED AS CASE
+1.
PRINT *
PRINT *, 'A NO RESPONSE INDICATES THAT THE VARIATION WILL BE O
+MITTED.
PRINT *
PRINT *, 'A YES RESPONSE INDICATES THAT THE VARIATION WILL BE
+INCLUDED.
PRINT *, 'AND THAT YOU WILL PROVIDE THE REQUIRED AMPLIFYING IN
+FORMATION.
PRINT *
10 CONTINUE
C-----READ FUNDAMENTAL CASE CONTROL FLAGS-----
C
20 PRINT *, '=> VARY SPANWISE TWIST DISTRIBUTION? (Y OR N)'
READ (5,'(A1)') ANS
IF (ANS.EQ.'Y') THEN
  INTINST = LCASE
ELSE IF (ANS.EQ.'N') THEN
  INTINST = 0
ELSE
  PRINT *, ' INVALID RESPONSE - REENTER.'
  GO TO 20
END IF
PRINT *
PRINT *, '=> VARY LEADING EDGE VERTICAL DISPLACEMENT? (Y OR N)'
30 READ (5,'(A1)') ANS
IF (ANS.EQ.'Y') THEN
  INHITE = LCASE
ELSE IF (ANS.EQ.'N') THEN
  INHITE = 0
ELSE
  PRINT *, ' INVALID RESPONSE - REENTER.'
  GO TO 30
END IF
PRINT *
PRINT *, '=> VARY JET DEFLECTION? (Y OR N)'
40 READ (5,'(A1)') ANS
IF (ANS.EQ.'Y') THEN
  INDELJ = LCASE
ELSE IF (ANS.EQ.'N') THEN
  INDELJ = 0
ELSE
  PRINT *, ' INVALID RESPONSE - REENTER.'
  GO TO 40
END IF

```

```

PRINT *
PRINT *, '==> VARY THE WING CAMBER? (Y OR N)'
50 READ (5,'(A1)') ANS
IF (ANS.EQ.'Y') THEN
  INCAMB = LCASE
ELSE IF (ANS.EQ.'N') THEN
  INCAMB = 0
ELSE
  PRINT * , ' INVALID RESPONSE - REENTER.'
  GO TO 50
END IF
PRINT *
PRINT *, '==> VARY THE WING HINGE DEFLECTION? (Y OR N)'
60 READ (5,'(A1)') ANS
IF (ANS.EQ.'Y') THEN
  INBETA = LCASE
ELSE IF (ANS.EQ.'N') THEN
  INBETA = 0
ELSE
  PRINT * , ' INVALID RESPONSE - REENTER.'
  GO TO 60
END IF
PRINT *

C-- SUMMARY OF FUNDAMENTAL CASE CONTROL FLAGS DATA
C-----
CALL CLRSCRN
WRITE (6,580)
580 FORMAT (1X,'SUMMARY OF FUNDAMENTAL CASE CONTROL FLAGS DATA?',1/1X,25H==> ENTER Y = YES; N = NO)
READ (5,'(A1)') ANS
IF (ANS.EQ.'N') GO TO 70
CALL CLRSCRN
WRITE(6,6) LCASE
6 FORMAT(1X,2X,'CONTROL FLAGS FOR FUNDAMENTAL CASE ',I2'.')
PRINT *
PRINT *, ' A NONZERO FLAG INDICATES THAT THE LINEAR VARIATION'
PRINT *, ' WILL BE INCLUDED. THE VALUE OF A NONZERO FLAG'
PRINT *, ' HAS BEEN SET TO THE FUNDAMENTAL CASE IN WHICH IT'
PRINT *, ' IS INCORPORATED, HOWEVER THIS CHOICE IS ARBITRARY.'
PRINT *
WRITE (6,581)
WRITE (6,582) INTWST,INHITE,INDELJ,INCAMB,INBETA
WRITE (6,590)
READ (5,'(A1)') ANS
IF (ANS.EQ.'Y') GO TO 10
581 FORMAT(1X,'INTWST',5X,'INHITE',5X,'INDELJ',5X,'INCAMB',5X,
+ 'INBETA')
582 FORMAT(1X,5(2X,I2,7X))
590 FORMAT(//,1X,25HCHANGE FUNDAMENTAL CASE CONTROL FLAGS DATA?,1/1X,25H==> ENTER Y = YES; N = NO)
70 CONTINUE
C WRITE TO DATA FILE
  WRITE(LUN, 601 ) INTWST,INHITE,INDELJ,INCAMB,INBETA
601 FORMAT(5I2)
C-----READ SECTIONAL TWIST, HEIGHT AND JET DEFLECTION DATA
  IF(INTWST .EQ. 0) GO TO 85
C-----TWIST DISTRIBUTION CARDS
C-----
CALL CLRSCRN
PRINT *
PRINT *, ' SPANWISE WING TWIST DISTRIBUTION VALUES'
PRINT *, ' THE SECTIONAL TWIST IS THE WING TWIST AT THE SECTION'
PRINT *, ' CENTERLINE WITH RESPECT TO THE WING REFERENCE PLANE.'
PRINT *
PRINT *, ' POSITIVE VALUES ARE IN THE SAME SENSE AS A POSITIVE'
PRINT *, ' ANGLE-OF-ATTACK (LEADING EDGE UP).'
PRINT *
PRINT *, '==> ENTER TWIST, SECTIONAL WING TWIST, IN DEGREES.(R)'
PRINT *
DO 80 K = 1,NROWS
  WRITE(6,12) K,NROWS
  READ(5,* ) TWIST(K,LCASE)
12 FORMAT(1X,' ENTER SECTION TWIST FOR SECTION ',I2,' OF ',I2,' SECT
+IONS.',/)
80 CONTINUE
PRINT *
C SUMMARY REQD
C-----WRITE TO DATA FILE
  WRITE(LUN, 701 ) (TWIST(K,LCASE),K=1,NROWS)
701 FORMAT(8F10.6)
C-----85 IF(INHITE .EQ. 0) GO TO 95
C-----LEADING EDGE VERTICAL DISPLACEMENT CARDS
C-----
CALL CLRSCRN
PRINT *
PRINT *, ' LEADING EDGE VERTICAL DISPLACEMENT'
PRINT *
PRINT *, ' THIS DATA INDICATES THE VERTICAL DISPLACEMENT OF THE'
PRINT *, ' LEADING EDGE FROM THE WING REFERENCE PLANE; VALUES'
PRINT *, ' MUST BE NORMALIZED BY THE SECTIONAL CHORD.'
PRINT *
PRINT *, ' DISPLACEMENT MAY BE THE RESULT OF DIHEDRAL, TWIST,'
PRINT *, ' NONLINEAR MOVEMENT OF A LEADING EDGE DEVICE, ETC.'

```

```

PRINT *, ' TRANSLATION DUE TO ORDINARY LINEAR LEADING AND'
PRINT *, ' TRAILING FLAP DEFLECTIONS AND ANGLE OF ATTACK ARE'
PRINT *, ' ACCOUNTED FOR AUTOMATICALLY BY THE PROGRAM.'
PRINT *
PRINT *,'==> ENTER HL, NORMALIZED LEADING EDGE DISPLACEMENT.(R)'
PRINT *
DO 90 K = 1,NROWS
  WRITE(6,22) K,NROWS
  READ(5,* ) HL(K,LCASE)
22 FORMAT(1X,' ENTER DISPLACEMENT FOR SECTION ',I2,' OF ',I2,
+ ' SECTIONS.',/)
90 CONTINUE
PRINT *
C SUMMARY REQD
C WRITE TO DATA FILE
  WRITE(LUN, 701 ) (HL(K,LCASE),K=1,NROWS)
C 95 IF(INDELJ .EQ. 0) GO TO 105
C-----C JET DEFLECTION CARDS
C-----CALL CLRSCRN
PRINT *
PRINT *,' JET DEFLECTION'
PRINT *
PRINT *,' THIS DATA INDICATES THE SPANWISE VARIATION OF JET'
PRINT *,' DEFLECTION RELATIVE TO THE TRAILING EDGE. THE JET'
PRINT *,' TURNING ANGLE IS MEASURED RELATIVE TO THE MEAN LINE'
PRINT *,' OF THE TRAILING EDGE. VALUES ARE INPUT WORKING'
PRINT *,' FROM THE RIGHTMOST JET TOWARDS THE CENTERLINE.'
PRINT *
PRINT *,' A DOWNWARD DEFLECTION IS DEFINED AS POSITIVE.'
PRINT *
PRINT *,'==> ENTER DJ, THE JET TURNING ANGLE, IN DEGREES.(R)'
PRINT *
DO 100 K = 1,NRONSJ
  WRITE(6,32) K,NRONSJ
  READ(5,* ) DJ(K,LCASE)
32 FORMAT(1X,' ENTER DEFLECTION FOR JET SECTION ',I2,' OF ',I2,
+ ' JET SECTIONS.',/)
100 CONTINUE
PRINT *
C SUMMARY REQD
C WRITE TO DATA FILE
  WRITE(LUN, 701 ) (DJ(K,LCASE),K=1,NRONSJ)
C 105 IF(INCAMB .EQ. 0) GO TO 160
C INPUT CAMBER TYPE OF EACH SECTION
C-----C WING SECTION CAMBER TYPE CARDS
C-----CALL CLRSCRN
PRINT *
PRINT *,' WING SECTION CAMBER TYPES'
PRINT *
PRINT *,' THIS DATA IS SIMILAR TO THE WING SECTION TYPE DATA.'
PRINT *,' IN ORDER FOR SECTIONS TO BE OF THE SAME CAMBER TYPE'
PRINT *,' THEY MUST BE OF THE SAME WING SECTION TYPE (ICTYPE)'
PRINT *,' AND THE CAMBER ANGLES ASSOCIATED WITH EACH ELEMENT'
PRINT *,' MUST BE THE SAME. BEGIN WITH A TYPE NUMBER OF 1 AND'
PRINT *,' WORK IN SEQUENCE, 2,3,...(ASCENDING ORDER).(I)'
PRINT *
PRINT *,' A SECTION WITH NO CAMBER HAS A TYPE OF 0 (ZERO).'
PRINT *
PRINT *,' A MAXIMUM OF 10 CAMBER TYPES IS ALLOWED.'
PRINT *
PRINT *,'==> ENTER ICT, THE CAMBER TYPE NUMBER OF EACH SECTION.'
PRINT *
NCT = 0
DO 110 K = 1,NROWS
  WRITE(6,42) K,NROWS
  READ(5,* ) ICT(K)
C DETERMINE NUMBER OF CAMBER TYPES
  IF(ICT(K) .EQ. 0) GO TO 110
  IF(ICT(K) .GT. NCT) NCT = ICT(K)
  ICK = ICT(K)
  NI(ICK) = NW(K)
  IF(NCT .GT. 8) THEN
    WRITE(6,41) NCT
    PRINT *,' A MAXIMUM OF 10 CAMBER TYPES IS ALLOWED.'
    PRINT *,' *****WARNING*****'
    PRINT *,' YOU MAY ENTER ONLY ONE MORE DIFFERENT TYPE.'
  END IF
41 FORMAT(1X,5X,29HNUMBER OF WING CAMBER TYPES =,I3)
42 FORMAT(1X,' ENTER CAMBER TYPE FOR SECTION ',I2,' OF ',I2,
+ ' SECTIONS.',/)
110 CONTINUE
C SUMMARY REQD
C WRITE TO DATA FILE
  WRITE(LUN, 101 ) (ICT(K),K=1,NROWS)
101 FORMAT(40I2)
C-----C CAMBER ANGLES FOR EACH CAMBER SECTION TYPE
C-----CALL CLRSCRN
PRINT *

```

```

PRINT *, ' CAMBER ANGLES FOR THE DOWNWASH CONTROL POINTS'
PRINT *, ' THE CAMBER ANGLE FOR THE DOWNWASH CONTROL POINT OF'
PRINT *, ' EACH EVD ELEMENT IS REQUIRED. THE DOWNWASH CONTROL'
PRINT *, ' POINT IS ARBITRARILY CHOSEN AS HALFWAY BETWEEN ANY'
PRINT *, ' TWO ADJACENT XBYEV(BOUNDARY) POINTS, INCLUDING THE'
PRINT *, ' TRAILING EDGE.'
PRINT *, ' POSITIVE VALUES ARE IN THE SAME SENSE AS A POSITIVE'
PRINT *, ' ANGLE-OF-ATTACK (LEADING EDGE UP).'
PRINT *, ' ==> ENTER AC, THE CAMBER ANGLE, IN DEGREES.(R)'
PRINT *
C READ THE CHORDWISE CAMBER ANGLES FOR EACH CAMBER TYPE
DO 130 N = 1,NCT
NIN = NI(N)
DO 125 L = 1,NIN
WRITE(6,52) NCT
WRITE(6,53) L,NIN
READ(5, *) AC(L,N)
125 CONTINUE
130 FORMAT(IX,' FOR CAMBER SECTION TYPE NUMBER ',I2)
52 FORMAT(IX,' ENTER CAMBER ANGLE FOR EVD ELEMENT ',I2,', OF ',I2,/)
53 FORMAT(IX,' LOCATED AT CHORDWISE COORDINATE =',F10.6)
C SUMMARY REQD
C WRITE TO DATA FILE
DO 135 N = 1,NCT
NIN = NI(N)
WRITE(LUN, 701 ) (AC(L,N),L=1,NIN)
135 CONTINUE
IF(NROWSJ .EQ. 0) GO TO 160
C-----C TRAILING EDGE CAMBER ANGLE DATA CASE WITH JETS AND CAMBER
C-----C CALL CLRSRN
PRINT *
PRINT *, ' TRAILING EDGE CAMBER ANGLE FOR WINGS WITH'
PRINT *, ' JET SHEETS AND CAMBER.'
PRINT *
PRINT *, ' THE TRAILING EDGE DEFLECTION ANGLE DUE TO CAMBER'
PRINT *, ' ONLY IS ENTERED HERE. THESE VALUES ARE USED TO'
PRINT *, ' DETERMINE THE TOTAL JET DEFLECTION ANGLE WITH'
PRINT *, ' RESPECT TO THE FREESTREAM. VALUES ARE INPUT WORKING'
PRINT *, ' FROM THE RIGHTMOST JET TOWARDS THE CENTERLINE.'
PRINT *
PRINT *, ' POSITIVE VALUES ARE IN THE SAME SENSE AS A POSITIVE'
PRINT *, ' ANGLE-OF-ATTACK (LEADING EDGE UP).'
PRINT *
PRINT *, ' ==> ENTER ACTE, TRAILING EDGE CAMBER ANGLE,(DEGREES).(R)'
PRINT *
C READ THE TRAILING EDGE CAMBER ANGLE FOR EACH JET SECTION
DO 140 K = 1,NROWSJ
WRITE(6,62) K
WRITE(6,63)
READ(5, *) ACTE(K)
140 CONTINUE
62 FORMAT(IX,' FOR JET SECTION NUMBER ',I2)
63 FORMAT(IX,' ENTER CAMBER ANGLE FOR TRAILING EDGE ',/)
C SUMMARY REQD
C WRITE TO DATA FILE
WRITE(LUN, 701 ) (ACTE(K),K=1,NROWSJ)
C STOPPED HERE (JAC) - CASES WITH JETS HAVE NOT BEEN FINISHED.
C-----C THE HINGE LOCATION, TYPE AND TURNING ANGLE DATA
C-----C READ THE HINGE LOCATION, TYPE AND TURNING ANGLE DATA
160 IF(INBETA .EQ. 0) GO TO 210
C 170 READ(5, 100 ) (IHT(K),K=1,NROWS)
NHT = 0
DO 180 K = 1,NROWS
IFIHT(K) .GT. NHT NHT = IHT(K)
180 CONTINUE
DO 200 N = 1,NHT
READ(5,190 } (XHB(L,N),IFS(L,N),BET(L,N),L=1,4)
190 FORMAT(4(F10.6,I1,F9.6})
200 CONTINUE
C 170 WRITE(5, 100 ) (IHT(K),K=1,NROWS)
210 RETURN
*****END *****
SUBROUTINE OUT1(LCASE)
C THIS SUBROUTINE PRINTS OUT THE GEOMETRIC DATA DERIVED FROM THE
C SECTIONAL METHOD INPUT
C
COMMON/MATHEW/NCASES,ISYMM,IPRINT,JETFLG,IGTYPE,IHINGE
COMMON/MARK/NRONS,NROWSJ,NWT,NJT,NMAX,NW(40),NJ(40),IW(40),IJ(40)
COMMON/LUKE/TITLE(20)
COMMON/JOHN/ AREA,SPAN,ARATIO,TR,SWEET,CREF,CMAC,CBAR,XMC,XCG
COMMON/GEOM1/Y(40),CHORD(40),DELTA(40),XB(600),XI(600),DEL(600),
1 D(40),KK(600),ITYPE(600)
1 COMMON/GEOM2/XLEAD(40),XTRAIL(40),TANLE(40),TANTE(40)
1 COMMON/FCASE2/XTWIST(40,10),HL(40,10),DJ(40),ACTE(40),AC(20,40),
1 XHB(4,40),BET(4,40),IFS(4,40),ICT(40),IHT(40),NCT,NHT
1 COMMON/FCASE3/EPS(600,10),BETA(600,10),THETA(40,10),THS(40,10)

```

```

COMMON/INDATA/ARE,SPA,CRE,XM,CMA,XC,NRO,NC,ISY,IPR,JET,IGT,IHI
C PRINT CASE TITLE AND GENERAL GEOMETRIC PARAMETERS
10 WRITE(6,20)TITLE
11 IF(LCASE .GT. 1) GO TO 60
12 FORMAT(1H1,39X,10(4H****))
13 40X,40H* EVD JET - WING COMPUTER PROGRAM */
14 40X,10(4H****)///20X,20A4)
15 CMA = CMAC * SPA / 2.0
16 WRITE(6, 40) AREA,ARE,SPAN,SPA,CREF,CRE,XMC,XM,CMAC,CMA,ARATIO,
17 ARATIO,XCG,XC
18 FORMAT(1HO//54X,4HUSED 11X,5HINPUT /
19 41X,6HAR2A =,2F15.6 / 41X,6HSPAN =,2F15.6 /
20 41X,6HCREF =,2F15.6 / 42X,5HXC =,2F15.6 /
21 41X,6HCMAC =,2F15.6 / 39X,8HARATIO =,2F15.6 /
22 42X,5HXCG =,2F15.6 )
23 WRITE(6, 50) NROWS,NRO,NCASES,NC,ISYMM,ISY,IPRINT,IPR,JETFLG,JET,
24 IGYTYPE,IGT,IHNGE,IHT,NHT,NJT,NMAX
25 FORMAT(1HO/ 48X,7HNRCWS =,I3,7X,I3 / 47X,8HNCASES =,I3,7X,I3 /
26 48X,7HTSYM1 =,I3,7X,I3 / 47X,8HIPRINT =,I3,7X,I3 /
27 47X,8HJETFLG =,I3,7X,I3 / 47X,8HIGTYPE =,I3,7X,I3 /
28 47X,8HHINGE =,I3,7X,I3 // 43X,25HNUMBER OF WING ELEMENTS =,I4 /
29 43X,25HNUMBER OF JET ELEMENTS =,I4 /
30 42X,26HTOTAL NUMBER OF ELEMENTS =,I4)
31 60 J = 0
32 JJ = NWT
C PRINT FUNDAMENTAL CASE HEADER
33 WRITE(6, 70) LCASE
34 70 FORMAT(1H1,23X,1H*,19(4H****)/
35 1 24X,54H* ELEMENT GEOMETRY DATA AND FUNDAMENTAL CASE DATA FOR,
36 2 17H FUNDAMENTAL CASE,I3,3H */24X,1H*,19(4H****))
37 ILINES = 3
38 DO 260 K = 1,NROWS
C PRINT SECTIONAL DATA
39 WRITE(6, 80) K,Y(K),DELTAK,K),XLEAD(K),XTRAIL(K),CHORD(K),TANLE(K)
40 FORMAT(1HO,11H*** SECTION,I3,4H ***,2X,3HY =,F10.6,2X,7HDELTAK =,
41 1 F10.6,2X,7HXLEAD =,F10.6,2X,8HXTRAIL =,F10.6,2X,7HCORD =,F10.6,
42 2 2X,7HTANLE =,F10.6)
C PRINT CHORDWISE DATA ON WING
43 NJK = NW(K)
44 WRITE(6, 90) NWK,TWIST(K,LCASE),HL(K,LCASE),THS(K,LCASE)
45 90 FORMAT(1HO,21HHINGE ELEMENTS ,NW =I3,5X,7HTWIST =,F10.6,5X,
46 1 4HHL =,F10.6,5X,9HTHETAS =,F10.6)
47 WRITE(6, 100) (XB(J+L),L=1,NWK)
48 100 FORMAT(1H,14X,2HBX,10F11.6 / 17X,10F11.6)
49 IF(LCASE .GT. 1) GO TO 130
50 WRITE(6, 110) (XI(J+L),L=1,NWK)
51 110 FORMAT(1H,14X,2HXI,10F11.6/17X,10F11.6)
52 WRITE(6, 120) (DEL(J+L),L=1,NWK)
53 120 FORMAT(1H,13X,3HDEL,10F11.6/17X,10F11.6)
54 130 IF(ICK(K).EQ. 0) GO TO 150
55 ICK = ICK(K)
56 WRITE(6, 140) (AC(L,ICK),L=1,NWK)
57 140 FORMAT(1H,10X,6HCAMBER,10F11.6/17X,10F11.6)
58 150 WRITE(6, 160) (EPS(J+L,LCASE),L=1,NWK)
59 160 FORMAT(1H,13X,3HEPS,10F11.6/17X,10F11.6)
60 WRITE(6, 170) (BETA(J+L,LCASE),L=1,NWK)
61 170 FORMAT(1H,12X,4HBETA,10F11.6/17X,10F11.6)
62 WRITE(6, 180) (ITYPE(J+L),L=1,NWK)
63 180 FORMAT(1H,12X,4HTYPE,10(3X,I2,6X)/17X,10(3X,I2,6X))
64 J = J + NWK
65 IL = 1
66 IF(NWK .GT. 9) IL = 2
67 ILINES = ILINES + 4 + 4*IL
68 IF(LCASE .EQ. 1) ILINES = ILINES + 2*IL
C PRINT CHORDWISE DATA ON JET
69 NJK = NJ(K)
70 IF(NJK .GT. 0) GO TO 200
71 WRITE(6, 190)
72 190 FORMAT(1H,8X,19HTHIS ROW HAS NO JET)
73 ILINES = ILINES + 1
74 GO TO 230
75 200 WRITE(6, 210) NJK,D(K),DJ(K),ACTE(K),THETA(K,LCASE)
76 210 FORMAT(1HO,1X,20HJET ELEMENTS ,NJ =,I3,5X,3HD =,F10.6,5X,4HDJ =,
77 1 F10.6,5X,6HACTE =,F10.6,5X,7HTHETA =,F10.6)
78 WRITE(6, 100) (XB(JJ+L),L=1,NJK)
79 IF(LCASE .GT. 1) GO TO 220
80 WRITE(6, 110) (XI(JJ+L),L=1,NJK)
81 WRITE(6, 120) (DEL(JJ+L),L=1,NJK)
82 220 WRITE(6, 170) (BETA(JJ+L,LCASE),L=1,NJK)
83 WRITE(6, 180) (ITYPE(JJ+L),L=1,NJK)
84 JJ = JJ + NJK
85 IL = 1
86 IF(NJK .EQ. 10) IL = 2
87 ILINES = ILINES + 1 + 3 * IL
88 IF(LCASE .EQ. 1) ILINES = ILINES + 2*IL
89 230 IF(K .EQ. NROWS) GO TO 260
90 NWK1 = NW(K+1)
91 IL = 1
92 IF(NWK1 .GT. 9) IL = 2
93 NEXT = 4 + 4*IL
94 IF(LCASE .EQ. 1) NEXT = NEXT + 2*IL
95 NJK1 = NJ(K+1)
96 IL = 1
97 IF(NJK1 .EQ. 10) IL = 2
98 NEXT = NEXT + 1

```



```

40 FORMAT(10(BZ,I2,F6.4))
70 CONTINUE
C   OUTPUT A 9 CARD AFTER NCC SETS OF DATA HAVE BEEN INPUT
100 WRITE(LUN, 102 )
102 FORMAT('9')
C   IR = 1
RETURN
C*****SUBROUTINE BLOWINI(JETFLG,IR)
C THIS SUBROUTINE READS THE SECTIONAL JET BLOWING RATES
C CMU(K) = J / (Q * CHORD(K))
C
COMMON/MARK/NROWS,NROWSJ,NWT,NJT,NMAX,NH(40),NJ(40),IW(40),IJ(40)
COMMON/JCASE/CMU(40),CMUP(40),CMUPP(40)
DIMENSION DCMU(40)
COMMON/INDAT/LUN
C
IF(JETFLG .NE. 0) GO TO 30
C READ THE CMU DATA ONLY FOR THOSE SECTIONS WHICH HAVE A JET
READ(5,10,END=60) (DCMU(K),K=1,NROWSJ)
10 FORMAT(8F10.6)
20 IF(DCMU(1) .LT. 800.0) GO TO 30
IR = 2
RETURN
C REARRANGE THE DATA INTO THE PROPER SEQUENCE
30 KP = 0
DO 50 K = 1,NROWS
40 CMU(K) = 0.00
IF(NJ(K) .EQ. 0) GO TO 50
KP = KP + 1
CMU(K) = DCMU(KP)
50 CONTINUE
IR = 1
RETURN
C AN END OF FILE HAS BEEN READ. THIS RUN IS COMPLETELY FINISHED.
60 WRITE(6,70)
70 FORMAT(1H1//41X,37HNO MORE CMU CASES HAVE BEEN REQUESTED)
IR = 3
RETURN
END
C*****

```

APPENDIX E. FIGURES GENERATED USING DISSPLA

PROGRAM PANEL- NACA 0012 AIRFOIL




Figure 26. Program PANEL- Shape Generated Using Airfoil Coordinates Data File

This figure was generated using the DISSPLA portion of EASYPLOT on the IBM mainframe computer. The surface coordinates for the airfoil were input to the PANEL program using an input data file containing 28 surface points.

PROGRAM PANEL- NACA 0012 AIRFOIL
EQUATION GENERATED SHAPE




Figure 27. Program PANEL- Shape Generated Using Internal Equation for NACA 0012

This figure was generated using the DISSPLA portion of EASYPLOT on the IBM mainframe computer. The surface coordinates for the airfoil were generated by the PANEL program using the internal equation for NACA XXXX series airfoils. Twenty points were used to describe the surface. Despite using fewer points to define the surface, there is virtually no difference between this plot and the one on the preceding page which used actual airfoil surface data.

PROGRAM PANEL- NASA LS(1)-0013




Figure 28. Program PANEL- Shape Generated Using DATA Statements for NASA LS(1)-0013

This figure was generated using the DISSPLA portion of EASYPLOT on the IBM mainframe computer. The surface coordinates for the airfoil were input to the PANEL program using the DATA statement entry method. The DATA statements for the NASA LS(1)-0013 within the PANEL program contain coordinates for 28 surface locations. This plot is nearly identical to that found in Ref. 18.

NACA 0012 & NASA LS(1)-0013




Figure 29. Program PANEL- Comparison of Shapes Generated for NACA 0012 and NASA LS(1)-0013

This figure compares the shapes of the NACA 0012 and NASA LS(1)-0013 airfoils. The actual surface coordinates were used for this plot. Again, this plot is nearly identical to a similar plot found in Ref. 18.

PROGRAM PANEL- NACA 0012 AIRFOIL




Figure 30. Program PANEL-Surface Pressure Distribution for NACA 0012

This figure was generated using the DISSPLA portion of EASYPLOT on the IBM mainframe computer. The pressure distribution is for the NACA 0012 airfoil defined by an input data file containing 28 surface points at an angle of attack of six degrees. The results of the program run are repeated below.

DATA FILE: PPRESS.DAT

ANGLE OF ATTACK IN DEGREES = 6.000

CD = 0.00387 CL = 0.70980 CM = -0.17750 CMC4 = -0.00092

PROGRAM PANEL- NACA 0012 AIRFOIL

EQUATION GENERATED SHAPE




Figure 31. Program PANEL- Surface Pressure Distribution for NACA 0012 Generated by the Internal Equation

This figure was generated using the DISSPLA portion of EASYPLOT on the IBM mainframe computer. The pressure distribution is for the NACA 0012 airfoil defined by the internal equation using 28 surface points, at an angle of attack of six degrees. The results of the program run are repeated below. A slight difference is noted between the plots and the values obtained. This is due largely to the difference in the number of data points used and the spline interpolation used by the plotting routine.

DATA FILE: PPRESS.DAT

ANGLE OF ATTACK IN DEGREES = 6.000

CD = 0.00721 CL = 0.72235 CM = -0.18377 CMC4 = -0.00398

PROGRAM PANEL- NASA LS(1)-0013




Figure 32. Program PANEL- Surface Pressure Distribution for NASA LS(1)-0013

This figure was generated using the DISSPLA portion of EASYPLOT on the IBM mainframe computer. The pressure distribution is for the NASA LS(1)-0013 airfoil defined by a set of DATA statements containing 28 surface points at an angle of attack of six degrees. The results of the program run are repeated below.

DATA FILE: PPRESS.DAT

ANGLE OF ATTACK IN DEGREES = 6.000

CD = 0.00324 CL = 0.69366 CM = -0.16505 CMC4 = 0.00750

**SPANWISE LIFT DISTRIBUTION
USING VORTEX LATTICE SOLUTION
COSINE SPACING**




Figure 33. Program VORLAT- Spanwise Lift Distribution Using Cosine Spacing

This figure was generated using DISSPLA and running the PLOTSPAN program on the IBM mainframe computer. The spanwise lift distribution is shown for a flat rectangular wing of aspect ratio 2 at an angle of attack of six degrees. The results of the VORLAT program run are repeated below. (The PLOTSPAN program is located on the AERO disk of the IBM mainframe.)

** COSINE GRID SPACING **

NX= 5 NY= 10 ASPECT RATIO = 2.00 ANGLE OF ATTACK = 6.00

CL = 0.25905
 CD = 0.0106492
 CD/CL² = 0.1587
 CMLE = -0.055061
 XCP = 0.21255

**SPANWISE LIFT DISTRIBUTION
USING VORTEX LATTICE SOLUTION
UNIFORM GRID**




Figure 34. Program VORLAT- Spanwise Lift Distribution Using Uniform Grid

This figure was generated using DISSPLA and running the PLOTSPAN program on the IBM mainframe computer. The spanwise lift distribution is shown for a flat rectangular wing of aspect ratio 2 at an angle of attack of six degrees. The results of the VORLAT program run are repeated below.

** UNIFORM GRID SPACING **

NX= 5 NY= 10 ASPECT RATIO = 2.00 ANGLE OF ATTACK = 6.00

CL = 0.25711
 CD = 0.0105673
 CD/CL² = 0.1598
 CMLE = -0.054301
 XCP = 0.21119

LIST OF REFERENCES

1. Moran, Jack, *An Introduction to Theoretical and Computational Aerodynamics*, pp.32-153, John Wiley & Sons, Inc., 1984.
2. Anderson, John D., *Fundamentals of Aerodynamics*, pp.164-267, McGraw-Hill, Inc., 1984.
3. Zucker, R. D., *Aerodynamic Analysis-A Set of Course Notes on Current Aerodynamic Analysis*, Naval Postgraduate School, Monterey, CA, 1977.
4. Clancy, L. J., *Aerodynamics*, pp.170-199, John Wiley & Sons, Inc., 1975.
5. Maron, M. J., *Numerical Analysis*, 2d ed., pp.71-74, Macmillian Publishing Company, 1987.
6. Hess, J. L., and Smith, A. M. O., "Calculation of Potential Flow About Arbitrary Bodies," *Prog. Aeronaut. Sci.*, v. 8., pp.1-138, 1966.
7. Lopez, M. L., Shen, C. C., and Wasson, N. F., *A Theoretical Method for Calculating the Aerodynamic Characteristics of Jet-Flapped Wings, Vol.I - The Elementary Vortex Distribution Jet-Wing Lifting-Surface Theory, Vol.II - EVD Jet-Wing Computer Program User's Manual*, Douglas Aircraft Company Report MDC J5519(May 1973), Second Edition 1977.
8. Soderman, A. P., *A Three-Dimensional, Finite Element Lifting-Surface Computer Program, Its Utilization and Underlying Theory*, Master's Thesis, Naval Postgraduate School, Monterey, CA, December 1976.
9. Digital Equipment Corporation, *VAX EDT Reference Manual*, AA-Z300A-TE, September 1984.

10. Harvey, Neil E., *User's Guide to MVS at NPS*, Technical Note MVS-01, Naval Postgraduate School W. R. Church Computer Center, Monterey, CA, May 1988.
11. International Business Machines Corporation, *MVS 370 JCL User's Guide*, GC28-1349-3, 4th ed., August 1987.
12. Mar, Dennis R., *Magnetic Tape Usage Under MVS at NPS*, Technical Note MVS-07, Naval Postgraduate School W. R. Church Computer Center, Monterey, CA, October 1987.
13. White, S. M., *Class Project AE-3501*, Naval Postgraduate School, Monterey, CA, 1985.
14. Kretzmann, Jane, *User's Guide to VM CMS at NPS*, Technical Note VM-01, Naval Postgraduate School W. R. Church Computer Center, Monterey, CA, January 1988.
15. International Business Machines Corporation, *Virtual Machine System Product CMS Command Reference*, SC19-6209-4, 5th ed., December 1986.
16. Digital Equipment Corporation, *VAX FORTRAN User's Guide*, AA-D035D-TE, September 1984.
17. Digital Equipment Corporation, *Programming in VAX FORTRAN*, AA-D034D-TE, September 1984.
18. NASA Technical Memorandum 4003, *Low-Speed Wind-Tunnel Results for Symmetrical NASA LS(1)-0013 Airfoil*, by J. C. Ferris, R. J. McGhee, and R. W. Barnwell, June 1987.
19. Hough, Gary. R., "Remarks on Vortex-Lattice Methods," *Journal of Aircraft*, v. 10, no. 5, pp. 314-316, May 1973.

INITIAL DISTRIBUTION LIST

| | No. Copies |
|---|------------|
| 1. Defense Technical Information Center Cameron Station Alexandria, VA 22304-6145 | 2 |
| 2. Library, Code 0142 Naval Postgraduate School Monterey, CA 93943-5002 | 2 |
| 3. E. R. Wood, Chairman, Code 67 Department of Aeronautics and Astronautics Naval Postgraduate School Monterey, CA 93943-5000 | 2 |
| 4. Professor M. F. Platzer, Code 67Pl Department of Aeronautics and Astronautics Naval Postgraduate School Monterey, CA 93943-5000 | 2 |
| 5. Professor R. M. Howard, Code 67Ho Department of Aeronautics and Astronautics Naval Postgraduat School Monterey, CA 93943-5000 | 2 |
| 6. Professor J. V. Healey, Code 67He Department of Aeronautics and Astronautics Naval Postgraduate School Monterey, CA 93943-5000 | 2 |
| 7. Professor G. H. Lindsey, Code 67Li Department of Aeronautics and Astronautics Naval Postgraduate School Monterey, CA 93943-5000 | 1 |
| 8. Professor R. D. Zucker, Code 67Zu Department of Aeronautics and Astronautics Naval Postgraduate School Monterey, CA 93943-5000 | 1 |
| 9. Commandant (G-PTE-1) U. S. Coast Guard 2100 Second St. S.W. Washington, DC 20593-0001 | 2 |

- | | | |
|-----|---|---|
| 10. | Commandant (G-EAE-4) U. S. Coast Guard 2100 Second St. S.W. Washington, DC 20593-0001 | 2 |
| 11. | Mr. O. D. Wells, MS 3504 C-17 Aerodynamics Group Douglas Aircraft Company 3855 Lakewood Blvd. Long Beach, CA 98046-0000 | 1 |
| 12. | LT J. A. Campbell 9800 Broadmoor Terrace Upper Marlboro, MD 20772-0000 | 1 |

Thesis
C19366 Campbell
c.1 FORTRAN programs for
aerodynamics analyses
on the MicroVAX/2000/
CAD/CAE workstation.

10 NOV 92

80517

Thesis
C19366 Campbell
c.1 FORTPAN programs for
aerodynamics analyses
on the MicroVAX/2000/
CAD/CAE workstation.

DEMLO



thesC19366

FORTRAN programs for aerodynamic analyse



3 2768 000 84081 3

DUDLEY KNOX LIBRARY